

E-mail Settings and Changing E-mail Address

E-mail (@ezweb.ne.jp) is a service which enables you to exchange e-mails with other cell phones which support e-mail and with PCs. An e-mail address is set automatically in the initial settings. You can change the e-mail address set in the initial settings.
 ● You cannot make the initial settings via Wi-Fi® communication.

Initial Settings

- 1 Home screen → [📧].
- 2 Confirm the contents → [閉じる] (Close).
- 3 Confirm the contents → [同意する] (Agree)/[同意しない] (Disagree) → [完了] (Done).

Changing E-mail Address

- 1 Home screen → [📧].
- 2 [📧] → [Change Address/Setting Filter].
- 3 [Eメールアドレスの変更へ] (To change e-mail address).
- 4 Enter the security code → [送信] (Send).
- 5 Confirm the contents → [承諾する] (Accept).
- 6 Enter an e-mail address → [送信] (Send).
- 7 [OK] → [閉じる] (Close).

Restoring Backed Up E-mail

You can restore mails an old product has backed up to this product.
 ● Save the mail data from the old au phone to the microSD™ memory card beforehand.

- 1 Home screen → [📧].
- 2 [📧] → [E-mail settings].
- 3 [Backup/Restore] → [Restore mails].
- 4 Select the mail type to restore → [OK].
- 5 Select the backed up data to restore → [OK].
- 6 [Add]/[Overwrite] → [OK].

Making/Receiving Calls

● Screens displayed when receiving a call or during a call may differ depending on the settings of a call, screen for receiving a call, operations during an incoming call/a call etc. For details, refer to the "Instruction Manual application" (Japanese version) that can be used on the product.

Entering a Phone Number and Making a Call

- 1 Home screen → [☎].
- 2 Enter a phone number → [CALL].

Making a Call Using Incoming History/Outgoing History

- 1 Home screen → [☎].
- 2 [Incoming]/[Outgoing].
- 3 Tap "📞" of the other party you want to make a call to.

Making a Call Using Address Book

- 1 Home screen → [☎].
- 2 [👤].
- 3 Select the other party you want to make a call to.
- 4 [📞].

Answering a Call

- 1 Slide "Answer" down while an incoming call is arriving.
- 2 The call starts.
- 3 Tap "End call" to end the call.

When a call arrives while the backlight is on (except when the lock screen is displayed), the left screen is displayed. Tap "Answer".

Putting a Current Call on Hold

While the call is on hold, guidance is played for the other party.

- 1 Tap "Hold" during a call.
- 2 The call is put on hold and the guidance is played for the other party.
- 3 Tap "Unhold" to return to the call.

How to Transfer Data with the au Settings Menu

You can return/store data from an old au phone to this product using a microSD™ memory card or au server. To protect important data, be sure to save (back up) data periodically to a microSD™ memory card or au server.

- To return data using an au server, store data from the old au phone to the au server beforehand. To use the au server, you must set an au ID. (If the old au phone does not have au Settings Menu, use Friends Note application or au Cloud application).
- To return data using a microSD™ memory card, save the data from the old au phone to the microSD™ memory card beforehand. (If the old au phone does not have au Settings Menu, use the au backup application.)

- 1 On the home screen → "App list screen" → [Settings].
- 2 [au Settings Menu].
- 3 [Data Transfer].*
- 4 Select "機種変更はこちら" (If you have changed a model) and transfer data by following on-screen guidances.

* If a confirmation screen is displayed for terms of use/privacy policy, follow the on-screen guidances.

Automatically Storing Photos, Address Book etc.

Use the following steps to set automatic backup of photos, address book entries etc. to the au server using the "Data Storage" application. Photos can only be automatically stored with a Wi-Fi® connection.

- On the home screen → "App list screen" → [Settings] → [au Settings Menu] → [Backup Setting] → Select the type of data to store automatically.

Viewing/Playing data

You can view/play data on the product by the following operations.

- On the home screen → "App list screen" → [Settings] → [Storage] → select the save destination (Internal shared storage/microSD/USB memory name)* → select the category and folder → select the data to display.
- * If the microSD™ memory card or USB memory is not inserted to the product, contents of the Internal shared storage are displayed.

Reducing Battery Consumption

You can access "function buttons" from the status panel to enable/disable functions and modify their settings. You can reduce the battery consumption by switching their setting frequently, such as when not using the functions. Enabled functions are displayed in white.

- You can also reduce the battery consumption using "Energy saving". For details, refer to the "Instruction Manual application" (Japanese version) that can be used on the product.

- 1 Slide the status bar down with your two fingers.
- 2 Tap the functions whose setting you want to switch by using "function buttons".*

* Flick the function buttons field to the left or right to switch pages.

Brighten the screen/Increase the light duration of the backlight

When the screen is dark/the backlight is quickly turned off, change the setting.

- 1 On the home screen → "App list screen" → [Settings].
- 2 [Display].
- 3 [Brightness level] → Slide the bar to the left or right and set the brightness* → [OK].
- 3 [Sleep] → Select time.

* You can set whether to automatically adjust the screen brightness according to the ambient brightness by switching "Automatic brightness" to be enabled/disabled.