$XPFRIA \times 7$ sov34

Basic Manual

Preface

They may be different from actual ones. Thank you for buying "Xperia™ XZ" (simply called the "product"

Before using the product, read "Basic Manual" (this manual) for proper handling. After reading, keep this manual close at hand for your reference.

Packaged items

Before your start using the product, make sure that you have all the following packaged with the product.

Xperia[™] X7



Sony Mobile TV antenna

ての注意事項

XZ) (Japanese)

USB Type-C[™] cable

● 取扱説明書 (Instruction Manual) (Japanese) Xperia[™] XZのご利用にあたっ

cable 02 (02SOHSA)

(Cautions on using Xperia™ ● 設定ガイド (Setting Guide)

The following items are not included in the package Desktop holder

- microSD memory card AC adapter Farphones

♦Information

• Purchase a specified charger (sold separately).

• The battery is built into the product.

4 Turn the product horizontally and then insert and push the tray with the cards straight into the main unit Pay attention to the direction of inserting tray.

5 Press the tray all the way and check there is no gap

1 Put your fingernail into the groove to pull out the cover

of microSD memory card/au Nano IC Card 04 slot

2 Pull out the tray straight from the main unit to remove

3 Remove au Nano IC Card 04 out of the tray, insert and

4 Press the tray all the way and check there is no gap

• Note the following points, otherwise handling the au Nano IC

When the screen lock is set, the backlight turns off to avoid

backlight turns off automatically and screen lock is activated.

The lock screen appears when turning the power on or the

1 On the lock screen, swipe (flick) the screen up or left

Alternatively, touch o to cancel the screen lock

 \bullet On the lock screen, swipe (flick) " $\ensuremath{\psi}$ " or " $\ensuremath{\mbox{\mbox{$\mbox{α}$}}}$ " to activate

The followings are the main functions of \Box , \Box ,

 \triangleleft \square

"Voice Search" app or "Camera" app, respectively

When the specified time elapses, the product's screen

• Do not touch the IC (metal) part of the au Nano IC Card 04.

etween the main unit and the cover

push the tray straight into the main unit

between the main unit and the cover

Card 04 may cause malfunction or damage

the kevs and touch panel from false operations

1 While the screen is displayed, 🕚

screen backlight on by pressing o

Basic Operation

keys located at the bottom of the screen

Insert in the correct direction.

Setting Screen lock

Unlocking screen

♦Information


Pay attention to the direction of inserting tray.

Removing au Nano IC Card 04

Before attaching/removing the au Nano IC Card 04, make


Attaching/removing the au Nano IC Card 04

- Attaching the au Nano IC Card 04
- 1 Put your fingernail into the groove to pull out the cover of microSD memory card/au Nano IC Card 04 slot
- 2 Pull out the tray straight from the main unit to remove



3 Set au Nano IC Card 04 into the tray with IC (metal) part facing up


Pay attention to the orientation of notch. Surely set au Nano IC Card 04 into the tray not to come off.





Force-quitting

1 Press and hold o and the upper part of the volume key at the same time for approximately eight seconds. and release your fingers after the product vibrates three



Initial settings

When "ようこそ (Welcome)" appears after the product is powered on, tap "日本語 (Japanese)" and select "English (United States)" then follow the onscreen instructions to set functions and services. For details on the initial settings, refer to "Setting Guide"

• To change the language later, from the Home screen, []▶[設定 (Settings)]▶[言語と入力 (Language & input)] ▶[地域/言語 (Language)]. To make settings for au service etc., from the Home screen, [■] > [Settings] > [au Settings Menu]▶[au Easy Setting]

from here on).

About Operating Instructions

Setting Guide"/"Basic Manual" (this manual) Handles only basic operations for main features

• Illustrations used in this manual are just images for explanations.

■ "Basic Manual" (Japanese) app

You can use the "Basic Manual" (Japanese) app on the product to check detailed operational procedures. Some functions can be directly activated from the explanation

- When you activate for the first time, follow the onscreen instructions to download and install app. For details, refer to
- "取扱説明書 (Full Instruction Manual)" (Japanese) For detailed descriptions on various functions, refer to the "取 扱説明書 (詳細版) (Full Instruction Manual)" (Japanese)

For Those Requiring an English Instruction Manual You can download the English version of the instruction manual from the au homepage

Download URL: http://www.au.kddi.com/english/support/

. Do not use force to attach or remove

- If the au Nano IC Card 04 is incorrectly attached or abnormal, an error message appears
- Do not lose the au Nano IC Card 04 after it has been • Do not insert au Nano IC Card 04 with conversion adapter
- attached. Doing so may cause a fault


Attaching/Removing microSD memory card

Before attaching/removing the microSD memory card, make sure to turn off the product.

■ Attaching microSD memory card

- 1 Put your fingernail into the groove to pull out the cover of microSD memory card/au Nano IC Card 04 slot
- 2 Pull out the tray straight from the main unit to remove $\boldsymbol{3}\,$ Set microSD memory card into the tray with the
- terminal facing up

Surely set a microSD memory card into the tray not to come



Return to the previous screen. Close a dialog Display the Home screen Long-touch to activate "Google" app. Display recently used apps on a list and activate or end them from the list.

Using the touch panel

The display of the product is a touch panel operated by touching it with your finger.

■ Tap/Double-tap

8

1

Tap: Gently touch a screen and then immediately release your finger. Double tap: Touch the same position twice.

Long-touch

Keep touching an item with your finger.

Slide

While your finger is gently touching the screen, trace it to the


Swipe (flick)

Operate the screen by quickly moving (flicking) your finger up/down or left/right

Touch the screen with two fingers and widen (pinch-out) or narrow (pinch-in) the fingers' distance

Names and functions of parts

Getting Ready



① USB Type-C connection

12 O Power key/Screen lock key/Fingerprint sensor 13 Volume key/Zoom key

14 Camera key

4 Press the tray all the way and check there is no gap between the main unit and the cover

Charging

When you purchase your product, the internal battery is not fully charged. Charge the battery before use.

• When the charging starts with the product powered on, the start sound for charging sounds and Notification LED lights according to the charging status. To check the battery level. see the status bar in the top of the Home screen, or from the Home screen, [::::]▶[Settings]▶[About phone]▶[Status] and see "Battery level"

- If you start charging with the product turned off, a screen indicating the charging status launches but operations are not available. Thus, do not charge the product in a place where the use is prohibited.
- It may take longer to complete for charging with a PC or while using the camera function.

■ Charging with the AC Adapter

Charging with connecting TypeC Common AC Adapter 01 (sold separately) is explained

• For some apps/functions, an explanation screen for the

content and follow the onscreen instructions.

permission may appear. A confirmation screen may appear

in several times and screen content may vary. Confirm each

1 Insert the power plug of TypeC Common AC Adapter 01 (sold separately) into an outlet

2 Inset the Type-C plug of TypeC Common AC Adapter 01 (sold separately) into USB Type-C connection terminal of the product straight The start sound for charging sounds and Notification LED

15 Camera lens

(16) RGBC-IR sensor:

Detects element of

lighting source for

to adjust white

when shooting.

17 Flash/Photo light

19 Laser AF sensor:

camera on

22 Back cover*4

23 Nameplate*

24 Wi-Fi® antenna*3

25 Built-in antenna*3

cause a fault.

automatically.

21) au Nano IC Card 04

Detects distance

from an object when

shooting to focus a

20 Wi-Fi®/Bluetooth® antenna*3

26 microSD memory card/au Nano IC Card 04 slot

*1 Do not jab with a sharp object such as a needle. Doing so may

sticker when you use a commercially available protective film.

*3 The antenna is built in. Covering around the antenna by the


hand may affect the quality of call/communication.

(8) GPS/Built-in antenna*3

shooting environment

balance automatically

of the product lights.



- 3 When charging is complete, remove the USB Type-C plug of TypeC Common AC Adapter 01 (sold separately) from the product
- 4 Remove the power plug of TypeC Common AC Adapter 01 (sold separately) from the outle

Turning on (Initial settings)

Turning the power on

1 (over 1 sec.)

The product vibrates and after a while the lock screen

When "ようこそ (Welcome)" appears after the product is powered on, follow the onscreen instructions to set the initial settings

2 Swipe (flick) the screen up or left

Alternatively, touch (b) to cancel the screen lock.

■ Turning the power off 1 (over 1 sec.)

2 [Power off]

 Press (over 1 sec.) Long-touch "Power off" ► [OK] to restart the product in safe mode (a function that enables to start the product in status at the time of purchase).

Widgets		Add widgets, shortcuts of contacts etc.	
Wallpapers	Album	Select an image from albums to set as a wallpaper. To set image range, adjust cropping area by dragging, etc.	
	Live Wallpapers	Select a content from albums to set as a wallpaper.	
	Photos	Select an image from photos to set as a wallpaper. If nothing is displayed, tap and then tap "Photos" again.	
		Select an image to set as a wallpaper. Images displayed to the right of "Photos"/"Live Wallpapers" are "Xperia™'s Wallpaper".	
Themes	•	Set the Home screen, wallpaper of the lock screen, etc. to the common image, or download themes.	
Settings		Set size of icons on the Home	

Adding a folder

1 From the Home screen, long-touch an icon

2 Drag the icon onto another icon

■ Moving shortcuts/widgets/folders

1 From the Home screen, long-touch an icon or folder vou want to move

2 Drag it to a destination to be moved

■ Deleting shortcuts/widgets/folders

1 From the Home screen, long-touch an icon or folder you want to delete 2 Drag the icon or the folder to "Remove from home

screen" displayed at the top of the screen To delete a folder, tap "DELETE" in a row. It also deletes shortcuts etc. included to the folder.

Using the Apps screen

You can call up functions from the Apps screen. App icons installed to the product are also displayed.

• You may incur communication charges depending on the

Starting an app

1 From the Home screen, [🔠]

If a confirmation screen related to data collection for the purpose of providing the app recommendations appears, operate following the onscreen instructions. Slide or flick left or right to switch the Apps screens.

2 Tap an app to use Some apps are stored in a folder

19

1

au Nano IC Card 04 attached are described. Screen illustrations shown in this manual may look different from the actual screens. In some cases, minor details or a part of a screen may be omitted

From the Home screen, []▶[お客さまサポート (Customer

 In this manual, screen displays for the product color. "Platinum" are described as examples. support)]▶[Basic Manual In this manual "microSD™ memory card" "microSDHC"

available on the au homepage http://www.au.kddi.com/support/

4 Turn the product horizontally and then insert and push the tray with the cards straight into the main unit Pay attention to the direction of inserting tray.

Regarding notations used in this document

simplified illustrations such as ◀, ຝ, ଢ, ଢ, ७

• In this manual, screens and operations for the product with

• Operations of tapping menu items/icons/buttons on the

screen etc. are indicated as [(name of the item etc.)].

memory card" and "microSDXC™ memory card" are

abbreviated as "microSD memory card" or "microSD".

• All of the indicated amounts exclude tax unless otherwise

• Company names and product names referred to in this

manual are trademarks or registered trademarks of


respective companies. The TM and ® marks may be

• "The Company" as appears in the manual refers to the

Sold by: KDDI CORPORATION, OKINAWA CELLULAR

Manufactured by: Sony Mobile Communications Inc.

• In this manual, keys (key icons) are represented by



5 Press the tray all the way and check there is no gap

Drag

to move

specified

omitted in this manual.

following companies:

TELEPHONE COMPANY

 Insert a microSD memory card in the appropriate direction. Inserting a microSD memory card forcefully into the slot could result in failure to remove the microSD memory card or damage

1 Put your fingernail into the groove to pull out the cover of microSD memory card/au Nano IC Card 04 slot

• Do not touch the terminal of the microSD memory card.

■ Removing microSD memory card


2 Pull out the tray straight from the main unit to remove

3 Remove the microSD memory card out of the tray, turn the product horizontally and then insert and push the

tray straight into the main unit Pay attention to the direction of inserting tray.

Keep touching an item or icon, trace it to the desired direction

Pinch



1

Setting app permission

of the product is activated for the first time, an access permission request appears. If such confirmation screen appears, confirm the content and

Swipe (flick)

When an app/function accessing the functions or information

tap "DENY"/"ALLOW". Example: When activating "Music" app for the first time

A confirmation screen appears 2 [DENY]/[ALLOW]

1 From the Home screen, []▶[Music]

♦Information

1

• If you do not permit, app/function may not be activated or use of function may be restricted. To change the permission setting, from the Home screen,

[]▶[Settings]▶[Apps]▶Tap an app to change the setting nissions] []/[] of permission to be changed.

Home screen

to the Home screen any time. (1) Google Search (2) Widgets (3) Shortcuts (Apps) 4 Home screen position Indicates the current position

au 🗦 😭 🔠

13

from multiple pages. Slide or flick left or right to move to the adjacent screen (5) Wallpaper

6 Folders (Google, 基本機能 (Basic functions)) (7) Apps key

If a confirmation screen related to data collection for the purpose of providing the app recommendations appears when it is tapped, operate following the onscreen instructions.

Adding to Home screen/Editing Home screen

You can change wallpaper or theme of the Home screen or add shortcuts of contacts etc., widgets on the Home screen.

1 Long-touch an area of the Home screen where no icons are displayed

			as a wallpaper. To set image range, adjust cropping area by dragging, etc.	
		Live Wallpapers	Select a content from albums to set as a wallpaper.	
	as a wall		Select an image from photos to set as a wallpaper. If nothing is displayed, tap and then tap "Photos" again.	
			Select an image to set as a wallpaper. • Images displayed to the right of "Photos"/"Live Wallpapers" are "Xperia™'s Wallpaper".	
the lock screen,			Set the Home screen, wallpaper of the lock screen, etc. to the common image, or download themes.	
	Settings		Set size of icons on the Home screen, switching screens, etc.	


*5 A sticker with CE mark, FCC ID, IMEI information, etc. printed is attached. Do not remove the sticker or nameplate

*4 Back cover is not removable. Removing so forcibly might cause damage or a fault. Also, battery is built into the main unit and

au Nano IC Card 04

not removable by customers

Your phone number etc. is recorded in the au Nano IC Card 04. The product is compatible with au Nano IC Card 04.



Downloading apps

You can download and install apps or games, etc. by using

• To use Google Play, you need to set a Google account. For details, refer to "Setting Guide"

Uninstalling apps

Before uninstalling, back up contents related to the app that you want to save including data saved in the app.

Some apps may not be uninstalled

Knowing the status of the product

■ Status bar

The status bar is located at the top of the product screen. On the left of the status bar, notification icons appear to inform missed calls, new mails, operations in progress, etc., and on the right, status icons appear to indicate the status of the product.



Symptom	What you should check	
The screen freezes and the power cannot be turned off	Shut down forcibly by pressing and holding ① and the upper part of the volume key at the same time for approximately eight seconds, and releasing your finger after it vibrates three times consecutively.	
(Out of service area) appears	Is the product out of the service area or in an area where the signal is weak? Is the built-in antenna covered with hand? Is au Nano IC Card 04 inserted?	
Cannot operate key/ touch panel	Is the power turned on? Is "Screen lock" set? Turn off the power and then turn it on again.	
Cannot operate touch panel as intended	Are you operating with a fingernail or foreign object on the operating screen?	
Cannot charge the battery (Notification LED does not light, the battery icon does not change into charging one)	Is the specified charging equipment (sold separately) attached properly?	
Charging is not complete	Is the temperature of the product raised or very low?	

For inquiries, call: Customer Service Center Replacement mobile phone delivery service (Member) Customer charge

For general information, charges and operation information (toll free) Business hours 9:00-20:00 (7 days a week)

60077-7-111 | 157 without area code

PRESSING ZERO WILL CONNECT YOU TO AN OPERATOR AFTER CALLING 157 ON YOUR au CELLPHON

For loss or theft (toll free) Business hours: 24 hours live support From fixed-line phones: | From au mobile phones 0077-7-113 113 without area code

In case above numbers are not available (toll free)

F 0120-977-033 (except Okinawa) 0120-977-699 (Okinawa)

Keitai Guarantee Service Center For loss, theft, damage (toll free)

Business hours 9:00—20:00 (7 days a week) From fixed-line phones/au mobile phones, 0120-925-919









Š	Missed call
Ø	Incoming/Talking/Calling
_	New PC mail message
	New Gmail message
585	New E-mail (@ezweb.ne.jp) message
586	New SMS/Receiving notification service message, New Receiving notification
ψ	USB device connected
? ?	Wi-Fi [®] open network available

■ Main status icons

Symptom

Battery usage time

The screen

he keys

nicroSD memory

Conditions: Basic charge

1st time

2nd time

2nd time

1st time

2nd time

backlight turns off

in a short while

■ Examples of notification icon

	Battery level (100%, Charging)	
1 , /	Signal level (Level 4, Out of service area)	
46 , 45 , 11 , 14 , 14 , 14 , 14 , 14 , 14	4G (LTE/WiMAX 2+) data communication status*1 (Available, data transferring or downloading)	
••	Silent mode (Vibrate) is set	
Θ	Silent mode (Mute) is set	
ন্ট , <u>ন্</u>	Wi-Fi® connected, Wi-Fi® communicating	
小	Airplane mode is activated	
*1 Two types of network "LTE" and "WiMAV 2.1" can be used "4C		

*1 Two types of network, "LTE" and "WiMAX 2+" can be used. "4G" appears on the screen for both networks. The company determines which network is less busy depending on the condition of the line to connect.

What you should check

Charge until Notification LED turns gree

Is the product used for a long period

at places where (Out of service

Is the proximity/light sensor blocked

microSD memory card, the screen

Is the microSD memory card unmounted?

ongtime user benefit*1 3,000 yen

Longtime user benefit*1 6,000 yen

ongtime user benefit*1 2,000 yen

ongtime user benefit*1 5,000 yen

ongtime user benefit*1 2,500 yen

ongtime user benefit*1 5,500 yen

35

esponse may be delayed.

or covered by sticker?

set "Sleep" period too short?

s the internal battery end-of-life?

Is the battery fully charged

area) appears?

The display is dark | Is "Brightness level" set to dark?

Screen response is When a large amount of data is saved

slow when you tap lin the product or transferring large

on the screen/press size data between the product and

Cannot recognize a Is the microSD memory card inserted

For more details, visit au homepage and check with "トラブル

5,000 yen/

8,000 yen/

Conditions: WEB割引 (Discount for web application)*2 and 代

.000 yen/

,500 yen/

,500 yen/

*1 This discount applies to customers who have used au for 3 years

(25 months) or more, and all the lines within that customer's

Family Discount, For customers using a data communication

device or tablet, this discount applies to customers who are

Smartphone Set Discount) and have been under the contract of

subscribed to a set discount (WIN Single Set Discount or

the line eligible for the set discount for 3 years or more.

Conditions: Only 代用機なし割引 (Discount for nonuse of

* Charge amounts are all tax excluded

用機なし割引 (Discount for nonuse of substitute)*3 applied

properly?

診断 (Diagnosis for trouble)" in au Customer support

http://cs.kddi.com/support/komatta/kosho/trouble/

After-sales service

■ Notification panel

■ Notification LED

Orange

Green

Flashing

♦Information

not sufficient.

white

22

If any notification icons are displayed, slide down the status

bar to open the Notification panel. You can check details of

• To delete a notification, flick the notification left or right. Some

notifications may not be deleted depending on the content.

(flicking) down on the lock screen. Or set to hide or keep

Notification LED informs charging prompt, battery level while

charging, missed calls, new mails, etc. by turning on or flashing.

attery level is 14% or lower

attery level is 15% - 89%

Flashing red The remaining battery level is 14% or lower.

• Flashing of Notification LED several times in red when pressing

with the power off indicates that the remaining battery is

new SMS message.

attery level is 90% or higher.

Description

he battery is charging when the remaining

he battery is charging when the remaining

The battery is charging when the remaining

Indicates missed call, new Gmail message,

Alternatively, you can check notifications by swiping

notification icons or start corresponding apps.

showing notifications on the lock screen

When asking for repair

For repair, contact Keitai Guarantee Service Center.

1 Flashes while backlight is turned off.

	Repairs will be done based on the terms of services of the free-of-charge repair warranty.	
warranty	We shall repair the product for a charge as requested by the customer if repair renders it usable.	
* The warranty period is one year from the date you purchased the		

product.

Information

- Before handing in the product for repair, make a backup of the contents of memory since they may disappear during repair. Note that the Company shall not be liable for any damages and loss of income should the contents of memory be altered or lost.
- Recycled parts that meet the Company's quality standards are sometimes used for repair. Collected au mobile phones by Replacement mobile phone
- delivery service which you used before are recycled to mobile phones for replacement after repairs. Also replaced parts by au after-sales service are collected and recycled by KDDI. They are not returned to customers.
- The product which is processed, remodeled, analyzed. (including by modifying or analyzing the software (including by rooting etc.), reverse engineering, decompiling), or repaired by an unauthorized repair office is not covered by the warranty and repair may be refused.

*2 WEB割引 (Discount for web application): 500 yen reduction from the customer charge is applied for application of "Replacement mobile phone delivery service" via au homepage.

A substitute mobile phone is not rent for "WFB割引 (Discount for web application)", instead, "代用機なし割引 (Discount for nonuse of substitute)" is also applied together

*3 代用機なし割引 (Discount for nonuse of substitute): 500 yen reduction from the customer charge is applied if you do not use a substitute mobile phone when using "Replacement mobile phone delivery service".

For details, refer to au homepage.

Online Reception Desk (24 hours a day over the Internet) *Reception only from PC or smartphone

https://cs.kddi.com/support/n_login.html

Replacement mobile phone delivery service When you have trouble with your au mobile phone,

- replacement mobile phone (same model, same color*1) is delivered by calling to. Return your damaged mobile phone within 14 days after the replacement mobile phone is delivered. *1 If the same model in the same color is difficult to provide, a replacement mobile phone of a model and a color that are
- specified by KDDI is provided. • Available up to twice in a year from the day you use this service as a start day. If you do not use this service in the past year for the subscription to this service, it will be 1st and if you use, it will be the 2nd.
- * For details, refer to au homepage In the event of theft or loss, when reissue of au IC card is needed at the same time of using this service, 1,900 yen will be applied separately as a charge of reissue.

36

• Although when you start charging with the product powered • Raising the volume by pressing the upper part of the volume off. Notification LED turns in red, after the screen indicating charging status appears, Notification LED lights in the color

■ Checking own phone number

indicating battery level.

1 From the Home screen, []▶[Settings]

2 [About phone]▶[Status]▶[SIM status] The phone number of the product is shown under "My phone number"

 Alternatively, from the Home screen, [□]▶[Contacts]▶ [Myself] to check your phone number

Setting the silent mode (Vibrate)

1 Press the upper or lower part of the volume key 2 [[]] The icon for the volume adjusting bar changes to (white).

■ Setting the silent mode (Mute)

1 Press the upper or lower part of the volume key

2 [☐]▶Press the lower part of the volume key The icon on the volume adjusting bar turns to 🔳 (gray).

- By tapping "▼" on the volume adjusting bar, you can adjust volume of media sound or alarm. However, setting of alarm volume in "Clock" app takes precedence.
- When the "silent mode" is set, sounds for shutter, shooting start/end sound when shooting videos, alarm, playback of video, or music, etc. are not muted.
- The battery built-into the main unit is not covered by free-of charge repair warranty excluding events arising from defects of battery material or the production. • Packaged items other than the main unit is not covered by
- free-of-charge repair warranty. Performance parts for repair The Company retains performance parts for repair of the Xperia" XZ main unit and its peripherals for four years after discontinuation

of production. "Performance parts for repair" refers to parts required for maintaining the functions of the product.

- Provisions for free-of-charge repair Please notify us of the production number (IMEI number) for repair request. The production number (IMEI number) can be checked on the product main unit, sticker on the outer packaging box, etc.
- 2. During the warranty period, we will repair the product free of charge for the malfunction under the condition that it is used correctly in line with the directions given in the instruction manual.
- 3. Even if the warranty period has not expired, a fee will be charged for repair under the following circumstances. (or, repair may not be possible).
- 1) The product has not been used correctly in line with the directions given in the instruction manual. 2 The malfunction or damage is due to unauthorized repair or modification of the product, (3) The product has been repaired other than at our specified repair offices. 4 The malfunction or damage is due to negligence in use or handling, or due to an accident. There are signs of the product having been dropped, wet, exposed to humidity, etc. ⑤ The malfunction or damage is due to natural

Holding over and repair

- Damages and malfunctions intentionally caused by the customer as well as those due to modification (e.g. disassembly, change of parts, painting, etc.) by the customer are not covered by this service.
- You cannot receive a refund for the replacement of the outer casing due to stains, scratches, paint removal, etc. on the outer casing.

SIM unlock

The product supports SIM unlock. By unlocking SIM lock, you can use non-au SIM cards. • The SIM unlock service is provided at the au homepage and

- au shops. Some services, functions, etc. may be unavailable when using
- non-au SIM card. The Company is not liable for any operations.
- For settings after SIM unlock, operate from the Home screen, [:] ▶ [Settings] ▶ [About phone] ▶ [Status] ▶ [SIM status]►[SIM card status].
- For details, refer to the au homepage https://cs.kddi.com/support/simcard/

- key in the silent mode, or adjusting volume of "Ring volume" OWFRTY keyboard In the QWERTY keyboard, you can also enter number or of "Sound & notification" in the silent mode (Vibrate) cancels symbol displayed in a small character above the alphabet on each key by long-touching. For some keys, furthermore character variants will appear. Slide over the candidates to
- Setting Airplane mode

When airplane mode is set, all wireless functions (phone, packet communication, Wi-Fi® function, Bluetooth® function, NFC Reader/Writer, P2P function) are turned off.

1 From the Home screen, []▶[Settings]

2 [] of "Airplane mode"

Entering characters Use software keyboard to enter characters.

The software keyboard appears when you tap the entry field for registering a contact, composing a mail, etc.

■ Switching software keyboards

With "SwiftKey Keyboard", you can use QWERTY keyboard to enter characters, the numeric keypad to enter numbers and symbols, and the symbol keypad for more symbols.

- 1 Tap a character input box
- 2 Tap [123] to switch to the numeric keypad For the symbol keypad, tap " on the numeric keypad.

- Tap " Tap " at the bottom of the screen to hide the software Word candidates will appear according to entered
- character, select a word you want to enter.
- Tap " to delete the character before the cursor.
- disasters (earthquakes, storm or flood damage, etc.), fire, salt damage, abnormal voltage, etc.
- 4. Repair may not be possible depending on the degree of damage. 5. The Company shall have no liability for any damage or loss
- resulting from the malfunction of the product. 6. The Company shall not bear any responsibility for accidents resulting from use of the product having been
- connected to unspecified devices. 7. Do not accept requests for service calls to the owner's home, place of business, etc.
- 8. This warranty is valid only in Japan.
- * This warranty guarantees repair free of charge during the period and under the conditions specified on this warranty card. Thus this warranty does not limit the legal rights of the owner with respect to the issuer of this warranty card (the guarantor) or any other business person or enterprise

■ Keitai Guarantee Service Plus LTE

An after-sales service membership program on a monthly basis called "Keitai Guarantee Service Plus LTE" (monthly fee 380 yen tax excluded) is available for using your au mobile phone for a long time without worries. This service expands coverage for many troubles including malfunction, theft and loss. For details of this service, refer to au homepage or contact Keitai Guarantee Service Center

❖Information

- \bullet You can apply for membership only at the time of purchasing your au mobile phone.
- Once you cancel the membership, you cannot reapply for it until you purchase an au mobile phone next time.

Peripheral devices

- Sony Mobile TV antenna cable 02 (02SOHSA)
- Sony Mobile Desktop Holder 02 (02SOPUA) (sold separately)* • TypeC Common AC Adapter 01 (0601PQA) (sold separately)
- Common AC Adapter 05 (0501PWA) (sold separately)*2
- Common DC Adapter 03 (0301PEA) (sold separately)*
- MicroB-TypeC conversion adapter (0601PHA) (sold separately)
- au Carrying Case G Black (0106FCA) (sold separately) *1 Use the Attachment 52B.
- *2 For use, MicroB-TypeC conversion adapter (sold separately) is

http://auonlineshop.kddi.com/

♦Information Accessories can be purchased from the au Online Shop.

Main specifications

Display	Approx. 5.2 inches, TRILUMINOS® Display for mobile Approx. 16.77 million colors
	1,080 x 1,920 dots
Weight	Approx. 161 g
Dimension (W x H x T)	Approx. 72 mm x 146 mm x 8.1 mm
Internal memory	ROM: Approx. 32GB RAM: Approx. 3GB

• Note that when changing the model or purchasing an extra mobile phone, this service only covers the most recently purchased au mobile phone.

Switch to lower-case " □ ", upper-case " □ " or caps " □ " on

• Tap = at the left edge of the candidate area to make

advanced settings for SwiftKey keyboard.

• To enter Japanese, change the software keyboard to

Xperia[™] Japanese keyboard by tapping
and then

You can update the product to the most recent software for

• You are charged for data communications when connecting to

• For details, visit http://www.sonymobile.co.jp/support/ or

instruction manual)" (Japanese) available on au homepage

refer to the "Basic Manual" (Japanese) app that can be

viewed on the product or "取扱説明書(詳細版)(Full

the Internet from the product by using packet communication.

optimal performance and to get the latest enhancements.

• You are recommended to back up your data before

select a variant you want to enter.

marking "Japanese"

Appendix

Updating Software

updating software.

25

32

- When an au mobile phone is handed over to you or someone else, the Keitai Guarantee Service Plus LTE membership is also handed over to the successor of the mobile phone.
- When you get a new au mobile phone by changing the model or purchasing an extra mobile phone, the "Keitai Guarantee Service Plus"/"Keitai Guarantee Service Plus LTE" membership for the old au mobile phone is automatically canceled.
- Service contents are subject to change without notice.

au Nano IC Card 04

Camera pixels

call time

stand-by

Charging time

atching time

Continuous In Japan

Continuous In Japan

Continuous Full Seg

onnection number

Wi-Fi[®] tethering maximum

Overseas

Overseas

(GSM)

(GSM)

The au Nano IC Card 04 is lent to you by au. In case of loss or damage, the card will be replaced at your expense. When a malfunction is suspected, or in case of theft or loss, contact an au shop or PiPit.

au after-sales service information Replacement mobile phone delivery service Keitai Guarantee Service Plus LTE members

Spontaneous failure 1st year	Free of charge
	mobile phone delivery
Partially damage, water soak, irreparable damage, theft or loss	service (Member) Customer charge"

Image pickup device (type) Camera: Backside

Downloading and updating software Update files can be downloaded from the Internet web site

into the product directly

- Note that when Wi-Fi[®] communication becomes unstable, data communication takes the place automatically, which may incur communication charges
 - 1 From the Home screen, []▶[Settings]▶ [About phone]▶[Software update]

 - 2 [**i**]▶[Refresh]
- er that, follow the onscreen instructions.

Troubleshooting

Before you assume that the product is malfunctioning, check the following in addition to performing "トラブル診断 (Diagnosis for trouble)" in "故障受付 (Repair desk)" app. To use "トラブル診断 (Diagnosis for trouble)", from the Home screen, [:::]▶[お客さまサポート (Customer support)]▶[故障 受付 (Repair desk)]▶[トラブル診断 (Diagnosis for trouble)].

Symptom	What you should check	
	Is the internal battery charged?	
on even though o is pressed	Is pressed for over one second?	
The power goes off	Is the internal battery charged?	
The power turns off while the product activation screen is displayed	Is the internal battery charged?	

Non-Keitai Guarantee Service Plus LTE members

Spontaneous failure 1st year	No recompense
Spontaneous failure 2nd year or later	
Partially damage, water soak, irreparable damage, theft, loss	

Holding over and repair

Keitai Guarantee Service Plus LTE members

Spontaneous failure 1st year	Free of charge
Spontaneous failure 2nd year or later	Free of charge (three-year warranty)
1010	**
Partially damage	Customer charge The upper limit: 5,000 yen
Water soak, irreparable	Customer charge
damage	10,000 yen
Theft, loss	No recompense

Non-Keitai Guarantee Service Plus LTE members

Spontaneous failure 1st year	Free of charge
Spontaneous failure 2nd year or later	Actual cost
Partially damage	
Water soak, irreparable damage	
	No recompense (model change)

^{*} Charge amounts are all tax excluded

Ilumination layered CMOS

illumination layered CMOS

Front camera: Backside

Camera: Effective pixels

Approx. 23 million pixels

Approx. 1,630 min

Approx. 710 min.

Approx. 660 hours

Approx. 690 hours

Approx. 160 min.

Continuous 1Seg viewing time | Approx. 9 hours 10 min.

Continuous tethering time | Approx. 500 min

Front camera: Effective pixel

Approx. 1.32 million pixels

Using TypeC Common AC

Adapter 01 (sold separately

33

39

Bluetooth Compliant with Bluetooth ınction standard Ver.4.2 Output Compliant with Bluetooth standard Power Class 1 Vithin 10 m with good Communication isibility coverage distance['] Supported HSP. HFP. PBAP*3. A2DP. AVRCP, SPP, OPP, HID, PAN HOGP, MAP, DUN*4, GATT 2.4 GHz band (2,400 MHz frequency band 2,483.5 MHz)

- 1 Varies by obstruction between communication devices or radio wave reception status.
- *2 It is a specification according to purpose of use of Bluetooth® device and is defined by Bluetooth® standard. *3 Some contacts data may not be displayed correctly on the other
- party's device. *4 Only supported to a part of car navigation systems. For use

refer to the au homepage.

continuous Full Seg watching time, continuous 1Seg viewing time and continuous tethering time may drop to less than half depending on the battery charging status, usage

The continuous call time, continuous stand-by time

environment such as temperature, reception condition at the location where the product is used, and the function settings