

# Galaxy S8

SCV36

**Basic Manual** 

#### Introduction

#### Preface

Thank you for purchasing the Galaxy S8 (referred to as the "product" in this manual). Before using the product, be sure to read the "Setting Guide" and "Basic Manual" to ensure correct usage.

# List of Packaged Items

Before you start using the product, make sure that you have all the following packaged with the product.





Main unit

SC TV Antenna Cable 04 (04SCHSA)



SIM card removal tool
(sample)

\* Use to insert/eject the au Nano IC

- Card 04 and microSD memory card.
- AKG Tuning High-quality Earphone with Microphone (sample)
- 取扱説明書 (Instruction Manual) (Japanese)
- ・設定ガイド (Setting Guide) (Japanese)

The following items are not included in the package.

- · microSD memory card
- · AC adapter
- · USB Type-C cable



- OPlease purchase a specified charger (sold separately).
- The battery is built into the product.
- © Illustrations used in this manual are just images for explanations. They may be different from actual ones.

#### Instruction Manuals

#### "Setting Guide" "Basic Manual"

Handles only basic operations of major functions of the product.

#### ■ Basic Manual application

You can use Basic Manual application on the your product to check the operation of this product.

In the Applications screen, [基本フォルダ(Basic folder)] → [Basic Manual]



- When using the application for the first time, you must download and install it following the on-screen instructions.
- "取扱説明書(詳細版) (Full Instruction Manual)" (Japanese)


For detailed descriptions on various functions, refer to the "取扱説明書(詳細版)(Full Instruction Manual)" (Japanese) available on the au homepage.

https://www.au.com/support/service/mobile/guide/manual/

# Illustrations and Descriptions in this Manual

#### ■ Note on key/button illustrations

In this manual, the key/button illustrations are simplified as shown below.



#### Description of operations for selecting item/icon/ button, etc.

In this manual, operation steps are described as follows.

Description	Explanation
ダ (Basic folder)] → [Settings] → [General management]	On the home screen, tap "基本 フォルダ (Basic folder)", then tap "Settings" in the displayed window and tap "General management".

 Tapping is lightly touching a button or icon displayed on the screen with your finger.

#### ■ Note on Screenshots

This manual uses screenshots and describes operations with the au Nano IC Card O4 inserted.

The illustrations and screenshots used in this manual are simplified and may look different from the actual screens. Note that in some cases, a part of a screen may be omitted





- On this manual, screenshots for body color "Orchid Gray" are provided as examples.

- All of the indicated amounts exclude tax unless otherwise specified.
- © Company names and product names referred to in this manual are trademarks or registered trademarks of respective companies. The TM and ® marks may be omitted in this manual.

# Contents

Introduction Preface	·· ii
Preface	·· ji
List of Packaged Items	·· ji
Instruction Manuals	·· ii
Illustrations and Descriptions in this Manual	]
Notes on Usage	З
For Using the Product ·····	З
Safety Precautions (Observe Strictly)	4
Material list	15
. Idi idii ilg pi ooddatioi io	17
Precautions for Waterproofness/Dustproofness	22
Notes on using Bluetooth®/	
wireless LAN (Wi-Fi®) functions·····	26
Available security codes/PIN code ······	28
Notes on data communication charge	29
Notes on applications	29
Configuring the app's permissions	30
Take your manners with you as well	30
Necessary and their functions	31
Names of parts and their functions au IC card	31 33
Attaching/removing an au IC Card ······	34
Attaching/removing a microSD memory card	36
Charging	39
Turning the power on/off ······	41
Setting the screen lock	42
Using the SC TV Antenna Cable 04 ·····	42
Using AKG Tuning High-quality Earphone with Microphone	
(sample) Basic operation	43
Basic operation	44
Using the home screen	44
Starting an application ·····	44

Monitoring the product's status	45
Checking your phone number·····	46
Setting the Silent mode	46
Setting the Airplane mode	46
Emergency call location notification	47
	48
Updating Software ······	48
Troubleshooting	49
After-sales service ······	49
Unlocking the SIM lock ······	52
Related accessories	52
Main specifications	53
Specific Absorption Rate (SAR) of cell phones	54
FCC RF exposure information	55
Export Administration Regulations	55
Intellectual Property Rights	55

# Notes on Usage

#### For Using the Product

Before you start using the product, be sure to read the "Safety Precautions" to ensure correct use.

- ・Before you assume that the product is malfunctioning, perform "トラブル診断 (Troubleshooting diagnosis)". In the Applications screen, [auツール/サポート(au tool/support)] → [随障受付 (Malfunction reception)] → [トラブル診断 (Troubleshooting diagnosis)] (in Japanese only) Alternatively, check for possible remedies in "トラブル診断 (Troubleshooting diagnosis)" on the au website. https://www.au.com/trouble-check/ (in Japanese only)
- Communication is not possible even inside the service area in places where the signal does not reach (e.g. tunnels and basements). Also, communication is sometimes not possible in poor reception areas. Communication is sometimes interrupted if you move into a poor reception areas during communications.
- Since this product uses radio waves, the possibility of communication intercepts by third parties cannot be eliminated. (Though LTE/WiMAX 2+/GSM/UMTS system has highly secure confidential communication features.)
- Use au's VoLTE (LTE network) to connect to Japanese emergency services. You cannot use 3G (call switching network) to connect to emergency services.
- While this product supports the au World Service, each network service described in this manual varies depending on the area and service content.
- Since this product is a radio station under the Radio Law, you
  may be asked to temporarily submit the product for inspection
  in accordance with the Radio Law.
- The IMEI information of your cell phone is automatically sent to KDDI CORPORATION for maintenance and monitoring operational status of your cell phone.

- To use it overseas, check the condition such as regulations of the country/region.
- The Company is not liable for any damages arising from earthquakes, lightning, storms, floods or other natural disasters, as well as fires, actions by third parties, other accidents, intentional or mistaken misoperation by the customer, or use under other unusual conditions outside the responsibility of the Company.
- The Company is not liable for any incidental damages (change/disappearance of saved content, loss of business income, disruption of business, etc.) arising from use of or inability to use the product.
- The Company is not liable for any damages arising from failure to observe the described content of Basic Manual (this manual).
- The Company is not liable for any damages arising, for example, from malfunction caused by combination with connected devices or software not related to the Company.
- Captured image data or downloaded data may sometimes be altered or lost due to faults, repair or other handling of the product. The Company is not liable for any damage or lost income resulting from recovery of these data.
- It is recommended you keep a copy of important data on your PC's hard disk, etc. Whatever the cause of the defect or malfunction may be, the Company assumes no responsibility for alteration or loss of saved data.
- Contents saved in the product, such as contacts, mails and favorites, might be altered or lost in accident, fault, repair or mishandling. Be sure to keep a copy of important contents. Note that the Company assumes no responsibility for any damages or lost profits resulting from altered or lost contents.
- Contents saved in this product, such as contacts, mails and bookmarks, might be altered or lost in an accident, fault, repair or mishandling. Be sure to keep a copy of important contents. Note that the Company assumes no responsibility for any damages or lost profits resulting from altered or lost contents.

- Note that content data (both charged or free content) saved with the product cannot be returned to the customer when the product is replaced for repair of a fault, for example.
- Although the display used by this product is made using high precision technology, some pixels (dots) might not light or are lit at all times. Please note that this is not a fault.
- If an image is displayed for a long time, an afterimage may occur but this is not a fault. To prevent afterimage and to conserve power, you are recommended to set the screen timeout time to a short time.
- You are recommended to store copies of individual data such as photos you took, videos and music on your PC by sending each file as mail attachment, etc. Note, however, that you may not be able to make copies of any copyrighted data even by the above mentioned means.
- Do not discard this product together with regular trash.
   Please cooperate in the collection of the product (including optional accessories) when it is no longer needed to protect the environment and effectively use resources. Old product are collected at au shops and other places.
- \* "The Company" as appears in this manual refers to the following companies: Sold by: KDDI CORPORATION, OKINAWA CELLULAR TELEPHONE COMPANY Imported by: SAMSUNG ELECTRONICS JAPAN Co., Ltd. Manufactured by: Samsung Electronics Co., Ltd.

#### Notice

- Reproduction of the content of this manual in part or in whole is prohibited.
- The content of this manual is subject to change without notice.
- Every effort has been made in the preparation of this manual. Should you notice any unclear points, omissions, etc., feel free to contact us.

# Safety Precautions (Observe Strictly)

- Before using this product, read the precautions below to ensure safe use and handling. After reading this manual, keep it carefully.
- These precautions are intended to protect you and others around you. Read and follow them carefully to avoid injury, damage to the product or damage to property.
- The signs below differentiate between the levels of danger that can occur if the product is not used within the specified guidelines.

<u> </u>	This sign denotes that death or serious injury <sup>(*)</sup> may directly result from improper use.
⚠ Warning	This sign denotes that death or serious injury <sup>(*)</sup> may result from improper use.
⚠ Caution	This sign denotes that minor injury <sup>(*2)</sup> or property damage <sup>(*3)</sup> to property may result from improper use.

- \*1 Serious injury: Loss of sight, injury, burns (high/low temperature), electric shock, bone fracture, poisoning, etc. with subsequent complications and/or those that require hospitalization or prolonged hospital visits.
- \*2 Minor injury: Injury, burns (high/low temperature), electric shock, etc. that do not require hospitalization or prolonged hospital visits.
- \*3 Property damage: Severe damage to property or live stock/pets.

#### ■ Explanation of graphic symbols used in this manual



Indicates an action that is not allowed.



Indicates that disassembly is not allowed.



Indicates that use in a place where the product is likely to get wet or allowing the product to get wet is not allowed.



Indicates that handling with wet hands is not allowed.



Indicates an action that must be obeyed at all times.



Indicates that the power plug must be disconnected from the power outlet.

Precautions common to the product main unit, internal battery, charging equipment, au IC card, peripheral devices



Be sure to read the following hazards before use.



Do not use, store, or leave the equipment in a place subject to high temperature or in places where heat builds up (such as close to fires or heating devices, inside kotatsu or inside of bedding, under direct sunlight, or in a car on an extremely hot day).

May cause fire, burns, injuries or electric shocks, etc.



Do not put the equipment into heating cooking device such as microwave oven, IH cooker or high-pressure container such as pressure cooker.

May cause fire, burns, injuries or electric shocks, etc.



Do not pour sand, soil or mud on the product or place the product directly on sand, soil or mud. Avoid touching the product with a hand covered with sand, etc.

May cause fire, burns, injury, electric shocks, etc. For waterproofness/dustproofness, refer to the following:

▶P.22 "Precautions for Waterproofness/Dustproofness"



Do not charge the product if it is wet with liquid such as water, sweat, seawater, pet urine, etc.

May cause fire, burns, injury, electric shocks, etc. For waterproofness, refer to the following:

▶P.22 "Precautions for Waterproofness/Dustproofness"



Do not attempt to disassemble or modify the equipment.

disasse

May cause fire, burns, injuries or electric shocks, etc.



Do not let the equipment get wet with liquids (drinking water, perspiration, sea water, pet urine, etc.) such as water, etc.

May cause fire, burns, injuries or electric shocks, etc.

For waterproofness, refer to the following:

▶P.22 "Precautions for Waterproofness/Dustproofness"



Do not put water (drinking water, perspiration, seawater, urine of pet animals, etc.) into the headset connection terminal or the external connection terminal.

May cause fire, burns, injuries or electric shocks, etc.

For waterproofness, refer to the following:

P.22 "Precautions for Waterproofness/Dustproofness"



Use the optional equipment specified by au for the product.

May cause fire, burns, injuries or electric shocks, etc.

# 

Be sure to read the following warnings before use.



Do not subject the equipment to strong forces, impacts or vibration such as being dropped, being stepped on, or being thrown, etc.

May cause fire, burns, injuries or electric shocks, etc.



Keep conductive materials (metal pieces, pencil lead, etc.) from coming in contact with the headset connection terminal or the external connection terminal, and keep dust from getting inside of them. May cause fire, burns, injuries or electric shocks, etc.



Do not cover or wrap the product with bedding, etc. while using or charging the product.

May cause fire, burns, injuries or electric shocks, etc.



Do not stick metallic items (such as stickers that contain metal) on the front of the wireless charger (sold separately) or this product.

May cause fire, burns or injuries.



Do not place metallic items (such as straps and clips that contain metal) between the wireless charger (sold separately) and this product.

May cause fire, burns or injuries.



When charging with the wireless charger (sold separately), remove the cover etc. with which the product is equipped.

Failure to charge arising from material and thickness of the cover or foreign objects such as dust caught between the product and the cover may cause fire, burns or injury.



Turn the product OFF near high-precision electronic control equipment or electronic equipment using low-power signals.

Failure to do so may cause the equipment to fail or malfunction.

Examples of electronic equipment to avoid Hearing aids, implanted pacemakers or defibrillators, other electronic medical equipment, fire alarms, automatic doors and other automatic control equipment. Users wearing implanted pacemakers or defibrillators or other electronic medical equipment should check with the manufacturer or sales outlet about the effect of radio wave on the equipment.



If charging is not completed after the specified charging time, stop charging.

Overcharging the battery may cause fire, burns or injury.



Turn the product OFF and stop charging before entering a place such as a gas station where there is a possibility of flammable gases being generated or a place where there is a possibility of dust being generated.

May catch explosion or fire.

When using Osaifu-Keitai® at a gas station, be sure to turn off the power in advance. (If NFC/Osaifu-Keitai lock has been set, cancel the lock before turning off the power.)



When anything is different from before, such as the equipment generates strange smells or strange sounds, emits smoke, produces heat, becomes discolored or deformed, etc. during use, charging or while being stored, then perform the following operations.

- Remove the power plug from the outlet or cigarette lighter socket.
- · Turn the product OFF.

If the above operations are not performed, this may cause fires, burns, injuries or electric shocks, etc.



Be sure to read the following cautions before use.



Do not use damaged equipment.

May cause fire, burns, injuries or electric shock.



Do not leave on unstable places such as rocky stands or tilting surfaces especially while the vibration mode set.

May fall and cause injuries, etc.



Do not store the equipment in extremely humid, dusty or hot areas.

Don t

May cause fire, burns, or electric shocks, etc. For waterproofness/dustproofness, refer to the following:

▶P.22 "Precautions for Waterproofness/Dustproofness"



Children using the equipment should be instructed in proper operation by an adult. Make sure they use the product correctly.

May cause injuries.



Store the equipment out of reach of small children. May be accidentally swallowed, or cause injuries, electric shocks, etc.



Exercise caution that the temperature of the product rises when the equipment is continuously being used for prolonged periods and while it is charging. In addition, be careful to not unintentionally come into contact with the equipment if you fall asleep, etc.

If you use apps, make calls, perform data communications, watch TV or videos, etc. while charging the battery for a long time, the temperatures of the product and the specified charging equipment (sold separately) may rise. Directly touching a hot part for a long time, you may have redness, itching or rash on your skin, or it may result in low-temperature burns etc. depending on your constitution and/or health condition.

# **⚠** Danger

Be sure to read the following hazards before use.



Do not put the battery in a fire or attempt to heat it. The battery may ignite, explode, generate heat, or leak and may result in fire, burns or injury.



Do not puncture with a nail (sharp object), strike with a hammer (hard object), stomp on, or apply excessive force on the battery.

The battery may ignite, explode, generate heat, or leak and may result in fire, burns or injury.



Keep the screen at least 20 cm away from your face during using iris recognition.

<sup>n't</sup> May cause diminished eyesight, etc.



Do not use iris recognition with infants. Doing so may damage their eyesight.



If the substance inside the internal battery gets into your eyes, rinse with clean water and receive medical care from a doctor immediately. Do not rub your eyes.

The substance inside the internal battery may cause loss of sight or poor health.



If the substance inside the display gets into your eyes or mouth, rinse with clean water and receive medical care from a doctor immediately. Do not rub your eyes.

The substance inside the display may cause loss of sight or poor health.



Anyone who has had dizziness, seizures, loss of awareness, blackouts, or other symptoms linked to an epileptic condition, or a family history of such symptoms or conditions, should see a doctor before using the iris recognition.

# ⚠ Warning

Be sure to read the following warnings before use.



Do not lighten the light near eyes. Especially, when you capture babies or infants, keep the product enough distance away from babies and infants. Such as vision disability may result. Accident may result from being dazzled or shocked.



Do not turn on the light and face the product to drivers. May disturb driving and cause accident.



Do not look at a flashing screen for a prolonged period. May cause seizure or loss of consciousness.



Do not put foreign objects such as liquid like drinking water, sweat, seawater or urine of the pet into au IC card/microSD memory card slot. Please do not mistake the insertion location and direction of the au IC card or microSD memory card.

May cause fire, burns, injuries or electric shocks, etc.



Do not expose the camera lens to direct sunlight for a prolonged period.

The light-gathering capabilities of the lens may cause fire, burns, injury, etc.



# When boarding an airplane, turn this product OFF or turn airplane mode on.

As there are usage restrictions in an airplane, follow the instructions from the airline.

Failure to do so may cause airplane electronic equipment to fail or malfunction. If you commit any prohibited acts, such as using the phone in an airplane, you will be punished in accordance with the law.



#### When using the product in a medical facility, follow the instructions of the facility.

Turn the product OFF in areas where use is prohibited. Failure to do so may cause electronic equipment or electronic medical equipment to fail or malfunction.



When you talk by setting handsfree, ringtone is sounding or during standby, keep the product away from your ear.

And, when connecting the earphone/microphone, etc. to the product and play a game, video or music, etc. adjust the volume moderately.

Using continuously for a long time with too loud volume may cause a hearing loss, etc.

And, if you cannot hear the sound around you clearly, it may cause an accident.



If you have weak heart, be careful when setting the vibrate ringtone (vibration) or ringtone volume setting.

May cause harmful effect on heart.



When you use electronic medical equipment, check with the equipment manufacturer to determine how the equipment is affected by radio waves before using. May cause harmful effect on electronic medical equipment etc.



When the display or camera lens is accidentally broken, be careful of broken glass or exposed internal parts of the product.

Touching broken or exposed part may cause burns, injury, electric shock, etc.



Should the internal battery leak or emit a strange odor, immediately discontinue use and move it away from fire.

The leaked fluid may catch fire and may cause ignition or explosion.



Take measures to prevent pets from biting on the product.

The internal battery may ignite, explode, generate heat or leak and may result in fire, burns, injury, etc.



Be sure to read the following cautions before use.



If the display part is accidentally broken and such as internal substance leaks out, do not make the substance contact with your skin of face or hands, clothes, etc.

May cause loss of sight or skin problems.

If the substance gets into your eyes or mouth or comes into contact with your skin or clothes, rinse with clean water immediately.

And if it gets into your eyes or mouth, rinse with clean water and seek medical care immediately.



#### Do not dispose with regular trash.

May ignite causing fire, burns, injury, etc. Environmental damage may also be caused. If the product becomes no longer needed, bring it to an outlet such as the au Shop or follow the instructions given by the collecting municipalities.



Should the substance inside the internal battery leak, avoid it from coming in contact with your face. hand or clothes.

May cause loss of sight or skin problems. If the substance gets into your eves or mouth or comes into contact with your skin or clothes, rinse with clean water immediately.

And if it gets into your eyes or mouth, rinse with clean water and seek medical care immediately.



To use the product in car, check with automobile manufacturer or dealer to determine how the device is affected by radio waves before using.

In rare cases, using the phone in some vehicle models can cause the vehicle's electronic equipment to malfunction. In that case, stop using the product immediately.



If you develop skin problems, stop using the phone immediately, and see a doctor. Mobile phones can give some users skin problems such as itching. allergic reactions or rashes.

For parts materials ▶P.15 "Material list"



Be sure to check that there are no metal fragments (such as cutter blades or staples) adhered to the magnetic parts used in the speaker and ear piece of this product.

Adhesion of such fragments may cause injury.



When watching the display, take a certain distance from the display in a fully bright place.

Watching the display in the dark or watching too close may cause reduced visual acuity, etc.

#### Charging equipment



Be sure to read the following warnings before use.



Do not use the specified charging equipment (sold separately) cable if it gets damaged.

May cause fire, burns or electric shocks, etc.



Do not use the specified charging equipment (sold separately) in a bathroom or other highly humid area.

May cause fire, burns or electric shocks, etc.



Always use the Common DC Adapter 03 (sold separately) with a negative-ground vehicle. Do not plug it into a positive-ground vehicle.

May cause fire, burns or electric shocks, etc.



If you hear thunder, do not touch the specified charging equipment (sold separately).

May cause electric shock, etc.



Do not short the charging jack while it is connected to the outlet or cigarette lighter socket. Do not touch the charging jack with a part of your body such as your hand or finger.

May cause fire, burns or electric shocks, etc.



Do not pull or place a heavy object on the power cord of the specified charging equipment (sold separately).

May cause fire, burns or electric shocks, etc.



When you insert and remove the specified charging equipment (sold separately) from power outlet, do not contact a metal strap or other metal objects with the jack.

May cause fire, burns or electric shocks, etc.



Do not connect the voltage converter for overseas travel (travel converter) to the specified charging equipment (sold separately).

May cause ignite, heat or electric shock, etc.



Do not apply excessive force to the product connected to the specified charging equipment (sold separately).

May cause fire, burns or electric shocks, etc.



Do not charge any parts wet with liquid such as drinking water, sweat, seawater or urine of the pet with the wireless charger (sold separately).

May cause fire, burns, injuries or electric shock.



Do not touch the code of the specified charging equipment (sold separately), USB cable, charging product or power plug with wet hands.

May cause fire, burns or electric shocks, etc.



Only use with the specified power source and voltage.

Do

When charging the product overseas, use the specified charging equipment (sold separately) for global use.

If incorrect power source and voltage is used, this may cause fire, burns or electric shocks, etc.

AC adapter: AC100V (Connect to the AC outlet for internal household use)

AC adapter for global use: Between 100V AC and 240V AC (Connect to an AC outlet for internal household use)

DC adapter: DC12V, 24V (specific for negative ground vehicle)



If the fuse of Common DC Adapter 03 (sold separately) changes, replace it only with the specified fuse.

If fuses other than those specified are used, this may result in fires, burns, or electric shocks, etc. Confirm specified fuses via individual user's manuals.



Wipe off any dust that accumulates on the power plug.

If the product is used with dust adhering to it, this may result in fires, burns, or electric shocks, etc.



When you connect the specified charging equipment (sold separately) to the outlet or cigarette lighter socket, do not fail to properly connect to the outlet. If not firmly inserted, this may result in fires, burns, or electric shocks, etc.



When you disconnect the power plug from the outlet or cigarette lighter socket, do not put excessive force such as pulling the cord of the adapter with excessive force. Instead, hold the specified charging equipment (sold separately) to disconnect.

If the specified charging equipment (sold separately) cord is pulled on, this may result in scratches, fires, burns, or electric shocks, etc.



If you have electronic medical equipment such as an implanted cardiac pacemaker or an implanted cardioverter-defibrillator equipped, consult a doctor about the use of the wireless charger (sold separately).

The product's signals may affect the performance of electronic medical equipment.



When unplugging and plugging in the specified charging equipment (sold separately) from and into the product, do not forcibly pull on the cord, etc., and straightly unplug and plug in the specified charging equipment (sold separately) from and into the connecting terminals.

If not properly unplugged or plugged in, this may cause fire, burns, injuries, electric shocks, etc.



Immediately discontinue use if the connection jack is bent or deformed. Do not try to straighten and reuse a deformed connection jack.

It may short circuit the battery and may result in fire, burns, injury, electric shock, etc.



Always remove the power plug from the outlet or cigarette lighter socket when not using the specified charging equipment (sold separately). If the power plug is left plugged in, this may cause fire, burns, injuries, electric shocks, etc.



Immediately remove the power plug from the outlet or cigarette lighter socket if water or other liquids (drinking water, sweat, sea water, urine of pet animals, etc.) get into the specified charging equipment.

May cause fire, burns or electric shocks, etc.



Always remove the power plug from the outlet or cigarette lighter socket when cleaning the equipment.

Cleaning the equipment with connecting to the outlet or cigarette lighter socket may cause fire, burns or electric shocks, etc.



Be sure to read the following cautions before use.



Do not touch a specified charging equipment (sold separately) for a long time that has been connected to a power outlet or cigarette lighter socket.

May cause burns etc.

#### au IC card

Be sure to read the following cautions before use.

0

Be careful of the cut surface when handling au IC card.

May cause injuries.

■ Use of this product near medical equipment and inside a medical facility

⚠ Warning

Be sure to read the following warnings before use.



Wearers of the electronic medical equipment such as implanted pacemakers or defibrillators must carry and use the product at least 15 cm away from the implanted device.

The product's signals may affect the operation of the electronic medical equipment.



When electronic medical equipment other than implanted pacemakers or defibrillators are in use outside of medical facilities (such as in home care settings), check with the device manufacturer to determine how the device is affected by electrical signals.

The product's signals may affect the operation of the electronic medical equipment.



When you are in a crowd etc. and you have difficulties to keep a distance of 15 cm or more from others, turn the airplane mode on or power off the product not to transmit signals.

There may be wearers of medical equipment such as implanted pacemakers or defibrillators around you. The product's signals may affect the performance of electronic medical equipment.



When using the product in a medical facility, be sure to observe the regulations of the facility.

The product's signals may affect the operation of the electronic medical equipment.

#### SC TV Antenna Cable 04

⚠ Danger

Be sure to read the following hazards before use.



Keep conductive materials (metal pieces, pencil lead, etc.) from coming in contact with the headset connection terminal, and keep those materials from getting inside of them.

Doing so may cause a fire, fault, or burns from overheating.

# ♠ Warning

Be sure to read the following warnings before use.



Do not use in places subject to direct splashing with water, pet urine or other liquids.

Doing so might result in faults resulting from overheating, fire, electric shock, injury or shortcircuiting of electronic circuits.

# 

Be sure to read the following cautions before use.



If you feel any abnormality with your skin. immediately consult a dermatologist.

Itching, rashes, eczema, etc. sometimes occurs depending on your physical constitution and condition

For parts materials ▶P.15 "Material list"

■ AKG Tuning High-quality Earphone with Microphone (sample)

♠ Warning

Be sure to read the following warnings before use.



Do not use the product for playing game or music while driving a car or motorbike, riding a bicycle or walking.

Doing so may compromise traffic safety and cause an accident



Be sure to read the following cautions before use.



When playing game or music, adjust the volume to the proper level.

Setting too loud volume or using the earphone continuously may be harmful to your ears. Even if the proper volume is applied, using for a long time may cause hearing loss.

Also, raising the volume too high might prevent you from hearing sounds around you, which might in turn lead to a traffic accident at a railroad crossing or pedestrian crossing.



When adjusting the volume, raise the volume a little at a time.

If you raise the volume too much from the outset, sudden loud noise from the earphone, etc. might adversely affect your ears.



If you feel any abnormality with your skin, immediately consult a dermatologist.

Itching, rashes, eczema, etc. sometimes occurs depending on your physical constitution and condition.

For parts materials ▶P.15 "Material list"

#### ■ SIM card removal tool (sample)

⚠ Warning

Be sure to read the following warnings before use.



Be sure to read the following warnings before use. The end of the SIM card removal tool (sample) is sharp. Do not use pointed at yourself or other people.

Doing so might hit yourself or other people resulting in injury or loss of sight.

# 

Be sure to read the following cautions before use.



If you feel any abnormality with your skin, immediately consult a dermatologist.

Itching, rashes, eczema, etc. sometimes occurs depending on your physical constitution and condition.

For parts materials ▶P.15 "Material list"



Store the SIM card removal tool (sample) in a place where infants cannot reach.

If it is accidentally swallowed, it might result in suffocation or injury.

#### Material list

#### ■ Main unit

Part	Material	Surface treatment
Display (Touch panel)	Glass	AF coating
Exterior case (front)	Aluminum	Anodic oxidation treatment
Exterior case (side)	Aluminum	Anodic oxidation treatment
au IC card/microSD memory card tray	PC	Laser printing
au IC card/microSD memory card tray (side)	Aluminum	Anodic oxidation treatment
Rear panel	Glass	AS coating
Power key/Screen lock key, Volume key/ Shutter key, Bixby key	Aluminum	Anodic oxidation treatment
Receiver	Aluminum	Anodic oxidation treatment
Fingerprint recognition sensor (surrounding area)	Aluminum	Anodic oxidation treatment
Fingerprint recognition sensor (center area)	Epoxy resin	UV Curing resin
Rear camera surrounding area	Aluminum	Anodic oxidation treatment
Rear camera lens panel	Glass	AF coating
Flash/Light, Cardiac rate sensor panel	Glass	AS coating
USB Type-C connection terminal	Corson Alloy and STS630	Nickel plating and Gold plating

Part	Material	Surface treatment
USB Type-C connection terminal (surrounding area), Headset connection terminal (surrounding area)	PBT-GF45% (MA- 5450/K24615)	-
Headset connection terminal	Copper + Titanium	Gold plating

#### SC TV Antenna Cable 04

Part	Material	Surface treatment
Headset connection terminal (metal part)	Brass	Nickel plating and Gold plating
Headset connection terminal (exterior), Plug (exterior)	LDPE, TPE	-
Cable	TPE material + TPE	_
Plug (metal part)	Brass	Nickel plating and Gold plating
Plug (resin)	LDPE, TPE	_

# ■ AKG Tuning High-quality Earphone with Microphone (sample)

Part	Material	Surface treatment
Plug (metal part)	Copper, Nickel	Nickel plating
Plug (outer covering)	TPE	Corrosion treatment
Cable (string)	Polyester	Water repellent coating
Cable junction	TPE	Corrosion treatment
Cable control ring	TPE	Corrosion treatment
Cable	TPE	_
Switch	PC	UV coating, transparent primer treatment
Earphone speaker part	TPU	Discharge corrosion treatment
Earphone outer covering	PC	UV coating, transparent primer treatment
Earphone (AKG area)	Aluminum (AL 5052)	Sanding, diacut, anodizing
Earphone (cable border side of the speaker)	TPE	Corrosion treatment
Earpiece	Silicone	Corrosion treatment

### ■SIM card removal tool (sample)

Part	Material	Surface treatment
Unit	SUS304	Barrel polishing

## Handling precautions

These precautions are provided to prevent the product from getting a malfunction and to ensure that performance can be fully demonstrated. Thoroughly read these precautions to ensure correct use.

#### ■ Precautions common to the product, internal battery, charging equipment, au IC card, peripheral devices

- Do not apply excessive force to the product during use. Be sure not to put the product into a tightly packed bag or place a heavy object on the product in a bag. Sitting on the product in your pocket might damage the display or internal circuit board resulting in a malfunction.
- And, keeping an external device connected to the external connection terminal or headset connection terminal might damage the connector resulting in a malfunction. Such damage and malfunction are not covered by the warranty, even if there is no external damage.
- To ensure waterproof property (equivalent to IPX5 and IPX8) of the product, make sure to attach the au IC card/microSD memory card tray securely when using the product. au does not guarantee actual operations under all states. Do not allow water to enter the product interior or splash water on the charger/accessories. Do not open or close the au IC card/microSD memory card tray in the rain or when it is wet. Water may enter the product interior and cause corrosion. Note that if a trouble is diagnosed as exposure to water or other liquid, repairs of the product may not be covered by the warranty.
- Do not use the product in extremely hot, cold or humid places. (Use within an ambient temperature range of 5 °C to 35 °C and humidity range of 35% to 85%.)
  - charging equipment
  - peripheral devices

- Do not use the product in extremely hot, cold or humid places. (Use within an ambient temperature range of 5  $^{\circ}$ C to 35  $^{\circ}$ C and humidity range of 35 $^{\circ}$ K to 85 $^{\circ}$ S. Store within an ambient temperature range of 0  $^{\circ}$ C to 45  $^{\circ}$ C.)
  - SC TV Antenna Cable 04
- Do not use the product in places that have extremely hot or low temperatures, or high humidity. (Use within an ambient temperature range of 5 °C to 35 °C and a humidity range of 35% to 85%. However it can be provisionally used if it is 36 °C to 40 °C and a humidity range of 86% to 90%. when storing the product, store it within the ambient temperature range of 0 °C to 45 °C.)
  - Galaxy S8 main unit
  - au IC Card (when attached to the Galaxy S8 main unit)
- Do not use in places subject to lots of dust or vibration. Doing so may cause a fault.
- Clean the connection terminals with dry cotton swabs, etc. every now and then. Soiled terminals might cause poor connection. Do not exert a strong force to clean the connection terminals to prevent deformation.
- Clean the product with a soft dry cloth (such as the type used for eyeglasses). Forceful rubbing with a dry cloth may scratch the display. The display may be stained if splash or smear is left attached to the surface. Wiping the product using alcohol, thinner, benzine, detergent, glass cleaner, etc. might erase the printing on the outer casing or cause discoloration.
- Use as far away as possible from land-line phones, TVs, radios, etc. Use nearby might affect them.
- The product may become warm while charging etc., depending on the situations, but this is not abnormal.
- Do not place near corrosive chemicals or in places where corrosive gas is generated. Doing so may cause a fault.
- Do not use outside when you can hear thunder. Doing so might risk lightning strikes and electric shock.
- Be sure to use only the specified peripheral devices. Use of other peripheral devices might cause fault.

- Do not put the product in a cooking apparatus such as microwave oven or a pressure vessel. Doing so might cause fault.
- The customer is not allowed to disassemble, modify or repair the product. Doing so might cause a fault. Modification of cell phones is in violation of the Radio Law and the Telecommunications Business Act.
- Do not short-circuit the external connection terminal or headset connection terminal. Do not allow conductive foreign objects (metal fragments, pencil leads, etc.) to come into contact with or get inside the connection terminals. Doing so might cause fault.
- If the product gets wet during charging, immediately disconnect the power plug of the specified charger (sold separately).
- Do not use a cell phone while walking or driving a car or riding a motorbike or bicycle. Use of a cell phone while driving a car or motorbike is prohibited by law. Use of a cell phone while riding a bicycle may be punishable by some regulations.
- Do not cover or wrap the product with bedding, etc. while using or charging the product.
- When using a charging equipment or external device, insert/ remove the connector straight to/from the product. Make sure the orientation of the connector is correct. Unless it is correct, it may cause fault.
- Do not expose the camera lens to direct sunlight for an extended period. Doing so might cause fault.
- Do not use, store or leave the product in places subject to direct sunlight (e.g. in automobiles), places that get hot, places that get extremely cold, and in humid or dusty places. Doing so might fault.
- Do not leave on unstable places such as rocky stands or tilting surfaces especially while charging the product or the vibration mode set. Dropping the product may cause fault.
- Do not use power outlets or wiring apparatus beyond its rating when charging the product, for example, by connecting multiple devices to a single power strip.

#### ■ Main unit

- The battery for this product is built-in and cannot be replaced by the customer. Contact an au shop or a Customer Service Center to replace the battery.
- Do not forcefully press, tap or intentionally subject the display to strong impact. Doing so might cause scratching or damage.
- Do not forcefully press your fingernails, sharp objects or hard objects against buttons or display surface. Doing so might cause scratching or damage.
- The touch panel is designed to be lightly touched by fingers.
   Do not apply strong pressure with your fingers or sharp-pointed objects (such as fingernails, ballpoint pens and pins) on the touch panel.

In the following cases, the product may not respond to touching the touch panel, or errors in operation may occur.

- Operation with gloved hands
- Operation with fingernails
- Operation with a foreign object placed on the touch panel
- Operation with a protective sheet or sticker on the touch panel
- Operation with water drops or dew condensation attached on the display
- Operation with wet or sweaty fingers
- Operation underwater
- Never use modified product. Use of a modified device violates
  the Radio Law and the Telecommunications Business Act.
  This product is compliant with rules on the technical standard
  conformance of specified wireless equipment based on the
  Radio Law and rules on the technology regulatory compliance
  of terminal device based on the Telecommunications Business
  Act. As proof of this, the "Technical Conformity Mark @" is
  indicated in this product.

How to confirm: On the home screen, [基本フォルダ (Basic folder)]

→ [Settings] → [About phone] → [Regulatory information].

If the screws on the product are removed and the modifications are made to the internal components, the certification of conformity with technical regulations will become invalid. Never use the product without the valid certification. Doing so violates the Radio Law and the Telecommunications Business Act.

- Take care not to place magnetized items such as magnetic cards, speakers and TV sets near the product, as it might cause malfunction. Putting a strong magnetism close to the product might cause false operation.
- Do not bring the product close to magnetized objects such as cash cards, credit cards, and prepaid cards. Doing so might result in loss of recorded information.
- When you put the product in your pocket or bag, take care so that the display does not come in contact with metal objects or other hard objects, as it might cause scratching or damage.
- When suddenly brought into a warm place from a cold place, or when in a humid location, or when used where temperature suddenly changes (e.g. near the air discharge port of an air conditioner), water droplets (i.e. condensation) sometimes are formed inside the product. Note that when used under conditions such as this, the humidity might cause corrosion or a fault.
- Do not exert excessive force when attaching/removing a microSD memory card. Doing so might injure your hands or fingers.
- While writing/reading data to/from a microSD memory card, do not subject the product to vibration or impact, or turn off the power. Doing so might cause loss of data or a fault.
- Do not cover the proximity/light sensor with your finger or put a sticker on it. Doing so may hinder it from detecting the ambient brightness and functioning correctly.
- Do not put a sticker, etc., on the proximity/light sensor. Doing so may cause the sensor to malfunction and make the display always turned off while receiving a call or during a call.
- Normally, keep the au IC card/microSD memory card tray closed when using the product. Otherwise, dust or water may enter the product interior and may cause malfunctions.

- Do not put liquids, metals, or other foreign objects into au IC card/microSD memory card slot of the product. Doing so may result in a malfunction.
- Do not subject to strong impact, such as dropping, stomping and throwing. Doing so might cause fault.
- Do not put the product directly on sand at a beach, etc. Sand or other small particles might get inside the receiver, the mouthpiece, the speaker, causing the volume to drop. If sand gets inside this product's main unit, it might cause fault.

#### ■ Touch Panel

- Do not put stickers or sheets (e.g. commercially available protective films, peep prevention sheets) on the display. Doing so might hinder correct operation of the touch panel.
- When carrying the product in your pocket or bag, take care not to put the touch panel close to metals or other conductive materials, as it might cause false operation of the touch panel.

#### ■ Organic EL (OLED) display

- Although lightning intensity of OLED can be decreased partly when the same image has been displayed for a long time, extreme continuous use is performed with "Brightness" setting of "Display and wallpaper" set to be always bright, it is not abnormal because that is the characteristic of OLED.
- Although the organic EL (OLED) display used on the product is made using high-precision technology, some pixels (dots) might be lit or out at all times. Or color may be changed or unevenness of brightness may be shown if looked at from different angles. Note that that is because of the structure of OLED display, not a fault.
- Leaving the OLED exposed to the direct sunlight might cause a fault. Take care when you place the product by the window or outside.

#### Internal battery



#### (The internal battery of the product is a lithiumion battery.)

The internal battery is not fully charged at the time of purchase. Charge the battery before using the product.

- At extremely high or low temperatures, such as if you leave the product in a closed car during summer, the capacity of the internal battery decreases and so will the amount of time it can be used decreases. This also decreases the lifespan of the battery. Use the product at room temperature whenever possible.
- After charging the battery, it gradually discharges, even if you do not use this product. If you do not use this product for a long time, you should charge the battery as the internal battery may have discharged.
- The internal battery is a consumable item. If the performance of the internal battery does not recover (e.g. the usable time after each charge has become extremely short), stop using the battery as it is at the end of its service life. As the battery is built-in, you can have it replaced at an au shop for a fee. Note that you will not be able to use the product for a certain period of time. The battery lifespan varies depending on how the product is used.
- Depending on the use condition, the internal battery may be inflated as it comes close to the end of its service life. This is due to the properties of lithium-ion batteries and does not pose any safety risks.

#### Charging equipment

 Do not wrap the power cord of the specified charging equipment (sold separately) around the adapter. Also, do not forcibly bend the plug of the charging equipment (sold separately) or the connection between the connector and power cord. Do not pull or place a heavy object on the charging equipment (sold separately) code with unnecessary force.  When unplugging the power plug of the specified charging equipment (sold separately) from the power outlet or cigarette lighter socket, hold and pull the power plug. If you pull the cord, the cord might be damaged.

#### Wireless charging

- Do not stick metallic items (such as stickers that contain metal) on wireless charging equipment (sold separately) or the back of the product. Doing so may result in a malfunction.
- Although the information light on the wireless charger (sold separately) may remain on after the product has finished charging, this is not a fault.
- · Charging may stop just before the battery is fully recharged.
- If charging stops before the battery is fully recharged, charging may not begin immediately.
- Depending on the Qi specification-compatible product, charging may repeatedly start and stop. Charge this product with an au-approved product.
- If the temperature exceeds a certain level, charging may stop or take a long time, but this is not a fault. Please wait for the temperature to decrease.
- Place the wireless charger (sold separately) on a flat, stable surface and charge the product.
- Turn off the vibration function when charging wirelessly. If the product vibrates, it may not fully charge or fall off the wireless charger.
- Remove any cases, covers, plastic film, stickers, and so on attached to the product before charging.
- Check that the wireless charger and the product are not wet.
- Do not wirelessly charge the product while it is connected to the specified charging equipment (sold separately).
- Keep the product away from devices that support wireless charging. Otherwise, the au product you wish to charge may not be detected correctly and may not be charged.
- If the product receives interference from a radio or TV, use the product as far away from the radio or TV as possible.

- Depending on the Qi specification-compatible product, it may not receive calls while charging. Charge this product with an au-approved product.
- Depending on the Qi specification-compatible product, charging may not be able to start due to mutual interference with the Osaifu-Keitai<sup>®</sup> function. Charge this product with an au-approved product.
- If you run an application on the product while it is being charged wirelessly, it may not fully charge.
- Although the product may become warm while it is on the wireless charger (sold separately), this is not a fault.
- Reception quality may decrease while the product is charging on the wireless charger (sold separately).
- Do not move the wireless charger (sold separately) and the product while it is charging.
- After the product has finished charging, the remaining battery level may decrease, even if the product is left as is.

#### ■au IC card

- Do not forcibly remove or insert the au IC card. Be careful not to exert excessive force when inserting the card into your au cell phone.
- You are responsible for any damage caused by inserting your au IC card into some other IC card reader/writer, etc.
- · Do not put stickers, etc. on the au IC card.
- Do not insert an au IC card to which a conversion adapter is attached. Doing so may cause a fault.
- Do not performs actions that may damage the au IC card (e.g. using in high temperature areas, tossing into fire, allowing foreign matter to come into contact with metal part, subjecting to shock, bending, applying heavy load, getting wet, etc.). It may cause data loss or other malfunctions.

#### AKG Tuning High-quality Earphone with Microphone (sample)

- Do not wrap the cord around the product. It may lower its sensitivity and the sound may cut off or noise may be generated. Do not pull the code to unplug. Do not hang the phone with the code, either. It may damage the code, connector plug and the headset connection terminal of the product.
- Be aware not to gather dust on the connector terminal.
   Doing so may cause a fault.
- Attach or remove the connector horizontally to or from the headset connection terminal of the product.

#### SC TV Antenna Cable 04

 SC TV Antenna Cable 04 is not covered by the free-of-charge repairs warranty.

#### ■ SIM card removal tool (sample)

- Do not force the SIM card removal tool (sample).
   Doing so might cause it to break or damage.
- When disposing of it, follow the rules regarding disposal in your area.
- Do not use the SIM removal tool (sample) for any other purposes except for what is written in this manual, also do not use it on other mobile phones.
   Doing so might cause the mobile phone to break or damage it.

#### Camera

- When photographing important occasions, take a trial shot and check the shot image to make sure it is correctly shot.
- Do not use the camera in places where photographing is not allowed.

#### ■ Copyrights and rights of portrait

 You are not allowed to copy, distribute, publish, modify or edit the data you shot, recorded or downloaded using this product without the consent of the copyright holder, except for personal use, under the copyright law.

In addition, do not use or modify portraits or names of other individuals without their consent, as it might infringe on rights of portrait.

Note that shooting and recording may be restricted at some live performances, shows and exhibitions even for personal use.

• Be careful about the copyright and portrait right when posting images you shot, etc. on Internet homepages.

#### ■ Backup content on the product

 Please back up important content recorded or downloaded for the product to an outside source. Content recorded to memory on the product sometimes disappears or is altered by unexpected factors, such as static electricity or a fault, repair, mishandling, etc.

#### Precautions for Waterproofness/ Dustproofness

- This product is waterproof to IPX5 \*1 (Grade 5 ingress protection of JIS C 0920) and IPX8 \*2 standards, as well as dustproof equivalent to the IP6X \*3 standard (based on inhouse testing).
- Before using the product, thoroughly read the "Important items to remember before use" for proper use. Failure to observe the safety precautions may allow water, sand or other foreign objects to enter the product interior and cause overheating, ignition, electric shock, injury, malfunction, etc.
  - \*1 IPX5 equivalent means that a phone keeps functioning after applying a jet flow of 12.5 liters per minute from every direction from a distance of approximately 3 m for at least 3 minutes using water nozzle in 6.3 mm inner diameter.
  - \*2 IPX8 equivalent means that a phone keeps functioning after being slowly submerged to depth of 1.5 m in static tap water at room temperature, left there for 30 minutes and then taken out.
  - \*3 IPGX equivalent means that dust does not enter the interior of a phone after it is placed in a device containing dust with diameter of 75 μm or less for 8 hours, agitated and then taken out.
- au does not guarantee actual operations under all states.
   Malfunctions deemed to be caused by inappropriate operation by the customer are not covered by the warranty.

#### Important precautions

- To ensure waterproof property of the product, make sure that the au IC card /microSD memory card tray is securely attached.
- Never open or close the au IC card/microSD memory card tray when your hand and/or the product is wet.

#### How to attach the au IC card/microSD memory card tray

Insert the au IC card/microSD memory card tray in a straight line all the way into the au IC card/microSD memory card slot as shown in the diagram.

 If you turn the au IC card/microSD memory card tray upside down, the au IC card may be dislodged.



- Do not immerse the product in or splash the product with liquid other than tap water (seawater, pool, hot spring, soap water, detergent water, water with bath salts in it, alcohol, beverages, seasonings, etc.). Also, do not use the product in places subject to splashing with pet urine.
- In the event that the product is splashed with such liquids, rinse off immediately with tap water.
- Do not place the product directly on beach sand, etc. Sand or other small particles might get inside the receiver, the mouthpiece or the speaker, causing the volume to drop. If sand gets into the interior of the product, it might cause overheating or a fault.
- · Do not use the product underwater.
- Do not use or store the product in a bathroom, kitchen or other highly humid areas for a prolonged period.

- There may be some water remaining on the product even after draining it. The product can be used normally, but remember to keep it away from objects you do not wish to get wet. Also be careful as your clothes, bag, etc. may get wet from the water remaining on the product.
- You need to perform draining if water accumulates in the mouthpiece or receiver temporarily making it harder to hear the sound.
- The product is not resistant to water pressure. Do not directly apply high water pressure to or immerse the product for a prolonged period.
- Do not wash the product using a washing machine or ultrasound cleaner.
- Do not immerse the product in a bathtub. The product is not heat resistant.
- Abrupt temperature changes may cause condensation to form and may result in malfunctions. Wait for the product to reach normal temperature when taking it into a warm bathroom, etc. from cold areas
- · This product does not float in water.

#### au IC card/microSD memory card tray

- Make sure to attach the au IC card/microSD memory card tray without any gaps. Even a fine debris (a piece of hair, etc.) between contact surfaces may allow water to enter the interior of the product.
- Do not wear gloves, etc. when you attach or remove the au IC card/microSD memory card tray. Even a fine debris (a piece of hair, etc.) between contact surfaces may allow water to enter the interior of the product. If there is any water droplets or debris on the tray, wipe them off completely with a dry clean cloth before attaching it.
- Deterioration or damage of the au IC card/microSD memory card tray will cause the waterproof performance to degrade.

#### • If any liquid other than water gets on the product

- In the event that the product comes into contact with liquid other than water (seawater, detergent water, alcohol, etc.), rinse it off immediately.
- You can wash the product under a mild flow (less than six liters per minute) of tap water at room temperature (5°C to 35°C) at a distance of about 10 cm from the faucet or shower head.
- If the product gets dirty, wash it with your hands holding the au IC card/microSD memory card tray so that it does not open. Do not use a brush or sponge.

#### • If the product gets wet

- After the product gets wet, drain water and wipe the product with a clean dry cloth.
- Water droplets adhered on the product may freeze in cold regions.
   Continued use of the product in such condition may cause malfunctions. Do not leave any water droplets on the product.

#### Rubber gaskets

- The rubber gaskets of the au IC card/microSD memory card tray play an important role for maintaining the waterproof performance. Do not damage or remove the rubber gaskets.
- When closing the au IC card/microSD memory card tray, take care not to get the rubber gaskets caught. Closing the tray forcibly may damage the rubber gaskets causing the waterproof performance to degrade. Even a fine debris (a piece of hair, etc.) between contact surfaces may allow water to enter the interior of the product.
- Liquid other than water (such as alcohol) adhered to the product may cause the durability performance to degrade.
- Do not insert a sharp object into the gap between the au IC card/microSD memory card tray. Doing so may damage/ deform the product or damage the rubber gaskets and may allow water to enter the interior of the product.
- To keep the product waterproof, replacement of parts is recommended every two years even if the product is functioning normally. Contact your nearest au shop for the replacement of parts.

#### Heat resistance property

 Do not put the product in hot water, use it in a sauna or apply hot airflow (from a hair dryer etc.) to it. This product is not heat resistant.

#### Impact tolerance

 This product is not impact-resistant. Do not drop or apply shock to the product. Do not poke the microphone, receiver, speaker, etc. with a sharp object. Doing so may damage/ deform the product and may allow water to enter the interior of the product.

#### Charging

Accessories and optional devices are not waterproof. Check the following before and after charging.

- Never try to charge the product when the product is wet.
   Doing so may cause fire, burns, injury, electric shocks, etc.
- Make sure that the product is not wet. To charge the product after it has been wet, drain the water thoroughly and wipe any remaining water using dry clean cloth.
- Do not touch the specified charging equipment (sold separately) with wet hands. Doing so may cause electric shock.
- Do not use the specified charging equipment (sold separately) in a bathroom, shower room, kitchen, lavatory or other highly humid area. Doing so may cause fire, burns, injury, electric shocks, malfunction, etc. Do not bring the product into a bathroom, etc. even when you are not charging it. Doing so may cause fire, burns, injury, electric shock, malfunction, etc.

#### Draining water when the product gets wet

- If the product gets wet, make sure to drain water from the tray eject hole, mouthpiece/microphone (upper/lower) holes, headset connection terminal, external connection terminal, and speaker.
- Continued use will present a risk of getting your clothes/bag wet or make it harder to hear the sound.
- · Follow the steps below to drain water.
  - ① Hold the product firmly and wipe off moisture on the product surface and back side with dry, clean cloth etc.



② Shake the product approximately 20 times, firmly holding it, until there is no more water splattering.



3 Swing the product about 10 times against a dry, clean cloth etc. to wipe off water remaining in the headset connection terminal, mouthpiece/microphone, receiver, speaker, key etc.



Wipe off water drained from the product with dry, clean cloth etc., and dry naturally.

Water, if any, remaining in the product may ooze up after wiping off.

Do not wipe off water remaining in gaps directly with a cotton swab etc.

# Notes on using Bluetooth®/wireless LAN (Wi-Fi®) functions

- The Bluetooth® function and wireless LAN (Wi-Fi®) function of this product conform to the domestic standards of Japan, FCC standards and EC Declaration, and have been certified.
- In some countries and regions, use of the Bluetooth® and wireless LAN (Wi-Fi®) functions may be restricted. Before you start using the product overseas, check the relevant laws and regulations of the country/region you visit.
- The 2.4 GHz band used by wireless LAN (Wi-Fi®) and Bluetooth® devices is shared by various other devices. For this reason, the communication speed and connectable range may be decreased, or disconnection may occur, due to interference from other devices.
- Do not use this product in places where electromagnetic waves are generated or near electric products, AV and OA equipment, or other magnetized devices.
- Subjecting this product to magnetic or electrical noise might increase noise and prevent it from performing communications. (This product is particularly susceptible to noise when it used near a microwave oven.)
- Using this product near a TV, radio or similar appliance might cause reception interference and disrupt TV images.
- The searching might not be successful if there are multiple wireless LAN (Wi-Fi<sup>®</sup>) access points near to the product or the same channel is being used.
- As there are usage restrictions in an airplane, follow the instructions from the airline.
- The communication speed and connectable range vary depending on the distance between communication devices and obstacles.

### 2.4 GHz frequency band precautions

The frequencies used by the Bluetooth® and/or wireless LAN (Wi-Fi®) function of this product are in the 2.4 GHz band. In this frequency band, other similar wireless stations, in-plant wireless stations for mobile unit identification that require a license to use, such as factory production lines, specific small power wireless stations that do not require licenses, amateur wireless stations (collectively called "other wireless stations" from here on) are operated in addition to home electrical appliances such as microwave ovens, devices for industrial, scientific and medical devices.

- Before using this product, make sure that "other wireless stations" are not in operation nearby.
- In the event that instances of radio wave interference have occurred between this product and "other wireless stations", immediately either relocate this product or stop operation of the device (stop the emission of radio waves).
- 3. If you are unclear on any points or are troubled by anything, contact an au shop or Customer Service Center.



- The connections between this product and all other Bluetooth<sup>®</sup> and wireless LAN (Wi-Fi<sup>®</sup>) devices have not been confirmed. Therefore, connections with all Bluetooth<sup>®</sup> and wireless LAN (Wi-Fi<sup>®</sup>) devices are not guaranteed.
- This product supports security features for wireless communications that are compliant with the Bluetooth® and wireless LAN (Wi-Fi®) standard specifications, but the security may not be sufficient depending on the usage environment and configuration. Be careful when making data communication using Bluetooth® or wireless LAN (Wi-Fi®) function.
- Wireless LAN (Wi-Fi<sup>®</sup>) has the advantage that it can be freely connected anywhere within the radio wave range, as it uses radio waves for exchanging information. At the same time, there is a risk that a malicious third party may obtain unauthorized access if security settings have not been configured. You are recommended to configure security settings before using wireless LAN (Wi-Fi<sup>®</sup>) at your decision and responsibility.
- The Company assumes no responsibility for leakage of data or information that may occur during Bluetooth<sup>®</sup>/wireless LAN (Wi-Fi<sup>®</sup>) communication.
- Since Bluetooth® and wireless LAN (Wi-Fi®) functions use the same frequency band, using the both functions at the same may cause radio wave interference resulting in decreased communication speed or disconnection from the network. If connection fails, stop using either of the Bluetooth® and wireless LAN (Wi-Fi®) functions.

Bluetooth® and wireless LAN (Wi-Fi®) functions of this product use frequencies in the 2.4 GHz band.

2.4 FH1 / DS4 / OF4 / XX8

Bluetooth® function: 2.4FH1/XX8

This product uses the 2.4 GHz band. For FH1, FH-SS is used as the modulation scheme. The interference distance is about 10 m or less. XX8 uses other schemes and interference distance is about 80 m or less.

Wireless LAN (Wi-Fi®) function: 2.4DS/OF4
 This product uses the 2.4 GHz band. DS-SS and OFDM are used as the modulation schemes. The interference distance is about 40 m or less.

 This means that all bandwidths can be used, and that bands of mobile unit identification devices cannot be avoided.

Available channels differ depending on the country. For use in an airplane, check with the airline company in advance.

#### 5 GHz frequency band precautions

Wireless LAN (Wi-Fi<sup>®</sup>) function of this product uses 5 GHz band. Using the 5.2 GHz band and 5.3 GHz band outdoors is prohibited by the Radio Law.

The channels used on the product are as follows. W52 (5.2 GHz band/36, 40, 44, 48 ch)

W53 (5.3 GHz band/52, 56, 60, 64 ch)

W56 (5.6 GHz band/100, 104, 108, 112, 116, 120, 124, 128, 132, 136, 140 ch)

IEEE802.11 b/g/n

IEEE802.11 a/n/ac

J52 W52 W53 W56

#### Available security codes/PIN code

#### Available security codes

The product has various security codes that you can use. The available security codes are as follows. Do not forget the various security codes that are set as they are necessary for various operations and contracts. Make sure to change the initial value to your own unique number.

#### ■ Security code

Example of usage	①To do remote operation of Voice mail and Call forwarding services from a land-line phone ②To use Customer Service Center and to do various inquiries, applications, and modifications on the au homepage
Initial value	A four-digit number chosen by the customer and noted on the application form

#### ■ Screen lock setting

Example of	To set and release the screen lock
usage	
Initial value	Swipe

#### ■ PIN for unlocking

Example of	To set and release the screen lock or the remote lock
usage	
Initial value	1234

Make sure to change the initial value to your own unique number

#### Password (Osaifu-Keitai lock setting)

Example of	To use the "Osaifu-Keitai lock setting"
usage	
Initial value	None

#### PIN code

#### PIN 1 code

To prevent unauthorized use of the au IC card by a third party, you can set the product to require PIN 1 code entry every time the power is turned on. You also need to enter PIN 1 code when setting whether the PIN 1 code entry is required. If the PIN code is incorrectly entered three times consecutively, the PIN code will be locked. Use the PUK code to unlock the PIN code.

 PIN 1 code is "1234" and PIN 1 code entry was set to not be required at the time of purchase. You can change PIN 1 code to any four- to eight-digit number, and set the PIN 1 code entry to be required as necessary.
 If you require a PIN 1 code to be entered, make sure to change the number to your own unique number.

#### PUK code

In case the PIN 1 code is locked, you can unlock it by entering the PUK code.

- PUK code is an eight-digit number given at the time of purchase, which is printed on the back side of the plastic card where your au IC card is attached.
- After entering the PUK code, you need to set a new PIN 1 code.
- If the PUK code is incorrectly entered ten times consecutively, contact an au shop, PiPit or the Customer Service Center.
- "PIN 1 code" is not reset by initializing the product.

#### Notes on data communication charge

- Since a constant Internet connection is possible with this
  product, data communication may be performed automatically
  by some applications, resulting in high data communication
  charges. Therefore, subscription to a data communication
  charge discount service or flat late plan is recommended.
- To browse homepages, download applications, communicate using applications, send/receive E-mails and configure various settings, connection to the Internet is required, to which data communication charge applies.
- \* Data communication charge does not apply to Wi-Fi® connection.

### Notes on applications

- Be sure to check the security of the application, then install it at your own risk. Some applications might cause virus infection, damage various data, and send out your location information, usage history or personal information stored in your cell phone via the Internet.
- The Company assumes no responsibility for any problems that might be caused by the applications you have installed. In such case, you may be charged a repair fee even during the warranty period.
- The Company assumes no responsibility for any disadvantage brought to you or any third party by applications you have installed.
- Insertion of a microSD memory card is necessary to use some applications.
- Some applications prohibit the product from entering sleep mode while they are active, or rapidly drain the battery while running in the background.
- Operational procedures and screen appearances of the applications preinstalled in this product and those installed by you are subject to change without notice as a result of version upgrade. In addition, operating procedures described in this manual may differ from the actual procedures.

#### Configuring the app's permissions

When you access a function or information on the product for the first time, a confirmation screen will appear requesting you to permit the access.

If a confirmation screen appears, read through the displayed information and tap either "DENY" or "ALLOW".

Example: When viewing the TV for the first time

On the home screen, [基本フォルダ (Basic folder)]→ [MobileTV]

The "Allow **MobileTV** to access photos, media, and files on you device?" window appears.

- 2 [ALLOW]
- 3 Follow the onscreen instructions

# **//**memo

- If you do not select "ALLOW", you may be unable to activate the app/function or the function may be restricted.
- ③ To change the permission setting: On the home screen, select  $[E \pm 7 J \mathcal{N} \mathcal{G}]$  (Basic folder)] → [Settings] → [Apps] → Tap the application whose permission setting you wish to change → [Permissions] → Operate / of the permission you wish to change.
- A screen explaining the permission may be displayed for some apps/functions. Or, a confirmation screen may appear multiple times and or be displayed differently. Check the displayed information carefully and follow the on-screen instructions.
- O Descriptions on the contents displayed on the confirmation screen(s) may have been omitted in this manual.

#### Take your manners with you as well

#### ■ Use of the product is not allowed in the following places!


- Do not use a cell phone while driving a car or riding a
  motorbike or bicycle. It may cause a traffic accident. Use of a
  cell phone while driving a car or motorbike is prohibited by law.
  (Use of a cell phone while riding a bicycle may be punishable
  by some regulations.) Traffic accidents may be caused due
  to ambient sounds being hard to hear, or due to you being
  distracted by the screen display. Especially, be careful at the
  railroad crossing, station platform, or pedestrian crossing.
- As there are usage restrictions in an airplane, follow the instructions from the airline.

#### ■ Consider people around you!

- To prevent ringtone from bothering other people, not only refrain from making a call but also power off or use Silent mode at a movie theater, theater, museum, library, etc.
- In a city area, use in a place where you do not bother people walking.
- It is extremely dangerous to walk while looking at the screen of the cell phone. Do not make calls or operate a cell phone while walking or by stopping suddenly.
- Move to a place where you do not disturb others while you are in shinkansen, a hotel lobby, etc.
- · Be careful not to be loud while talking.
- If you are in a place with people around you, such as a train, be aware of noise emanating from your headphones or earphones.
- · Ask permission if you take photos with your cell phone camera.
- Please keep general morals when using camera functions.
- There may be a person with a cardiac pacemaker nearby at a place filled with people such as in a crowded train. Set "Airplane mode" or turn off beforehand.
- When a medical institution has laid down designated areas where use of the product is prohibited or is not allowed to be brought in, abide by the instructions of that medical institution.

# **Getting ready**

# Names of parts and their functions



#### Notification LED

Notify missed calls, indicate charging status, etc. only while the display backlight is turned off.

- 2 Iris recognition LED \*1
- 3 Proximity/Light sensor \*1

Turn off display and adjust the display brightness when proximity of face is detected or according to the ambient brightness. Also, operate this product by detecting motion of hand (gesture).

- (4) Edge screen
- 5 Display (Touch panel)

The screen is curved on the both sides. Colors may look different depending on what angle you are looking at the curved screen.

The display is covered with a protective film. To use a commercially-available protective film, remove the protective film on the display first.

- 6 Receiver
- (7) Front camera
- 8 Iris recognition camera \*1
- 9 GPS antenna part \*2
- (10) Flash/Light
- (1) Cardiac rate sensor

Measure cardiac rate by activating the "S Health" application and holding up your finger.

- 12 2 mark
- (13) **Q** mark

When doing wireless charging, this is the place which is aligned with the "Qi" symbol on the Wireless Charging Pad (sold separately).

- (14) Wi-Fi®/Bluetooth® antenna part \*2
- 15 Rear camera
- 16 Fingerprint recognition sensor
- 17 LTE Built-in antenna part \*2
- (8) au IC card/microSD memory card slot

#### ① Tray eject hole

The hole for inserting the SIM card removal tool (sample) to retrieve the au IC card/microSD memory card tray.

20 Mouthpiece/Microphone (upper) \*3

Mouthpiece/Microphone (upper) operates for calling, handsfree calling or recording by voice recorder, etc.

② Volume key/Shutter key

Adjust ringtone volume and media sound volume.

Release the shutter while shooting a still picture and video.

② Bixby key

Start the "Bixby".

② | Power key/Screen lock key

Press and hold for over one second to turn the power on/off. Press when the power is on to set screen lock.

- 24 Headset connection terminal
- USB Type-C connection terminal
- Mouthpiece/Microphone (lower) \*3 Mouthpiece/Microphone (lower) operates for speech recognition such as calling or recording, etc.
- ② Speaker hole



You can charge the product without a cable by just placing it on an au-approved wireless charger (sold separately) that has the symbol on the left. Refer to the compatible device's User Manual as well. Products with this symbol conform to the wireless charging standard by the Wireless Power Consortium (WPC).



This product is compatible with "Okudake-Juden" Wireless recharging.


- "おくだけ充電 (Okudake-Juden)" and the "おくだけ充電 (Okudake-Juden)" logo are registered trademarks of NTT Docomo.
- \*1 Do not cover with a protective sheet, etc. Functions may not work correctly.
- \*2 The antenna is built into the phone. Covering around the antenna by hand may affect quality.
- \*3 Be careful to not cover over the mouthpiece/microphones (top and bottom, 2 areas) with your fingers, etc., while relevant functions are being used. In addition, do not insert the SIM removal tool (sample) into the product since this might cause damage.

# //memo

- The rear cover of this product cannot be removed. Forcibly attempting to remove the rear cover may cause damage or a fault
- The battery is built-in to the product and you cannot remove it.
- To forcibly restart the product, refer to "Turning the power on/off" (PP.41).

#### au IC card

Your phone number etc. is recorded on the au IC card. This product is compliant with au Nano IC Card 04 only. Power off the product before attaching/removing the au IC card.





- © Since the au IC card might become faulty or get damaged when it is handled, be aware of the following.
  - · Do not touch the IC (metallic) part of the au IC card.
  - · Check that the card is inserted in the correct direction.
  - · Do not use force to attach or remove.
- An error message will be displayed when the au IC card is not properly inserted, or if something is wrong with the au IC card.
- O Do not lose the au IC card after it has been removed.
- © Do not insert the au IC card to which a conversion adapter is attached. Doing so may cause a fault.
- © The bundled SIM card removal tool (sample) is necessary to insert/eiect the au IC card.
- © Do not insert the bundled SIM card removal tool (sample) into any hole other than the tray eject hole. In addition, do not use it for any other purposes except for what is written in this manual.

#### ■ When au IC card is not inserted

When the au IC card is not inserted, the following operations are not available. Also, the will be displayed.

- Making a call\*1/receiving a call
- · Receiving/sending SMS
- Receiving/sending and initial settings of e-mail (@ezweb.ne.jp)
- · Setting up PIN code
- Checking the phone number and mail address of this product Besides the above, some functions requiring your phone number might not be available.
  - \*1 Emergency calls to 110 (Police). 119 (Fire department or ambulance service). 118 (Japan Coast Guard), are also not available. However, when the signal strength is other than "out of service area" during GSM/UMTS/LTE roaming, calling is available (The calls may not be connected since emergency call numbers differ depending on countries).

# Attaching/removing an au IC Card

### Attaching the au IC Card

Insert the tip of the SIM card removal tool (sample) into the au IC card/microSD memory card tray eject hole in a straight line

The au IC card/microSD memory card tray will slightly eject.


 Not inserting the tool in a straight line might result in damage or a fault.



Pull out the au IC card/microSD memory card tray in a straight line



- 3 Place the IC (metallic) part of the au IC card face down on the au IC card/microSD memory card tray
  - · Take care to note the direction of the notch.
  - Fit the au IC card securely into the tray or it may come off when you try to insert it into the slot.



- Insert the au IC card/microSD memory card tray in a straight line all the way into the au IC card/microSD memory card slot as shown in the diagram
  - If you turn the au IC card/microSD memory card tray upside down, the au IC card may be dislodged.



## Removing the au IC card

Insert the tip of the SIM card removal tool (sample) into the au IC card/microSD memory card tray eject hole in a straight line

The au IC card/microSD memory card tray will slightly eject.

- Not inserting the tool in a straight line might result in damage or a fault.
- Pull out the au IC card/microSD memory card tray in a straight line
  - If you turn the au IC card/microSD memory card tray upside down, the au IC card may be dislodged.



Remove the au IC card from the au IC card/ microSD memory card tray



Insert the au IC card/microSD memory card tray in a straight line all the way into the au IC card/microSD memory card slot as shown in the diagram



# Attaching/removing a microSD memory card

Power off the product before attaching/removing a microSD memory card.

- Do not apply excess force when inserting/removing a microSD memory card.
- Attaching a microSD memory card
- Insert the tip of the SIM card removal tool (sample) into the au IC card/microSD memory card tray eject hole in a straight line

The au IC card/microSD memory card tray will slightly eject.

• Not inserting the tool in a straight line might result in damage or a fault.



- Pull out the au IC card/microSD memory card tray in a straight line
  - If you turn the au IC card/microSD memory card tray upside down, the au IC card may be dislodged.



- 3 Place the IC (metallic) part of the microSD memory card face down on the au IC card/ microSD memory card tray
  - Make sure that the microSD memory card is fitted correctly in the au IC card/microSD memory card tray. If the microSD memory card is not fitted correctly, the card may get jammed in the product when you insert the tray.



- Insert the microSD memory card tray in a straight line all the way into the au IC card/ microSD memory card slot as shown in the diagram
  - If you turn the au IC card/microSD memory card tray upside down, the microSD memory card may be dislodged.





The microSD memory cards have distinguishable front and back/forward and backward orientations. If they are forcibly put in and can no longer be able to be removed, this might cause damage.

#### Removing a microSD memory card

Insert the tip of the SIM card removal tool (sample) into the au IC card/microSD memory card tray eject hole in a straight line The au IC card/microSD memory card tray will slightly eject

The au IC card/microSD memory card tray will slightly eject.

- Not inserting the tool in a straight line might result in damage or a fault.
- 2 Pull out the au IC card/microSD memory card tray in a straight line
  - If you turn the au IC card/microSD memory card tray upside down, the microSD memory card may be dislodged.



Remove the microSD memory card from the au IC card/microSD memory card tray



4 Insert the au IC card/microSD memory card tray in a straight line all the way into the au IC card/microSD memory card slot as shown in the diagram





After using this product for a long time, the removed microSD memory card may be warm; this is normal.


## Charging

When you purchase your product, the internal battery is not fully charged. Be sure to charge the internal battery before use

#### ■ Plugging USB Type-C plug

When charging with TypeC Common AC Adapter 01 (sold separately)

Please insert straight in the external connection terminal of the product as shown in the figure below.



Failure to do so may cause significant damage to the product. Damage from incorrect connection is out of compensation.




- Olf charging with a PC or using the camera function or other functions, charging time may increase.
- The product is compatible with quick charging when a TypeC Common AC Adapter 01 (sold separately) or Common AC Adapter 05 (sold separately) is used. Quick charging is possible when the power is off or the screen backlight is off. However, quick charging is not possible during a call even if the screen is off.
- When battery level is 50% or more, charging speed by quick charging may be slow.
- If the LED indicator continues to blink red even after it has been charging for some time, check that the cable is connected correctly. If the LED indicator then continues to blink, stop charging the product and contact an au shop or the Repair and Delivery Service Center.

# Charging with the AC adapter

The following describes how to charge the internal battery using the TypeC common AC Adapter O1 (sold separately).

- Insert the power plug of the TypeC common AC Adapter 01 (sold separately) into the AC 100 V outlet
- With the engraved side up, insert the USB
  Type-C plug of the TypeC common AC Adapter
  01 (sold separately) straight into the external
  connection terminal of the product
  - appears on the status bar.
  - When charging is finished, 100% appears on the status bar.
  - When you start charging powered off, animation is displayed to show the status of charging in a certain period of time. It will be displayed after finished, if you press (Power key).



When the charging is finished, pull the USB Type-C plug of the TypeC common AC Adapter O1 (sold separately) straight out from the product and the power plug out from the outlet

# Turning the power on/off

# Turning the power on

- Press and hold (Power key) over one second.

  The lock screen is displayed.
- Swipe the screen up, down, left or right to unlock the screen



- \* When Safe mode starts, "Safe mode" appears on the lower left corner of the screen.
- \* To terminate Safe mode, restart the product.
- \* Back up any data as necessary before using Safe mode.
- \* Any widgets that you create yourself may not work correctly.

# Initial settings and switching to English mode

The first time the product turns on, the initial setting screen appears automatically. Follow the onscreen instructions to switch to English mode. For details, refer to the supplied "Setting Guide".

・To change language to use, on the home screen, [基本フォルダ(Basic folder)] → [設定 (Settings)] → [一般管理 (General management)] → [言語とキーボード (Language and input)] → [言語を追加 (Add language)] → Select language you want to use→ [標準に設定 (SET AS DEFAULT)].

## Turning the power off

- 1 Press and hold (Power key) over one second
- [Power off] → [Power off]

# Force restarting

Press and hold (Power key) and lower side of volume key simultaneously for over seven seconds



O Note that as this is a force restart, some data or settings may be lost.

# Setting the screen lock

If the screen lock is set, the screen backlight turns off to prevent the keys or touch panel from erroneous operation. If no operation is made during certain period of time, the screen of the product automatically turns off and is locked in approximately five seconds.

- When you carry in your bag to put this product, prevent erroneous, please set the screen lock always. Also, please do not press (Power key) of this product in such a bag.
- While the screen is displayed, (Power key)
  Backlight turns off and screen lock activates.

# Canceling the screen lock

- 1 While the screen is displayed, 

  (Power key)
  The lock screen is displayed.
- Plick (swipe) the screen up/down/left/right

# Using the SC TV Antenna Cable 04

To watch mobile TV on the product, use the SC TV Antenna Cable 04.

To output the mobile TV audio to the speaker, only connect the SC TV Antenna Cable 04 to the product. To output the mobile TV audio to the earphone, connect the earphone to the SC TV Antenna Cable 04 and then connect it to the product.


- Connect the earphone connection plug to the headset connection terminal of the SC TV Antenna Cable 04
- 2 Connect the connection plug of the SC TV Antenna Cable 04 to the headset connection terminal of the terminal



# Using AKG Tuning High-quality Earphone with Microphone (sample)

Connect and use the AKG Tuning High-quality Earphone with Microphone (sample).

1 Connect the connection plug of the AKG Tuning High-quality Earphone with Microphone (sample) to the headset connection terminal of the product





- You can perform the following operations using the AKG Tuning High-quality Earphone with Microphone (sample).
  - Press the switch: Play/Pause the music in the "Play Music" application. You also can answer/end an incoming call.
  - Hold the switch for more than one second: Start the "Google" application.
  - To output the audio of the mobile TV to the AKG Tuning High-quality Earphone with Microphone (sample), connect the included SC TV Antenna Cable 04 with the AKG Tuning Highquality Earphone with Microphone (sample) first. If audio is not output from the earphones, press the switch on the AKG Tuning High-quality Earphone with Microphone (sample).

# **Basic operation**

# Using the home screen

The home screen consists of multiple screens that can be switched by flicking left or right.

You can return to the home screen at any time by tapping  $\hfill \Box$  .



- ① Quick search box

  Tap to display the searching screen.
- ② Widgets Tap to activate or operate.
- 3 Home screen guide Indicates which screen you are in.

Dial icon

Tap to active the dial.

- ⑤ Navigation bar
  - ≓ History button

Display the recently-used applications.

☐ Home button

Return to the home screen. Touch and hold to start the "Google" application.

← Back button

Return to the previous screen.

6 Edge screen

You can register and quickly access your favorite apps, shortcuts and important contacts.

# Starting an application

- 1 On the home screen, flick up or flick down Applications screen appears.
  - Flicking from side to side toggles applications screen.
- Tap an icon of the application to be used

# Monitoring the product's status

An icon indicating the product status is displayed on the status bar at the top of the screen. At the left of the status bar, notification icons indicating missed calls, new mail, running actions, etc. are appeared. At the right of the status bar, status icons indicating the status of the product are appeared.



#### Icon view

Main notification icons		
<b>X</b>	Missed call	
	New PC-mail message	
<u> </u>	New E-mail (@ezweb.ne.jp) message	
	New SMS/Message	

Main status icons		
.d / ⊘	Signal strength/Out of service area	
4G / 4G	4G (LTE/WiMAX 2+) data communication status*  4G (LTE/WiMAX 2+) communication available/ 4G (LTE/WiMAX 2+) communication in process	
ক / ক	Wireless LAN (Wi-Fi <sup>®</sup> ) communication status  Wireless LAN (Wi-Fi <sup>®</sup> ) available/ Wireless LAN (Wi-Fi <sup>®</sup> ) communication in process	
	Battery level/Charging/Charging completed	
NI.	Silent mode (Vibrate) set	
×	Silent mode (Mute) set	
<b></b>	Airplane mode activated	
N	Reader/Writer, P2P functions of NFC activated	

<sup>\*</sup> Both the 'LTE' and 'WiMAX 2±' networks can be used. Even if only one can be used, '4G' will be displayed. Depending on network traffic, au may determine that one network has less traffic than the other and connect this product to that network.

# Notification panel

When a notification icon appears on the status bar, you can check overview of the notification by slide down the status bar and open the notification panel. Tap icon on the Notification panel to set functions or check the information notified. Drag " – "(③) down to show all Quick Settings Button.



- 1) Show date and time.
- (3) Switch on/off of each function (Quick Settings Button). Drag " "((3)) down to show hidden icons.
- 3 Drag down to show all Quick Settings Button.
- (4) Displays information and notifications.
- (5) Select apps for which you want to block notifications.
- 6 Settings menu screen appears.
- ⑦ Clear notification information.
  - You may not be able to clear certain types of notification information.

- ® Network operator currently connected is shown.
  - · Slide up to close the Notification panel.
- 9 Set display brightness.

#### Notification LED

When the screen turns off, by the lighting/flashing notification LED, you can promote the charge, or to inform the state of charge of the charging, and receive mail and missed calls.

Operations	Description
Lights red	Charging battery
Lights green	Charging completed
Blinks red	Battery level is low
Blinks green (Approx. 5 sec. interval)	Notifications such as missed calls exist
Blinks blue (Approx. 5 sec. interval)	Notifications such as new message, new mails, etc. exist
Blinks blue (Approx. 0.5 sec. interval)	Recording with voice recorder
Lights alternately in light blue and blue	Turning on to activate/turning off to shut down

<sup>\*</sup> If a notification exists while charging, operation for a notification is given priority.

# Checking your phone number

1 On the home screen, [基本フォルダ (Basic folder)]
→ [Settings] → [About phone]

Your phone number is shown in the "My phone number" field.

# Setting the Silent mode

In the terminal, sounds (shutter sound, video sound, music sound, etc.) are not muted even when silent mode (Mute, Vibrate) is set.

- Open notification panel
- 2 Tap [ ◁ ) ] and set [ ☒ ] or [ ☒ ]

# Setting the Airplane mode

If you enable "Airplane mode", wireless functions (call, data communication, wireless LAN(Wi-Fi®), Bluetooth®) turn off.

- Open notification panel
- 2 [ 🚣 ]

# **Emergency call location notification**

If you make an emergency call to the police, fire station or Regional Coast Guard Headquarters, your current location (GPS information) will be transmitted to the agency receiving the emergency call.

- Use au's VoLTE (LTE network) to connect to Japanese emergency services. You cannot use 3G (call switching network) to connect to emergency services.
- In this section, the police (110), fire station (119) and Regional Coast Guard Headquarters (118) are collectively referred to as the emergency call receiving agency.
- This feature may not yet be available at some emergency call receiving agencies.
- If you add "184" before the emergency call number 110/119/118, the emergency call receiving agency will not be notified of your location and phone number.
- In places where signal reception from GPS satellites or a base station is relatively poor, such as in an underground mall, inside a building or behind a tall building, the emergency call receiving agency may be notified of some other place different from your actual location.
- When GPS cannot be used to notify of your location, base station signal is used instead.
- When making an emergency call to the police, fire station or Regional Coast Guard Headquarters, always confirm where you are, and tell them your exact location on the phone. Note that depending on the area where you are calling, your call may not be connected to the agency having jurisdiction over that area
- If the emergency call receiving agency determines that human lives and health are in danger, they will be able to acquire the caller's location information during the call or within a certain period of time after the call.

- If you make an emergency call with call reject set, the call reject setting is automatically turned off so that the emergency services can contact you.
- If you insert a SIM card other than the au IC card, you may not be able to make an emergency call to 110 (police), 119 (fire and ambulance), and 118 (coast guard).
- You may not be able to make an emergency call on some networks.

# **Appendix**

# **Updating Software**

Updating to the latest software delivers the best performance and availables the latest enhanced functions.

- You are charged for data communication when connecting to the Internet from the product by using data communication.
   OS updates will especially use a large amount of data. au recommends that you update software using a Wi-Fi® connection.
- When a software update is necessary, you will be informed on the au homepage, etc. For details, contact the au shop or Customer Service Center (157/Toll-free). Customers using a Galaxy S8 requiring a software update may be sent a notification from au so that the terminal can be used in optimum condition.
- You are recommended to back up your data before updating software.
- Be sure to fully charge the internal battery before use.
   Updating software may fail if the battery level is low or becomes low while updating.
- Check the radio wave condition. Updating software may fail in poor reception areas.
- If software update has failed or stopped, update the software again.
- If you fail to update software, it may become impossible to operate the product. If this happens, bring it to an au shop or PiPit (not accepted by some shops).
- · The software update function may not be available overseas.
- Operations are not available during software update. Calls to 110 (Police), 119 (Fire department or ambulance service), 118 (Japan Coast Guard) and 157 (Customer Service Center) are also not available. Also, alarm, etc. cannot be used.

# Downloading and updating software

Update files can be downloaded from the Internet web site via wireless communication into the product directly.

- 1 On the home screen, [基本フォルダ (Basic folder)]→ [Settings]
- 2 [Software update] → [Download updates manually]
- 3 [INSTALL NOW]

  From here on follow the onscreen instructions

Japanese only)

# Connecting to a PC for updating software

You can update software via a PC using "Smart Switch". You can download "Smart Switch" from Smart Switch homepage. For details of downloading and the way to use, refer to Smart Switch homepage.

<PC> http://www.samsung.com/smartswitch/ (in

# Troubleshooting

Before you assume that the product is malfunctioning, check the following items and perform "Troubleshooting diagnosis" in the "Malfunction reception" app. In the Applications screen, [auツール/サポート(au tool/support)]  $\rightarrow$  [故障受付 (Malfunction reception)]  $\rightarrow$  [トラブル診断(Troubleshooting diagnosis)] (in Japanese only)

If the problem does not improve even if you check the above items, check for possible remedies in "トラブル診断 (Troubleshooting diagnosis)" on the au website. https://www.au.com/trouble-check/ (in Japanese only)

## After-sales service

#### ■ When asking for repair

For repair, contact Repair and Delivery Service Center.

During the
warranty period
Outside the
warranty period

Repairs will be done based on the terms of services of the free-of charge repair warranty described.

We shall repair the product for a charge as requested by the customer if repair renders it usable.

- \* The warranty is valid for one year from the day that you first buy the product.
- Before handing in the product for repair, make a backup of the contents of memory since they may disappear during repair.
   Note that the Company shall not be liable for any damages and loss of income should the contents of memory be altered or lost.
- Recycled parts that meet the Company's quality standards are sometimes used for repair.
- Collected au cell phones by Replacement mobile phone delivery service which you used before are recycled to cell phones for replacement after repairs. Also replaced parts by au after-sales service are collected and recycled by KDDI. They are not returned to customers.

- The product which is processed, remodeled, analyzed (including by modifying or analyzing the software (including by rooting etc.), reverse engineering, decompiling), or repaired by an unauthorized repair office is not covered by the warranty and repair may be refused.
- The battery in this product is not covered by the free-ofcharge repairs warranty except in the case of a fault caused by a defect in the battery's materials or manufacture.

#### ■ Performance parts for repair

The Company retains performance parts for repair of the Galaxy S8 main unit and its peripherals for four years after discontinuation of production. "Performance parts for repair" refers to parts required for maintaining the functions of the product.

#### Free-of-charge repair warranty

- 1. When you contact the repairs help desk, have the serial number (IMEI number) ready. You can find the serial number (IMEI number) on this product or on a sticker attached the box this product is sold in.
- 2.If this device malfunctions during the warranty period and during normal use that follows the precautions listed in the instruction manual, au will repair the device for free.
- 3. Repairs will not be free of charge in the following cases, even during the warranty period. (Or repair may not be possible.)
  - ① If you did not follow the instruction manual and use the device correctly.
  - ② If the device broke or was damaged by unauthorized repairs or modifications.
- (3) If you had the device repaired at a facility that is not an authorized repair facility as designated by au.
- (4) If the device breaks or is damaged due to an accident or your own negligence when you are using or handing the device. Alternatively, there are indications that the device was dropped, got wet, damp, or the like.
- (§) If the device breaks or is damaged due to natural disasters, such as earthquakes, wind and flood damage, fire, damage from salt, or abnormal voltage.

- 4.Depending on how damaged the device is, repair may not be possible.
- 5.The Company assumes no responsibility for any damages or losses due to faults with the device.
- 6.The Company assumes no responsibility if an accident occurs in the event that you connect a device that is not designed to be used with this device.
- 7. The company does not offer on-site repairs.
- 8. This warranty is valid only in Japan.
- This warranty guarantees free repair based on the period and conditions listed above. Therefore, customers' legal rights against the issuer of this warranty and other business are not restricted by this warranty.

#### ■ Repair and Delivery Service

An after-sales service membership program on a monthly basis called "Repair and Delivery Service" (monthly fee: 380 yen excluding tax) is available for using your au cell phone for a long time without worries. This service expands coverage for many troubles including malfunction, theft and loss. For details of this service, refer to au homepage or contact Repair and Delivery Service Center.

- You can apply for membership only at the time of purchasing your au cell phone.
- Once you cancel the membership, you cannot reapply for it until you purchase an au cell phone next time.
- Note that when changing the model or purchasing an extra cell phone, this service only covers the most recently purchased au cell phone.
- When an au cell phone is handed over to you or someone else, the "Repair and Delivery Service" membership is also handed over to the successor of the cell phone.
- When you get a new au cell phone by changing the model or purchasing an extra cell phone, the "Repair and Delivery Service Center" membership for the old au cell phone is automatically canceled.
- · Service contents are subject to change without notice.

#### au IC Card

The au IC card is lent to you by au. In case of loss or damage, the card will be replaced at your expense. When malfunction is suspected, or in case of theft or loss, contact an au shop or PiPit.

#### ■ au after-sales service information

Services	Repair and Delivery Service		
Services	Members	Others	
Replacement mobile phone delivery service			
Spontaneous failure (1st year)	Free of charge	No recompense	
Spontaneous failure (2nd year or later)	See the "Replacement mobile phone delivery		
Partially damage, water soak, irreparable damage, theft or loss	service" (membership) fee table below.		
Holding over and repai	r		
Spontaneous failure (1st year)	Free of charge	Free of charge	
Spontaneous failure (2nd year or later)	Free of charge (for 3 years)	Actual cost	
Partially damage	Customer charge Upper limit: 5,000 yen		
Water soak, irreparable	Customer charge 10,000 yen		
Loss, theft	No recompense	No recompense (model change)	

<sup>\*</sup> Charge amounts are all tax excluded.

#### ■ "Replacement mobile phone delivery service" (membership) fee

Applicable conditions	First use	Second use
Normal	5,000 yen/ 3,000 yen (Longtime au users discount*1)	8,000 yen/ 6,000 yen (Longtime au users discount <sup>*1</sup> )
Both "WEB discount"*2 / "No replacement discount"*3 are applied	4,000 yen/ 2,000 yen (Longtime au users discount*1)	7,000 yen/ 5,000 yen (Longtime au users discount*1)
Only "No substitute discount" is applied	4,500 yen/ 2,500 yen (Longtime au users discount*1)	7,500 yen/ 5,500 yen (Longtime au users discount*1)

- \* Charge amounts are all tax excluded.
- \*1 This covers customers who are in the third year (25 months) or more of usage, or all of the lines in the family discount which the customer belong to. This covers customers who are using data communications terminals and tablets, who are enrolled in set discounts (WIN single set discounts, or smartphone set discounts), if the line contracts which cover the set discounts are for the third year or longer.
- \*2 WEB discount: If you subscribe the "Replacement mobile phone delivery service" from the au homepage, 500 yen will be discounted from your service fee. Since no substitute mobile phone is provided in "WEB discount", the "No substitute discount" will also be applied automatically.
- \*3 No substitute discount: If you do not request a substitute mobile phone when using the 'Replacement mobile phone delivery service', 500 yen will be discounted from the service fee. Check the au Web site for details.

#### Online Replacement Desk (24 hours a day over the Internet)

 Can be accepted only from a personal computer or smartphone https://www.au.com/support/service/mobile/trouble/repair/application/ (in Japanese only)



#### Replacement mobile phone delivery service

- When you have trouble with your au cell phone, replacement cell phone (same model, same color\*) is delivered to the specified place by calling to. Return your damaged cell phone within 14 days after the replacement cell phone is delivered.
  - \* In the event that it is difficult for au to provide the same model and color, we will provide you with another replacement mobile phone and color which is to be specified by us.
- Available up to twice in a year from the day you use this service as a start day. If you do not use this service in the past year at the subscription to this service, it will be 1st and if you use, it will be the 2nd.
  - \* For details, refer to au homepage.
- If you wish to request a re-issue of the au IC card along with the use of this service due to theft or loss, the au IC card re-issue fee of 1900 yen will be payable in addition to the service fee.

#### Holding over and repair

- © Damages and malfunctions intentionally caused by the customer as well as those due to modification (e.g. disassembly, change of parts, painting, etc.) by the customer are not covered by this service.
- You cannot receive a refund for replacement of the outer casing due to stains, scratches, paint removal, etc. on the outer casing.

# Unlocking the SIM lock

You can unlock the SIM lock for this product. If you unlock the SIM lock, you can use other carrier's SIM cards.

- The au homepage and au shops are accepting requests to unlock the SIM lock.
- If you use another carrier's SIM card, some services and functions may be restricted. Note that au does not guarantee any operations.
- To unlock the SIM lock, on the home screen, [基本フォルダ (Basic folder)] → [Settings] → [About phone] → [Status] → [SIM card status] → [SIM lock status].
- For more details, refer to the au homepage. https://www.au.com/support/service/mobile/procedure/ simcard/ (in Japanese only)

#### Related accessories

- SC TV Antenna Cable 04 (04SCHSA)
- TypeC Common AC Adapter 01 (0601PQA)\*1
- Common AC Adapter 05 (0501PWA)\*1\*2
   Common AC Adapter 03 (0301PQA)\*1\*2
   Common AC Adapter 03 Navy (0301PBA)\*1\*2
   Common AC Adapter 03 Green (0301PGA)\*1\*2
   Common AC Adapter 03 Pink (0301PPA)\*1\*2
   Common AC Adapter 03 Blue (0301PLA)\*1\*2
   AC Adapter JUPITRIS (White) (L02P001W)\*1\*2
   AC Adapter JUPITRIS (Red) (L02P001B)\*1\*2
   AC Adapter JUPITRIS (Blue) (L02P001L)\*1\*2
   AC Adapter JUPITRIS (Pink) (L02P001P)\*1\*2
   AC Adapter JUPITRIS (Champagne) (L02P001N)\*1\*2
   MICTOLOGIA (L02P001R)\*1\*2
   MICTOLOGIA (L02P001R)\*1\*2
   MICTOLOGIA (L02P001R)\*1\*2
   MICTOLOGIA (L02P001R)\*1\*2

microUSB cable 01 Navv (0301HBA)\*1\*2

- microUSB cable 01 Green (0301HGA)\*1\*2 microUSB cable 01 Pink (0301HPA)\*1\*2 microUSB cable 01 Blue (0301HLA)\*1\*2 Common DC Adapter 03 (0301PEA)\*1\*2
- Wireless Charging Pad 01 (0101PUA)\*1
   Wireless Charging Pad 02 (0102PUA)\*1
- Portable Charger 02 (0301PFA)\*1\*2
- · Micro-B Type-C Adapter (0601PHA)\*1
- au Carrying Case G Black (0106FCA)\*1
- \*1 Sold separately.
- \*2 To use this accessory, a Micro-B Type-C Adapter (sold separately) is required.



You can purchase accessories from au online shop. http://auonlineshop.kddi.com (in Japanese only)

# Appendix

# Main specifications

# ■ Galaxy S8

Display		Approx. 5.8 inches	
		Approx. 16,777,216 colors	
		(Organic EL (Super AMOLED))	
		QHD+ (2960×1440 dots)	
Weight		Approx. 150 g	
Dimension (\	$N \times H \times T$ )	Approx. 68 mm×149 mm×8 mm	
		(Thickest part: 8.2 mm)	
CPU		MSM8998	
Storage (RO	M/RAM)	ROM: 64 GB	
		RAM: 4 GB	
Continuous	In Japan	Approx. 370 hours	
stand-by	Overseas	Approx. 380 hours	
time*1	(GSM/UMTS)		
Continuous	In Japan	Approx. 1420 min.	
call time <sup>1</sup>	Overseas	Approx. 790 min.	
	(GSM/UMTS)		
Continuous t	tethering time	Approx. 790 min.	
Maximum nu	mber of	Up to 14 devices	
tethering co	nnection	<ul> <li>Wi-Fi® tethering 10 devices</li> </ul>	
devices		Bluetooth® tethering 3 devices	
		USB tethering 1 device	
Charging tim	ne	TypeC Common AC Adapter 01	
		(sold separately) Approx. 110 min.	
		Common DC Adapter 03 (sold	
		separately) *2 Approx. 410 min.	
		Wireless Charging Pad 02 (sold	
		separately) Approx. 200 min.	

Camera	Image pickup device	CMOS
	Effective pixels	Out-camera: Approx. 12,200,000 pixels In-camera: Approx. 8,000,000 pixels
Wireless LAI	V (Wi-Fi®)	IEEE802.11a/b/g/n/ac-compliant*3
Bluetooth®	Version	Bluetooth® standard Ver. 5.0
function	Output	Bluetooth® standard Power Class 1
	Communication distance*3	Within 10 m with no obstacles in the range
	Compatible profiles 4	GATT (Generic Attribute Profile) OPP (Object Push Profile) HSP (Headset Profile) HSP (Headset Profile) HFP (Hands-Free Profile) A2DP (Advanced Audio Distribution Profile) AVRCP (Audio/Video Remote Control Profile) SPP (Serial Port Profile) PBAP (Phone Book Access Profile) HID (Human Interface Device Profile) PAN (Personal Area Networking Profile) DUN (Dial-up Networking Profile) SAP (SIM Access Profile) DI (Device Identification Profile) HOGP (HID over GATT Profile) 2.4 GHz band
1000/	bands	(2.402 GHz to 2.480 GHz)
1Seg/ Full Seg continuous watching time	1Seg Full Seg	Approx. 750 min. Approx. 560 min.

- \*1 The continuous call time and continuous stand-by time may drop to less than half depending on the battery charging status, usage environment such as temperature, reception condition at the location where the product is used, and the function settings.
- \*2 To use this accessory, a Micro-B Type-C Adapter (sold separately) is required.
- \*3 2.4 GHz and 5 GHz are supported for IEEE 802.11n.
- \*4 Changes according to objects obstructing devices and signal reception.
- \*5 Specifications provided in Bluetooth® standards for making communication between Bluetooth®-compatible devices in accordance with their intended use.
- \*6 This application supports part of car navigations. For details ,refer to the au homepage.

#### SC TV Antenna Cable 04

Size	Length Approx. 130 ± 10 mm
Weight	Approx. 4.75 ± 5% g

 Please note that the specifications and exterior may change without prior notice for improvements.

# Specific Absorption Rate (SAR) of cell phones

This model Galaxy S8 mobile phone complies with Japanese technical regulations and international guidelines regarding exposure to radio waves.

This mobile phone has been designed in observance of the Japanese technical regulations regarding exposure to radio waves "1" and limits to exposure to radio waves recommended by equivalent international guidelines. These international guidelines were set out by the International Commission on Non-lonizing Radiation Protection (ICNIRP), which is in collaboration with the World Health Organization (WHO), and the permissible limits include a substantial safety margin designed to assure the safety of all persons, regardless of age and health condition.

The Japanese technical regulations and international guidelines define the limits using a unit of measurement known as the Specific Absorption Rate (SAR), which represents the average amount of radio frequency energy absorbed by the human head. The SAR limit for mobile phones is 2.0 W/kg. The highest SAR value for this model handset when tested for use at the ear is 0.672 W/kg<sup>(\*2)</sup> and when worn on the body is 0.852 W/kg<sup>(\*2)</sup>. There may be slight differences in SAR levels among individual products, but they all satisfy the limit.

The actual SAR of this mobile phone while talking on the phone can be well below that indicated above. This is due to automatic changes in the power level of the mobile phone to ensure it only outputs the minimum power required to communicate with a base station. Therefore in general, the closer you are to a base station, the lower the power output of the mobile phone.

This mobile phone can be used in positions other than against your ear. Use an accessory such as a carrying case, etc. so that you can hold the product at least 1.5 cm away from your body and also do not contain metal parts between the product and your body. By doing this, this mobile phone complies with Japanese technical regulations and international guidelines regarding exposure to radio waves.

The World Health Organization has stated that present scientific information does not indicate that use of mobile devices has any harmful effects on the human body. They recommend that if you are still worried about your exposure then you can limit your talk time or use a handsfree kit to keep the mobile phone away from your head and body. If you would like to know more detailed information, please refer to the WHO website.

http://www.who.int/docstore/peh-emf/publications/facts\_press/fact\_english.htm

- \*1 Technical regulations are defined by the Ministerial Ordinance Related to Radio Law (Article 14-2 of Radio Equipment Regulations).
- \*2 This includes other radio systems that can be used simultaneously.

Please refer to the websites listed below if you would like to know more detailed information regarding SAR.

- Ministry of Internal Affairs and Communications website: http://www.tele.soumu.go.jp/e/sys/ele/index.htm
- Association of Radio Industries and Businesses website: http://www.arib-emf.org/01denpa/denpa02-02.html (in Japanese only)
- O Galaxy homepage:

http://www.samsung.com/sar/sarMain.do

O au homepage:

https://www.au.com/english

# FCC RF exposure information

This product has been certified of Federal Communications Consortium (FCC).

FCC ID of this product is A3LSCV36.

In addition, you can also be found in the following way. How to confirm:

On the home screen, [基本フォルダ (Basic folder)] → [Settings] → [About phone] → [Battery information] → FCC certification

# **Export Administration Regulations**

This product and its accessories may be subject to the Japan Export Administration Regulations ("Foreign Exchange and Foreign Trade Law" and its related laws). In addition, U.S. Re-export Regulations (Export Administration Regulations) may apply to this product and its accessories. To export and re-export this product and its accessories, take the required measures on your responsibility and at your expenses. For details on the procedures, contact the Ministry of Economy, Trade and Industry or the U.S. Department of Commerce.

# Intellectual Property Rights

#### Trademarks

The company names and product names appearing in this manual are trademarks or registered trademarks of their respective holders.



 microSD logo, microSDHC logo, microSDXC logo are trademarks of SD-3C, LLC.

# Bluetooth<sup>®</sup>

- The Bluetooth<sup>®</sup> and logo are registered trademarks owned by the Bluetooth SIG, Inc., and Samsung Electronics Co., Ltd. is licensed to use these trademarks.
- Wi-Fi®, Wi-Fi Protected Setup™, Wi-Fi Direct™, Wi-Fi CERTIFIED™, and the Wi-Fi logo are registered trademarks of the Wi-Fi Alliance.
- Excel® and PowerPoint® are trademarks or registered trademarks of Microsoft Corporation in the U.S.A. and other countries.
- Microsoft® Word is a product name of Microsoft Corporation in the U.S.A.
- Qi (pronounced chee) is a registered trademark of the Wireless Power Consortium.
- FeliCa is a contactless IC card technology developed by Sony Corporation.

FeliCa is a registered trademark of Sony Corporation.

- 🔊 is a registered trademark of FeliCa Networks, Inc.
- Twitter and Twitter logo are trademarks or registered of Twitter. Inc.
- Facebook and Facebook logo are trademarks or registered of Facebook. Inc.
- "Google", "Google" logo, "Android", "Android" logo, "Google Play", "Google Play" logo, "Gmail", "Google Calendar", "Google Chrome", "Google Waps", "Google+", "Google Voice Search" and "YouTube" are trademarks or registered trademarks of Google Inc.
- iWnn of OMRON SOFTWARE Co., Ltd. is used for conversion methods. iWnn© OMRON SOFTWARE Co., Ltd. 2008-2017 All Rights Reserved.
- Microsoft®, Windows Media®, ActiveSync® are trademarks or registered trademarks of Microsoft Corporation in the U.S.A. and other countries.
- Oracle and Java are registered trademarks of Oracle Corporation and the subsidiaries and affiliate companies in the U.S. and other countries. Company and product names in this manual, etc., may be trademarks and registered trademarks of each company.

 All other company names and product names are trademarks or registered trademarks of respective companies referred to in this manual.

#### License

The software installed on this product or part of it may not be altered, translated/adapted, reverse-engineered, decompiled or reverse-assembled and any such actions are prohibited.

Under the MPEG-4 Visual Patent Portfolio License, customers have licensed permission for the following use of this product to engage in non-profit personal use. Other uses are not permitted.

- Recording MPEG-4 Visual standard video (henceforth referred to as MPEG-4 Video)
- Playing back MPEG-4 Video that a customer engaged in personal and non-profit activities has recorded
- Playing back MPEG-4 Video obtained from a provider licensed by MPEG-LA

When using for promotion, in-house use, profit use, and other intended uses, contact MPEG LA, LLC.

• This product is licensed under the AVC patent portfolio license for the personal and noncommercial use of a consumer to (i) encode video in compliance with the AVC standard (henceforth referred to as AVC video) and/or (ii) decode AVC video that was encoded by a consumer engaged in a personal and noncommercial activity and/or was obtained from a video provider licensed to provide AVC video. No license is granted or shall be implied for any other use. Additional information may be obtained from MPEG LA. LLC.

Visit http://www.mpegla.com

This product is licensed under the VC-1 Patent Portfolio License for the personal and noncommercial use of a consumer to (i) encode video in compliance with the VC-1 standard (henceforth referred to as VC-1 video) and/or (ii) decode VC-1 video that was encoded by a consumer engaged in a personal and noncommercial activity and/or was obtained from a video provider licensed to provide VC-1 video. No license is granted or shall be implied for any other use. Additional information may be obtained from MPEG LA, LLC. Visit http://www.mpegla.com

# For inquiries, call:

## Customer Service Center

For general information, charges and operation information (toll free)

Business hours 9:00 – 20:00 (7 days a week)

From fixed-line phones:

From au cell phones:

**E** 0077-7-111

PRESSING "ZERO" WILL CONNECT YOU TO AN OPERATOR AFTER CALLING 157 ON YOUR au CELL PHONE.

# For loss or theft (toll free)

Business hours 24 hours (7 days a week)

From fixed-line phones:

From au cell phones:

0077-7-113

In case above numbers are not available. call toll-free:

0120-977-033 (except Okinawa)

0120-977-699 (Okinawa)


# Repair and Delivery Service Center

For loss, theft, damage (toll free)

Business hours 9:00 - 20:00 (7 days a week)

From fixed-line phones/au cell phones.

0120-925-919







携帯電話・PHS のリサイクルにご協力

Cell phone and PHS operators collect and recycle unused telephones, batteries and battery chargers at stores bearing the (2) logo regardless of brand and manufacturer to protect the environment and reuse valuable resources.

April 2017, 1st Edition

Sold by: KDDI CORPORATION • OKINAWA CELLULAR TELEPHONE COMPANY

Imported by: SAMSUNG ELECTRONICS JAPAN Co., Ltd.

Manufactured by: Samsung Electronics Co., Ltd.