Be sure to read this manual before use


AQUOS sense8

SHG11

Quick Start Guide

- The company names and product names appearing in this manual are trademarks or registered trademarks of their respective holders.
- In this manual, the "AQUOS sense8 SHG11" is abbreviated as the "SHG11" or the "product".
- In this manual, "microSD™ memory card (commercially available)",
 "microSDHC™ memory card (commercially available)" and
 "microSDXC™ memory card (commercially available)" are abbreviated
 as "microSD memory card" or "microSD".
- For illustrations and descriptions in this manual, refer to "取扱説明書詳細版 (Full Instruction Manual)" (Japanese) available on the homepage of the network operator you contracted.

Names and Functions of Parts



- ① Display (Touch panel)
- 2 In camera lens
- 3 Earpiece (Receiver)*1
- 4 Proximity sensor/Light sensor

Proximity sensor prevents inadvertent operations of the touch panel during a call. Light sensor detects the ambient brightness and adjusts the brightness of display.

(5) [(+) Volume up key/[(-) Volume down key

Adjust the volume. Also, set/ disable manner mode.

⑥ ()(ර) Power key/Fingerprint sensor

Use to turn the power on/off and turn the screen on/off.

Press and hold this key to

- launch the set app.

 Keep touching this key with
- (+) at the same time displays a "Power menu" to allow you to operate the power off, etc.
- SIM card/microSD memory card tray
- 8 Sub microphone*1
- Mouthpiece (Microphone)*1
- 10 Earphone/Microphone jack

11) External connection jack

Use when connecting Quick Switch Adapter (sample), a specified AC adapter (supports USB Type-C™) (sold separately), USB Type-C cable (commercially available), etc. to the product.

® Speaker*1

Mobile light

The surrounding clearance gap serves as an air vent*1 to maintain product performance.

(i) Wide camera lens

Standard camera lens

- 16 5G/4G antennas*2
- 🗓 🔊 mark
- ® Wi-Fi®/Bluetooth® antenna*2
- ® 5G/4G/GPS antennas*2
- 20 5G/4G/UMTS antennas*2
- ② 5G/4G/UMTS/GSM antennas*2
- *1 Covering the sections with stickers, fingers, etc. may hinder product performance.
- *2 Antennas are built into the product.
 Do not cover with hand during
 calls or data communication.
 Doing so may affect call/
 communication quality.

The outer case (back) of the product cannot be removed. Removing it forcibly may cause damage or a fault.

 The battery is built into the product, and cannot be removed by the customer. To force the power off if the screen freezes etc., hold down (I(♠) and (I(♠) for at least 8 seconds.

Proximity sensor/Light sensor

- Placing stickers, etc. over the proximity sensor/light sensor may prevent the product from operating properly.
- O Do not stare into proximity sensor.

May temporarily affect eyesight, leading to accidents.


Earphone/Microphone jack

An earphone/microphone with the switch or depending on the type of the earphone/microphone, it may not be available with the product.

Attaching the SIM card

Before attaching the SIM card attach it with the display side turned up.

Pull out the SIM card/microSD memory card tray with your finger on the groove.




Fit the SIM card to the SIM card/microSD memory card tray with the IC (metal) side turned down while pressing the card against the projection of the tray

Check the direction of the SIM card and fit it securely.


Not to let the SIM card lift up from the card tray.

If the SIM card does not fit the card tray, may cause a fault.



Insert the SIM card/microSD memory card tray all the way to the product straight and horizontally.

Push the \bigcirc areas securely and make sure there is no space between the product and the card tray.



Attaching or removing the SIM card/microSD memory card tray

- When pulling out the card tray from the product, pull it slowly and horizontally with the display side turned up.
 - Pulling out the card tray forcefully or obliquely may cause damage.
- When attaching the card tray, insert it slowly with the display side turned up and make sure there is no space between the product and the card tray.
 - Insert the card tray with the mark of "画面側 (display side)" turned up.
 - Do not insert the card tray with the wrong side down. Failure to do so may cause damage it.
 - Inserting the card tray not deeply enough may cause impairment of the waterproof/dustproof property or prevent the product from functioning properly.

IMEI information (international mobile equipment identity number)


The IMEI information is marked on the SIM card/microSD memory card tray. You can check the IMEI information when requesting servicing or repairs.

Turning the Power On

- 『(ம) (hold down for at least 3 seconds) while the product is turned off.
 - When you turn the power on for the first time or perform factory reset after purchasing the product, the initial setting screen is displayed automatically. For details on the initial setting, refer to "取 扱說明書 詳細版 (Full Instruction Manual)" (Japanese).

Transferring data

If you connect an old smart phone and the product by connecting included the Quick Switch Adapter (sample) to the external connection jack of the product, you can easily transfer data.



- In "Copy apps & data" of the initial settings displayed when turning on the product for the first time or perform factory reset, follow the instructions on the screen, connect smart phones together, and transfer your data.
 - \cdot Connect to the wireless LAN (Wi-Fi®) or mobile network in advance.
 - For details on the data transfer by using Quick Switch Adapter (sample) such as a transfer after the initial settings is complete, connect to the SHARP website and refer to "データの引き継ぎについて (About data transfer)".

https://k-tai.sharp.co.jp/support/datacopy/pdf/easy_data_copy.pdf (Japanese)



- Do not use Quick Switch Adapter (sample) for intended uses other than transferring data (charging etc.).
- O Not all data can be transferred.

Using the Product

Before using the product, be sure to read the "Safety Precautions" for proper use.

lf you think the product may be malfunctioning, first check with the "かんたん診断 (Quick check)" under "使い方サポート (Usage support)" app (Japanese).

https://www.au.com/mobile/service/tsukaikata-support/usage/(Japanese)

Quick check

This service is provided in Japanese.

Operate on the home screen → "App list screen" → [au Service] → [使 い方サポート] (Usage support) → [診断] (Check)→ [かんたん診断] (Quick check).

* This is available to the customers who contract to au or UQ mobile.

Also refer to "故障とお考えになる前に (Troubleshooting)" in "取扱説明書詳細版 (Full Instruction Manual)" (Japanese).

https://www.au.com/online-manual/shg11/ (Japanese)

https://www.au.com/support/service/mobile/guide/manual/(Japanese)

- Communication is not possible even inside the service area in places where the signal does not reach (e.g. tunnels and basements). Also, communication may not be possible in poor reception areas.
 Communication may be interrupted if you move into a poor reception areas during communications.
- Since this product uses radio waves, the possibility of communication intercepts by third parties cannot be eliminated. (Though the 5G/LTE/ WiMAX 24/UMTS/GSM system has high security and confidential communication features.)
- Only VoLTE (LTE network) can be used when connecting with organizations that receive emergency call within Japan.
- The product is compatible with the international roaming service. Each network service in this manual varies depending on the area and service content.

- Since the product is a radio station under the Radio Law, you may be asked to temporarily submit the product for inspection in accordance with the Radio Law.
- The IMEI information of your cell phone is automatically sent to network operators for maintenance and monitoring operational status of your cell phone.
- of your cell phone.

 If you are using the product overseas, check the relevant laws and regulations of the country/region you visit in advance.
- The Company is not liable for any damages or lost profits arising from earthquakes, lightning, storms, floods or other natural disasters, as well as fires, actions by third parties, other accidents, intentional or mistaken operation by the customer, or use under other unusual conditions outside the responsibility of the Company.
- The Company is not liable for any incidental damages (change/ disappearance of saved content, loss of business income, disruption of business, etc.) arising from use of or inability to use the product.
- The Company is not liable for any damages or lost profits arising from failure to observe the described content of "取扱説明書 (Instruction Manual)".
- Information about positioning etc. obtained by the measuring sensor
 of the product or GPS is for reference only and cannot be used for the
 purpose requiring high reliability. Note that the Company assumes no
 responsibility for any damages or lost profits resulting from these
 measurement error.
- The Company is not liable for any damages or lost profits arising, for example, from malfunction caused by combination with connected devices or software not related to the Company.
- Captured image data or downloaded data may sometimes be altered or lost due to faults, repair or other handling of the product. The Company is not liable for any damage or lost profits resulting from recovery of these data.
- It is recommended you keep a copy of important data on your PC's hard disk, etc. Whatever the cause of the defect or malfunction may be, the Company assumes no responsibility for alteration or loss of saved data.
- Data saved in the product, such as contacts or images/videos might be altered or lost by an accident, fault, repair or mishandling. Be sure to keep a copy of important contents. Note that the Company assumes no responsibility for any damages or lost profits resulting from altered or lost contents.

- Note that content data (both charged or free content) saved on the product cannot be returned to the customer when the product is replaced for repair of a fault, for example.
- When displaying the same image on the screen for a long period of time, an afterimage may be left on the screen. This is not a malfunction. To prevent afterimages from appearing and saving power consumption, it is recommended that the light duration of the screen setting be set a short time.
- Although the display used on the product is made using highprecision technology, some pixels (dots) might be lit or out at all times.
 This is not a malfunction.
- You are recommended to store copies such as still pictures/videos and music saved on the product in your PC, cloud services, etc. Note, however, that you may not be able to make copies of some copyrighted data even by the above-mentioned means.
- Do not discard together with regular trash. Please cooperate in the collection of the product (including optional accessories) when it is no longer needed to protect the environment and effectively use resources.
 - * "The Company" as appears in this manual refers to the network operator you contracted and the manufacturer (Sharp Corporation).
 - Reproduction of the content of the instruction manual in part or in whole is prohibited.
 - The content of the instruction manual is subject to change without notice.
 - Part of functions cannot be used due to a specification change of the operating system or change/end of the service.
 - © Every effort has been made in the preparation of the instruction manual. Should you notice any unclear points, omissions, etc., feel free to contact us.

Safety Precautions (Observe Strictly)

- Before using the product, thoroughly read these safety precautions for proper use. After reading, store the precautions in a safe place.
- These precautions contain information intended to prevent injury to the user and to surrounding people, as well as damage to property, and must be observed at all times.
- The following symbols indicate the different degrees of injury or damage that may occur if information provided is not observed and the product is used improperly.

This symbol indicates that "death or serious injury" may directly and immediately result from improper use". This symbol indicates that "death or serious injury" may result from improper use". This symbol indicates that "death or serious injury" may result from improper use".

caution injury 2 and/or physical damage 3 may result from improper use. 1 Serious injury: This refers to loss of sight, injury, burns (high- and low-

This refers to loss of sight, injury, burns (high- and low-temperature), electric shock, broken bones, injuries with residual aftereffects from poisoning, etc., and injuries requiring hospital admission for treatment or long-term hospital

- attendance as an outpatient.

 *2 Minor injury:This refers to injuries, burns (high- and low-temperature), electric shock, etc. that do not require hospital admission for treatment or long-term hospital attendance as an outpatient.
- *3 Physical damage:This refers to extended damage to buildings, furniture, livestock, pets, etc.

Explanation of Prohibited or Enforcement Symbols



Indicates an action that is not allowed.



Indicates that handling with wet hands is not allowed.



Indicates that disassembly is not allowed.

Instruction

Indicates that instructions specified are compulsory (must

be followed).



Indicates that use in a place where the product is likely to get wet or allowing the product to get wet is not allowed.



Indicates that the power plug must be disconnected from the power outlet.

Precautions Common to the Main Unit, Internal Battery, Charger, SIM card, Peripheral Devices

! DANGER



Do not use, store or leave the equipment in locations subject to high temperatures or accumulation of heat (near a fire or heating unit, in a kotatsu or bedding, under direct sunlight, inside a vehicle on a hot day, etc.). May cause fires, burns, injury, electric shock, etc.



Do not place the equipment inside cooking appliances such as microwave ovens and induction cookers or high pressure vessels such as pressure cookers, or near them. May cause fires, burns, injury, electric shock, etc.



Do not sprinkle sand, soil or dirt on the equipment or put the equipment directly on it. Also, do not touch the equipment when sand etc. is adhering to your hand.

May cause fires, burns, injury, electric shock, etc. Refer to the following for details on waterproofness/ dustproofness.

▶P.34 "Notes on Waterproof, Dustproof and Shockresistant Properties"



Do not charge the equipment while it is wet with liquids such as water (drinking water, sweat, seawater, pet urine, etc.). Also, do not charge the equipment where water is regularly in use such as a bathroom or near a humidifier.

May cause fires, burns, injury, electric shock, etc. Refer to the following for details on waterproofness. ▶P.34 "Notes on Waterproof, Dustproof and Shockresistant Properties"



Do not press the equipment strongly or broken it. Especially when carrying the equipment in your pocket, do not allow it to be hit with or nipped in objects.

May cause fires, burns, injury, etc. because of damage of the internal battery.

*Take particular care with the followings

- Sitting or squatting down while putting the equipment in your pocket of trousers or skirt
- Allow the equipment to be nipped in the door or vehicular door while putting the equipment in your pocket of outerwear
- Stepping on the equipment while it is placed on a soft object such as the sofa or bedding, or floor
- Allow the equipment to enter between seats on a train, bus, etc.



Do not attempt to disassemble or modify the equipment. May cause fires, burns, injury, electric shock, etc.



Do not remove the internal battery of the product.

May cause fires, burns, injury, etc.



The outer case (back) of the product cannot be removed. Do not attempt it. Also, if the product becomes swollen due to issues such as internal battery swelling, do not try to open or forcefully push in the outer case (back). May cause fires, burns, injury, etc.



Do not get the equipment wet with liquids such as water (drinking water, sweat, seawater, pet urine, etc.).

May cause fires, burns, injury, electric shock, etc. Refer to the following for details on waterproofness.

▶P.34 "Notes on Waterproof, Dustproof and Shockresistant Properties"



Do not allow liquids such as water (drinking water, sweat, seawater, pet urine, etc.) to get inside the charging jack or external connection jack.

with water May cause fires, burns, injury, electric shock, etc. Refer to the following for details on waterproofness. ▶P.34 "Notes on Waterproof, Dustproof and Shock-resistant Properties"



Use only optional parts specified by the Company.

May cause fires, burns, injury, electric shock, etc. if you use $_{\eta}$ a device other than the specified one, or if the manufacturer, distributor or specification of the device is unclear.

⚠WARNING



Do not subject the equipment to strong force, impacts or vibration such as letting it fall, stepping on it or throwing it.

May cause fires, burns, injury, electric shock, etc.



Do not allow conductive materials (such as metal objects and pencil lead) to come into contact with the charging jack or external connection jack or dust to get inside it.

May cause fires, burns, injury, electric shock, etc.



Do not cover or wrap the equipment with bedding etc. when using or charging.

ohibited May cause fires, burns, etc.



If charging is not completed after the specified charging time, stop charging.

Instruction May cause fires, burns, injury, etc. because of overcharging.



Be sure to turn off the product and not to charge the battery in locations where flammable gas may be generated and where dust is generated.

May cause explosions, fires etc., because of igniting flammable gas etc.



When using at a gas station, or nearby follow the instructions of each facility.

Do not charge the equipment at the gas station or nearby. Also, pay attention to when using the product at a gas station, or nearby and do not using it while refueling. May cause explosions, fires etc., because of igniting flammable gas etc.



If any trouble such as an unusual odor, unusual noise, smoking, overheating, discoloration or deformation is found during use, charge or storage, pay attention to safety and follow the instructions below.

- Unplug the power plug of the specified charger (sold separately) from the outlet.
- · Turn off the product.

May cause fires, burns, injury, electric shock, etc. if you do not follow the instructions above.





Do not use a damaged equipment.

May cause fires, burns, injury, etc.



Do not leave the equipment on unstable surfaces, such as on a wobbly table or sloped surface. Be very careful $_{\rm j}$ while the vibrator is set.

May fall and cause injury etc.



Do not use or store the equipment in locations that are subject to humidity, dust or high temperatures.

May cause fires, burns, electric shock, etc.

Refer to the following for details on waterproofness/

dustproofness.
▶P.34 "Notes on Waterproof, Dustproof and Shock-

▶P.34 "Notes on Waterproof, Dustproof and Shock resistant Properties"



If being used by a child, have a guardian teach him/her the proper handling procedures and do not have him/her use it improperly.

A child may swallow the equipment, or suffer injury, electric shock, etc.



Do not place the equipment within reach of young children or where pets can access it.

Be careful about where to store of small parts such as

the SIM card/microSD memory card tray and Quick Switch Adapter (Sample) in particular. A young child may swallow the equipment, or suffer injury,

A young child may swallow the equipment, or suffer injury electric shock, etc.



Be careful when using the product continuously or charging because it may become warm. Also, be careful not to touch it unintentionally and continuously when you carry the equipment in your pocket, fall asleep, etc.

The product or specified charger (sold separately) may become warm when using an application, a call, data communication, watching video, etc. continuously or charging. Directly touching a warmed part continuously may cause redness, itching, rashes, low-temperature burns, etc. on your skin depending on your constitution or health condition.

! DANGER



Do not throw the product into a fire or heat it.

May cause fires, burns, injury, etc.



Do not apply excessive force on the product such as puncturing it with a sharp object (nail etc.), hitting it with a hard object (hammer etc.) or stepping on it.

May cause fires, burns, injury, etc.



If the substance inside the product comes into contact with your eyes, mouth, etc., immediately rinse the contacted area with clean water. Then seek prompt medical treatment

May result in loss of eyesight, sick, etc. because of the substance inside the product.

WARNING



Do not point the illuminated light directly at someone's eyes. Especially when you use it for young children, keep sufficient distance from them.

Do not use Mobile light near people's faces. Eyesight may be temporarily affected leading to accidents etc.



Do not illuminate or emit the mobile light at anyone driving a car or other vehicles.

 $_{\mbox{\scriptsize d}}$ May prevent a driver from driving safely and cause a traffic accident etc.



Do not watch the screen which is flashing repeatedly for a long time.

Prohibited May cause spasm or loss of consciousness.



Do not allow water or other liquids (drinking water, sweat, seawater, pet urine, etc.), metal, flammable material or other foreign object to enter the SIM card/microSD memory card tray slot on the product.

Also, do not mistake the slot place and direction of the SIM card or microSD memory card.



Do not expose the camera lens to direct sunlight etc. for an extended period.

Prohibited

May cause fires, burns, injury etc. because of the lightcollecting mechanism of the lens.

May cause fires, burns, injury, electric shock, etc.



Laser (proximity sensor)

Do not stare into proximity sensor.

Prohibited May temporarily affect eyesight, leading to accidents.

EN60825-1:2014/A11:2021

CLASS 1 LASER PRODUCT Consumer LASER PRODUCT EN 50689:2021



Do not ring an alarm in your ear when it sounds.

May damage your hearing such as difficulty in hearing.



Turn off the product or set it to Airplane mode before going aboard an airplane.

Instruction Since using the product on airplanes is restricted, follow the instructions given by the respective airlines.

Failure to do so might affect an airplane's electronic instrumentation because of signals.

If you commit a prohibited act while using the product on an airplane, you may be punished by law.



Follow the instructions given by the respective medical institution regarding the use of the product in a hospital. Turn off the product in areas where the use of cell phones is prohibited.

Failure to do so might cause interference with the operation of electronic devices and electronic medical devices because of signals.



Keep the product away from the ears during a call in which hands-free is set, while the ringtone is ringing loudly, during stand-by, etc.

When you attach the earphone/microphone etc. to the product to play games, video/music, etc., do not make the volume too loud.

During a call in which hands-free is set, loud sounds are being emitted from the product.

Even during stand-by, the ringtone or alarm sound may activate suddenly.

Hearing loud sounds for a long time may damage your hearing such as difficulty in hearing.

Also, excessively high volume prevent you from hearing ambient sounds and cause an accident.



If you have a weak heart, take extra precautions when setting functions such as the vibrator and ringtone volume for incoming calls.

You may be startled at the sudden vibrator and ringing for incoming calls and may have harmful effects on your heart.



If you are using electronic medical equipment etc., contact the respective manufacturer or dealer to check whether the operation of the equipment is affected by signals.

May interfere with the operation of electronic medical equipment etc. because of signals.



Turn off the product near high-precision electronic devices or devices that use weak electronic signals. May interfere with the operation of electronic devices

because of signals.

*Take particular care with the following devices

Hearing aids, implanted cardiac pacemakers, implanted cardioverter-defibrillators, other electronic medical equipment, other equipment controlled by electronic signals. etc. If you use an implanted cardiac pacemaker, implanted cardioverter-defibrillator or other electronic medical equipment, contact the respective manufacturer or dealer to check whether the operation of the equipment is affected by signals.



If the display part or camera lens is damaged, be careful of broken parts and the exposed inside of the product. May cause burns, injury, electric shock, etc. if you touch the

broken or exposed parts.



If the internal battery leaks or emits an unusual odor. immediately stop using the product and move it away from any naked flames or fire.

The battery fluid is flammable and could ignite, causing a fire, explosion, etc.



Do not allow a pet etc. to bite the product.

May cause fires, burns, injury, etc. because of catching fire, Instruction exploding, overheating or leaking of the internal battery.

!\CAUTION



For using a motion sensor and geomagnetic sensor, check the safety around, hold the product and do not swing it more than necessary.

May cause an accident such as injury.



If the display is broken and the internal substance then leaks, do not get it on your skin (face, hands, etc.),

May result in damage your eyes or skin.

If the internal substance comes into contact with your eyes, mouth, skin or clothes, immediately rinse the contacted area with clean water.

Also, if it comes into contact with your eyes, mouth, etc., seek medical treatment immediately after rinsing the contacted area.



Do not dispose of the product in ordinary garbage.

May cause fires, burns, injury, etc. Also, may damage to the environment. Follow the instructions of the unnecessary product by a local institution that handles used products.



If the substance inside the internal battery leaks, do not get the liquid on your skin (face, hands, etc.), clothes, a etc.

May result in damage your eyes or skin.

If the internal substance comes into contact with your eyes, mouth, skin or clothes, immediately rinse the contacted area with clean water.

Also, if it comes into contact with your eyes, mouth, etc., seek medical treatment immediately after rinsing the contacted area.



If you use the product in a vehicle, contact the vehicle manufacturer or dealer to check whether the operation of the vehicle is affected by signals.

May interfere with the operation of electronic equipment because of signals in some vehicle models. In this case, stop using the product



If any trouble on your skin is occurs due to using the product, immediately stop using it and seek medical treatment.

Use of the product may cause itching, rashes, eczema, etc. depending on your constitution or health condition. For details on materials of each part, refer to "Material List" (*P.25).



Make sure that there is no metal (a blade of cutter, staple, etc.) on the product because the earpiece (receiver), speaker section, camera section and vibrator section (back bottom right) contain parts that generate magnetic waves.

May cause injury etc. because of the adhered object.



Look at the display in a well-lit place, keeping a certain distance.

n Eyesight may be weakened etc. if you look at it in a dark place or closely.

Charger

MARNING



Do not use if the cord of the specified charger (sold separately) is damaged.

Prohibited May cause fires, burns, electric shock, etc.



Do not touch the specified charger (sold separately) if you hear thunder.

Prohibited May cause electric shock etc.



Do not short-circuit the charging jack when connected to an outlet. Also, do not allow any part of your body (hands, fingers, etc.) to come into contact with the charging lack.

May cause fires, burns, electric shock, etc.



Do not place heavy objects on the cord of the specified charger (sold separately) or apply excessive force on it such as pulling it.

May cause fires, burns, electric shock, etc.



When plugging/unplugging the specified charger (sold separately) into/from the outlet, do not allow metallic objects to come into contact with the prongs of the plug. May cause fires, burns, electric shock, etc.



Do not connect the voltage converter (travel converter for overseas travel, etc.) to the specified charger (sold separately).

May catch fire, or cause overheat, electric shock, etc.



Do not apply excessive force on the connection part with the specified charger (sold separately) connected to the product.

May cause fires, burns, injury, electric shock, etc.



Do not handle the cord, charging tack or power plug of the specified charger (sold separately) with wet hands. May cause fires, burns, electric shock, etc.



Always use the specified power supply and voltage. When using overseas, use the specified charger (sold separately) that is available overseas.

Using the incorrect power supply and voltage may cause fires, burns, electric shock, etc.

AC adapter: 100V AC (Connect only with a household AC outlet)

AC adapter available overseas: 100 to 240V AC (Connect only with a household AC outlet)



Wipe off any dust on the power plug of the specified charger (sold separately).

May cause fires, burns, electric shock, etc. if you use the power plug with dust adhering.



Fully plug the specified charger (sold separately) into the outlet. Instruction May cause fires, burns, electric shock, etc. if you do not insert it securely.



Always grasp the body of the adapter when unplugging the power plug of the specified charger (sold separately) from the outlet.

Instruction

Do not apply excessive force on it such as pulling the cord. May cause fires, burns, electric shock, etc. since the cord is damaged by pulling it.



When plugging/unplugging a specified charger (sold separately) into/from the product, plug/unplug it straightly toward the jack to connect, not applying excessive force on it such as pulling the cord.

May cause fires, burns, injury, electric shock, etc. if you do not plug/unplug it correctly.



If the charging jack is deformed such as bending it, immediately stop using it. Also, do not use the deformed one by returning it to the original shape.

May cause fires, burns, injury, electric shock, etc. because of short circuit of it.



Unplug the power plug of the specified charger (sold separately) from the outlet when not using.

Disconnect May cause fires, burns, electric shock, etc. if you leave the plug from power outlet power plug with it plugged into the outlet.



If water or other liquids (drinking water, sweat, seawater, pet urine, etc.) are attached on the equipment, immediately remove the power plug of the specified charger (sold separately) from the outlet.

power outlet May cause fires, burns, electric shock, etc. because of short circuit by the adhered object.



Always unplug the power plug of the specified charger (sold separately) from the outlet before cleaning the equipment.

plug from power outlet

May cause fires, burns, electric shock, etc. if you do not tunplug it.





Do not touch the specified charger (sold separately) continuously when connected to an outlet.

Prohibited May cause burns etc.

ACAUTION



Be careful with the cutting surface not to injure any part of your body such as fingers when handling the SIM card.

May cause injury etc. because the cutting surface may be sharp.

Quick Switch Adapter (Sample)

WARNING



Do not short-circuit the charging jack when connected to the product. Also, do not allow any part of your body (hands, fingers, etc.) to come into contact with the jack.



When insert/remove the Quick Switch Adapter (sample) into/from the product, do not allow metallic objects to come into contact with the prongs of the plug.

May cause fires, burns, electric shock, etc.



Do not apply excessive force on the connection part with the Quick Switch Adapter (sample) connected to the product.

May cause fires, burns, injury, electric shock, etc.



Do not touch the Quick Switch Adapter (sample) with your hands wet.

Wet hands May cause fires, burns, electric shock, etc.



Wipe off any dust on the jack.

May cause fires, burns, electric shock, etc. if you use the Instruction power plug with dust adhering.



Fully insert the Quick Switch Adapter (sample) into the product.

1 May cause fires, burns, electric shock, etc. if you do not insert it securely.



If the jack is deformed such as bending it, immediately stop using it. Also, do not use the deformed one by returning it to the original shape.

May cause fires, burns, injury, electric shock, etc. because of short circuit of it.

ACAUTION



Do not touch the Quick Switch Adapter (sample) continuously when connected to the product.

Prohibited May cause burns etc.



If any trouble on your skin is occurs, immediately stop using it and seek medical treatment.

Instruction

Use of the product may cause itching, rashes, eczema, etc. depending on your constitution or health condition. For details on materials of each part, refer to "Material List" (>P.25).

Use near Medical Instruments and Inside Medical Facilities

! WARNING



If you have electronic medical equipment such as an implanted cardiac pacemaker or an implanted cardioverte-defibrillator, always carry or use your product at least 15 cm away from your implant.

Electromagnetic signals may have harmful effects on the operation of the electronic medical equipment.



Patients receiving medical treatment away from a medical facility (e.g. home treatment) who are using electronic medical equipment other than implanted cardiac pacemakers or implanted cardioverter-defibrillators should consult the respective manufacturers etc. for information regarding the effects of signals on the equipment.

Electromagnetic signals may have harmful effects on the operation of the electronic medical equipment.



If there is any chance that the distance between the product and a person closest to you may get shorter a than 15 cm such as when you cannot freely move around, set the product not to emit radio wave in advance (by setting Airplane mode, turning the power off, etc.).

Somebody nearby may be equipped with electronic medical equipment such as an implanted cardiac pacemaker or an implanted cardioverter-defibrillator. Electromagnetic signals may have harmful effects on the operation of the electronic medical equipment.



Follow the instructions given by the respective medical facilities regarding the use of the product on their premises.

Electromagnetic signals may have harmful effects on the operation of the electronic medical equipment.

Material List

Main unit (SHG11)

Part	Material	Surface treatment
Display side	Reinforced glass	AF coating
Exterior (Metal section)	Aluminum	Anodizing
Exterior (Resin section)	PBT resin (with glass)	None
Power key/Fingerprint sensor	Epoxy resin	Hard coating
Volume up key/Volume down key	Aluminum	Anodizing

Part	Material	Surface treatment
Camera panel	Reinforced glass	AF coating
Decoration of camera cover	ABS resin + PC resin	None
Wide camera panel	Reinforced glass	AF coating
Mobile light panel	PC resin	None
Decoration of earpiece (Receiver)	PC resin	None
Surrounding area of earphone/microphone jack (inner side surface)	PBT resin (with glass)	None
Surrounding area of external connection jack (inner side surface)	PBT resin (with glass)	None
SIM card/microSD memory card tray (Exterior section)	Aluminum	Anodizing
SIM card/microSD memory card tray	POM resin	None
Rubber seal of SIM card/ microSD memory card tray	Silicon rubber	None

Quick Switch Adapter (Sample)

Part	Material	Surface treatment
USB Type-C plug (Metal section)	Stainless	Nickel plating
USB Type-C plug (Resin section)	LCP resin	None
USB Type-A jack (Metal section)	SPCC	Nickel plating
USB Type-A jack (Resin section)	LCP resin	None
Main unit (Metal section)	Aluminum alloy	Anodizing
Main unit (Resin section)	PBT resin	None

Handling Precautions

These precautions are provided to prevent product faults and to ensure that performance can be fully demonstrated. Thoroughly read these precautions to ensure correct use.

Precautions common to the main unit, internal battery, charger, SIM card, peripheral devices

Do not apply excessive force to the product during use. Be sure not to put the product into a tightly packed bag or place a heavy object on the product in a bag. Sitting on the product in your pocket might damage the display or internal circuit board resulting in a malfunction.

Keeping an external device connected to the external connection jack might damage the connector resulting in a malfunction. Such damage and malfunction are not covered by the warranty, even if there is no external damage.

 To ensure waterproof/dustproof property (equivalent to IPX5, IPX8 and IP6X) of the product, use the product with the SIM card/microSD memory card tray tightly closed.

Note that the waterproof/dustproof property is not guaranteed in every usage condition. Do not allow foreign objects such as liquid or dust to get inside the product or attach foreign objects such as liquid or dust to the charger or optional accessories. Do not open/close the SIM card/microSD memory card tray in the rain or with water drops on the surface of the product. Doing so might cause water intrusion resulting in internal corrosion.

Malfunctions determined to be caused by water intrusion are not covered by the warranty.

- Do not use the followings in extremely hot, cold or humid places. (Use within an ambient temperature range of 5°C to 35°C and humidity range of 35% to 85%.)
 - The product itself
 - SIM card (inserted into the product)

For using the product in a bathroom, refer to "Precautions when using the product in a bathroom" (>P.37).

- Do not use the followings in extremely hot, cold or humid places. (Use within an ambient temperature range of 5°C to 35°C and humidity range of 35% to 85%.)
 - Charger
 - Peripheral devices

- Clean the product with a soft dry cloth (such as the type used for eyeglasses). Forceful rubbing with a dry cloth may scratch the display. The display may be stained if splash or smear is left attached to the surface. Wiping the product using alcohol, thinner, benzene, detergent, glass cleaner, etc. might erase the printing on the outer casing, cause a fault, etc.
- Use as far away as possible from fixed-line phones, TVs and radios.

 Use possible might affect them.
- Use nearby might affect them.
- The product may become warm while charging or during other operations, depending on the situation, but this is not abnormal.
- Do not place near corrosive chemicals or in places where corrosive gas is generated. Doing so might cause a fault.
- Do not use outside when you can hear thunder. Doing so might risk lightning strikes and electric shock.
- The customer is not allowed to disassemble, modify or repair the product. Doing so might cause a fault. Also, modification of the product is in violation of the Radio Law and/or the Telecommunications Business I aw.
- Do not use product while driving a car or riding a motorbike or bicycle
 or while walking. Use of it while driving a car or riding a motorbike is
 prohibited by law. Use of a cell phone while riding a bicycle may be
 punishable by some regulations.
- When the product becomes warm during use, the screen brightness or part of its functions may be restricted.

Main unit

- Since the battery is built into the product, you cannot replace it yourself. For replacing the battery, contact au Style/au shop or customer support.
- Do not forcefully press, tap or intentionally subject the display to strong impact. Doing so might cause scratching or damage.
- Do not forcefully press sharp objects or hard objects against keys or display surface. Doing so might cause scratching or damage.

Never use the modified product. Use of a modified device violates the Radio Law and/or the Telecommunications Business Law. You can perform the following operations to confirm the unique authentication and standard marks (including certification/ authentication numbers) for the product.

On the home screen \rightarrow "App list screen" \rightarrow [Settings] \rightarrow [About phone] \rightarrow [Regulatory labels].

The product has acquired the certification of conformity with technical regulations for the specified radio station based on the Radio Law and certification of conformity with technical regulations for the terminal based on the Telecommunications Business Law, and the "Technical Conformity Mark (a)" can be confirmed in the product as a certificate. Confirm contents of electrical certificates in the product for information on certification.

If the modifications are made to the internal components, the certification of conformity with technical regulations will become invalid. Never use the product without the valid certification. Doing so violates the Radio I aw and/or the Telecommunications Business I aw.

- Take care not to place magnetized items such as magnetic cards, speakers and TV sets near the product, as it might cause malfunction.
 - Putting strong magnetism close to the product might cause false operation.
- Do not bring the product close to magnetic cards such as cash cards, credit cards, and prepaid cards. Doing so might result in loss of recorded information.
- When you put the product in your pocket or bag, take care so that the display does not come in contact with metal objects or other hard objects. Doing so might cause scratching or damage.
- When suddenly brought into a warm place from a cold place, or when in a humid location, or when used where temperature suddenly changes (e.g. near the air discharge port of an air conditioner), water drops (i.e. condensation) sometimes are formed inside the product. Note that when used under conditions such as this, humidity might cause corrosion or a fault.
- Do not exert excessive force when attaching/removing a microSD memory card. Doing so might injure your hands or fingers.
- While writing/reading data to/from a microSD memory card, do not subject the product to vibration or impact or turn off the power. Doing so might cause loss of data or a fault.

- Do not cover the light sensor with your finger or put a sticker on it.
 Doing so may hinder the light sensor from detecting the ambient brightness and functioning correctly.
- Do not put a sticker, etc. on the proximity sensor. Doing so may cause the sensor to malfunction and make the display always turned off while making a call or during a call.
- Covering earpiece (receiver), mouthpiece (microphone), speaker, sub microphone and air vent port section (mobile light) with stickers or fingers may hinder product performance.
- If you hold the phone to talk with hair covering your ear, the proximity sensor may malfunction. This may cause the display to remain on, allowing the call to be disrupted if the display is accidentally touched.
- If the display gets damaged, immediately stop use and contact au Style/au shop or customer support. Continued use may cause injury.
- Putting a sticker, etc. on the display or a key may cause malfunction or shortened usage time. Also, doing so may damage the product.
- If you put magnetized objects close to the product, the speaker section sometimes emits sounds. This is not a fault
- Note that if you forcefully pull the SIM card/microSD memory card tray or apply excessive force on it, it may be damaged.
- Bright places such as under the direct sunlight sometimes make it hard to see the display. This is not a fault.
- Use the product with the SIM card/microSD memory card tray closed.
 If the card tray is open, dirt or water may get inside causing a fault.
- Do not allow liquids, metal objects, and other foreign matter to get inside the SIM card/microSD memory card tray slot of the product.
 Doing so might cause a fault.

Touch panel

• The touch panel is designed to be lightly touched by fingers. Do not apply strong pressure with your fingers or sharp-pointed objects (such as fingernails, ballpoint pens and pins) on the touch panel. In the following cases, the touch panel may not work even if you touch it.

May cause a malfunction.

- · Operation with a gloved finger*
- · Operation with the tip of a fingernail
- · Operation with foreign object placed on the operation pad
- Operation on the touch panel on which a protective film, sticker, etc. is put
- Operation while water drops or condensations are left attached to the display

- Operation with wet fingers or moisture fingers with sweat
- Operation under water
 - * When [glove mode] is set to ON, you can operate the touch panel with a glove on.
- Placing stickers or sheets (e.g. protective films, peep prevention sheets) on the display might hinder correct operation of the touch panel.
- When carrying the product in your pocket or bag, take care not to put the touch panel close to metals or other conductive materials, as it might cause false operation of the touch panel.

Organic EL (OLED) display

- Although lighting intensity of OLED can be decreased partly and displayed color can be changed when the same image has been displayed for a long time, the brightness set to bright more than necessary or using extremely for a long time. It is not abnormal because that is the characteristic of OLED.
- Although the OLED used on the product is made using highprecision technology, some pixels (dots) might be lit or out at all times. Or color may be changed or unevenness of brightness may be shown if looked at from different angles. Note that that is because of the structure of OLED, not a fault.
- Leaving the OLED exposed to the direct sunlight might cause a fault.
 Take care when you place the product by the window or outside.

Internal battery



(The internal battery of the product is a lithium-ion battery.) The internal battery is not fully charged at the time of purchase. Charge the battery before using the product. Also charge the battery after long periods of disuse before using the product.

Use in very hot or cold environments, for example, when left in an automobile with the windows closed in summer, will cause the internal battery capacity to drop and shorten the available battery usage time. This will also shorten the internal battery's service life. Try to use the internal battery as much as possible at room temperature.

- The internal battery gradually discharges after charging even if the product is not used. The internal battery may discharge completely after long time no use. Charge before using the product.
- Internal batteries sometimes swell up as they approach the end of their service life depending on the usage condition. This is due to the properties of lithium-ion batteries, and is not a problem in terms of safety.
- The internal battery is a consumable item. If the performance of the internal battery does not recover and deteriorates (e.g. the usable time after each charge has become extremely short or the internal battery swells), the internal battery is at the end of service life, so stop using it. Since the battery is built-in type, the product will be kept at an au Style/au shop etc. and charges will be incurred for repair. Please understand this in advance. Battery life varies depending on usage conditions and other factors.
- Because the internal battery performance or service life will become low, do not store the product in the following conditions.
 - Battery level is full (soon after charging is complete)
 - Battery level is empty (to the extent that the product is not powered on)
 - · In extremely hot or humid conditions

SIM card

- Do not forcibly remove or insert the SIM card. Be careful not to exert excessive force when inserting the card into your product.
- You are responsible for any damage caused by inserting your SIM card into some other IC card reader/writer, etc.
- Do not put stickers etc. on the SIM card.
- Do not insert the SIM card attached with a conversion adapter. Doing so might cause a fault.
- Do not subject the SIM card to actions that can damage it (use in high-temperature conditions, throwing in a fire, allowing metal contacts to come in contact with foreign objects, subjecting to shock, bending or pressing, wetting, etc.). Doing so might erase data or cause a fault.

Quick Switch Adapter (Sample)

 Fully insert the Quick Switch Adapter (sample) all the way to the product. Not doing so might cause overheating, ignition, electric shock, fires or injury. Also, insert/remove it in parallel to the external connection jack. Not doing so might cause a fault or operation failure.

- Remove the Quick Switch Adapter (sample) from the product when not using.
 - May cause fires, burns, electric shock, etc. if you leave the Quick Switch Adapter (sample) with it connected to the product.
- If water or other liquids (drinking water, sweat, seawater, pet urine, etc.) are attached on the equipment, immediately remove the Quick Switch Adapter (sample) from the product.
 - May cause fires, burns, electric shock, etc. because of short circuit by the adhered object.
- Always remove the Quick Switch Adapter (sample) from the product before cleaning the equipment.
 May cause fires, burns, electric shock, etc. if you do not unplug it.

Camera

- If the camera lens breaks, immediately discontinue use, and contact au Style/au shop near you or the Repair and Delivery Support Center. Continued use may cause injury.
- When photographing important occasions etc., take a trial shot and check the shot image to make sure it is correctly shot in advance.
- Do not shoot in areas where shooting is prohibited.

Copyrights and rights of portrait

- If the data you shot or recorded using the product or the data you downloaded from the Internet etc. is in part or in whole protected by the third party's copyright, you are not allowed to copy, distribute, publicly send, modify the data without consent of the copyright holder, except for personal use such as copying or quoting where provided for under the copyright law.
 - In addition, do not use or modify portraits or names of other individuals without their consent, as it may infringe on rights of portrait.
 - Note that shooting and recording might be restricted at some live performances, shows and exhibitions even for personal use.
- Be careful about the copyright and portrait right when posting still pictures you shot, etc. on Internet homepages.

Notes on Waterproof, Dustproof and Shock-resistant Properties

Before using the product, thoroughly read the contents of "Notes on Waterproof, Dustproof and Shock-resistant Properties" to ensure correct use. Failure to follow the contents described in these sections may cause liquid or dust to get inside, resulting in overheating, ignition, electric shock, injury or fault.

Proper operations of the product are not guaranteed in every possible condition. Faults determined, after an inspection, to be caused by mishandling by the customer such as by using the product without following the contents written on "Notes on Waterproof, Dustproof and Shock-resistant Properties" are not covered by the warranty.

Waterproof, Dustproof and Shock-resistant Properties of the Product

The product has a protection rating (JIS C 0920) for waterproof property equivalent to IPX5*1 and IPX8*2, as well as dustproof property equivalent to IP6X*3 on the condition that the SIM card/microSD memory card tray is securely closed (Based on the experiments by the Company). The product also employs a shock-resistant structure passing MIL-standard testino*4.

- *1 IPX5 means that the cell phone continues to function as a phone after being subjected to a water jet (approximately 12.5 liters/min) discharged from a water pouring nozzle (inner diameter: 6.3 mm), from all directions and approximately 3 meters away from the cell ohone for at least 3 minutes.
- 12 IPX8 means that the cell phone continues to function as a phone after being gently lowered into a tank filled with still tap water (at room temperature) to the depth of 1.5 meter, immersed at the bottom for approximately 30 minutes and then taken out of the tank.
- *3 IP6X means that the cell phone securely continues to its function of no grit and dust getting inside the main unit even after it has been placed in an apparatus with grit and dust (diameter: 75 μ m or less) and shaken for 8 hours.
- *4 MIL standard compliant
 - We conduct our own testing based on MIL-STD-810H (MIL-STD-810G for shock-resistant drop testing) established by the US Department of Defense.
- Since performance of the product was confirmed based on the test environment, proper operation of all the product in every possible situation during actual use is not guaranteed. In addition, it does not guarantee that there will be no damage or failure for all impacts.

Waterproof and dustproof properties of the product enables you

- To use the product at the poolside. However, do not get it wet with water other than tap water such as water in the swimming pool or submerge it in water in the swimming pool.
- To wash the product with the low-pressure water flow of a tap water (6 liters/min or lower) at the room temperature (5°C to 35°C).

Handling the product

- Close the SIM card/microSD memory card tray securely. The waterproof and dustproof properties are shown its ability by completely closing the cover. Even a fine obstacle (hair, sand, tiny fiber, etc.) put between contact surface may cause liquid or dust to get inside.
- If liquid such as water is splashed onto the product with the SIM card/microSD memory card tray opened, the liquid may seep inside and cause electric shock or fault. Stop using it, turn off the power and contact au Style/au shop near you or the Repair and Delivery Support Center.
- . When the product is wet, wipe it with a dry and clean cloth.
- When your hand or the product is wet or foreign objects are attached to it, never open/close the SIM card/microSD memory card tray.
- The product is resistant to fresh and tap water at room temperature (5° C to 35°C) only. If you let the product get wet with or submerged into
 the liquids other than fresh and tap water at room temperature, stop
 using it and wash it with fresh and tap water at room temperature.
- Do not use the earphone/microphone jack or external connection jack when the jack is wet or sand or dust is attached to it. Doing so may cause impairment of the waterproof/dustproof property or cause

electric shock, short circuit, etc. resulting in a fire, burns, or a fault. Closing the SIM card/microSD memory card tray

Insert the SIM card/microSD memory card tray all the way to the product horizontally.

. For details, refer to the step 3 in "Attaching the SIM card" (▶P.4).

Dustproof property of the product

- The dustproof property of the product only guarantees a protection rating equivalent to IP6X and does not guarantee its performance under other using conditions such as when the product is directly put on sand such as a beach.
- If dust is attached to the product, immediately wash it away with water or otherwise clear it completely before use.

Notes on Using the Product

- Do not let the product submerged into or get wet with the liquids (seawater, water from a swimming pool, hot water of hot spring, water containing soap, detergent or bath powder, alcohol, soft drink, seasoning, etc.) other than tap water. Also, do not use it in a place where it gets wet with pet urine. If it gets wet, immediately rinse it with tap water.
- If foreign object such as salt water, seawater, drink, seasoning, food, dirt or soil is attached on the product, immediately wash it away.
 When it gets dry and coagulated on the product, the stains get hard to get rid of and may cause scratching or fault.
- Using the product without completely washing sand or mud away may cause fault such as scratches and damages on the product.
- Do not immerse the product in a bathtub or swimming pool. Also, do not use it under water. (including key operations.)
- The product is not designed to withstand high water pressure. Do not expose the product to a strong water flow with tap water, shower, etc.
 (6 liters/min or more) or submerge it under water.
- Do not let the product into hot water, use it in saunas or expose it to hot air from hair driver etc. The product is not designed to resist the heat.
- The rapid changes of temperature may cause condensation, resulting in malfunction. Wait until the product reaches room temperature before you bring it from a cold place into a warm place. If condensation occurs, leave it in room temperature until the condensation is removed.
- Do not use or store the product for a long time in humid places such as a bathroom and kitchen.
- The product does not float on water.
- · Do not use the product in heavy rain.
- Do not leave the product wet. Doing so may let the liquids freeze on the product in cold places or otherwise cause fault.
- Volumes may temporarily become lower due to water entering in the earpiece (receiver), mouthpiece (microphone) and speaker. Drain water and dry the product well before use.
- Do not place the product directly on sand at a beach, sandbox, etc. or on mud. Grains of sand may get into the earpiece (receiver), mouthpiece (microphone), speaker, sub microphone, earphone/ microphone jack, external connection jack, etc., causing the volume to drop. If sand gets inside the product etc., it might cause overheating or a fault.

- If the SIM card/microSD memory card tray degrades or is damaged, the waterproof/dustproof property cannot be maintained.
- Do not drop or subject to impact. Also, do not jab the earpiece (receiver), mouthpiece (microphone), speaker, sub microphone, etc. with a sharp object. Doing so may cause damage or deformation to/of the product, resulting in impairment of waterproof/dustproof property.

Precautions when using the product in a bathroom

- Do not let the product submerged into or get wet with hot water of a
 bathtub or hot spring or water containing soap, detergent or bath
 powder. Doing so might cause a fault.
 If liquid other than tap water is attached on the product, you fall the
 - If liquid other than tap water is attached on the product, you fall the product into the bathtub, etc., immediately rinse the product in the specific procedure and drain water or dry the product naturally.
- Use the product within 2 hours continuously in a bathroom where the range of a temperature is 40°C or less, a humidity is 99% or less.
 After that, be sure to drain water or dry the product naturally in the specific procedure.

All function's continuous operations are not completely guaranteed.

- · Take care not to get the product wet with high temperature water.
- The rapid changes of temperature may cause condensation.
 Wait until the product reaches room temperature before you bring it from a cold place into a warm bathroom etc.
 - Also, do not get the warmed product wet with cold water in a bathroom.
 - Doing so might cause water intrusion or a fault.
- If condensation occurs inside the camera lens or display, leave it in room temperature until the condensation is removed.
- Do not use the product connected to an earphone/microphone or external device in a bathroom.
- Do not charge the product in a bathroom.
- · Set "glove mode" to OFF in a bathroom.
 - On the home screen → "App list screen" → [Settings] → [Display] → [glove mode] to change the setting.

Maintaining the Waterproof and Dustproof Properties

Rubber seal

The rubber seal on the SIM card/microSD memory card tray is important to maintain the waterproof/dustproof property. Be sure to observe the following items.

- · Do not remove or scratch it.
- When closing the SIM card/microSD memory card tray, do not get the rubber seal caught. Also, do not insert sharp objects into gaps around the SIM card/microSD memory card tray, the earphone/microphone jack or external connection jack section.
 - Doing so may damage the rubber seal and cause liquid or dust to get inside.
- It is recommended to replace the parts for maintaining the waterproof/ dustproof property (pay service) once every two years regardless of whether any abnormality is present. For information on part replacement, contact au Style/au shop near you.

Precautions on Charging

Specified charger (sold separately) and optional accessories are not waterproof/dustproof. Be sure to check the following items before and after charging.

- Check that there are no water drops or foreign objects on the product.
 If foreign objects are attached on the product, immediately wash it
 away. Also, if it is wet or after it gets wet, drain water well and wipe
 remaining water off with a clean dry cloth etc. before inserting the USB
 Type-C plug into the external connection jack.
- Never connect the USB Type-C plug when the product or charger is wet or foreign objects are attached to it.
 - Although the product is water/dust resistant, the specified charger (sold separately) and optional accessories are not water/dust resistant. Any water or foreign matter on the product or USB Type-C plug when inserting the USB Type-C plug while the product is wet or dirty might cause electric shock or short circuit/corrosion causing abnormal overheating, burnout, fire, burns, or a fault.
- Do not touch the specified charger (sold separately) with wet hands.
 Doing so may cause electric shock.

Do not splash water onto the specified charger (sold separately) or
optional accessories when using the equipment and do not use it in
places where water is regularly used such as a bathroom, shower
room, kitchen and lavatory. Doing so may cause fire, burnout, electric
shock, a fault, etc. Also, do not take it in a bathroom etc. even when
not charging. Doing so may cause fire, burnout, electric shock, a fault,
etc.

Washing the Product

If any stain, dust, sand, soft drink, etc. is attached to the surface of the product, gently wipe it off with a cloth and wash the product under a mild water flow (up to 6 liters/min) of tap water at room temperature (5°C to 35°C) approximately 10 cm away from the faucet or shower head. Hold the SIM card/microSD memory card tray so that it does not open, and wash the product with your hands without using a brush or sponge. After washing the product, drain water off and then use the product.

- Make sure that the SIM card/microSD memory card tray is securely closed before washing the product.
- Do not wash the product with a washing machine or an ultrasound bath.
- The earphone/microphone jack section and external connection jack section are especially subject to stain such as dust or sand adhesion. Wash away stain carefully so as not to keep it remaining in the sections. Also, after washing it away, make sure the sections get sufficiently dried off before using the product. Using the product with sand or water drops remaining in the jack sections may cause fault.
- When cleaning the earphone/microphone jack section and external connection jack section, do not use tools such as a cotton swab or jam a cloth into the jack sections. Doing so may cause impairment of waterproof/dustproof property etc., resulting in fire, burns, or a fault.
- Never put the product in a microwave oven for drying it. Doing so may cause the internal battery to leak liquid, overheat, rupture or ignite.
 Also, doing so may cause the product to overheat, emit smoke, ignite or cause destruction of circuit components.
- Do not expose the product to hot air from a hair dryer or leave it in a high temperature environment for drying it. Doing so may cause the product to deform, discolor, get out of order, etc.

Draining Water


If the product gets wet, make sure to drain water remaining in the earphone/microphone jack section, external connection jack section, earpiece (receiver) section, mouthpiece (microphone) section, speaker section, key section, sub microphone section, air vent port section (mobile light), etc.

Wipe off water on the surface of the product carefully with a dry and clean cloth etc.




Plot the product securely and shake it approximately 20 times until there is no more water splashing.


Make sure of the safety around you and shake the product while holding it securely not to let it drop.











Wipe off water remaining in the grooves of each section by gently putting the product against a dry and clean cloth etc.

Since water is sometimes left in the grooves of each section, clear them of water by putting a cloth against their openings and gently patting them. Make sure that there is no more water or foreign objects remaining in them.



4 Lay out a dry cloth etc. beneath and leave the product on the cloth at room temperature for approximately 2 to 3 hours to dry it.

Water, if any, remaining in the product may ooze up after wiping off. Do not wipe off water remaining in the grooves directly by a cotton swah etc.

Precautions to be taken after water draining

Do not use the product with water drops still left on it.

- · Doing so may cause call disruption or cause clothes or bags to get wet.
- Doing so may cause the earphone/microphone jack, external connection jack, etc. to short-circuit, causing fire or a fault.
- Doing so in a cold region may cause a fault due to water drops freezing.

Notes on Using Bluetooth®/Wireless LAN (Wi-Fi®) Functions

- Connections between the product and all other Bluetooth® and wireless LAN (Wi-Fi®) devices have not been confirmed. Therefore, connections with all Bluetooth® and wireless LAN (Wi-Fi®) devices are not quaranteed.
- The product supports security features for wireless communications that are compliant with the Bluetooth® and wireless LAN (Wi-Fi®) standard specifications, but the security may not be sufficient depending on the usage environment and configuration. Be careful when making data communication using Bluetooth® or wireless LAN (Wi-Fi®) function.
- Wireless LAN (Wi-Fi®) has the advantage that it can be freely connected anywhere within the radio wave range, as it uses radio waves for exchanging information. At the same time, there is a risk that a malicious third party may obtain unauthorized access if security settings have not been configured. You are recommended to configure security settings before using wireless LAN (Wi-Fi®) at your decision and responsibility.
- The Company assumes no responsibility for leakage of data or information that may occur during Bluetooth®/wireless LAN (Wi-Fi®) communication.
- Since Bluetooth® and wireless LAN (Wi-Fi®) functions use the same frequency band, using the both functions at the same time may cause radio wave interference resulting in decreased communication speed or disconnection from the network. If connection fails, stop using either of the Bluetooth® and wireless LAN (Wi-Fi®) functions.

Voluntary control for radio wave interference

This product satisfies technical requirements based on VCCI Rules for Voluntary Control Measures and its satisfied mark is displayed on the electronic nameplate of the product.

You can see the electronic nameplate by operating the product as follows.

On the home screen → "App list screen" → [Settings] → [About phone] → [Regulatory labels].

Notes on Data Communication Charge

- Since constant Internet connection is possible with the product, data communication may be performed automatically by some applications, resulting in high data communication charges. Therefore, subscription to the flat-rate/discount service for data communication charges is recommended.
- To browse homepages, download applications, communicate using applications, send/receive mails and configure various settings, connection to the Internet is required, to which data communication charge applies.

Notes on Call Charge

 When you end a call, make sure to disconnect the call. If you forget to disconnect, the call charges may be higher.

After-Sales Service

■ To Request Repairs

To request repairs, contact the Repair and Delivery Support Center.

	Repairs are covered in accordance with our free repair warranty.
Outside the	If the product can be repaired, charged repairs will
warranty period	be carried out upon request.

^{*} The warranty period for a new product is 1 year from the date of purchase.

- Please note that contents of memory may be lost during the repair process. Note that the Company assumes no responsibility for any damages or lost profits resulting from altered or lost contents of the memory.
- When repairing, we may use recycled parts that fulfill our quality standards.
- The product that you have been using, and that has been collected by the replacement mobile phone delivery service will, after refurbishment and repair, be used as a replacement terminal. Furthermore, parts replaced in an after-sales service are collected and recycled by the Company. Accordingly, these parts cannot be returned to the customer.
- If the product has been processed, modified, or analyzed (including software modification or analysis (including rooting, etc.), reverse-engineered, decompiled, or disassembled), or has had repairs performed at repair locations other than as designated by us, then this will not be covered by the Warranty, or repairs may be refused.
- The internal battery of the product is not covered by the free repair warranty because it is a consumable product.
- Accessories and samples other than the main unit of the product are not covered by the free repair warranty.

■ Replacement Parts

We guarantee availability of replacement parts for main unit of our product and its peripheral devices for a period of 4 years after the end of production. Replacement parts are those required to maintain the functionality of the product.

■ Free Repair Warranty

- When applying for repairs, the serial number (IMEI number) is required. You can check it on the main unit or sticker pasted on outer hox.
- If malfunctions occur even though you have properly operated following notes on the instruction manual during the warranty period, you are not charged a repair fee.
- 3. In the following cases, you are charged a repair fee even during the warranty period. (Or repairs may not be possible.)
 - ① When you have not properly operated following instruction manuals.
 - ② When malfunctions or damages have caused by unwarranted repairs or modifications.
 - ③ When the product has been repaired at a location other than an authorized repair location designated by the company.
 - When you have made mistaken operation while handling or malfunctions or damages have caused by accidents. Also, the product has traces of being dropped, water intrusion, humidity, etc.
 - (§) When malfunctions or damages have arisen from earthquakes, storms, floods or other natural disasters, as well as fires, salt damages, abnormal voltage, etc.
- 4. Repairs may not be possible depending on the damage state.
- The Company does not compensate any damages or losses arising from product faults.
- The Company assumes no responsibility for any accidents that might be caused by connecting the product to the device other than specified one.
- 7. Visiting repairs are not possible.
- 8. This warranty is valid only in Japan.
- * This warranty is liable for the free repair warranty subject to the abovementioned period and condition. Therefore, it does not restrict your legal authority for assurance parties and other operators.

Repair and Delivery Support with Cloud

In order that you can use the au/UQ mobile device with peace of mind for a long period of time, we provide an after-sales service called "Repair and Delivery Support with Cloud" with a monthly subscription. This service provides compensation to cover a range of issues including damage, theft, and loss. For details on the monthly pricing and provided services refer to the au/IQ mobile website

For subscriber of au

https://www.au.com/mobile/service/kosho-funshitsu-cloud/

· For subscriber of UQ mobile

https://www.uqwimax.jp/mobile/plan/option/repair-cloud/ (Japanese)

* Details of the service are subject to change without prior notice.

■ SIM Card

The SIM card is lent to you by the network operator you contracted. In case of loss or damage, the card will be replaced at your expense. When malfunction is suspected, or in case of theft or loss, contact au Style/au shop or Toyota locations that carry au products.

Regulatory information

Hereby, SHARP CORPORATION declares that the radio equipment type SHG11 is in compliance with Directive 2014/53/EU.

The full text of the EU declaration of conformity is available at

the following internet address: https://ip.sharp/k-tai/ (Japanese)

Manufacturer's Address: SHARP CORPORATION

1 Takumi-cho, Sakai-ku, Sakai-shi, Osaka 590-8522, Japan

CE/FCC Notice;

Before use, read CE/FCC notice in the below detailed operation manual to ensure proper operation.

- This manual describes detailed guidance and operations of functions. Download from the operator's website.
- The device is electronically labeled and the FCC ID can be displayed via the About phone & the Regulatory labels under the Settings menu.

Export Administration Regulations

The product and its accessories may be subject to the Japan Export Administration Regulations ("Foreign Exchange and Foreign Trade Law" and its related laws). In addition, U.S. Re-export Regulations (Export Administration Regulations) may apply to the product and its accessories. To export and re-export the product and its accessories. take the required measures on your responsibility and at your expenses. For details on the procedures, contact the Ministry of Economy, Trade and Industry or the U.S. Department of Commerce.

Intellectual Property Rights

■ Trademarks

The company names and product names appearing in this manual are trademarks or registered trademarks of their respective holders











- . The microSD logo, microSDHC logo and microSDXC logo are
- trademarks of SD-3C, LLC. USB Type-C[™] is a trademark of USB Implementers Forum.
- The Bluetooth® word mark and logo are registered trademarks owned by the Bluetooth SIG, Inc., and SHARP CORPORATION is licensed to use these trademarks
- Wi-Fi® and Wi-Fi CERTIFIED logo are trademarks of Wi-Fi Alliance®.
- Wi-Fi CERTIFIED™ is a trademark of Wi-Fi Alliance®.
- QR code is a registered trademark of Denso Wave Inc.
- a is a registered trademark of FeliCa Networks, Inc.
- Android™ and Android logo are trademarks of Google LLC.

- Oracle and Java are registered trademarks of Oracle and/or its affiliates.
- iPhone is a trademark of Apple Inc., registered in the U.S. and other countries. The iPhone trademark is used under license from AiPhone Co. I td.
- "AQUOS/アクオス" and the "AQUOS" logo are trademarks or registered trademarks of Sharp Corporation.
- All other company and product names appearing in this manual are trademarks or registered trademarks of their respective holders.

■ Open Source Software

 The product includes software based on GNU General Public License (GPL), GNU Lesser General Public License (LGPL), and other licenses.

For details on licenses of related software, on the home screen → "App list screen" → [Settings] → [About phone] → [Legal information] → [Third-party licenses].

 Source codes of software based on GPL, LGPL and Mozilla Public License (MPL) can be referred to on the following site for free. For details, refer to the following site.

https://k-tai.sharp.co.jp/support/developers/oss/ (Japanese)

License

[OpenSSL License]

Copyright @ 1998-2009 The OpenSSL Project. All rights reserved.

This product includes software developed by the OpenSSL Project for use in the OpenSSL Toolkit. (http://www.openssl.org/)

THIS SOFTWARE IS PROVIDED BY THE OpenSSL PROJECT "AS IS" AND ANY EXPRESSED OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE OPENSL PROJECT OR ITS CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

[Original SSLeay License]

Copyright © 1995-1998 Eric Young (eay@cryptsoft.com) All rights reserved.

This product includes cryptographic software written by Eric Young (eav@cryptsoft.com)

THIS SOFTWARE IS PROVIDED BY ERIC YOUNG "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE AUTHOR OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE

Windows Notations

In this manual, operating systems (Japanese editions) are abbreviated as follows.

- Windows 10 is an abbreviation of Microsoft® Windows® 10 (Home, Pro. Enterprise and Education).
- Windows 11 is an abbreviation of Microsoft® Windows® 11 (Home, Pro, Enterprise and Education).

More

The software installed on this product or part of it may not be altered, translated/adapted, reverse-engineered, decompiled or reverse-assembled and any such actions are prohibited.

• This product is licensed under the AVC patent portfolio license for the personal and noncommercial use of a consumer to (i) encode video in compliance with the AVC standard (henceforth referred to as AVC video) and/or (ii) decode AVC video that was encoded by a consumer engaged in a personal and noncommercial activity and/or was obtained from a video provider licensed to provide AVC video. No license is granted or shall be implied for any other use. Additional information may be obtained from MPEG LA, L.L.C. Visit http://www.mpedia.com

<For subscriber of au>

au Support



Mv au app

You can check your fee, points, and contract details and do various procedures. * For povo users, check above with povo 2.0/povo 1.0 app.







http://kddi-l.jp/mFH (Japanese) useful for solving your problem.

au Support (web) Provides various support information



http://kddi-l.jp/Gf9 (Japanese)



(©) Message

Consult us anytime/anywhere simply by chat! Al answers you soon all day and our advisor guides you in detail.

http://kddi-l.ip/Bz6 (Japanese)



<For subscriber of UO mobile>

UQ mobile Support

App/Website

■ My UQ mobile (app)

You can check your remaining data, billing. and subscription of services





http://kddi-l.ip/FJ7 (Japanese)

■UQ mobile Support (web) Provides various support information useful for solving your problem.



http://kddi-l.jp/jQX (Japanese)



(Chat

Consult us anytime/anywhere simply by chat! Al answers you soon all day and our advisor guides you in detail.



http://kddi-l.ip/i9z (Japanese)



Repair and Delivery Support Center

(Service for members of Repair and Delivery Support/ Repair and Delivery Support with Cloud)

For repair or replacement cell phone delivery service (Toll free) Business hours: 9:00 to 20:00 (7 days a week)

From au mobile phones/UQ mobile phones/general subscriber phones

£ 0120-925-919



モハイル・リサイクル・ネットワーク 携帯電話・PHSのリサイクルにご協力を Cell phone and PHS operators collect and recycle unused telephones, batteries and battery chargers at stores bearing the (2) logo regardless of brand and manufacturer to protect the environment and reuse valuable resources.





