- "Setting Guide", "Basic Manual", "Notes on Usage", etc. are collectively referred to as "Instruction Manual
- In this manual, "isai V30+" is usually referred to as the "product". In this manual, "microSD™ memory card (commercial item)", "microSDHC™ memory card (commercial item)" and "microSDXC™
- memory card (commercial item)" are abbreviated as "microSD memory v names and product names in this manual are eithe
- All company names and product names in this manual are eitner trademarks or registered trademarks. The trademark symbol (TM) and the registered trademark symbol (®) may be omitted in places in this manual.

January 2018, 1st Edition

Do not let the product get wet with water (drinking water, perspiration, seawater, urine of pet animals, s etc.)

May cause fire, burns, injuries, or electric shock, etc. For the waterproof function, refer to the following. →P.36 "Notes on waterproof, dustproof and shock resistance properties"

Do not put water (drinking water, perspiration, seawater, urine of pet animals, etc.) into the charging Not liquids terminal or the external connection terminal. May cause fire, burns, injuries, or electric shock, etc.

For the waterproof function, refer to the following →P.36 "Notes on waterproof, dustproof and shock resistance properties"

Use the optional products specified by au for your cell phone. Not doing so may cause fire, burns, injuries or electric

shocks, etc.

! WARNING

On not drop, step on, or throw the product or give a strong force or vibration to it. Don't May cause fire, burns, injuries, or electric shock, etc.

Keep conductive materials (metal pieces, pencil lead, etc.) from coming in contact with the charging terminal Don't or the external connection terminal and prevent dust

from getting inside.

May cause fire, burns, injuries, or electric shock, etc.

Do not cover or wrap the product with a bedding, etc. while using or charging. Don't May cause fire or burns, etc.

- 7 -

Be careful not to let your pet bite the product.

May cause internal battery to ignite burst heat or let the product. May cause internal battery to ignite, burst, heat, or leak, and may cause fire, burns, or injuries, etc.

CAUTION

 $\begin{picture}(60,0)\put(0,0){\line(0,0){10}}\end{picture}$ Do not swing the product by the LG TV antenna cable 01, etc. Don't May cause injuries, etc.

When using the motion sensor, stay alert to your surroundings, hold the product firmly, and do not swing Don't it excessively. May cause injuries, etc.

If the display breaks and the fluid etc. leaks out from inside, do not let the fluid contact with the skin on your face or hands or clothes.

May cause eyes or skin problems If the fluid etc. enters your eyes or mouth, or contacts skin

or clothes, immediately flush the contacted area with clear If the fluid etc. enters your eyes or mouth, immediately see a

On not discard the product together with other garbage.

May cause ignition burns or injuries etc. Also may cause environmental destruction.

Bring them to a sales outlet such as an au shop. If your

- 14 -

May cause injuries, etc. due to adhered objects. local municipality has a battery recycling program, dispose When watching the display screen, keep a condition distance from the display in a fully bright place. When watching the display screen, keep a certain If witching the display in the dark or watching too close, may

When Using the Product

Before using the product, be sure to read the "Notes on Usage" (this manual) available on the au homepage to ensure correct use Before you assume that the product is malfunctioning, perform

On the Home screen ▶ [au] ▶ [故障紛失サポート (Repair and Delivery Service)] ▶ [トラブル診断 (Trouble check)]
Alternatively, check for possible remedies in "Troubleshooting diagnosis" on the au website.

https://www.au.com/trouble-check/ (in Japanese only)

- Communication is not possible even inside the service area n places where the signal does not reach (e.g. tunnels and basements). Also, communication is sometimes not possible in poor reception areas. Communication is sometimes interrupted if you move into a poor reception areas during communications.
- Since this product uses radio waves, the possibility of communication intercepts by third parties cannot be eliminated (though LTE/WiMAX 2+/GSM/UMTS system has highly secure confidential communication features).
- When connecting to emergency services in Japan, use au VoLTE (LTE network). You cannot connect through 3G (circuit switching) · While this product supports the au World Service, each network
- service described in this manual varies depending on the area and Since this product is a radio station under the Radio Law, you
- may be asked to temporarily submit the product for inspection in accordance with the Radio Law. IMEI information of your cell phone is automatically sent to KDDI
- CORPORATION for maintenance and monitoring operational status of your cell phone.
- Before you start using the product overseas, check the relevant laws and regulations of the country/region you visit.

- 1 -

Do not stick metallic items (such as stickers that contain metal) on the front of the (sold separately) or this product. May cause fire, burns or injuries, etc.

Do not place metallic items (such as straps and clips that contain metal) between the wind. that contain metal) between the wireless charger (sold separately) and this product. May cause fire, burns or injuries, etc

When charging with the wireless charger (sold separately), remove the cover etc. with which the Do product is equipped. Failure to charge arising from material and thickness of the

cover or foreign objects such as dust caught between the product and the cover may cause fire, burns or injuries, etc.

Turn the product OFF near high-precision electronic control equipment or electronic equipment using lowpower signals.

May cause the equipment to fail or malfunction. Examples of electronic equipment to avoid: Hearing aids, implanted pacemakers or defibrillators, other electronic medical equipment, and other automatic control equipment. Users wearing implanted pacemakers or defibrillators, or other electronic medical equipment should check with the manufacturer or sales outlet about the effect of radio frequencies on the equipment

f charging is not complete after the specified charging time has passed, stop charging.

If fluid etc. leaks out from the internal battery, do not let the fluid contact with the skin on your face or hands.

Be careful of the nib of the IC card opener for LGV35 (sample) when removing an article

To use the product in car, check with the automobile manufacturer or deplacts.

nanufacturer or dealer to determine how vehicle

devices are affected by radio waves before using.

In rare cases, the product's signals in some vehicle models can cause the vehicle's electronic equipment

to malfunction. In that case, stop using the product

The use of the product may cause reciming, recises, eczema, or other symptoms depending on the user's The use of the product may cause itching, rashes,

If you develop skin problems, stop using the product immediately, and see a doctor.
For materials of parts →P.24 "Material list"

Make sure that there is no adhered metal pieces (cutter blade, staples, etc.) as the speaker part of the

- 15 -

damage a part of your body such as fingers.

If the fluid etc. enters your eyes or mouth, or contacts skin or clothes, immediately flush the contacted area with clean water.

If the fluid etc. enters your eyes or mouth, immediately see a

Touching the nib of the IC card opener for LGV35 (sample)

May cause loss of sight or skin problems.

doctor after flushing.

may cause injuries.

Do physical condition.

Do product generate magnetism.

May cause fire, burns, or injuries, etc. due to overcharge.

 The Company is not liable for any damages arising from earthquakes, lightning, storms, floods or other natural disasters, as well as fires, actions by third parties, other accidents. under other unusual conditions outside the responsibility of the Company.

The Company is not liable for any incidental damages (change/ disappearance of described content, loss of business income disruption of business, etc.) arising from use or inability to use the product.

The Company is not liable for any damages arising from failure to

observe the described content of the "Instruction Manual". The Company is not liable for any damages arising, for example,

from malfunction caused by combination with connected devices or software not related to the Company. Captured image data or downloaded data may sometimes be

altered or lost due to faults, repair or other handling of the product. The Company is not liable for any damage or lost income resulting from recovery of these data.

 It is recommended you keep a copy of important data on your PC's hard disk, etc. Whatever the cause of the defect or malfunction may be, the Company assumes no responsibility for alteration or loss of saved data. Contents saved in the product, such as contacts, mails and favorites, might be altered or lost in an accident, fault, repair or

mishandling. Be sure to keep a copy of important contents. Note that Company assumes no responsibility for any damages or lost profits resulting from altered or lost contents. Note that contents (both charged or free content) saved with

the product cannot be taken over to the customer when it is replaced for repair of a fault. Although the display used on the product is made using high-

precision technology, some pixels (dots) might be lit or out at all times. Note that this is not a malfunction. · If an image is displayed for a long time, an afterimage may occur but

this is not a fault. To prevent afterimage and to conserve power, you are recommended to set the screen timeout time to a short time - 2 -

Make sure to turn off the product or stop charging before you get close to places such as a gas station where a flammable gas or dust can be generated. f using at the place where there is a possibility o

ignite or fire When using Osaifu-Keitai at a gas station, be sure to turn off the power in advance. (If NFC/Osaifu-Keitai lock has been set, cancel the lock

flammable gases being generated, may cause the gas to

before turning off the power.) If the product gives off a strange smell, noise, smoke, or overheats or becomes discolored or deformed

Do during use, charge, or storage, perform the following operations Remove the power plug from the outlet or accessory

socket. Turn the product OFF

Not doing so may cause fire, burns, injuries, or electric shock, etc.

ACAUTION

Do not use the damaged product.

Do not leave on unstable places, such as wobbly

tables or objects that are on an angle. Be particularly careful when the device has the vibration function turned on. May cause the device to fall and lead to injuries, etc.

- 9 -

Charging equipment

⚠ WARNING

Do not use the specified charger (sold separately) cable if it is damaged May cause fire, burns, or electric shock. etc.

Do not use the specified charger (sold separately) in a bathroom or other highly humid area. Don't May cause fire, burns, or electric shock, etc

Always use the specified DC adapter with a negativeground vehicle. Do not plug it into a positive-ground vehicle. May cause fire, burns, or electric shock, etc.

If it starts to thunder, do not touch the adapter.

May cause electric shock atc.

Do not short the external connection terminal while it is connected to an outlet or the accessory socket. Do not touch the external connection terminal with a part of your body such as your hands or fingers. May cause fire, burns, or electric shock.

Do not place heavy objects on the cord of the specified charger (sold senarately) or put avecage. as pulling the cord of the charger. May cause fire, burns, or electric shock, etc.

When connecting/disconnecting specified charger (sold separately) to/from an outlet, do not contact a metal strap or other metal objects with it. May cause fire hurns or electric shock etc.

- 16 -

able to make copies of any copyrighted data even by the above mentioned means. Do not discard this product together with regular trash

Please cooperate in the collection of the product (including optional accessories) when it is no longer needed to protect the environment and effectively use resources. Old product are collected at au shops and other places. "The Company" as appears in this manual refers to the following

You are recommended to store copies of individual data such as

photos you took, videos and music on your PC by sending each

file as mail attachment, etc. Note, however, that you may not be

companies: Sold by : KDDI CORPORATION OKINAWA CELLULAB TELEPHONE COMPANY

Imported by : LG Electronics Japan, Inc. Manufactured by : LG Electronics Inc.

memo

Reproduction of the content of this manual in part or in whole is The content of this manual is subject to change without notice.

· Every effort has been made in the preparation of this manual Should you notice any unclear points, omissions, etc., feel free to

and low-temperature), electric shock, broken bones, injuries with residual aftereffects from poisoning, etc., and injuries

temperature), electric shock, etc. that do not require hospital admission for treatment or long-term hospital attendance as an outpatient.

furniture, livestock, pets, etc.

Do not store the product in extremely humid, dusty or hot areas. May cause fire, burns, or electric shock, etc.

→P.36 "Notes on waterproof, dustproof and shock

- 3 -

When children use the product, parents or guardians should give them propor instruction should give them proper instructions and do not allow them to use the product in the wrong way. May cause injuries.



Be careful when using the product continuously for a long time or charging as it gets hot. Also, avoid Do touching the terminal for a long time by falling asleep unintentionally.

While using the terminal for a long time such as using application, calling, using data communication, watching videos, etc. or charging, the product, the internal battery, or the adapter may get hot. Directly touching a hot part for a long time, you may have redness, itching or rash on your skin, or it may result in low-temperature burns depending on your constitution and/or health condition

■ Main unit

DANGER

Do not throw the product into fire or apply heat. May cause fire, burns or injuries, etc.

- 10 -

Do not use an electric transformer for overseas (travel converter) with the specified state. converter) with the specified charger (sold separately). Don't May cause ignition, heating, or electric shock, etc.

Do not apply force on the connected parts when adapter is connected to the product Don't May cause fire, burns, injuries, or electric shock, etc.

Do not charge any parts wet with liquid such as drinking water, sweat, seawater or urine of the pet with Don't the wireless charger (sold separately). May cause fire, burns, injuries or electric shock, etc.

Do not touch adapter cord, external connection terminal or nower plus with May cause fire, burns, or electric shock, etc.

Only use with the specified power source and voltage. When charging the product overseas, use specified Do charger (sold separately) for global use. If incorrect voltage is used, it may cause fire, burns or

electric shock.
AC adapter: 100 V AC (Connect to an AC outlet for internal (sold separately) to/from the terminal, do not use force household use) and connect/disconnect straight without bending. AC adapter for global use : Between 100 V AC and 240 V not properly unplugged or plugged in, may cause fire AC (Connect to an AC outlet for internal household use) burns, injuries, or electric shock, etc. DC adapter: 12 or 24 V DC (specific for negative-ground Immediately stop using the product if the external

When replacing the specified DC adapter's fuse, replace it only with a specified fuse. Replacing with a different type of fuse might cause fire, burns, electric shock, etc. For specified fuses, see the instructions that come with the DC adapter.

Safety Precautions (Observe Strictly)

■ Before using the product, thoroughly read these safety precautions for proper use.

■ These precautions are intended to protect you and others around you. Read and follow them carefully to avoid injury. damage to the product or damage to property. ■ The signs below differentiate between the levels of danger

that can occur if the product is not used within the specified guidelines. This symbol indicates the potential and

A DANGER imminent danger of death or serious injury* to a person if the product is handled incorrectly. his symbol indicates the possibility of WARNING death or serious injury*1 to a person if the

This symbol indicates the possibility of minor injury*2 to a person or physical CAUTION minor injury— to a person or priyerce damage*3 if the product is handled incorrectly. *1 Serious injury: This refers to loss of sight, injury, burns (high-

product is handled incorrectly.

requiring hospital admission for treatment or long term hospital attendance as an outpatient. *2 Minor injury: This refers to injuries, burns (high- and low-

*3 Physical damage: This refers to extended damage to buildings,

- 4 -

Do not apply excessive force such as sticking a nail into the product hitting it with a little of the product o into the product, hitting it with a hammer, or stepping

May cause fire, burns or injuries, etc.

If materials inside the product enters your eyes or your mouth, do not rub your eyes and immediately flush Do them with clean water and see a doctor right away. May cause loss of sight due to the influence of the fluid, etc. inside the product.

• WARNING

Do not look directly at the light of the laser autofocus sensor. Don't May cause damage to your eyesight, etc

Do not lighten or flash the lighting part of the light close to person's ever Keep apparent distance. light close to person's eye. Keep enough distance especially from small children.

dazzled or surprised causing an accident. Do not lighten or flash the light to drivers of cars, etc. May disturb driving and cause an accident, etc.

Do not watch the display that blinks repeatedly for a long time. Don't May cause spasm, loss of consciousness, etc.

- 11 -

When you connect the specified charger (sold

fire, burns, or electric shock, etc.

hold the adapter to disconnect.

electronic medical equipment.

Do restoring the deformation.

short circuit of the charging terminal.

may cause fire, burns, electric shock, etc.

If you wears of medical equipment such as implanted pacemakers or defibrillators.

the use of the wireless charger (sold separately).

When connecting/disconnecting the specified charge

The product's signals may affect the performance of

connection terminal is deformed. Do not use it by

- 18

May cause fire hurns injuries etc or electric shock due to

Do connect it to the outlet.

Wine off any dust that attached to the power plug

ne terminal is used with dust adhering to it, may cause

separately) to an outlet or an accessory socket, firmly

If not firmly inserted, may cause fire, burns, electric shock, etc.

When you disconnect the power plug from an outlet or

an accessory socket, do not pull the specified charger

If the adapter cord is pulled on this may result in scratches

(sold separately) cord with excessive force. Instead,

■ Explanation of graphic symbols used in this manual to indicate actions that are not allowed and actions that must be done

that is not allowed. Indicates that Indicates an action that disassembly is not nust be obeyed at all allowed. Do times. ndicates that use Indicates that the in a place where the product is likely to get in a place where the power plug must be wet or allowing the power plug disconnected from the power plug power outlet.

■ Precautions common to the main unit, internal battery, charging equipment, au IC Card, LG TV antenna cable 01, IC card opener for LGV35 (sample), transparent cover (sample) cleaning cloth (sample), peripheral devices

not allowed.

DANGER

Do not use, store or leave the product in hot places (e.g. by a fire, near a heater, under a kntatsu or Don't bedding, in direct sunlight, in a car in the hot sun) May cause fire, burns, injuries, or electric shock, etc.

O not put the product into or near a heating cooking device such as a microwave oven or IH cooker, or high-Don't pressure container such as a pressure cooker. May cause fire, burns, injuries, or electric shock, etc.

- 5 -

Do not put foreign objects such as liquid like water (drinking water perspireties (drinking water, perspiration, seawater, urine of pet animals, etc.) metal pieces or burnable things into au IC Card inside the product or microSD memory card

Insert the au IC Card or microSD memory card in the correct place and in correct direction.

May cause fire, burns, injuries, or electric shock, etc.

Do not expose the camera lens to direct sunlight for an extended period. May cause fire, burns, injuries, etc. by the light-collecting mechanism of the lens.

When on board an airplane, turn the power of the product off or put it in Airplane mode.

Follow the instructions of each airline, because there are different restrictions for using the product on an airplane. The product's signals may cause electronic equipment of If you do a prohibited act such as using the product in an airplane, you will be punished according to law.

- 12 -

Always remove the power plug of the specified charger (sold separately) from an outlot or an analysis of the specified charger

power plug If the power plug is left plugged in, may cause fire, burns,

Immediately remove the power plug from an outlet or an accessory socket if water (drinking water, perspiration,

power plug Adhesion of such fragments may cause fire, burns, or

May cause fire, burns, electric shock, etc

Always remove the power plug from an outlet or an accessory socket when alcohold in the control of the control

ACAUTION

seawater, urine of pet animals, etc.) gets into the adapter

Unplug socket when not using the adapter

injuries, or electric shock, etc.

electric shock, etc.

When using the product in a medical facility, be sure to observe the regulations of the facility. Turn the product off where its use is prohibited The product's signals may cause electronic equipment or electronic medical equipment to fail or malfunction.

When using the handsfree call, ringtone is ringing with loud sound or in the attail." with loud sound, or in the standby mode, be sure to keen the product off of the ears. Also, when playing games, video, or music with an earphone microphone connected to the product, adjust the volume to the

When using the handsfree call, loud noise sounds from the

suddenly. Jsing continuously for a long time with too loud volume may

Be careful when setting vibrator (vibration) or ringtone

if your heart is weak.

If you wear an electronic medical device, etc., check with the equipment manufacturer or sales outlet to Do determine how the device is affected by radio waves

The product's signals may cause harmful effect on the

When the display or camera lens is accidentally When the display or camera let is is accordingly, broken, be careful of broken glass or exposed internal Do parts of the product.

If the internal battery leaks or gives off a strange smell, immediately stop using and are smell, immediately stop using and move it away from

May cause leaking fluid to ignite or explode

- 13 -

• DANGER

The LG TV antenna cable 01 does not have waterproof function. Do not let the it get wet with water. Do not Not liquids use in places subject to direct splashing with water. pet urine or other liquids. And do not touch it with wet

Doing so might result in faults resulting from overheating, fire, electric shock, injuries, shortcircuiting of electronic

get dirty. May cause a fault.

The use of the product may cause itching, rashes, eczema, or other symptoms depending on the user's physical condition. If you develop skin problems, stop using the product immediately, and see a doctor.

plug into/from the earphone jack in a straight line

- 20 -

- 19 -

Indicates that handling with wet hands is not Indicates an action with wet hands is not

> hit against surroundings or being put between the obiects. Doing so may cause fire, burns, or injuries, etc. due to internal battery damage. * Examples to avoid

Don't to which sand or others adhere

resistance properties"

resistance properties"

Don't animals, etc.).

Sitting or squatting with the product put in a pocket of trousers or skirt Putting the product in a pocket of outer wear and

Do not put sand, dirt, or mud on the product or put it on them directly. Do not touch the product with hands

For the waterproof and dustproof functions, refer to the

→P.36 "Notes on waterproof, dustproof and shock

May cause fire, burns, injuries, or electric shock, etc.

For the waterproof function, refer to the following.

→P.36 "Notes on waterproof, dustproof and shock

Do not subject the product to strong pressure or break

the product. Especially when bringing the product

putting in a pocket of clothes, do not let the product

Do not charge when the product is wet with water (drinking water, perspiration, seawater, urine of pet

catching them in a door or a door of a car Stepping on the product on a soft object such as a sofa, bed, or bedding, or on a floor

Do not disassemble or remodel the equipment. May cause fire, burns, injuries, or electric shock, etc.

cause a hearing loss, etc.

- 6 -

proper level.

product. Even in the standby mode, ringtone and vibrator may work

And, if you cannot hear the sound around you clearly, it may cause an accident.

Surprised by sudden vibrate ringtone (vibration) or ringtone, it may cause harmful effect on heart.

before using the product.

electronic medical device, etc.

If you mistakenly touch broken or exposed parts, it may cause burns, injuries or electric shocks, etc.

the vicinity of open flames

■ LG TV antenna cable 01

hands

ACAUTION

Do not let the LG TV antenna cable 01 connecting plug

Insert or remove the LG TV antenna cable 01 connecting

For materials of parts →P.24 "Material list

Do not touch the specified charger (sold separately) for a long time while they are connected to an outlet

au IC Card • CAUTION

Don't or accessory socket.

May cause burns, etc

Be careful of the cut surface when handling au IC Card as it may damage a part of your handling. as it may damage a part of your body such as fingers, May cause injuries, etc. by the sharp cut surface.

- 17 -

⚠ WARNING

The end of the IC card opener for LGV35 (sample) is sharp. Do not use pointed at yourself or other people. May hit yourself or other people resulting in injuries or loss of sight.

CAUTION

The use of the product may cause itching rashes eczema, or other symptoms depending on the user's physical condition. If you develop skin problems, stop using the product immediately, and see a doctor. For materials of parts →P.24 "Material list"

Store in a place where small children cannot reach. or injuries

■ Transparent cover (sample)

! CAUTION

Do not get your fingers caught when attaching the transparent cover (sample). Don't May cause injuries, etc.

If you feel any abnormality with your skin, immediately consult a dermatologist. Itching, rashes, eczema, etc. sometimes occurs depending on your physical constitution and condition.
For materials of parts →P.24 "Material list"

- 21 -

 Do not allow conductive foreign objects (metal fragments, pencil leads, etc.) to come into contact with or get inside the connection terminal, earphone terminal, etc. to avoid the connection terminal earphone microphone terminal, etc. from short-circuit

- If the product gets wet while charging, immediately disconnect the power plug of the specified charger (sold separately)
- Do not use while driving a car or riding a motorbike or bicycle or while walking. Use while driving a car or riding a motorbike is rohibited by law. Use of a cell phone while riding a bicycle may be punishable by some regulations.
- Using or charging the product inside a bag or covered with bedding, etc. may cause malfunction. When using a charging equipment or external device, insert/
- remove the connector straight to/from the terminal. Make sure the orientation of the connector. Unless it's correct, it may cause malfunction
- Do not expose the camera lens to direct sunlight for an extended period. May cause malfunction.
- Do not store or leave the product in places subject to direct sunlight (e.g. in automobiles), places that get hot, places that get extremely cold, or in humid or dusty places. May cause malfunction Do not leave the equipment on unstable or sloping surfaces.
- Be careful especially while charging or the vibrator is set. The product might fall causing malfunction Do not use power outlets or wiring apparatus beyond its rating
- hen charging the product, for example, by connecting multiple devices to a single power strip.

■ Main unit

 The product's battery is built in, and cannot be replaced by the customer. For battery replace nent, contact an au shop or Customer Service Center

 Do not forcefully press, strike, or intentionally subject the display to strong impact. May cause scratching or damage

- 28 -

■ Transparent cover (sample)

 Do not force the transparent cover (sample) May cause it to break or damage.

 When disposing of it, follow the rules regarding disposal in your area. Cleaning cloth (sample)

• Do not force the cleaning cloth (sample) when you clean the product May cause damage of the product and the display, wrinkles of

protective film. ■ Copyrights and rights of portrait

You are not allowed to copy, distribute, publish, modify or edit

the data you shot, recorded or downloaded using the product without the consent of the copyright holder, except for personal use, under the copyright law. line difficency from the coupying row.

In addition, do not use or modify portraits or names of other individuals without their consent, as it might infringe on rights of

te that shooting and recording may be restricted at some live

performances, shows and exhibitions even for personal use.

 Be careful about the copyright and portrait right when posting images you shot, etc. on Internet homepages

■ Backup content on the product

 Please back up important content recorded or downloaded for the product to an outside source. Content recorded to memory on the product sometimes disappears or is altered by unexpected factors, such as static electricity or a fault, repair, mishandling, etc.

■ FCC Compliance information

The product is certified by Federal Communications Commission

FCC ID of this product is ZNFQVR. Or you can check as follows.

<How to check>> On the Home screen ▶ [Settings] ▶ "General" tab ▶ [Regulatory & safety] - 35 -

Cleaning cloth (sample)

♠ CAUTION

If you feel any abnormality with your skin, immediately consult a dermatologist.

Itching, rashes, eczema, etc. sometimes occurs depending on your physical constitution and condition For materials of parts →P.24 "Material list"

■ Use of this product near medical equipment and inside a medical facility

⚠ WARNING

Wearers of medical equipment such as implanted pacemakers or defibrillators must carry and use the Do product at least 15 cm away from the implanted device. The product's signals may affect the performance of

electronic medical equipment.

When electronic medical equipment other than implanted pacemakers or defibrillators. implanted pacemakers or defibrillators are in use Do outside of medical facilities (such as in home care settings), check with the device manufacturer to determine how the device is affected by electrical The product's signals may affect the performance of

electronic medical equipment.

- 22

 Do not forcefully press your fingernails, sharp objects, or hard objects against keys or display surface. May cause scratching or damage.

The touch panel is designed to be lightly touched by fingers. Do not apply strong pressure with your fingers or sharp-pointed objects (such as fingernails, ballpoint pens, and pins) on the touch panel.

 In the following cases, the touch panel may not work even if you touch it. Note that it may cause malfunct Operation with gloved hands / Operation with fingernails Operation with a foreign object placed on the touch panel / Operation with a protective sheet or sticker on the touch panel / Operation with water drops left or frozen on the surface / Operation with wet or sweaty fingers / Operation under water

 Never use modified products. Use of a modified device violates the Radio Law and Telecommunications Business Law. The product has acquired the certification of conformity with technical regulations for the specified radio station based on the Radio Law, and to such regulations as technical conformity based on the Telecommunications Business Law. And the "Technical Conformity Mark 😭" is checkable on the product as a certificate.

On the Home screen ▶ [Settings] ▶ "General" tab ▶ [Regulatory If the product is modified, technical standard compliance

becomes invalid. Never use the product without the valid certification. Doing so violates the Radio Law and Telecommunications Business Law.

 Take care not to place magnetized items such as magnetic cards, speakers and TV sets near the product, as it might cause malfunction. Putting a strong magnetism close to the product

might cause false operation Do not bring magnetic cards such as cash cards, credit cards, and prepaid cards near to the product. May result in loss of

recorded information.

- 29

Notes on waterproof, dustproof and shock resistance properties

This product has a protection-rated (JIS C 0920) at IPX5*1 and IPX8*2, as well as a dustproof property equivalent to IP6X*3 on the condition that the card tray is securely attached (based on in-house testing).

The product also meets 14 ruggedization test of the US Department of Defense's MIL-STD-8 I OG standards' 4 (by Company test methods). Product capabilities are confirmed in a test environment, and does not guarantee capabilities under all conditions of actual use. No guarantees are made with regard to non-breakage or non-fault.

Before using the product, thoroughly read "Important items to member before use" to ensure correct use. Failure to follow the contents described in these sections may cause the ntrusion of water, sand or other foreign material, resulting in overheating, fire, electric shock, injury or a fault,

- IPX5 equivalent means that the product will maintain its operability as a phone even if it is sprayed with water from a 6.3 mm diameter nozzle at a distance of about 3 meters for more than 3 minutes at a rate of about 12.5 liters per minute from any direction.
 *2 IPX8 equivalent means that the product will maintain its operability
- as a phone with no water getting inside the main unit even if it is gently submerged in a tank of still tap water at room temperature to a depth of 1.5 meter for about 30 minutes.
- *3 IP6X equivalent means that the product will securely maintain its function of no grit and dust getting inside the main unit even after it has been placed in an apparatus with grit and dust of diameters of 75 μ m or less and shaken for 8 hours (ingress of grit and dust cannot be prevented completely).

Make sure that the product will not emit any signals Material list (turn off power, put it in Airplane mode, etc.) if within <Main unit>

15 cm of those around you, such as where crowded and you cannot move freely. arers of implanted pacemakers or defibrillators may be

nearby. The product's signals may affect the performance of electronic medical equipment.

Obey rules inside medical facilities regarding use of the terminal in such facilities.

The product's signals may affect the performance of electronic medical equipment.

■ Laser Safety Statement

This product employs a laser system. To ensure proper use of this product, please read this owner's manual carefully and retain for future reference. Should the unit require maintenance, contact the Customer Service Center or Repair and Delivery Service Center Use of controls, adjustments, or the performance of procedures ther than those specified herein may result in hazardous radi exposure. To prevent direct exposure to laser beam, do not try to onen the enclosure or make direct contact with the lase

LASER PRODUCT LASER PRODUKT LASER LAITE LASER APPARAT PRODUIT LASER LIOKAN

 When you put the product in your pocket or bag, take care so that the display does not come in contact with metal objects or other hard objects. May cause scratching or damage. Also, be careful not to scratch or damage the display by using a strap whose metal or other hard part comes in contact with the display.

- 23

 When suddenly brought into a warm place from a cold place. or when in a humid location, or when used where temperature suddenly changes such as near the air discharge port of an air conditioner, water droplets (i.e. condensation) sometimes form inside the product. Note that when used under conditions such as this, the humidity might cause corrosion or a fault.

- While writing/reading data to/from a microSD memory card, do not subject the product to vibration or impact or turn off the power. May cause loss of data or a fault.
- Do not cover the illuminance sensor with your finger or put a sticker on it. May hinder the sensor from detecting the ambient light level and functioning correctly. When you put a sticker, etc. on the proximity sensor, the sensor
- vill malfunction and indications on the display will turn off at all times while receiving or making a call. In this case, note that you may not be able to operate the product. Use the product with the card tray, etc. closed. If the covers are open, dirt or water may get inside causing malfunction.
- Do not allow liquids, metal objects, and other foreign matter to get inside the au IC Card and microSD memory card slot inside
- the product. May cause malfunction. Do not drop, throw, or step on the product or give a strong force or vibration to it. May cause malfunction.
- Do not place the product directly on sand at a beach, etc. Sand or other small particles might get inside the earpiece microphone or speaker etc., causing the volume to drop. If sand gets inside the product's main unit, it might cause malfunction

- 30

*4 14 categories of MIL-STD-810G

item	Contents of the test
ow Pressure Operation)	Tested continuously for 1 hours (57.2 kPa/ equivalent to altitude of about 4,572 m)
igh Temperature Operation)	Tested in an operation environment of 43°C continuously for 4 hours, and a storage
igh Temperature Storage)	environment of 63℃ continuously for 4 hours
ow Temperature Operation)	Tested in an operation environment of -21°C continuously for 4 hours, and a storage
ow Temperature Storage)	environment of -33°C continuously for 4 hours
emperature hock	Tested by subjecting to sudden temperature change from -21 to 43°C continuously for 2 hours, repeated for 3 times
olar Radiation	Tested by subjecting continuously for 24 hours to maximum light quantity 1,120 W/m² (maximum temperature 49°C) followed, repeated for 3 days
lowing Rain	Tested by subjecting to rainfall of 2 cm/hour, 15 minutes
umidity	Tested by subjecting continuously for 15 days (humidity 88-95%, temperature 31 to 41°C)
alt Fog	Resistance to salt water tested by subjecting continuously for 24 hours to salt fog and then drying for 24 hours, repeated for 4 days
and and Dust	Dust resistance tested by subjecting to dust continuously for 6 hours (wind 8.9±1.3 m/sec, concentration 10±7 g/m²)
nmersion	Tested by immersing in approx. 1 ± 0.1 m of water for 30 minutes
bration	Tested by subjecting to vibration for 3 hours (in 3 directions at 1 hour each/20 to 2,000 Hz)

 Putting stickers or sheets (e.g. commercially available protective films, peep prevention sheets) on the display might cause mproper reaction of touch panel.

 When carrying the product in your pocket or bag, take care not to put the touch panel close to metals or other conductive materials, as it might cause false operation of the touch panel.

■ Organic EL (OLED) display

Part

Outer case (front, top and

Outer case (front, left and

JSB connection termina

terior case decoration

amera lens decoration

amera lens decoration

wer key decoration

Power Cloud Silver, Aurora Epoxy resin

nd bottom, left and right)

arpiece (receive

olume key

Card tray

nside)

mera lens

Material

Aluminum

Aluminum

Aluminum

Aluminum

Reinforced gla

Surface treatment

eamed

Anodic oxidation

Black printing

/D coating

nodic oxidatio

Anodic oxidation

Anodic oxidation

Anodic oxidatio

Urethane coating

 The lightning intensity of OLED may be decreased partly and the color of OLED may be changed, when the same image has been displayed for a long time, the brightness of display is set to be brighter than necessary, or the extreme continuous use is performed. It is not abnormal because that is the characteristic of OLED

 Although the organic EL (OLED) display used on the product is made using high-precision technology, some pixels (dots) might be lit or out at all times. Or color may be changed or unevenne of brightness may be shown if looked at from different angles. Note that that is because of the structure of OLED display, not

 Leaving the OLED exposed to the direct sunlight might cause a fault. Take care when you place the product by the window or outside.

Internal battery



(The internal battery of the product is a lithium-ion battery) When you purchase your product, the internal battery is not fully charged. Charge the battery before using the product. Also charge the battery before using the product if you have not used the product for a long time.

sted by dropping from about 1.22 m in 10

Contents of the test

- 31 -

Proper operation of the product in every possible condition during actual use is not guaranteed. Malfunctions determined to be caused by mishandling by the customer are not covered

Important items to remember before use

· Make sure that the card tray is tightly closed. Waterproofness is only effective when the covers are securely closed.

• Do not open/close the card tray if your hands or the main unit is wet. · Do not splash the product with or immerse it in liquid other than tap water (seawater, a swimming pool, hot spring, soap, detergent or water with bath salts, alcohol, juices, seasonings, etc.). Do not

use in places subject to direct splashing with pet urine. · If any liquid falls on the product, immediately rinse it off with tap water







• Do not place the product directly on the sand at a beach, etc. Sand or other small particles might get inside the earniece microphone or speaker, causing the volume to drop. If sand gets inside the product's main unit from the hinge part, etc., it might cause overheating or a fault.

<LG TV antenna cable 01>

Material	Surface treatment
TPE resin	-
TPE resin	-
TPE resin	-
Brass	Gold plating
	TPE resin TPE resin TPE resin

Material Surface treatment Part

Part	Material	Surface treatment				
Transparent cover (sample)>						
lain unit	SUS304	-				

UV coating

PC resin

<Cleaning cloth (sample)

Main unit

i di t	Iviatoriai	ouriace deadneric
	Polyester 70%,	-
	Nylon 30%	

recommended to charge the product before use.

The internal battery is a consumable item. If the performance of

type, an au shop will accept holding over and repair for a charge. You may not use the product for a certain period. Please be

forewarned. The life time of the internal battery depends on the

The internal battery sometimes swell up as they approach the

end of their service life. This is due to the properties of lithium-

Do not wrap the cord of the specified charging equipment (sold separately) around the adapter itself. Do not forcibly bend a

the connector and power cord. Do not place heavy objects on the adapter cord or USB cable, or apply unnecessary force by

(sold separately) from the power outlet or accessory socket, hold

plug of the charging equipment or the connection between

When unplugging the plug of the specified charging equipment

and pull the power plug. Pulling on the cable might damage it.

Do not stick metallic items (such as stickers that contain metal)

- 32

Do not leave the product in a humid place such as a bathroom or

Even after water is drained, the inner parts might be still wet. Although you can use the product, do not place it near things

that must not get wet. Take care not to wet your clothes, bag or

Drain water if it becomes temporarily hard to hear the sound due

Avoid spraying the product with high-pressure water or submerging it in water for extended periods of time, as the

product is not designed to withstand high water pressure.

Do not wash the product in a washing machine or ultrasound

Do not immerse the product into a bathful. The product is not.

Extreme changes in temperature cause condensation resulting in a malfunction. Wait until the main unit reaches room temperature

before you bring the product from a cold place into a warm

Make sure that the card tray is securely closed. Just a small

Do not attach/remove the card tray with gloved hands. Just a

mall particle (a hair, etc.) on the seals can cause water leaks.

Wipe off any minuscule droplets of water or dirt with a clean dry

For details on closing the card tray, refer to "Basic Manual" and

alcohol) gets on the product, immediately rinse it with plain water

particle (a hair, etc.) on the seals can cause water leak

If the card tray is deteriorated or damaged, the waterproof

• If any liquid other than plain water gets on the product

If any liquid other than plain water (e.g. seawater, detergent

to water remaining in the microphone or earpiece.

designed to withstand the hot temperatures.

· This product does not float on water.

cloth before closing the covers

property becomes ineffective

Basic Manual application".

Card tray

wireless charger (sold separately) or the back of the product.

strongly pulling them, etc. May cause malfunction.

Doing so may result in a malfunction.

Do not use the product underwater.

contents of the bag.

kitchen for an extended period of time.

ion batteries, and is not a problem in terms of safety.

Charging equipment

■ Wireless charging

Handling Precautions

These precautions are provided to prevent damage to the product and ensure that performance can be fully demonstrated. Thoroughly read these precautions to ensure correct use.

■ Precautions common to the main unit, internal battery, charging equipment, au IC Card, LG TV antenna cable 01, IC card opener for LGV35 (sample), transparent cover (sample), cleaning cloth (sample), peripheral devices Do not apply excessive force to the product during use. Be

sure not to put the product into a tightly packed bag or place a heavy object on the product in a bag. Sitting on the product in your pocket might damage the display or internal circuit board resulting in a malfunction. Keeping an external device connected to the external connector or earphone jack might damage the connector resulting in a malfunction. Such damage and malfunction are not covered by the warranty, even if there is no external damage.

To ensure waterproof property (equivalent to IPX5 and IPX8) of this product, use the product with the card tray tightly closed. Note that the waterproof property is not guaranteed in every usage condition. Do not allow water to get inside the product or splash water on the charging equipment or optional accessories Do not attach/remove the card tray in the rain or with water drops on the surface of the product. May cause water intrusion resulting in internal corrosion. Malfunctions determined to be caused by water intrusion are not covered by the warranty.

 Do not use the product in extremely hot, cold or humid places. (Use within an ambient temperature range of 5°C to 35°C and humidity range of 35% to 85%.) Peripheral devices

- 26 -

 Use in very hot or cold environments, for example, when left in a car with the windows closed in summer, will cause the battery Although the information light on the wireless charger (sold) separately) may remain on after the product has finished capacity to drop and shorten the available battery usage time charging, this is not a fault. This will also shorten the battery pack service life. Try to use the internal battery as far as possible at room temperature. Charging may stop just before the battery is fully recharged.

• If charging stops before the battery is fully recharged, charging After the internal battery is charged, battery power decreases bit by bit even if the product is not used. The internal battery Depending on the Qi specification-compatible product, charging may be discharged if the product is not used for a long time. It is

nay repeatedly start and stop. Charge this product with an au approved product. the internal battery does not recover (e.g. the usable time after each charge has become extremely short), the battery is at the end of service life, so stop use. Because the battery is a built-in If the temperature exceeds a certain level, charging may stop or take a long time, but this is not a fault. Please wait for the temperature to decrease.

 Place the wireless charger (sold separately) on a flat, stable surface and charge the product. Turn off the vibration function when charging wirelessly. If the product rates, it may not fully charge or fall off the wireless charger.

 Remove any cases, covers, plastic film stuck by your own stickers, and so on attached to the product before charging.

 Check that the wireless charger and the product are not wet. Do not wirelessly charge the product while it is connected to the optional AC adapter or Type-C cable.

 Keep the product away from devices that support wireless charging. Otherwise, the au product you wish to charge may not be detected correctly and may not be charged.

If the product receives interference from a radio or TV, use the product as far away from the radio or TV as possible.

 Depending on the Qi specification-compatible product, it ma not receive calls while charging. Charge this product with an auapproved product.

Depending on the Qi specification-compatible product, charging may not be able to start due to mutual interference with the Osaifu-Keitai® function. Charge this product with an au-approved product.

- 33 -

· You can wash the product under a mild flow (up to 6 liters per minute) of tap water at room temperature (5°C to 35°C) at a distance of about 10 cm from the faucet or showerhead.

If the product gets dirty, instead of using a brush, wash it with your hands holding the card tray so that they do not open After the product gets wet

After the product gets wet, drain water, and wipe the main unit and the card tray with a clean dry cloth without removing the card tray. In cold climates, water on the main unit may turn to frost. Using the product with frost may cause a fault. Do not leave the

Rubber seals

Rubber seal in the card tray plays an important part in waterproof property. Do not damage or remove the rubber seals.

 Take care not to get the rubber seals caught when closing the card tray. Forcibly closing the cover with the rubber seals caught may damage them resulting in loss of waterproof property. Just a small particle (a hair, etc.) on the seals can cause water leak If any liquid other than plain water (e.g. alcohol) gets on the

rubber seals, it may cause deterioration in durability

product without wiping off water.

 Do not insert the sharp pointed object in the card tray. May damage or deform the product or damage the rubber seals, causing water leak.

It is recommended to replace the parts for maintaining waterproof property once every two years regardless of whether any abnormality is present. For information on part replacement, contact an au shop near you.

Do not immerse the product into boiling water or splash boiling water

assumes usage in daily situations; subjecting the product to cessive shock such as by throwing or causing/letting the

 Do not use the product in extremely hot, cold or humid places.
 (Use within an ambient temperature range of 5°C to 35°C and humidity range of 35% to 85%. However it can be provisionally sed if it is 36°C to 40°C.) - isai V30+ main unit

- au IC Card (when attached to the product unit)

 Do not use in places subject to lots of dust or vibration. May cause malfunction. Occasionally clean the external connection terminal and earphone terminal with a dry cotton bud. Dirty terminals may

minals as this may deform them. Clean the product with cleaning cloth (sample) or a soft dry cloth (such as the type used for eyeglasses). Forceful rubbing with a dry cloth may scratch the display. The display may be stained if splash or smear is left attached to the surface. Wiping

cause malfunction. Use as far away as possible from land-line phones, TVs, and

radios. Use nearby might affect them. The product may become warm while charging etc., depending on the situations, but this is not abnormal.

Do not place near corrosive chemicals or in places where corrosive gas is generated. May cause malfunction.

Do not use outside when you can hear thunder. May risk.

 Be sure to use only the specified peripheral devices. Use of other devices might cause malfunction

 The customer is not allowed to disassemble, modify or repair the product. May cause malfunction. Modification of the product is in violation of the Radio Law and Telecommunication Business Act.

- 27 -

 If you run an application on the product while it is being charged wirelessly, it may not fully charge. Although the product may become warm while it is on the

• Reception quality may decrease while the product is charging on

level may decrease, even if the product is left as is

exert excessive force when inserting the card into your au cell phone

Do not put stickers, etc. on the au IC Card.

 Do not damage the card (use in a hot place, throw into fire. ontact the metal part with foreign object, give an impact, bend, apply a load, moisten, etc.). May cause data loss or malfunction.

When photographing important occasions, take a trial shot in advance and check the shot image to make sure it is correctly shot.

■ IC card opener for LGV35 (sample) Do not force the IC card opener for LGV35 (sample). May cause

- 34

roof. Be sure to check the following points before and after

burns, injuries, or electric shock.

as in a hathroom, shower room, kitchen or washroom, Failure o do so might cause fire, burns, electric shock, or malfunction Do not bring them into a bathroom, etc. even when you are not charging with them. Failure to do so might cause fire, burns, electric shock, or malfunction

Precautions on charging

charging. Never charge the battery if the main unit is wet. May cause fire,

Check that the main unit is not wet. If you are charging the battery just after the product gets wet, drain water well and wipe remaining water off with a clean dry cloth before charging.

Do not touch the specified charging equipment (sold separately) with wet hands. May cause electric shock.

- 41 -

Heat resistance

on it. The product is not designed to withstand the hot temperatures Shock

The product is resistant to shock, but product shock resistance

product fall forcefully may break the product.

result in a poor connection. Also do not forcefully clean the

the product using alcohol, thinner, benzene, detergent, glass cleaner, etc. might erase the printing on the outer casing or

ightning strikes and electric shock.

 Do not put the product into a heating cooking device such as a nicrowave oven or high-pressure container. May cause malfunction

vireless charger (sold separately), this is not a fault.

• Do not move the wireless charger (sold separately) and the product while it is charging. • After the product has finished charging, the remaining battery

Do not forcibly remove or insert the au IC Card. Be careful not to

 You are responsible for any damage caused by inserting your au IC Card into some other IC card reader/writer, etc

Do not insert au IC Card with a conversion adapter. May cause

Do not shoot where shooting is prohibited.

■ LG TV antenna cable 01 LG TV antenna cable 01 is not covered by the warranty.

it to break or damage.

The supplied and optional accessories are not waterproof.

Do not splash water over the specified charging equipment (sold separately) when using them. Do not use them near water such,

- 38 -- 40 -- 39 -

Draining water after wetting the product

- After the product gets wet, be sure to drain water from the power
- If you use the product after it gets wet, water remaining in those parts might wet your clothes or bag, or the sound might become hard to hear.
- Follow the steps below to drain water.
- 1 Carefully wipe the moisture off the main unit with a dry towel, cloth, etc.


2 Hold the product firmly and shake it about 20

times in the direction of the arrow shown in the figure until water drops no longer fly off. When shaking the product, confirm the safety around you

and hold it firmly so as not to drop it. 3 Cover the power key and volume key with a towel,

cloth, etc. and press each key two to three times. 4 Wipe the moisture coming out from inside with a

dry towel, cloth, etc.





Depending on applications, microSD memory card is required when using the application.

- 42 -

- Some applications prohibit the product from entering sleep mode while they are active, or rapidly drain the battery while running in the Operational procedures and screen appearances of the applications
- preinstalled in the product and those installed by you are subject to change without notice as a result of version upgrade. In addition. operating procedures described in this manual may differ from the

Cell Phone Etiquette

Use of the product is not allowed in the following places!

- Do not listen to music, watch videos or TV while driving a car or riding a motorbike or bicycle. Use of cell phones while driving a car or riding a motorbike is brobibited by law. (Use of cell phones while riding a bicycle may also be punishable by law.) In addition, stay alert to the traffic around you even when walking. Surrounding sounds may not be heard clearly, and gazing at the screen might distra your attention causing a traffic accident. Be especially careful at railroad crossings, on a platform, and at pedestrian crossings.
- Use of cell phones on board is restricted. Follow the instructions

Consider people around you

- To prevent ringtone from bothering other people, not only refrain from making a call but also power off or use Silent mode at a movie theater, theater, museum, library, etc.
- In a city area, use in a place where you do not bother people walking
- It is extremely dangerous to walk while looking at the screen of the cell phone. Do not make calls or operate a cell phone while walking or by stopping suddenly.

From au cell phones

- 49 -

For inquiries, call:

Customer Service Center For general, charge, operations (toll free) Business hours 9:00 – 20:00 (7 days a week)

157 area code not required Pressing "zero" will connect you to an operator, after calling" 157" on your au cellphone.

case above numbers are not available,

110120-977-699 (Okinawa)

For service canceling procedure in case of loss or theft (toll free isiness hours 24-hour (7 days a week) From au cell phones

113 area code not required

Repair and Delivery Service Center

For loss, theft or damage (toll free) siness hours 9:00 - 20:00 (7 days a wee



OKINAWA CELLULAR TELEPHONE COMPAN' Manufactured by: LG Electronics Inc

5 Place it on a dry towel, cloth, etc. and let it dry at ambient temperature. (Around 30 minutes)

If it is not fully dried, the sound may become hard to hear. Let it fully dry before use.

Bluetooth®/Wireless LAN (Wi-Fi®) Function

- · The Bluetooth® function and the wireless LAN (Wi-Fi®) function of this product conforms to the domestic standards of Japan, FCC standards, and EC directives, and has been certified. · In some countries and regions, use of the Bluetooth® and
- wireless LAN (Wi-Fi®) functions may be restricted. Before you start using the product overseas, check the relevant laws and regulations of the country/region you visit.
- The 2.4 GHz band used by wireless LAN (Wi-Fi®) and Bluetooth® devices is shared by various other devices. For this reason, the communication speed and connectable range may be decreased, or disconnection may occur, due to interference from other devices.
- or other magnetized devices.
- increase noise and prevent it from performing communications (This product is particularly susceptible to noise when it used near a microwave oven.)
- cause recention interference and disrupt TV images
- The searching might not be successful if there are multiple wireless LAN (Wi-Fi[®]) access points near to the product or the same channel is being used.
- of each airline.
- The communication speed and connectable range vary depending on the distance between communication devices, obstacles and the devices to connect.

- 43 -

- shinkansen, a hotel lobby, etc.
- · Be careful not to be loud while talking.
- · Be careful of sound leakage from earphones in trains or other places with many people around you.
- Ask permission if you take photos with your cell phone camera.
- When using the camera, follow common rules of etiquette regarding camera use.
- mode" or turn off beforehand.
- where the use of the product is prohibited or is not allowed to be brought in, follow the instructions of that medical institution.

Specific Absorption Rate (SAR) of Cell Phones

This model "isai V30+" mobile phone complies with Japanese technical regulations and international guidelines regarding exposure to radio waves.

technical regulations regarding exposure to radio waves*1 and limits to exposure to radio waves recommended by a set of equivalent international guidelines. These international guidelines were set out by the International Commission on Non-Ionizing Radiation ntection (ICNIRP) which is in collaboration with the World Health Organization (WHO), and the permissible limits include a substantial safety margin designed to assure the safety of all persons, egardless of age and health condition

The Japanese technical regulations and international guidelines define the limits using a unit of measurement known as the Specific Absorption Rate (SAR), which represents the average amount of radio frequency energy absorbed by the human. The SAR limit for mobile phones is 2.0 W/kg. The highest SAR value for this mobile phone when tested for use at the ear is 0.455 W/kg*². The highest SAR value for this mobile phone when tested for use on the body is 0.475 W/kg*². There may be slight differences in SAR levels among

- 50 -

- This product has been granted the licenses which code (i) AVC standard compliant video (hereinafter stated as AVC video) based upon the AVC Portfolio License for the individual use of customers, and non-commercial use, and/or the licenses which decode (ii) VC-1 video, (this is restricted to the AVC video that has been coded by customers who are not engaged in individual, and commercial activities, and/or pertains to the provision of coded AVC video from video providers who have been granted the licenses). For any other purposes, licence is not permitted even for the implied usage. Additional information may be obtained from MPEG LA, LLC, Refer to http://www.mpegla.com
- This product has been granted the licenses which code (i) VC-1 standard compliant video (hereinafter stated as VC-1 video) based upon the VC-1 Patent Portfolio License for the individual use of customers, and non-commercial use, and/or the licenses which decode (ii) VC-1 video. (this is restricted to the VC-1 video that has been coded by customers who are not engaged in individual, and commercial activities, and/or pertains to the provision of coded VC-1 video from video providers who have been granted the licenses). For any other purposes, licence is not permitted even for the implied usage. Additional information may be obtained from MPEG LA, LLC. Refer to http://www.

2.4 GHz Frequency Band Precautions

The frequencies used by the Bluetooth® and/or wireless LAN (Wi-Fi®) function of this product are in the 2.4 GHz band. In this frequency and, other similar wireless stations, in-plant wireless stations for mobile unit identification that require a license to use, such as factory production lines, specific small power wireless stations that do not require licenses, amateur wireless stations (collectively called other wireless stations" from here on) are operated in addition to home electrical appliances such as microwave ovens, devices for industrial, scientific and medical devices.

1. Before using the product, make sure that "other wireless stations" are not in operation nearby.

- 2. In the event that instances of radio wave interference have occurred between this product and "other wireless stations", immediately either relocate this product or stop operation of the device (stop the emission of radio waves).
- If you are unclear on any points or are troubled by anything, contact an au shop or Customer Service Center.

memo

The connections between this product and all other Bluetooth® and wireless LAN (Wi-Fi®) devices have not been confirmed. Therefore connections with all Bluetooth® and wireless LAN (Wi-Fi®) devices have not been confirmed.

that are compliant with the Bluetooth® and wireless LAN (Wi-Fi® standard specifications, but the security may not be sufficier depending on the usage environment and configuration. Be careful when making data communication using Bluetooth® or wireless LAN

- 44

individual products, but they all satisfy the limit. The actual SAR of this mobile phone while talking on the phone can be well below that indicated above. This is due to automatic changes in the power level of the mobile phone to ensure it only outputs the minimum power required to communicate with a base station. Therefore in general, the closer you are to a base station,

ear. Use an accessory such as a carrying case, etc. so that you can hold the product at least 1.5 cm away from your body and also do not contain metal parts between the product and your body. By doing this, this mobile phone complies with Japanese technical regulations and international guidelines regarding exposure to radio waves. The World Health Organization has stated that present scientific information does not indicate that use of mobile devices has any harmful effects on the human body. They recommend that if you are still worried about your exposure then you can limit your talk time or use a handsfree kit to keep the mobile phone away from your head

If you would like to know more detailed information, please refer to the WHO website http://www.who.int/docstore/peh-emf/publications/facts_press/

fact english.htm

OMinistry of Internal Affairs and Communications Website: http://www.tele.soumu.go.ip/e/svs/ele/index.htm

http://www.arib-emf.org/01denpa/denpa02-02.html (in Japanese only)

Refer to "Specifications" page of this product. http://www.lg.com/jp/mobile-phone (in Japanese only) (URL are subject to change without notice.)

Please refer to the websites listed below if you would like to know more detailed information regarding SAR.

OAssociation of Radio Industries and Businesses Website:

https://www.au.com/english

This product uses the 2.4 GHz band. DS-SS and OFDM are used as the modulation schemes. The interference distance is about Bandwidth to use: Full band This means that full band can be used, and that band of mobile

> *1 Technical regulations are defined by the Ministerial Ordinance Related to Radio Law (Article 14-2 of Radio Equipment Regulations). *2 This value includes the wireless function available for

• For use in an airplane, check with the airline company in advance.

- 45 -

Wireless LAN (Wi-Fi®) has the advantage that it can be freely

waves for exchanging information. At the same time, there is a

connected anywhere within the radio wave range, as it uses radio

risk that a malicious third party may obtain unauthorized access if

security settings have not been configured. You are recommende

The Company assumes no responsibility for leakage of data of

information that may occur during Bluetooth®/wireless LAN (Wi-Fi®

Since Bluetooth® and wireless LAN (Wi-Fi®) functions use the same

frequency band, using the both functions at the same may cause

radio wave interference resulting in decreased communication

This product uses the 2.4 GHz band. FH-SS and other schemes are

ised as the modulation scheme. The interference distance is about

2.4034/0F4

Wireless LAN (Wi-Fi®) function: 2.4DS4/0F4

unit identification devices can be avoided.

· Available channels differ depending on the country.

to configure security settings before using wireless LAN at your

decision and responsibility.

frequencies in the 2.4 GHz band.

Bluetooth® function: 2.4FH1/XX1

communication.

Export Administration Regulations

This product and its accessories may fall under the category of application of Japan Export Control Regulations ("Foreign Exchange and Foreign Trade Law and relevant laws and regulations). U.S. Re-export Regulations (Export Administration Regulations) is applied to this product and its accessories. If you export or re-export this product or its accessories, please follow the necessary procedures at your own risk and expense. For details on the procedures, contact the Ministry of Economy, Trade and Industry or the U.S. Department of Commerce

5 GHz Frequency Band Precautions

Wireless LAN (Wi-Fi®) function of this product | IEEE802.11 b/g/n ses 5 GHz hand. Using the 5.2 GHz hand and 5.3 GHz band outdoors is prohibited by the Radio Law.

The channels used on the product are as

IEEE802.11 a/n/ac W52 W53 W56

■ HT20 [a/n], VHT20 [ac] W52 (5.2 GHz band/36, 40, 44, 48 ch)

W53 (5.3 GHz band/52, 56, 60, 64 ch) W56 (5.6 GHz band/100, 104, 108, 112, 116, 120, 124, 128, ■ VHT80 [ac]

■ HT40 [n], VHT40 [ac]

speed or disconnection from the network. If connection fails, stop using either of the Bluetooth® and wireless LAN (Wi-Fi®) functions. Bluetooth® and wireless LAN (Wi-Fi®) functions of this product use

W52 (5.2 GHz band/38, 46 ch) W53 (5.3 GHz band/54, 62 ch) W53 (5.3 GHz band/54, 62 ch) W56 (5.6 GHz band/102, 110, W56 (5.6 GHz band/106, 122

Security code/PIN code

Available security codes

The product has various security codes that you can use. The available security codes are as follows. Do not forget the various security codes that are set as they are necessary for

Security code

 To use Customer Service Center and to do various inquiries, applications, and modifications on the au homepage - 46 -

Intellectual Property Right

Trademarks

 The microSD logo, microSDHC logo, and microSDXC logo are trademarks of SD-3C, LLC.

trademarks owned by Bluetooth SIG INC LG Electronics Inc. have the rights of using the above trademarks

- Google Play logo, Gmail are trademarks of Google, Inc.
- · FeliCa is a contactless IC card technology developed by Sony
- Corporation.
 FeliCa is a registered trademark of Sony Corporation.
- · All other company names and product names are trademarks or registered trademarks of respective companies referred to in this

Initial value 1234

PIN for unlocking

Initial value 1234

number

Example of

PIN Code

■ PIN 1 code o prevent unauthorized use of the au IC Card by a third party, you

can set the product to require PIN 1 code entry every time the power is turned on. You also need to enter PIN 1 code when setting nether the PIN 1 code entry is required. If the PIN 1 code is incorrectly entered three times consecutively. the PIN 1 code will be locked. You can unlock the PIN 1 code using

Initial value A four digit number chosen by the customer and

Example of To set and release the screen lock or the remote

* Make sure to change the initial value to your own unique

Lock No. (NFC/Osaifu-Keitai lock)

Password (Osaifu-Keitai lock setting)

 The default PIN 1 code is "1234" and does not need to be changed but you can change the PIN 1 code to any four- to eight-digit number if necessary, and you can change settings so

that the PIN 1 code must be entered.

If you require a PIN 1 code to be entered, make sure to change the number to your own unique number.

- 47 -

OpenSSL License

Copyright © 1998-2011 The OpenSSL Project. All rights

[OpenSSL License]

reserved. This product includes software developed by the OpenSSL

Project for use in the OpenSSL Toolkit. (http://www.openssl.org/) THIS SOFTWARE IS PROVIDED BY THE OPENSSL PROJECT
"AS IS" AND ANY EXPRESSED OR IMPLIED WARRANTIES,
INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOS ARE DISCLAIMED. IN NO EVENT SHALL THE OpenSSL PROJECT OR ITS CONTRIBUTORS BE LIABLE FOR ANY DIRECT. INDIRECT UNCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT

PROFITS; OR BUSINESS INTERRUPTION)
HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY WHETHER IN CONTRACT STRICT LIABILITY OR TORT (INCLUDING WHETHER IN CONTRACT, STRICT LIABILITY, OF TOH TIME WEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE

OF SUBSTITUTE GOODS OR SERVICES: LOSS OF USE, DATA, OR

[Original SSLeay License]

Copyright © 1995-1998 Eric Young (eay@cryptsoft.com) All rights reserved. This product includes cryptographic software written by Eric Young

(eay@cryptsoft.com)
THIS SOFTWARE IS PROVIDED BY ERIC YOUNG "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT ANY EAPHESS ON IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE AUTHOR OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY

■ PUK code

In case the PIN 1 code is locked, you can unlock it by entering the

- PLIK code is an eight-digit number given at the time of nurchase which is printed on the back side of the plastic card on which your au IC Card is attached.
- After entering the PUK code, you need to set a new PIN 1 code. If the PUK code is incorrectly entered 10 times consecutively, contact an au shop, PiPit or Customer Service Center.
- PIN code is not reset by Factory data reset.

Notes on Data Communication Charge

- Since a constant Internet connection is possible with the product. data communication may be performed automatically by some again communication may be be inclined action inducing by some applications, resulting in high data communication charges. Therefore, subscription to a data communication charge discount service or flat late plan is recommended. On the product to browse websites, download applications
- communicate using applications, send/receive e-mails, and configure various settings, connection to the Internet is required, to which data communication charge applies. Data communication charge does not apply to wireless LAN
- (Wi-Fi®) connection.

Applications

- your own risk. Some applications might cause virus infection, damage various data, and send out your location information, usage history or
- The Company assumes no responsibility for any disadvantage brought to you or any third party by applications you have installed.



USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY

To obtain the source code under GPL, LGPL, MPL, and other

open source licenses, that is contained in this product, please visit http://opensource.lge.com. In addition to the source code, all referred license terms, warranty disclaimers and copyright notices are available for download. LG Electronics will also provide open source code to you on CD-ROM for a charge covering the cost of performing such distribution (such as the cost of media, shipping, and handling) upon email. request to opensource@lge.com. This offer is valid for a period of three years after our last shipment of this product. This offer is valid to anyone in receipt of this information.

For software installed in this product or part of the installed software, you are not allowed to change, translate or adapt, reverse, engineering, decompile, reverse assemble them, or do anything related to the above.

without any profits, you are allowed to use them only when:

- Recording videos that are compliant with the standard of MPEG-4 Visual (hereinafter referred to as MPEG-4 Video)
- Playing MPEG-4 Videos recorded personally by consumers not

£ 0120-977-033 (except Okinawa)

personal information stored in your cell phone via the Internet. The Company assumes no responsibility for any operation problems

This product is licensed complying with the MPEG-4 Visual

Playing MPEG-4 Video supplied from the provider licensed from

Sold by: KDDI CORPORATION

- 52 -

Make sure to change the initial value to your own unique number Example of To do remote operation of voice mail and call forwarding services from a landline phone

All company names and product names in this manual are either trademarks or registered trademarks.

Bluetooth® word mark and logos are registered **Bluetooth**

for Japanese language. iWnn© OMRON SOFTWARE Co., Ltd. 2008-2017 All Rights Reserved.

• 🔊 is a registered trademark of FeliCa Networks, Inc. Facebook and Facebook logo are trademarks or registered of Facebook, Inc.

- 54 -

WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING

- 55 -

0120-925-314

 Do not use this product in places where electromagnetic waves are generated or near electric products, AV and OA equipment. · Subjecting this product to magnetic or electrical noise might

· Using this product near a TV, radio or similar appliance might

· Use of cell phones on board is restricted. Follow the instructions

Move to a place where you do not disturb others while you are in

 There may be a person with a cardiac pacemaker nearby at a place filled with people such as in a crowded train. Set "Airplane When a medical institution has laid down designated areas

This mobile phone was designed in observance of Japanese

For further utilizing such as promotion, in-house use or profitmaking business, please contact MPEG LA, LLC in U.S.

やめましょう、

歩きスマホ。

This product supports security features for wireless communication

the lower the power output of the mobile phone.
This mobile phone can be used in positions other than against your

Oau Website: OLG Electronics Inc. Website:

Wi-Fi®, Wi-Fi Direct® are registered trademark of Wi-Fi Alliance® Google, the Google logo, Android, the Android logo, Google Play, the iWnn of OMRON SOFTWARE CO., Ltd. is used for conversion methods

- 53

Be sure to check the security of the application, then install it at

that might be caused by the applications you have installed. In such case, you may be charged a repair fee even during the warranty period.

OF SUCH DAMAGE. Open Source Software Notice Information

Patent Portfolio License. If you use it for private purpose