Setting Guide

Introduction

Status bar

Current status and

notification icons

O sony O

au GG

Display (Touch panel)

long-touching an input field or item

Displaying menu

Operate directly touching with your finger

are displayed.

Fingerprint sensor

Unlocking Screen Lock

Tap to display the apps screen.

Tap to display the Home screen.

Tap to return to the previous screen.

☐ History/Task key

touch o to unlock.

△ Home key

☐ Back kev

There are two types for displaying the screen menu: tapping "" or

E Apps key

The lock screen appears when turning the power

(flick) the screen up/left to cancel the screen lock.

Alternatively, while the lock screen is displayed,

Tap to display recently-used apps in the thumbnail

list and activate or end them from the list.

Screen Lock

operations).

Thank you for buying "Xperia™ XZ" (simply called the "product" from here on). In this guide, settings and precautions for using the product are described. *For detailed descriptions of operations, refer to the "Basic Manual" (Japanese) app installed on the product or "取扱説明書(詳細版) (Full Instruction Manual)" (Japanese) available on the au homepage

Basic operation Describes the basic operations When "ようこそ (Welcome)" appears after the product is powered on,

E-mail setting Make initial settings for @ezweb. ne.jp etc.

Making a call

make initial settings

Describes how to receive a cal

Transferring data from au Settings Menu Import/export data to/from the product using microSD memory card or au Smart Pass server.

Sending contacts Send contacts to another phone.

Using "Basic Manual" app You can check the detail operation method for the product.

Receiving a call

Company names and product names referred to in this manual are trademarks or registered

The TM, ® marks may be omitted in this manual.

Screen illustrations shown in this manual may look different from the actual screens.

October 2016, 1st Edition

trademarks of respective companies

In some cases, a part of screen may be omitted.

Sold by: KDDI CORPORATION, OKINAWA CELLULAR TELEPHONE COMPANY

Manufactured by: Sony Mobile Communications Inc.

Basic operation Opening Notification panel

> If any notification icons are displayed on O Power key/Screen lock key/ the left side of the status bar, slide down the status bar to open the Notification panel. You can check details of notification Press and hold of for over one second. icons, start corresponding apps, etc. ■ Slide the status bar down with two fingers Press 🐧 while the screen is displayed. The 👢 or slide the Notification panel down to backlight turns off and screen lock is activated display the quick setting panel. You can set (avoiding the keys or touch panel from false on/off of the functions.

-Notification panel

Touch panel operations

Tap: Gently touch a screen and then immediately release your finger. Doubletap: Touch the same position twice

While your finger is gently

Touch the screen with two

fingers and widen (pinch-

out) or narrow (pinch-in)

the fingers' distance.

touching the screen,

trace it to the desired

direction to move over.

Slide

Long-touch

Keep touching an item with your finger.



Swipe (flick)


Operate the screen by quickly moving (flicking) your finger up/down or left/right.



Keep touching an item or icon, trace it to the desired direction to



% / 7 8 9 🛛 123



Initial settings

When "ようこそ (Welcome)" appears after the product is powered on, follow the onscreen instructions to set functions and services.

STEP START: Starting basic settings

Select "English (United States)" and tap "GET STARTED".

● Tap "日本語 (Japanese)" to switch language.

• Alternatively, after the initial setting is complete, from the Home screen, tap []→[設定 (Settings)]→[言語と入力 (Language & input)] →[地域/言語 (Language)] to set the language.

STEP 1: Setting important information

Confirm the collection of anonymous data/statistical information and mark/unmark the checkbox→[NEXT].

■To change the settings, after the initial settings, from the Home screen, [:::]→[Settings]→[About phone]→[Usage info settings]

STEP 2: Setting Wi-Fi® connection

Use home wireless LAN (Wi-Fi®) or public wireless LAN to connect Internet service. Operate in a place where signal of Wi-Fi® network can

- Wi-Fi® network with sis open network.
- Wi-Fi® network with % is protected by security. To connect, enter password (security key). ● To detect Wi-Fi® network manually or make Wi-Fi® advanced settings,
- after the initial setting is complete, from the Home screen, tap [:::]→ [Settings]→[Wi-Fi]→[]→[Refresh]/[Settings]
- ●To add Wi-Fi® network manually, operate from [Add network]→Enter a network name (SSID) etc. →[SAVE]. Check the necessary information for the connection in advance.
- If you do not set Wi-Fi® connection, tap "SKIP".

Jsing Wi-Fi® network selection settings

Select from detected Wi-Fi® network to set. To select a protected Wi-Fi® network, you need to enter a password (security key).



STEP 3: Setting up a Google account

Set up a Google account so that you can synchronize with Gmail, contacts of online service, calendar, etc.

Setting for creating new Google account is explained here.

- To set online service, make sure that data communication is enabled. Check that appears on the status bar or the product is connected to a Wi-Fi® network.
- If you set up a Google account, you can use Google apps such as "Gmail", "Google Play" or "Hangouts".
- ●Gmail's mail address "(user name) @gmail.com" is automatically created from the user name set with a Google account. To create an account, you are required to register "First name", "Last name", "Birthday" and "Gender"
- Although you can use the product without setting a Google account, some apps using Google account cannot be used. When you activate the app, a setup screen for Google account appears.



[I AGREE]→[NEXT] Confirm the Google services settings→[NEXT]

Set purchase settings for Google Play as required→ [CONTINUE]

*1 To copy Google account etc. from the other device, operate [Copy your Google Accounts, apps, and data from your other device]→[NEXT] and then follow

- *2 If you have your Google account, enter the Gmail address and tap "Next", then follow the onscreen instructions
- *3 Checking registration of username starts. If a username is unavailable, an entry screen for prompting another user name appears
- *4 The phone number of your au Nano IC Card 04 is entered automatically. When you enter another phone number, enter the notified verification code and then tap

STEP 4: Setting device protection

Set a fingerprint or unlock screen method. Tap "Set up fingerprint"/"Set up PIN, pattern or password" and follow the onscreen instructions. If you do not use the device protection, operate [No thanks]→[SKIP]→[SKIP ANYWAY].

• Alternatively, after the initial settings, operate from the Home screen, [:::] →[Settings]→[Lock screen & security]→[Fingerprint Manager]/ [Screen lock] to set device protection.

STEP 5: Setting Google Now

Set whether to use Google Now. Select "Yes, I'm in" or "Skip"→[NEXT].

STEP 6: Setting Xperia[™] services

Sign in for using Xperia[™] services. [Sign in with Google]→Follow the onscreen instructions→[NEXT]. If you do not sign in, [NOT NOW]→[SKIP].

STEP 7: Completion of setup

When the setup completion screen appears, tap "FINISH"

au Easy Setting

Set au convenient functions or services.

Setting app permission

permission appears.

may be restricted.

Character entry

Software keyboard

a contact, composing a mail, etc.

symbol keypad for more symbols.

on the numeric keypad

《QWERTY keyboard》

Use software keyboard to enter characters.

When you first activate app/function that access the functions or

information of the product, a confirmation screen for requesting access

If such confirmation screen appears, confirm the content and tap "DENY"/"ALLOW".

• For some apps/functions, an explanation screen for the permission may

appear. A confirmation screen may appear in several times and screen

• In this manual, description of such confirmation screen may be omitted.

■ The software keyboard appears when you tap the entry field for registering

characters, the numeric keypad to enter numbers and symbols, and the

● Tap "123" to display the numeric keypad. For the symbol keypad, tap "166"

● Tap "■" at the left edge of the candidate area to make advanced settings

\$ & _ - 1 2 3 ?

= + 4 5 6

With "SwiftKey Keyboard", you can use QWERTY keyboard to enter

content may vary. Confirm each content and follow the onscreen instructions.

If you do not permit, app/function may not be activated or use of function

●By setting au ID, you can use various services provided by au such as auスマートパス (au Smart Pass) or "au Kantan Kessai", which allows you to purchase apps from Google Play.

£ € ¥ ¢ © ® ™ ~ ¿

《Symbol keypad》

- * au ID which is already used by another user cannot be set.
- Alternatively, after the initial setting is complete, from the Home screen, tap [:::]→[Settings]→[au Settings Menu]→[au Easy Setting], you can set au service.





- * The screens of the step from 8 to 12 appear only if "Agree" is selected in the step 7.
- * To complete the initial setting of Lookout for au, permit the access authority on the each request screen appeared after the step 11.












「次へ (Next)]





select your previous au

phone type

select "auスマートパスの

サーバから戻す (Import

Does not appear if you

from au Smart Pass

server)" in the step

-バから戻す (Import

server)"(exported data

from au Smart Pass

on au Smart Pass

server), set au ID

