

au

DIGNO<sup>®</sup> rafre

Setting Guide

Introduction

Thank you for buying the "DIGNO<sup>®</sup> rafre" (simply called the "product" from here on). In this guide, settings and precautions for using the product are described.  
For explanations of basic functions, refer to "Basic Manual".

■ **Basic Operation**

Describes the basic operations.

■ **Initial settings**

Make initial settings when you turn the power on for the first time.

■ **au Easy Setting**

Set au ID.

■ **E-mail**

Make initial settings for E-mail (@ezweb.ne.jp) etc.

■ **Making a call**

Add a new contact to Contacts to call.

■ **Receiving a call**

Describes how to receive a call.

■ **Saving battery power**

Describes the setting to save battery consumption using "Eco Mode".

■ **Setting Wi-Fi\***

Describes how to connect Wi-Fi\* network.

■ **Viewing/playing data**

Describes how to view/play still images or video data.

■ **Infrared communication**

Describes how to send/receive data between the product and another device using infrared communication function.

■ **Transferring data from au Settings Menu**

Restore/back up data from/to your previously used au phone to/from this product using microSD card or the au Smart Pass server.

Company names and product names referred to in this manual are trademarks or registered trademarks of respective companies.  
The TM, ® marks may be omitted in this manual.  
Screen illustrations shown in this manual may look different from the actual screens.  
In some cases, minor details or a part of a screen may be omitted.

November 2015, 1st Edition  
Sold by: KDDI CORPORATION  
OKINAWA CELLULAR TELEPHONE COMPANY  
Manufactured by: KYOCERA Corporation

Basic Operation

For explanations of basic functions, refer to "Basic Manual".

「Home screen (standard home)」

Weather widget

Display weather information. When activating for the first time, tap to select an area.

Power button

Press and hold (Power button) until the charging light turns on

Power ON

Press and hold (Power button) until the charging light turns on

Displaying Home screen

From the Start screen, swipe (Start screen)

Chrome icon

Use Google Chrome to view Web pages.

Apps list icon

Display the app list.

Navigation bar

(BACK button): Return to the previous screen. When (appears in the character entry screen, tap this button to hide the keyboard or menu.

(HOME button): Display the Home screen. Long-touching or sliding up this button displays the semi-circular shaped assist ring. Slide it to (to activate the Notification panel/Google (Google NOW)/the slide screen.

(RECENT button): Show recently-used applications.

Touch directly with your finger to operate.

Tap

Lightly touch a screen and then immediately release your finger.

Long-touch

Keep touching a screen.

Slide (Swipe)

While lightly touching the screen, trace to the desired direction.

Flick

Touch the screen and flick up/down/left/right.

Character entry

Use flick input or tap a key several times to enter characters.  
In the character entry screen, [ ] → [Keitai Input] to enter characters with the same operations as cell phones.

Character entry mode switch key

Tap to switch character type.

Character entry screen (10-key))

Magnifying characters

To magnify characters of menu items etc. operate as follows.

Apps list → [Settings] → [Accessibility] → Turn "Large text" to ON

Alternatively, from Apps list → [Settings] → [Accessibility] → [Magnification gestures] to magnify the screen. For operation method, see the description on the screen.

Initial settings

When you turn on the product for the first time after purchasing the product, follow the onscreen instructions to set language, functions and services.

Setting up Google account

User name	Register your Google account (user ID) and a character string for mail address. You can register a desired name, but a name already registered by another user cannot be set.
Password	Register password for the Google account.

1

Welcome

Select language, [ ]

2

Select Wi-Fi network

Set up the Wi-Fi network to connect as required  
\* If you do not set up, tap "SKIP".

3

Tap & Go

Quickly copy any Google Accounts, backed up apps and data from your existing Android device. To copy and unlock.

1. Make sure your other device is on and unlocked.

2. Briefly place the two devices back-to-back until you hear a tone, then set aside.

Learn more

4

Add your account

Sign in to get the most out of your device.

Or create a new account

5

Create a Google Account

Enter "First name" and "Last name" → [NEXT]

6

How you'll sign in

You'll use this username to sign in to your Google Account

Enter a user name → [NEXT]  
Checking registration of user name starts.

7

Create password

Create password

Enter a password and reenter the password for confirmation → [NEXT]

8

Recovery phone

A phone number can help you get back into your Google Account in case you forget your password.

Check/change the country name and phone number → [NEXT]\* → [VERIFY]  
\* If you do not set up, tap "SKIP".

9

Privacy & Terms

By continuing, you agree to the Privacy Policy and Terms of Service.

Don't create the account

Check the contents, then [I AGREE]

10

Your Google Account

Check the contents, then [NEXT]

11

Set up payment info

Make purchase settings of Google Play as required → [NEXT]

12

Protect your phone

[SET SCREEN LOCK NOW] → Follow onscreen instructions to set security and notification  
\* If you do not set up, tap "SKIP".

13

Google services

Confirm the Google service settings, then [NEXT]

\*1 Text message for Google verification code will be sent to the set phone number.

au ID*	Register your au phone number or a character string for au ID (user ID).
au ID password	Register password for using au ID.

\* "au ID" which is already used by another user cannot be set.  
• If you skip the operation of "au Easy Setting" at that time, you can set au ID later. In that case, operate from Apps list → [Settings] → [au Settings Menu] → [au Easy Setting], or from Apps list → [au ID Setting]

1

Welcome to au

Welcome to au screen → [Next]

2

au ID Registration

[Register "au ID"] → [Next]

3

au ID Setting

[au ID の設定・保存 (Set and save au ID)]

4

au ID Setting

Enter the security code → [OK]  
\* Default value is a four-digit number written at subscription.

5

au ID Setting

Enter a security password → [設定 (Settings)] → [終了 (Exit)]

6

Update

[Update] → [Next]

7

Terms of Use of au Services

Check the terms and conditions (reading requires), [Agree] → [Next]

8

Terms of Use

[Agree]\*1

9

Automatic Backup Setting

[Turn Auto Backup on]/[Turn Auto Backup off] → [Next]  
\* To back up photos and contacts to au Smart Pass automatically using "Data Storage App", tap "Turn Auto Backup on".

10

おすすめアプリ

Select apps to install → [次へ (Next)]  
\* If there are apps to be restored, the restoration of apps screen appears. Follow the onscreen instructions.

11

Home Screen Setting

[Activate]/[Skip activation] → [Next]

12

Texting While Walking Alert

[Activate]/[Skip activation] → [Next]

13

データを戻す

Select data to restore → [次へ (Next)]  
\* When the screen for checking Wi-Fi\* connection is displayed, follow the onscreen instructions.

14

Initial Setting Completed

[Finish]

\*1 Configurations for LISMO and Lookout for au are complete when you tap "Agree".

E-mail

To use E-mail (@ezweb.ne.jp), subscription to LTE NET is required.  
If you did not subscribe it when you purchased the product, contact an au shop or Customer Service Center.  
Your E-mail address is determined automatically after initial setting. You can change the E-mail address later.

1

Home screen

Home screen → [E-mail]

2

Check the contents, then [接続する (Connect)]

3

Check your E-mail address → [閉じる (Close)]

4

Check the contents, then [Agree]/[Disagree] → [Done]

5

When Outline of customer information for "About use of customer information" appears, tap "Accept". Subsequently the explanation screen for E-mail function appears. Confirm the contents and then tap "Close".

1

Home screen

Home screen → [E-mail]

2

[E-mail] → [E-mail settings]

3

[Other settings]

4

Check the contents, then [接続する (Connect)]

5

[Eメールアドレスの変更へ (To Change E-mail address)]

6

Enter the security code → [送信 (Send)]

7

Check the contents, then [承諾する (I accept)]

8

Enter E-mail address → [送信 (Send)]

9

[OK]

10

[閉じる (Close)]

■ Backing up E-mail

You can back up E-mail.  
Backed up data is saved on a microSD™ memory card (/SD card/private/au/email/BU/) when a microSD™ memory card is attached. If a microSD™ memory card is not attached, data is saved on the internal storage (/Internal storage/private/au/email/BU/).

Home screen → [E-mail]

[E-mail] → [E-mail settings]

[E-mail settings] → [Backup/Restore]

[Backup/Restore] → Confirm the notes and [OK]

Confirm the notes and [OK] → Select a character code to make backup data → [OK]

Select a mail type to back up → [OK]

Setting other than E-mail

You can use mail addresses except for E-mail (@ezweb.ne.jp).  
You need to set up an account to use it. For the first time use, make settings as follows.

Apps list → [Gmail] → Follow the onscreen instructions.

Making a call

■ Adding new contact and making a call

Apps list → [Contacts]

Contacts list screen → Tap "CONTACTS" tab

[ADD] → Enter necessary items → [SAVE]

\* When "ADD" is not displayed, [CREATE A NEW CONTACT] → [Phone]/[ADD NEW ACCOUNT], then follow the onscreen instructions to register a contact/account.

Home screen → [Phone] → Tap "RECENT CALLS" tab

[Phone] → Tap "RECENT CALLS" tab

[Phone] → Tap "RECENT CALLS" tab

■ Making a call from the call history

Checking your own phone number (Profile)

Operate as follow to check your own phone number.

Apps list → [Settings] → [Profile] → Profile screen appears.

Changing your E-mail address

Your E-mail address can also be checked on profile screen.  
If you make initial settings for [E-mail] app as follows, the E-mail address of E-mail (@ezweb.ne.jp) can be automatically registered to profile screen.

Home screen → [E-mail] → [接続する (Connect)] → [閉じる (Close)] → [Agree]/[Disagree] → [Done] → [Close]

→ The e-mail address is registered to the profile screen.

Receiving a call

You can receive a call in the following steps.  
\* "Display the popup on an incoming call" is set to "ON" in "Sync Call settings" by default. When you set it "OFF", in sleep mode, or when the start screen is displayed, follow the onscreen instructions.

■ Calling

Receiving screen → [Accept]

Calling starts

To end the call, [END]

Receiving screen → [Phone Screen]

Drag the operation panel down

[MENU] → [Reply Auto answering]

The caller hears the guidance.

To answer the call, slide right from "☎" to "☎"

Saving battery power

Use "Eco Mode" to set sleep time of backlight, screen brightness, etc. so that you can save the battery power. When the battery power is low, set "Data communication" to "OFF" and limit communications only for calling to extend standby time.

Apps list → [Eco Mode]

[ON]/[OFF]

\* Tap "☎" to check or change the battery saving items.

Setting Wi-Fi®

Use your home Wireless LAN (Wi-Fi®) or public wireless LAN to connect to the Internet.  
Main settings are as follows.

Wi-Fi Easy Settings	Answer to the questions on the screen or follow the instructions to register an access point easily.
WPS system	Use for registration of access point compatible with Wi-Fi Protected Setup™ with WPS mark.

\* If you turn on wireless LAN (Wi-Fi®) function, battery consumption increases. You are recommended to turn wireless LAN (Wi-Fi®) function to OFF when not using wireless LAN (Wi-Fi®) function.

Apps list → [Settings]

[Wi-Fi]

Turn "ON" and [Wi-Fi]

Available Wi-Fi® networks are listed. Select a Wi-Fi® network to connect → Enter a password as required → [CONNECT] to connect the Wi-Fi network

If a Wi-Fi® network you want to connect cannot be detected, operate from [Wi-Fi] → [Add network] and connect the Wi-Fi® network manually.

[Wi-Fi Easy Settings]

Answer the questions on the screen and follow the instructions to register an access point.

[Advanced] → [WPS Push Button]/[WPS Pin Entry]

For using WPS button, tap "WPS Push Button" and then keep pressing WPS button of access point to set to WPS mode. An access point is automatically detected and registration starts.

For entering WPS PIN, tap "WPS Pin Entry" and enter displayed PIN code for access point, then registration starts.

Viewing/playing data

By transferring data from the previously used au phone to a microSD™ memory card, you can view/play still image or movie data using "File Commander" in the product. When you activate for the first time, the Terms and Conditions appears. Follow the onscreen instructions.  
\* Copyrighted data on the previously used au phone cannot be transferred to the product. However, some Chaku Uta Full®, Video Clip, Chaku Uta Full Plus® may be able to be transferred and played on the product with the same phone number by backing up with LISMO Port Ver 4.2 or later.

Apps list → [File Commander]

Tap a category to be displayed → Tap data

Tap data Data is played.

Infrared communication

Use infrared communication to send/receive profile or various data between the product and other devices.

Apps list → [Infrared]

Select an item to operate

To receive data, select "Infrared" and point the infrared data port of the product to the infrared data port of the other device.

To send, select "Send profile"/"Send contacts"/"Send file", select data to send for sending contacts/file → [OK], and then point the infrared data port of the product to the infrared data port of the other device.

\* For sending data from File Commander, tapping "OK" operation is not needed.

• When authentication code entry screen appears, enter authentication code (four-digit number) → [OK].

Transferring data from au Settings Menu

Restore/back up data to/from the product from/to your previously used au phone via au Smart Pass server.  
• Setting au ID is required for restoring/backing up data using au Smart Pass server  
• For restoring data using microSD memory card, save the data to the microSD memory card using your previously used au phone in advance.

Apps list → [Settings]

[au Settings Menu]

[Data Transfer]

[データを保存する (Back up data)]/[データを戻す (Restore data)]

Restoring data from au Settings Menu

データを選択

データを選択

データを選択

データを選択

データを選択

データを選択

データを選択

データを選択

データを選択

データを選択

データを選択

データを選択

データを選択

データを選択

データを選択

データを選択

データを選択

データを選択

Saving data from au Settings Menu

データを選択

データを選択

データを選択

データを選択

データを選択

データを選択

データを選択

データを選択

データを選択

データを選択

データを選択

データを選択

データを選択

データを選択

データを選択

Using "Data Storage App"

To use "Data Storage" app to back up photos and contacts to au Smart Pass server automatically, set as follows.

Apps list → [Settings] → [au Settings Menu] → [Backup Setting] → Tap to turn on "定期的に自動で預ける (Back up periodically)"