


DRAPE

English Simple Manual



Turning the Power On and Off

- Turning the Power On
Press and hold for more than one second.
- Turning the Power Off
Press and hold for more than one second.

Checking Your Own Phone Number and E-mail Address

From the stand-by screen: press ➔ press .

Making/Answering a Call

- Making a Call
From the stand-by screen: enter the phone number ➔ press .
To end the call: press .
- Answering a Call
Press while the phone is ringing.
To adjust the earpiece volume during a call: press ➔ press [OK].

Storing/Recalling an Entry in the Phone Book

● Storing an Entry

From the stand-by screen: press and hold **[M]** for more than one second ➔ press **[S]** to select the item ➔ press **[Select]** (Select) to enter the data ➔ press **[Add]** (Add).

● Recalling an Entry

From the stand-by screen: press **[M]** to display the Name Search screen ➔ press **[Select]** to select the name ➔ press **[Select]** (Select) to display the entry's details screen.

Using the Camera (Movie Clips/Photos)

● Recording a Movie Clip


From the stand-by screen: press and hold **[Camera]** for more than one second ➔ press **[Camera]** ➔ press **[Rec]** (録画) to start recording ➔ press **[Save]** (保存) to save the movie.
To stop recording: press **[Stop]** (停止) during recording.

● Taking a Photo

From the stand-by screen: press and hold **[Camera]** for more than one second ➔ press **[Shot]** (撮影) to take a photo ➔ press **[Save]** (保存) to save the photo.

Making an International Call

Ex: To call 212-123-△△△△ in the USA



English Announcement Function

You can play Voice Mail Service operation instructions and answering messages in English.

From the stand-by screen: press **[Call]** ➔ press **[5]** ➔ press **[3]** ➔ press **[6MIN]** ➔ press **[Call]** (発信).

Other Handy Features

● Setting the Manner Mode

From the stand-by screen: press and hold **[Manner]** for more than one second.

To cancel Manner mode: press and hold **[Manner]** for more than one second from the stand-by screen.

● Setting the Voice Memo

From the stand-by screen: press and hold **[Voice Memo]** for more than one second.

To cancel the Voice Memo: press and hold **[Voice Memo]** for more than one second from the stand-by screen.

For inquiries, please contact

au Customer Service Center (General Information)

● If you are calling from a landline phone: ☎ 0077-7-111 (toll free)

● If you are calling from an au mobile phone: 157 (toll free)