
# LG it

- "Setting Guide", "Basic Manual", "Notes on Usage", etc. are collectively referred to as "Instruction Manual". In this manual, "LG it" is usually referred to as the "product". In this manual, "Tid it" is usually referred to as the "product".
- "microSDHC™ memory card (comme ercial item)" and "microSDXC™ memory card (commercial item)" are abbreviated as "microSD memory
- mpany names and product names in this manual are eithe narks or registered trademarks. The trademark symbol (TM) and the registered trademark symbol (®) may be omitted in places in this manual.

November 2018, 1st Edition

Do not put water (drinking water, perspiration, seawater, urine of pet animals, etc.) into the seawater, urine of pet animals, etc.) into the charging s terminal or the external connection terminal May cause fire, burns, injuries, or electric shock, etc.



Do Not doing so may cause fire, burns, injuries or electric shocks, etc.

### ⚠ WARNING

 $\begin{tabular}{ll} \begin{tabular}{ll} \beg$ Don't May cause fire, burns, injuries, or electric shock, etc.

Keep conductive materials (metal pieces, pencil lead, etc.) from coming in contact with the charging terminal Don't or the external connection terminal and prevent dust

from getting inside. May cause fire, burns, injuries, or electric shock, etc. Do not cover or wrap the product with a bedding, etc. while using or charging.

Don't May cause fire or burns, etc. If charging is not complete after the specified charging time has passed stop charging

time has passed, stop charging.

May cause fire, burns, or injuries, etc. due to overcharge.

Make sure to turn off the product or stop charging

before you get close to places such as a gas station where a flammable gas or dust can be generated. If using at the place where there is a possibility of mable gases being generated, may cause the gas to

-7-

Make sure that there is no adhered metal pieces (cutter blade, staples, etc.) as the speaker part of the product generate magnetism

May cause injuries, etc. due to adhered objects When watching the display screen, keep a certain

distance from the display in a fully bright place. reduce visual acuity, etc.

Battery pack

### ⚠ DANGER

Do not contact pieces of metal (such as necklaces and hair pins), conductive foreign matter, etc. and the Don't connection terminal. Also, do not carry or keep them together with the battery pack. May cause fire, burns, or injuries, etc

If you can not attach the battery pack properly to this product, do not forcibly attach it. Also, if you can not Don't remove the battery pack properly from this product, do

not forcibly remove it. May cause fire, burns, or injuries, etc.

\* For details on attaching and removing the battery pack,

refer to "Basic Manual".

Do not throw the battery pack into fire or apply heat. May cause fire, burns or injuries, etc.

Do not puncture with sharp object (a nail, etc.), strike with hard object (a hammer, etc.), stomp on, or apply excessive force on the product. May cause fire, burns or injuries, etc

- 14 -

### When Using the Product

Before using the product, be sure to read the "Safety Precautions n this manual available on the au homepage to ensure correct use Before you assume that the product is malfunctioning, perform "クイック診断 (Quick diagnosis)" or "トラブル診断 (Troubleshooting diagnosis)" with the "故障紛失サポート (Repair and Delivery Service)" app.

■ クイック診断 (Quick diagnosis)

On the Home screen ▶ [au Supports] ▶ [故障紛失サポート (Repair and Delivery Service)] ▶ [クイック診断してみる (Try quick diagnosis)] ■ トラブル診断 (Troubleshooting diagnosis)

On the Home screen ▶ [au Supports] ▶ [故障紛失サポート (Repair and Delivery Service)] ▶ [便利な機能 (Convenient function)] ▶ [トラブル診 断を試す (Try troubleshooting diagnosis)]
Alternatively, you can also check it on the au website.

https://www.au.com/trouble-check/ (in Japanese only)



- Communication is not possible even inside the service area in places where the signal does not reach (e.g. tunnels and basements). Also, communication is sometimes not possible in poor reception areas. Communication is sometimes interrupted if you move into a poor reception areas during communications.
- Since this product uses radio waves, the possibility of communication intercepts by third parties cannot be eliminated (though LTE/WiMAX 2+/GSM/UMTS system has highly secure confidential communication features). When connecting to emergency services in Japan, use au VoLTE
- (LTE network). You cannot connect through 3G (circuit switching
- While this product supports the au World Service, each network service described in this manual varies depending on the area and service content.

- 1 -

If the product gives off a strange smell noise smoke

or overheats or becomes discolored or deformed during use, charge, or storage, perform the following operations.

- Remove the power plug from the outlet or accessory socket.
- · Turn the product OFF.

 Remove the battery pack from the product. Not doing so may cause fire, burns, injuries, or electric

Be careful not to let your pet bite the product.

May cause bettook peak to the product. May cause battery pack to ignite, burst, heat, or leak, and may cause fire, burns, or injuries, etc.

### **A**CAUTION

Do not use the damaged product.

May cause fire huma or in the latest and the latest are the latest and the latest are the latest and the latest are the lat

O not leave on unstable places, such as wobbly tables or objects that are on an angle. Be particular tables or objects that are on an angle. Be particularly Don't careful when the device has the vibration function turned on

May cause the device to fall and lead to injuries, etc. Do not store the product in extremely humid, dusty or hot areas.

May cause fire, burns, or electric shock, etc.

When children use the product, parents or guardians should give them proper instructions and do not allow them to use the product in the wrong way. May cause injuries.

When attaching the battery pack in this product please check the orientation of the battery pack. Attaching with incorrect orientation, may cause fire, burns

injuries due to ignite, burst, heat or leak the battery pack For details on attaching battery pack, refer to "Basic Manual".

If materials inside the battery pack enters your eyes or your mouth, etc., immediately flush them with clean water and see a doctor right away.

May cause loss of sight due to the influence of the fluid inside the battery pack.

### **⚠** WARNING

If the battery pack gives off a strange smell, overheats or becomes discolared deformed. or becomes discolored, deformed, etc., do not use it. May cause fire, burns or injuries, etc

If material inside the battery pack, etc. leaks or gives off a strange smell, immediately stop using and move Do it away from fire. May cause leaking fluid to ignite or explode.

Be careful not to let your pet bite the battery pack. lay cause battery pack to ignite, burst, heat, or leak, and may cause fire, burns, or injuries, etc.

Since this product is a radio station under the Radio Law, you may be asked to temporarily submit the product for inspection in accordance with the Badio Law. IMEI information of your cell phone is automatically sent to KDD CORPORATION for maintenance and monitoring operational

status of your cell phone. Before you start using the product overseas, check the relevant

laws and regulations of the country/region you visit.

The Company is not liable for any damages arising from earthquakes, lightning, storms, floods or other natural disasters, as well as fires, actions by third parties, other accidents, intentiona or mistaken misoperation by the customer, or use under other unusual conditions outside the responsibility of the Company. The Company is not liable for any incidental damages (change/

Do not discard this product together with regular trash. Please cooperate in the collection of the product (including disappearance of described content, loss of business income, disruption optional accessories) when it is no longer needed to protect the environment and effectively use resources. Old product are collected at au shops and other places. of business, etc.) arising from use or inability to use the product. The Company is not liable for any damages arising from failure to observe the described content of the "Instruction Manual". \* "The Company" as appears in this manual refers to the following

· The Company is not liable for any damages arising, for example from malfunction caused by combination with connected devices or software not related to the Company.

 Captured image data or downloaded data may sometimes be ered or lost due to faults, repair or other handling of the product. The Company is not liable for any damage or lost income resulting from recovery of these data. It is recommended you keep a copy of important data on

your PC's hard disk, etc. Whatever the cause of the defect or malfunction may be, the Company assumes no responsibility for alteration or loss of saved data. Contents saved in the product, such as contacts, mails and

favorites, might be altered or lost in an accident, fault, repair or mishandling. Be sure to keep a copy of important contents. Note that Company assumes no responsibility for any damages or lost profits resulting from altered or lost contents Note that contents (both charged or free content) saved with

the product cannot be taken over to the customer when it is replaced for repair of a fault.

- 2 -

Do not store the product within reach of small children.

May be accidentally swallowed or save. shock, etc.

Be careful when using the product continuously or charging as it gets hot. Also, avoid touching the terminal continuously if you putting it in a pocket of clothes or fall asleep unintentionally.

While using the terminal continuously such as using application, calling, using data communication, watching videos, etc. or charging, the product, the battery pack, or the adapter may get hot. Directly touching a hot part for a long time, you may have redness, itching or rash on your skin, or it may result in low-temperature burns depending on your constitution and/or health condition.

### ■ Main unit

### **A** DANGER

Do not throw the product into fire or apply heat. May cause fire, burns or injuries, etc.

Do not puncture with sharp object (a nail, etc.), strike with hard object (a hammer, etc.), stomp on, or apply excessive force on the product.

If materials inside the product enters your eyes or your mouth, etc., immediately flush them with clean water and see a doctor right away.

May cause loss of sight due to the influence of the fluid,

**!** CAUTION

If the material inside the battery pack leaks out from

May cause eyes or skin problems. If the fluid enters your eyes or mouth, etc., or contacts skin

If the fluid enters your eyes or mouth, etc., immediately see a doctor after flushing.

May cause ignition, burns, or injuries, etc. Also may cause

Bring them to a sales outlet such as an au shop by sticking

a tape, etc. to the connection terminal and insulating them. If your local municipality has a battery pack recycling

Do not charge the battery pack using the specified

charger (sold separately), after removing it from the

inside, do not let the fluid contact with the skin on

or clothes, immediately flush with clean water.

Do not dispose the battery pack together with other garbage.

program, dispose of them as provided for.

Do not use or charge wet battery pack.

May cause fire, burns, or injuries, etc.

May cause fire, or electric shock, etc.

your face or hands or clothes, etc.

environmental destruction.

inside the product.

### Charging equipment • WARNING

- 10 -

Do not use the specified charger (sold separately) cable if it is damaged cable if it is damaged. Don't May cause fire, burns, or electric shock, etc.

The product uses liquid crystal for its display. The display response speed may become slow when the ambient

normal at room temperature.

times. Note that this is not a malfunction.

temperature is low, which is due to the property of liquid crystal

Although the display used on the product is made using hig

and not a malfunction. The display response speed will return to

precision technology, some pixels (dots) might be lit or out at all

You are recommended to store copies of individual data such as

photos you took, videos and music on your PC by sending each file as mail attachment, etc. Note, however, that you may not be

able to make copies of any copyrighted data even by the above

Sold by : KDDI CORPORATION
OKINAWA CELLULAR TELEPHONE COMPANY

Reproduction of the content of this manual in part or in whole is

The content of this manual is subject to change without notice

Some functions may not be available due to change OS specification /

Should you notice any unclear points, omissions, etc., feel free to

- 3 -

**↑** WARNING

May cause damage to your eyesight. Also, you may get dazzled or surprised causing an accident.

Do not lighten or flash the light to drivers of cars, etc.

May disturb driving and cause on assistant.

O not watch the display that blinks repeatedly for a long time.

Do not put foreign objects such as liquid like water (drinking water perspiration account)

Don't animals, etc.), metal pieces or burnable things into au

correct place and in correct direction.

May cause fire, burns, injuries, or electric shock, etc.

Do not expose the camera lens to direct sunlight for an extended period.

May cause fire, burns, injuries, etc. by the light-collecting mechanism of the lens.

IC Card inside the product or microSD memory card

Insert the au IC Card or microSD memory card in the

Don't May cause spasm, loss of consciousness, etc.

Do not lighten or flash the lighting part of the light close to person's eye. Keep enough distance

Every effort has been made in the preparation of this manual.

Imported by : LG Electronics Japan, Inc Manufactured by : LG Electronics Inc.

the service or terminate the service, etc.

Don't especially from small children.

Always use the specified DC adapter with a negative ground vehicle. Do not plug it into a positive-ground

May cause fire, burns, or electric shock, etc. If it starts to thunder, do not touch the adapter.
May cause electric shock, etc.

Do not short the external connection terminal while it is connected to an outlet or the accessory socket. is connected to an outlet or the accessory socket. Do

Don't not touch the external connection terminal with a part of your body such as your hands or fingers. May cause fire, burns, or electric shock Do not place heavy objects on the cord of the specified charger (sold separately) as set charger (sold separately) or put excessive force such Don't as pulling the cord of the charger.

May cause fire, burns, or electric shock, etc.

When connecting/disconnecting specified charger (sold separately) to/from an sublimited (sold separately) to/from an outlet, do not contact a metal strap or other metal objects with it. May cause fire, burns, or electric shock, etc.

Do not use an electric transformer for overseas (travel converter) with the specified charger (sold separately). May cause ignition, heating, or electric shock, etc.

### ■ Explanation of graphic symbols used in this manual to Safety Precautions (Observe Strictly)

- Before using the product, thoroughly read these safety precautions for proper use.
- These precautions are intended to protect you and others around you. Read and follow them carefully to avoid injury. damage to the product or damage to property.
- The signs below differentiate between the levels of danger that can occur if the product is not used within the specified guidelines.

This symbol indicates the potential and A DANGER imminent danger of death or serious injury\* to a person if the product is handled incorrectly. his symbol indicates the possibility of

This symbol indicates the possibility of

WARNING death or serious injury\*1 to a person if the

ACAUTION minor injury\*2 to a person or physical damage\*3 if the product is handled minor injury\*2 to a person or physical incorrectly. \*1 Serious injury: This refers to loss of sight, injury, burns (highand low-temperature), electric shock, broken bones, injuries with residual aftereffects from poisoning, etc., and injuries

product is handled incorrectly.

- with residual acterieurs from poisoning, etc., and injuries equiring hospital admission for treatment or long term hospital attendance as an outpatient. \*2 Minor injury: This refers to injuries, burns (high- and lowtemperature), electric shock, etc. that do not require hospital admission for treatment or long-term hospital attendance as an outpatient.
- \*3 Physical damage: This refers to extended damage to buildings

- 4 -

furniture, livestock, pets, etc.

When on board an airplane, turn the power of the product off or put it in Airplane mode.

Follow the instructions of each airline, because there are different restrictions for using the product on an airplane.

The product's signals may cause electronic equipment of airplanes to fail or malfunction. If you do a prohibited act such as using the product in an airplane, you will be punished according to law.

When using the product in a medical facility, be sure to observe the regulations of the facility. urn the product off where its use is prohibited The product's signals may cause electronic equipment or

electronic medical equipment to fail or malfunction. When using the handsfree call, ringtone is ringing with loud sound, or in the standby mode, be sure to keep the product off of the ears Also, when playing games, video, or music with an

earphone microphone connected to the product, adjust the volume to the proper level. When using the handsfree call, loud noise sounds from the

product.
Even in the standby mode, ringtone and vibrator may work suddenly. Using continuously for a long time with too loud volume may

cause a hearing loss, etc. And, if you cannot hear the sound around you clearly, it may cause an accident.

Be careful when setting vibrator (vibration) or ringtone if your heart is weak. Surprised by sudden vibrate ringtone (vibration) or ringtone it may cause harmful effect on heart.

- 11 -

Do not apply force on the connected parts when adapter is connected to the product.

Don't May cause fire, burns, injuries, or electric shock, etc

Do not touch adapter cord, external connection terminal, or nower plus with the time. No May cause fire, burns, or electric shock, etc

electric shock.

Only use with the specified power source and voltage. When charging the product overseas, use specified Do charger (sold separately) for global use.

> AC adapter: 100 V AC (Connect to an AC outlet for internal AC adapter for global use : Between 100 V AC and 240 V AC (Connect to an AC outlet for internal household use

rrect voltage is used, it may cause fire, burns or

DC adapter: 12 or 24 V DC (specific for negative-ground

When replacing the specified DC adapter's fuse,

replace it only with a specified fuse.
Replacing with a different type of fuse might cause fire, burns, electric shock, etc. For specified fuses, see the instructions that come with the DC adapter.

Wipe off any dust that attached to the power plug. If the terminal is used with dust adherence in the control of the control o he terminal is used with dust adhering to it, may cause fire, burns, or electric shock, etc. When you connect the specified charger (sold

separately) to an outlet or an accessory socket, firmly Do connect it to the outlet. If not firmly inserted, may cause fire, burns, electric shock, etc.

Indicates that disassembly is not must be obeyed at all allowed. Do times. ndicates that use Indicates that the in a place where the product is likely to get power plug must be wet or allowing the product to get wet is wet is well as the product to get wet is wet is power plug power outlet. not allowed.

indicate actions that are not allowed and actions that must

Indicates that handling with wet hands is not

hands allowed.

with wet hands is not

Indicates an action that

be done

Indicates an action

that is not allowed.

■ Precautions common to the main unit, back cover, battery pack, charging equipment, au IC Card, peripheral devices

### **A** DANGER

Do not use, store or leave the product in hot places (e.g. by a fire peer a boots. (e.g. by a fire, near a heater, under a kotatsu or Don't bedding, in direct sunlight, in a car in the hot sun). May cause fire, burns, injuries, or electric shock, etc.

Do not put the product into or near a heating cooking device such as a microwave oven or IH cooker, or high-Don't pressure container such as a pressure cooker.

May cause fire, burns, injuries, or electric shock, etc.

- 5 -

If you wear an electronic medical device, etc., check with the equipment man for

before using the product.

lowpower signals.

Do parts of the product.

Don't it excessively.

May cause injuries, etc

with the equipment manufacturer or sales outlet to

determine how the device is affected by radio waves

The product's signals may cause harmful effect on the electronic medical device, etc.

control equipment or electronic equipment using

Hearing aids, implanted pacemakers or defibrillators, other electronic medical equipment, and other automatic

control equipment. Users wearing implanted pacemakers

or defibrillators, or other electronic medical equipment should check with the manufacturer or sales outlet

about the effect of radio frequencies on the equipment

proken, be careful of broken glass or exposed internal

If you mistakenly touch broken or exposed parts, it may

May cause battery pack to ignite, burst, heat, or leak, and

surroundings, hold the product firmly, and do not swing

When you disconnect the power plug from an outlet or

an accessory socket, do not pull the specified charger

If the adapter cord is pulled on, this may result in scratches, may cause fire, burns, electric shock, etc.

When connecting/disconnecting the specified charger

mmediately stop using the product. Do not use it by

May cause fire, burns, injuries, etc. or electric shock due to short circuit of the external connection terminal.

Always remove the power plug of the specified charger

an accessory socket if water (drinking water, perspiration,

seawater, urine of pet animals, etc.) gets into the adapter.

(sold separately) from an outlet or an accessory

power plug If the power plug is left plugged in, may cause fire, burns,

Immediately remove the power plug from an outlet or an accessory socket if water (did 1)

power plug Adhesion of such fragments may cause fire, burns, or

Always remove the power plug from an outlet or an accessory socket when cleaning the equipment.

If not properly unplugged or plugged in, may cause fire,

(sold separately) to/from the terminal, do not use force

(sold separately) cord with excessive force. Instead

hold the adapter to disconnect.

and connect/disconnect straightly.

burns, injuries, or electric shock, etc.

socket when not using the adapter.

Jiplug May cause fire, burns, electric shock, etc.

Do restoring the deformation.

electric shock, etc.

If the external connection terminal it deformed, immediately stop using at

When the display or camera lens is accidentally

cause burns, injuries or electric shocks, etc.

may cause fire, burns, or injuries, etc.

Be careful not to let your pet bite the product.

**CAUTION** 

- 12 -

When using the motion sensor, stay alert to your surroundings hold the product for

Turn the product OFF near high-precision electronic control equipment or electronic

May cause the equipment to fail or malfunction.

Examples of electronic equipment to avoid:

Do not put sand, dirt, or mud on the product or put it on them directly. Do not touch the product with hands Don't to which sand or others adhere.

May cause fire, burns, injuries, or electric shock, etc.

Do not charge when the product is wet with water Do not charge when the product is well with the (drinking water, perspiration, seawater, urine of pet Don't animals, etc.).

Also, please do not charge in places that touch water such as a bathroom.

May cause fire, burns, injuries, or electric shock, etc.

Do not subject the product to strong pressure or break the product. Especially when bringing the product putting in a pocket of clothes, do not let the product hit against surroundings or being put between the obiects. Doing so may cause fire, burns, or injuries, etc. due to

> attery damage. \* Examples to avoid

Sitting or squatting with the product put in a pocket of trousers or skirt

Putting the product in a pocket of outer wear and

catching them in a door or a door of a car Stepping on the product on a soft object such as a

sofa, bed, or bedding, or on a floor Do not disassemble or modify the equipment.

May cause fire, burns, injuries, or electric shock, etc.



Do not let the product get wet with water (drinking water, perspiration, seawater, urine of pet animals, Do not let the product get wet with water (drinking

May cause fire, burns, injuries, or electric shock, etc.

- 6 -

If the display breaks and the fluid leaks out from inside, do not let the fluid contact with the do not let the fluid contact with the skin on your face or hands or clothes. May cause eyes or skin problems.

If the fluid, etc. enters your eyes or mouth, etc., or contacts

skin or clothes, immediately flush the contacted area with If the fluid, etc. enters your eyes or mouth, etc., immediately see a doctor after flushing.

Do not exert excessive force when removing back Don't May cause back cover's damaging, injuries, etc.

Do not get a part of body such as fingers caught when attaching back cover. Don't May cause injuries, etc

Do not use the product with the back cover removed. May cause burns, injuries, or electric shock, etc.

To use the product in car, check with the automobile manufacturer or dealer to determine how vehicle devices are affected by radio waves before using. In rare cases, the product's signals in some vehicle models can cause the vehicle's electronic equipment

to malfunction. In that case, stop using the product mmediately. If you develop skin problems, stop using the product

mmediately, and see a doctor. The use of the product may cause itching, rashes, eczema. or other symptoms depending on the user's physical

For materials of parts →P.22 "Material list"

- 13 -

### **CAUTION**

O not touch the specified charger (sold separately) for a long time while they are connected to an outlet Don't or accessory socket. May cause burns, etc

au IC Card

Be careful of the cut surface when held long such as fingers, as it may damage a part of your body such as fingers, Be careful of the cut surface when handling au IC Card

- 15 -- 16 - 17 -- 18 -- 19 -

# **CAUTION**

- 20 -

May cause injuries, etc. by the sharp cut surface

# **⚠** WARNING

Wearers of medical equipment such as implanted pacemakers or defibrillators must carry and use the product at least 15 cm away from the implanted

The product's signals may affect the performance of electronic medical equipment.

When electronic medical equipment other than implanted pacemakers or defibrillators are in use outside of medical facilities (such as in home care settings), check with the device manufacturer to determine how the device is affected by electrical The product's signals may affect the performance of

Make sure that the product will not emit any signals (turn off power, put it in Airplane mode, etc.) if within 15 cm of those around you, such as where crowded and you cannot move freely.

Wearers of implanted pacemakers or defibrillators may be nearby. The product's signals may affect the performance of electronic medical equipment.

- 21 -

Obey rules inside medical facilities regarding use of the terminal in such facilities.

The product's signals may affect the performance of electronic medical equipment.



(The battery pack of the product is a lithium-ion battery) When you purchase your product, the battery pack is not fully charged. Charge the battery before using the product. Also charge the battery before using the product if you have not used the product for a long time.

- Use in very hot or cold environments, for example, when left in a car with the windows closed in summer, will cause the battery capacity to drop and shorten the available battery usage time. This will also shorten the battery pack service life. Try to use the product as far as possible at room temperature.
- If the product is not to be used for a long time, remove the
- The battery pack is a consumable item. If the performance of the battery pack does not recover (e.g. the usable time after each charge has become extremely short), the battery is at the end of service life, so stop use, and purchase a specified, new battery pack. The life time of the battery pack depends on the usage,
- Battery packs sometimes swell up as they approach the end of their service life. This is due to the properties of lithium-ion batteries, and is not a problem in terms of safety.
- Do not use a battery pack that has been damaged, or leaks liquid. Doing so might cause a fault, etc.
- no not get the battery pack wet. Doing so may cause fault, etc If you accidentally drop the product in water, immediately turn off the power, remove the battery pack, and contact an au shop or Renair and Delivery Service Center. Do not charge a wet battery

- 28 -

### Material list

Part	Material	Surface treatment
Outer case	PC + ASA resin + GF30%	UV coating
Display	Glass	Black printing
Earpiece (receiver)	SUS	Baking finish
Volume key (UP/DOWN)	PC	UV coating
Power key, Power key decoration, Camera lens decoration	PC	UV coating
Camera lens	MR58U	2 times back printing
au IC Card slot / microSD memory card slot	SUS+Cu	Ni+Au
Speaker decoration part	ISPM + Tape	1 time printing

<Back cover>

Part	Material	Surface treatment
Main unit	PC	UV coating
<battery pack=""></battery>		

Part	Material	Surface treatmen
Outer (front, back, left and right)	Al	-
Outer (top and bottom)	PC	Texture
Terminal part	CU	Electroplating (nickel + gold)

- 22 -

 Be sure to use the recessed part of this product to remove the battery pack. Attempting to remove the battery pack from other parts than the recessed part of this product may cause damage o the connection terminal of this product.

- When using the recessed part of this product, please do not insert a thin tip such as a pen. May cause fire, break or damage.
- If the warning beep sounds and "Battery low" is displayed on the display, the battery is exhausted. Charge it quickly or replace

### Charging equipment

- Do not wrap the cord of the specified charging equipment (sold separately) around the adapter itself. Do not forcibly bend a plug of the charging equipment or the connection between the connector and power cord. Do not place heavy objects on the adapter cord or USB cable, or apply unnecessary force by strongly pulling them, etc. May cause malfunction.
- When unplugging the plug of the specified charging equipment (sold separately) from the power outlet or accessory socket, hold and pull the power plug. Pulling on the cable might damage it.

### au IC Card

- Do not forcibly remove or insert the au IC Card. Be careful not to xert excessive force when inserting the card into your au cell phone.
- You are responsible for any damage caused by inserting your au IC Card into some other IC card reader/writer, etc.
- Do not put stickers, etc. on the au IC Card.
- Do not insert au IC Card with a conversion adapter. May cause
- Do not damage the card (use in a hot place, throw into fire) contact the metal part with foreign object, give an impact, bend, apply a load, moisten, etc.). May cause data loss or malfunction.

- 29 -

### Handling Precautions

These precautions are provided to prevent damage to the product and ensure that performance can be fully demonstrated. Thoroughly read these precautions to ensure correct use.

- Precautions common to the main unit, back cover, battery pack, charging equipment, au IC Card, peripheral devices
- Do not apply excessive force to the product during use. Be sure not to put the product into a tightly packed bag or place a neavy object on the product in a bag. Sitting on the product in your pocket might damage the display or internal circuit board resulting in a malfunction Keeping an external device connected to the external connector or earphone lack might damage the connector resulting in a
- malfunction. Such damage and malfunction are not covered by the warranty, even if there is no external damage. Do not use the product in extremely hot cold or humid places (Use within an ambient temperature range of 5°C to 35°C and humidity range of 35% to 85%.)
- Do not use in places subject to lots of dust or vibration. May
- Occasionally clean the external connection terminal and
- earphone terminal with a dry cotton bud. Dirty terminals may result in a poor connection. Also do not forcefully clean the terminals as this may deform them. Clean the product with a soft dry cloth (such as the type used)
- for eyeglasses). Forceful rubbing with a dry cloth may scratch the display The display may be stained if splash or smear is left attached to the surface. Wiping the product using alcohol, thinner, benzene, detergent, glass cleaner, etc. might erase the printing on the outer casing or cause malfunction.
- Use as far away as possible from land-line phones. TVs. and radios. Use nearby might affect them

 When disposing of the terminal, follow the rules regarding disposal in your area.

### ■ Camera

- When photographing important occasions, take a trial shot in advance and check the shot image to make sure it is correctly shot.
- Do not shoot where shooting is prohibited.

### ■ Copyrights and rights of portrait

- You are not allowed to copy, distribute, publish, modify or edit the data you shot, recorded or downloaded using the product without the consent of the copyright holder, except for personal use, under the copyright law.

  In addition, do not use or modify portraits or names of other
- ndividuals without their consent, as it might infringe on rights of Note that shooting and recording may be restricted at some live
- Be careful about the copyright and portrait right when posting ages you shot, etc. on Internet homepage
- Backup content on the product
- Please back up important content recorded or downloaded memory on the product sometimes disappears or is altered by unexpected factors, such as static electricity or a fault, repair shandling, etc.

### ■ FCC Compliance information

 The product is certified by Federal Communications Commission ECC ID of this product is ZNELET

### The product may become warm while charging, etc., depending on the situations, but this is not abnormal. When using a charging equipment or external device, insert/ remove the connector straight to/from the terminal. Make sure

- Do not place near corrosive chemicals or in places where corrosive gas is generated. May cause malfunction.
- the battery pack before turning off the power may result in corruption or loss of saved data.

Turn the power off before removing the battery pack. Removing

- Do not use outside when you can hear thunder. May risk lightning strikes and electric shock.
- Be sure to use only the specified peripheral devices. Use of other devices might cause malfunction.
- Do not put the product into a heating cooking device such as a vave oven or high-pressure container. May cause malfunction The customer is not allowed to disassemble, modify or repair the
- product. May cause malfunction. Modification of the product is in violation of the Radio Law and Telecommunication Business Act Do not allow conductive foreign objects (metal fragments, pencil)
- leads, etc.) to come into contact with or get inside the connection terminal, earphone terminal, etc. to avoid the connection terminal, earphone microphone terminal, etc. from short-circuit. Do not let the product get wet with water. Do not use in a humid
- place such as a bathroom. And do not touch it with wet hands. Doing so might result in short-circuiting of electronic circuits or corrosion Malfunctions determined to be caused by water intrusion or
- humid are not covered by the warranty If the product gets wet while charging, immediately disconnect
- the power plug of the specified charger (sold separately). Do not use while driving a car or riding a motorbike or bicycle
- or while walking. Use while driving a car or riding a motorbike is prohibited by law. Use of a cell phone while riding a bicycle may pe punishable by some regulations.
- Using or charging the product inside a bag or covered with bedding, etc. may cause malfunction. - 24 -

# Bluetooth®/Wireless LAN (Wi-Fi®) Function

- The Bluetooth® function and the wireless LAN (Wi-Fi®) function of this product conforms to the domestic standards of Japan, FCC standards, and EC directives, and has been certified. In some countries and regions, use of the Bluetooth® and
- wireless LAN (Wi-Fi®) functions may be restricted. Before you start using the product overseas, check the relevant laws and regulations of the country/region you visit. The 2.4 GHz band used by wireless LAN (Wi-Fi®) and Bluetooth® devices is shared by various other devices. For this reason, the
- communication speed and connectable range may be decreased or disconnection may occur, due to interference from other devices. Do not use this product in places where electromagnetic waves
- are generated or near electric products, AV and OA equipment, or other magnetized devices.
- Subjecting this product to magnetic or electrical noise might increase noise and prevent it from performing communications This product is particularly susceptible to noise when it used near a microwave oven.) Using this product near a TV, radio or similar appliance might
- cause reception interference and disrupt TV images. The searching might not be successful if there are multiple
- wireless LAN (Wi-Fi®) access points near to the product or the same channel is being used. Use of cell phones on board is restricted. Follow the instructions
- of each airline. The communication speed and connectable range vary depending on the distance between communication devices, obstacles and the devices to connect

- 31 -

# Do not store or leave the product in places subject to direct

 Do not expose the camera lens to direct sunlight for an extended period. May cause malfunction

the orientation of the connector. Unless it's correct, it may

- sunlight (e.g. in automobiles), places that get hot, places that get extremely cold, or in humid or dusty places. May cause malfunction Do not leave the equipment on unstable or sloping surfaces.
- Be careful especially while charging or the vibrator is set. The product might fall causing malfunction.
- Do not use nower outlets or wiring apparatus beyond its rating when charging the product, for example, by connecting multiple devices to a single power strip.

### ■ Main unit

IEEE802.11b/g/n

IEEE802.11a/n/ac

W52 W53 W56

2.4FH1/DS4/OF4/XX8

- Do not forcefully press, strike, or intentionally subject the display to strong impact. May cause scratching or damage. Do not forcefully press your fingernails, sharp objects, or hard
- objects against keys or display surface. May cause scratching • The touch panel is designed to be lightly touched by fingers.
- Do not apply strong pressure with your fingers, or sharp-pointed objects (such as fingernails, ballpoint pens and pins) on the touch panel. In the following cases, the product may not respond to touch

the touch panel, errors in operation may occur or may cause malfunction. Operation with gloved hands / Operation with fingernails /

Operation with a foreign object placed on the touch panel / Operation with a protective sheet or sticker on the touch panel / Operation with water drops left or frozen on the surface / Operation with wet or sweaty fingers

- 25 -

# This product supports security features for wireless communications (Wi-Fi<sup>®</sup>) function.

### 2.4 GHz Frequency Band Precautions

The frequencies used by the Bluetooth® and/or wireless LAN (Wi-Fi®) function of this product are in the 2.4 GHz band. In this frequency band, other similar wireless stations, in-plant wireless stations for mobile unit identification that require a license to use, such as factory production lines, specific small power wireless stations that do not require licenses, amateur wireless stations (collectively called "other wireless stations" from here on) are operated in addition to home electrical appliances such as microwave ovens, devices for industrial, scientific and medical devices. 1. Before using the product, make sure that "other wireless stations"

- are not in operation nearby.

  2. In the event that instances of radio wave interference have occurred
- between this product and "other wireless stations", immediately either relocate this product or stop operation of the device (stop the emission of radio waves). 3. If you are unclear on any points or are troubled by anything, contact
- an au shop or Customer Service Center.

### memo

The connections between this product and all other Bluetooth® and wireless LAN (Wi-Fi®) devices have not been confirmed. Therefore, connections with all Bluetooth® and wireless LAN (Wi-Fi®) devices have

### that are compliant with the Bluetooth® and wireless LAN (Wi-Fi®) standard specifications, but the security may not be sufficient depending on the usage environment and configuration. Be careful vhen making data communication using Bluetooth® or wireless LAN Wireless LAN (Wi-Fi®) has the advantage that it can be freely

\*Technical Conformity Mark \*\* is displayed in the printed seal of the IMEI that affixed to the place where the battery pack was

removed. "Technical Conformity Mark @" is a proof that this

Never use modified products. Use of a modified device violates

The product has acquired the certification of conformity with technical regulations for the specified radio station based on

the Radio Law, and to such regulations as technical conformit

based on the Telecommunications Business Law. And the "Technical Conformity Mark (\$\mathbb{e}"\) is displayed on the nameplate

If the product is modified by turning the screw to the left to disassemble, technical standard compliance becomes invalid.

Never use the product without the valid certification. Doing so

violates the Radio Law and Telecommunications Business Lav

cards, speakers and TV sets near the product, as it might cause malfunction. Putting a strong magnetism close to the product

Take care not to place magnetized items such as magnetic

Do not bring magnetic cards such as cash cards, credit cards, and prepaid cards near to the product. May result in loss of

When you put the product in your pocket or bag, take care so that

the display does not come in contact with metal objects or other

hard objects. May cause scratching or damage. Also, be careful

not to scratch or damage the display by using a strap whose

or when in a humid location, or when used where temperature

suddenly changes such as near the air discharge port of an air conditioner, water droplets (i.e. condensation) sometimes form

- 26 -

inside the product. Note that when used under conditions such

metal or other hard part comes in contact with the display

When suddenly brought into a warm place from a cold place

as this, the humidity might cause corrosion or a fault.

the Radio Law and Telecommunications Business Law.

I aw, so please do not remove it.

sticker on the product unit.

might cause false operation.

recorded information.

- connected anywhere within the radio wave range, as it uses radio aves for exchanging information. At the same time, there is a risk that a malicious third party may obtain unauthorized access if security settings have not been configured. You are recommended o configure security settings before using wireless LAN at your decision and responsibility.
- The Company assumes no responsibility for leakage of data or information that may occur during Bluetooth®/wireless LAN (Wi-Fi®) Since Bluetooth® and wireless LAN (Wi-Fi®) functions use the same
- requency band, using the both functions at the same may cause radio wave interference resulting in decreased communication speed or disconnection from the network. If connection fails, stop using either of the Bluetooth® and wireless LAN (Wi-Fi®) functions.

Bluetooth® and wireless LAN (Wi-Fi®) functions of this product use frequencies in the 2.4 GHz band Bluetooth® function: 2 4FH1/XX8

- This product uses the 2.4 GHz band. For FH1, FH-SS is used as the modulation scheme. The interference distance is about 10 m or less XX8 uses other schemes and interference distance is about 80 m
- Wireless LAN (Wi-Fi®) function: 2.4DS4/0F4
  This product uses the 2.4 GHz band. DS-SS and 0FDM are used as the modulation schemes. The interference distance is about

- 33 -

 While writing/reading data to/from a microSD memory card, do not give the product to vibration or remove the battery pack or impact or turn off the power. May cause loss of data or a fault

- Do not cover the light sensor with your finger or put a sticker on it. May hinder the sensor from detecting the ambient light level
- product and communication module used by customers are compliant with the Radio Law and Telecommunications Business and functioning correctly. When you put a sticker, etc. on the proximity sensor, the sensor will malfunction and indications on the display will turn off at all
  - may not be able to operate the product. Do not use the product with the back cover removed. Also, do not leave or store. Doing so might allow dust or other foreign
  - objects to get inside and cause a fault. Do not allow liquids, metal objects, and other foreign matter to get inside the au IC Card and microSD memory card slot of the
  - product. May cause malfunction Do not drop, throw, or step on the product or give a strong force
  - or vibration to it. May cause malfunction. Do not place the product directly on sand at a beach, etc. Sand or other small particles might get inside the earpiece (receiver),

mouthpiece (microphone), sub microphone, speaker, etc., causing the volume to drop. If sand gets inside the product's

### ■ Touch Panel

 Putting stickers or sheets (e.g. commercially available protective films, peep prevention sheets) on the display might cause improper reaction of touch panel.

main unit, it might cause malfunction.

 When carrying the product in your pocket or bag, take care. not to put the touch panel close to metals or other conductive materials, as it might cause false operation of the touch panel.

- 27 -

his means that full band can be used, and that band of mobile unit identification devices can be avoided.

Available channels differ depending on the country For use in an airplane, check with the airline company in advance.

### 5 GHz Frequency Band Precautions Wireless LAN (Wi-Fi®) function of this product uses 5 GHz band.

Using the 5.2 GHz band and 5.3 GHz band (W52/W53) outdoors is prohibited by the Radio Law. Except when communicating with access point of 5.2 GHz high-output data communication system or relay station

he channels used on the product are as follows.

W52 (5.2 GHz band/36, 40, 44, 48 ch) W53 (5.3 GHz band/52, 56, 60, 64 ch) W56 (5.6 GHz band/100, 104, 108, 112, 116, 120, 124, 128.

Bandwidth to use: Full hand

132, 136, 140 ch)

118, 126, 134 ch)

■ HT20 [a/n], VHT20 [ac]

■ HT40 [n], VHT40 [ac]

■ VHT80 [ac] W52 (5.2 GHz band/38, 46 ch) W52 (5.2 GHz band/42 ch) W53 (5.3 GHz band/54, 62 ch) W53 (5.3 GHz band/58 ch)

W56 (5.6 GHz band/102, 110, W56 (5.6 GHz band/106, 122

# Security code/PIN code

### Available security codes

The product has various security codes that you can use. The available security codes are as follows. Do not forget the various security codes that are set as they are necessary for various operations and contracts.

Make sure to change the initial value to your own unique number.

 Security code Example of To do remote operation of voice mail and call

 To use Customer Service Center and to do various inquiries, applications, and modifications on the au homepage A four digit number chosen by the customer and

forwarding services from a landline phone

### Screen lock setting

usage	To set and release the screen lock
Initial value	Swipe

# PIN Code

To prevent unauthorized use of the au IC Card by a third party, you can set the product to require PIN 1 code entry every time the power is turned on. You also need to enter PIN 1 code when setting whether the PIN 1 code entry is required. If the PIN 1 code is incorrectly entered three times consecutively,

. The default PIN 1 code is "1234" and does not need to be changed but you can change the PIN 1 code to any four- to eight-digit number if necessary, and you can change settings so that the PIN 1 code must be entered If you require a PIN 1 code to be entered, make sure to change

the PIN 1 code will be locked. You can unlock the PIN 1 code using

### ■ PUK code

case the PIN 1 code is locked, you can unlock it by entering the PUK code.

the number to your own unique number.

- PUK code is an eight-digit number given at the time of purchase, which is printed on the back side of the plastic card on which your au IC Card is attached. After entering the PUK code, you need to set a new PIN 1 code.
- If the PUK code is incorrectly entered 10 times consecutively. contact an au shop, PiPit or Customer Service Cente PIN 1 code is not reset by Factory data reset.

### Notes on Data Communication Charge

- 30

- Since a constant Internet connection is possible with the product. data communication may be performed automatically by some applications, resulting in high data communication charges. Therefore, subscription to a data communication charge discount rvice or flat late plan is recommended.
- On the product to browse websites, download applications. communicate using applications, send/receive mails, and configure various settings, connection to the Internet is required, to which data ommunication charge applies.
- Data communication charge does not apply to wireless LAN (Wi-Fi®) connection.

### Applications

- · Be sure to check the security of the application, then install it at your own risk. Some applications might cause virus infection, damage various data, and send out your location information, usage history or personal information stored in your cell phone via the Internet.
- The Company assumes no responsibility for any operation problems that might be caused by the applications you have installed. In such case, you may be charged a repair fee even during the warranty period. The Company assumes no responsibility for any disadvantage brought.
- to you or any third party by applications you have installed. · Depending on applications, microSD memory card is required when using the application. Some applications does not enter sleep mode while they are active, or

rapidly drain the battery while running in the background.

· Operational procedures and screen appearances of the applications preinstalled in the product and those installed by you are subject to change without notice as a result of version upgrade. In addition, operating procedures described in this manual may differ from the actual procedures.

### Cell Phone Etiquette

### Use of the product is not allowed in the following places!

- Do not listen to music or watch videos while driving a car or riding a motorbike or bicycle. Use of cell phones while driving a car or riding a motorbike is prohibited by law. (Use of cell phones while riding a bicycle may also be punishable by law.) In addition, stay alert to the traffic around you even when walking. Surrounding sounds may not be heard clearly, and gazing at the screen might distract your attention causing a traffic accident. Be especially careful at railroad crossings, on a platform, and at pedestrian crossings. · Use of cell phones on board is restricted. Follow the instructions
- Consider people around you
- To prevent ringtone from bothering other people, not only refrain from making a call but also power off or use Silent mode at a movie theater, theater, museum, library, etc. In a city area, use in a place where you do not bother people walking.
- It is extremely dangerous to walk while looking at the screen of the cell phone. Do not make calls or operate a cell phone while walking or by stopping suddenly. Move to a place where you do not disturb others while you are in
- Be careful not to be loud while talking. Be careful of sound leakage from earphones in trains or other places with many people around you.

shinkansen, a hotel lobby, etc.

- Ask permission if you take photos with your cell phone camera. · When using the camera, follow common rules of etiquette
- regarding camera use.

 There may be a person with a cardiac pacemaker nearby at a place filled with people such as in a crowded train. Set "Airplane" mode" or turn off beforehand. When a medical institution has laid down designated areas

- 32 -

where the use of the product is prohibited or is not allowed to be brought in, follow the instructions of that medical institution.

### Specific Absorption Rate (SAR) of Cell Phones

This model "LG it" mobile phone complies with Japanese technical regulations and international guidelines regarding exposure to radio This mobile phone was designed in observance of Japanese

technical regulations regarding exposure to radio waves\*1 and limits to exposure to radio waves recommended by a set of equivalent nternational guidelines. These international guidelines were set out by the International Commission on Non-Ionizing Radiation Protection (ICNIRP), which is in collaboration with the World Health Organization (WHO), and the permissible limits include a substantial safety margin designed to assure the safety of all persons, regardless of age and health condition.

The Japanese technical regulations and international guidelines define the limits using a unit of measurement known as the Specific Absorption Rate (SAR), which represents the average amount of radio frequency energy absorbed by the human. The SAR limit for mobile phones is 2.0 W/kg. The highest SAR value for this mobile phone when tested for use at the ear is 0.820 W/kg\*2. The highest SAR value for this mobile phone when tested for use on the body is 0.541 W/kg\*2. There may be slight differences in SAR levels among individual products, but they all satisfy the limit. The actual SAR of this mobile phone while talking on the phone can be well below that indicated above. This is due to automatic

changes in the power level of the mobile phone to ensure it only station. Therefore in general, the closer you are to a base station. the lower the power output of the mobile phone. is mobile phone can be used in positions other than against your

ear. Use an accessory such as a carrying case, etc. so that you can

hold the product at least 1.5 cm away from your body and also do not contain metal parts between the product and your body. By doing this, this mobile phone complies with Japanese technical regulations and international guidelines regarding exposure to radio waves.

The World Health Organization has stated that present scientific information does not indicate that use of mobile devices has any harmful effects on the human body. They recommend that if you are still worried about your exposure then you can limit your talk time or use a handsfree kit to keep the mobile phone away from your head and body.

If you would like to know more detailed information, please refer to

the WHO website. http://www.who.int/emf Please refer to the websites listed below if you would like to know more detailed information regarding SAR.

http://www.tele.soumu.go.jp/e/sys/ele/index.htm OAssociation of Radio Industries and Businesses Website: https://www.arib-emf.org/01denpa/denpa02-02.html (in Japanese only)

OMinistry of Internal Affairs and Communications Website:

Oau Website: https://www.au.com/english

OLG Electronics Inc. Website:

Refer to "Specifications" page of this product. https://www.lg.com/jp/mobile-phone (in Japanese only) (URL are subject to change without notice.) \*1 Technical regulations are defined by the Ministerial Ordinance

Related to Radio Law (Article 14-2 of Radio Equipment Regulations). \*2 This value includes the wireless function available for

### Export Administration Regulations

This product and its accessories may fall under the category of application of Japan Export Control Regulations ("Foreign Exchange and Foreign Trade Law' and relevant laws and regulations). U.S. Re-export Regulations (Export Administration Regulations) is applied to this product and its accessories. If you export or re-export this product or its accessories, please follow the necessary procedures at your own risk and expense. For details on the procedures, contact the Ministry

- 34 -

### Intellectual Property Right

### Trademarks

All company names and product names in this manual are either trademarks or registered trademarks.

rademarks of SD-3C, LLC. Bluetooth® word mark and logos are registered rademarks owned by Bluetooth SIG, INC. LG

Electronics Inc. have the rights of using the above

Google Play logo, Gmail are trademarks of Google LLC iWnn of OMBON SOFTWARE CO., Ltd. is used for conversion methods

Facebook and Facebook logo are trademarks or registered of Facebook, Inc.

registered trademarks of respective companies referred to in this

- 41 -

- 37 -- 38 -- 39 -

of Economy, Trade and Industry or the U.S. Department of Commerce

The microSD logo, microSDHC logo, and microSDXC logo are 

Wi-Fi®, Wi-Fi Direct® are registered trademark of Wi-Fi Alliance®

**Bluetooth** 

Google, the Google logo, Android, the Android logo, Google Play, the

for Japanese language. iWnn© OMRON SOFTWARE Co., Ltd. 2008-2018 All Rights Reserved.

All other company names and product names are trademarks or

### OpenSSL License

[OpenSSL License]

Copyright © 1998-2011 The OpenSSL Project. All rights reserved.

This product includes software developed by the OpenSSL Project for use in the OpenSSL Toolkit. (http://www.openssl.org/) THIS SOFTWARE IS PROVIDED BY THE OpenSSL PROJECT
"AS IS" AND ANY EXPRESSED OR IMPLIED WARRANTIES,
INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF

MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE OPENSSL PROJECT OR ITS CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT. INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES: LOSS OF USE, DATA, OR

PROFITS: OR BUSINESS INTERRUPTION)
HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY. WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE

### [Original SSLeay License]

Copyright © 1995-1998 Eric Young (eay@cryptsoft.com) All rights reserved. This product includes cryptographic software written by Eric Young

THIS SOFTWARE IS PROVIDED BY ERIC YOUNG "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE AUTHOR OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING

- 42 -

USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

### Open Source Software Notice Information

To obtain the source code under GPL, LGPL, MPL, and other open source licenses, that is contained in this product, please visit http://opensource.lge.com. In addition to the source code, all referred license terms, warranty disclaimers and copyright notices are available for download. LG Electronics will also provide open source code to you on CD-ROM for a charge covering the cost of performing such distribution (such as the cost of media, shipping, and handling) upon email request to opensource@lge.com. This offer is valid for a period of three years after our last shipment of this product. This offer is valid to anyone in receipt of this information.

For software installed in this product or part of the installed software, you are not allowed to change, translate or adapt, reverse, engineering, decompile, reverse assemble them, or do anything related to the above.

This product is licensed complying with the MPEG-4 Visual

Patent Portfolio License. If you use it for private purpose without any profits, you are allowed to use them only when:

- Recording videos that are compliant with the standard of MPEG-4 Visual (hereinafter referred to as MPEG-4 Video)
- Plaving MPEG-4 Videos recorded personally by consumers not
- Plaving MPEG-4 Video supplied from the provider licensed from

NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE For further utilizing such as promotion, in-house use or profitmaking business, please contact MPEG LA, LLC in U.S.

- This product has been granted the licenses which code (i) AVC standard compliant video (hereinafter stated as AVC video) based upon the AVC Portfolio License for the individual use of customers, and non-commercial use, and/or the licenses which decode (ii) VC-1 video. (this is restricted to the AVC video that has been coded by customers who are not engaged in individual. and commercial activities, and/or pertains to the provision of coded AVC video from video providers who have been granted the licenses). For any other purposes, licence is not permitted even for the implied usage. Additional information may be obtained
- from MPEG LA, LLC. Refer to http://www.mpegla.com This product has been granted the licenses which code (i) VC-1 standard compliant video (hereinafter stated as VC-1 video) based upon the VC-1 Patent Portfolio License for the individual
- use of customers, and non-commercial use, and/or the licenses which decode (ii) VC-1 video. (this is restricted to the VC-1 video that has been coded by customers who are not engaged in individual, and commercial activities, and/or pertains to the provision of coded VC-1 video from video providers who have been granted the licenses). For any other purposes, licence is not permitted even for the implied usage. Additional information may be obtained from MPEG LA, LLC. Refer to http://www. mpegla.com

- 44

- 43 -



Customer Service Center For general, charge, operations (toll free) Business hours 9:00 – 20:00 (7 days a week)

From fixed-line phones:
From au cell phones:
157 area code not required

Pressing "zero" will connect you to an operator, after calling" 157" on your au cellphone.
In case above numbers are not available,

**£** 0120-977-033 (except Okinawa)

**£** 0120-977-699 (Okinawa) For service canceling procedure in case of loss or theft (toll free)

From fixed-line phones: From au cell phones: 113 area code not required

0120-925-314

Repair and Delivery Service Center





OKINAWA CELLULAR TELEPHONE COMPANY Imported by: LG Electronics Japan Inc. Manufactured by: LG Electronics Inc.