

# Qua phone

## Setting Guide

Thank you for buying the "Qua phone" (simply called the "product" from here on). In this guide, settings and precautions for using the product are described.

For explanations of basic functions, refer to "Basic Manual".

Company names and product names referred to in this manual are trademarks or registered trademarks of respective companies. The TM, ® marks may be omitted in this manual.

Illustrations/screens shown in this manual may look different from the actual product/screens. In some cases, minor details or a part of a screen may be omitted.


December 2015, 1st Edition

Sold by: KDDI CORPORATION • OKINAWA  
CELLULAR TELEPHONE COMPANY  
Manufactured by: KYOCERA Corporation

- Basic Operation**  
Describes the basic operations.
- Initial settings**  
Make initial settings when you turn the power on for the first time.
- au Easy Setting**  
Set au ID.
- E-mail**  
Make initial settings for E-mail (@ezweb.ne.jp) etc.
- Making a call**  
Add a new contact to Contacts to call.
- Receiving a call**  
Describes how to receive a call.
- Setting Wi-Fi®**  
Describes how to connect Wi-Fi® network.
- Viewing/playing data**  
Describes how to view/play still images or video data.
- Saving battery power**  
Describes the setting to save battery consumption using "Eco Mode".
- Transferring data from au Settings Menu**  
Restore/back up data from/to your previously used au phone to/from this product using microSD card or the au Smart Pass server.








### Basic Operation

For explanations of basic functions, refer to "Basic Manual".

**Power button**  
**Power ON**  
Press and hold  (Power button) until the charging light turns on

**Displaying Home screen**  
Swipe (slide)/flick the start screen.

**Chrome icon**  
Use Google Chrome to view Web pages.

**Navigation bar**  
: Return to the previous screen. When  appears in the character entry screen, tap this button to hide the keyboard or menu.  
: Display the Home screen. Long-touching or sliding up this button displays the semi-circular shaped assist ring. Slide it to / /  to activate the Notification panel/ Google (Google NOW)/the slide screen.  
: Show recently-used applications.

**Display**  
Touch directly with your finger to operate.

**Tap**  
Lightly touch a screen and then immediately release your finger.

**Long-touch**  
Keep touching a screen.

**Slide (Swipe)**  
While lightly touching the screen, trace to the desired direction.

**Flick**  
Touch the screen and flick up/down/left/right.

### Character entry

Use flick input or tap a key several times to enter characters.

#### Flick input

Tap a key to display enterable characters as shown in the right. Flick to the direction of the character to enter.

#### Magnifying characters

To magnify characters of menu items etc. operate as follows.

Home screen → [基本機能 (Basic function)] → [Settings] → [Accessibility] → Turn "Large text" to ON

Alternatively, from Home screen → [基本機能 (Basic function)] → [Settings] → [Accessibility] → [Magnification gestures] to magnify the screen. For operation method, see the description on the screen.

### Initial settings

When you turn on the product for the first time after purchasing the product, follow the onscreen instructions to set language, functions and services.

#### Setting up Google account

Set up Google account to use Google applications such as "Gmail", "Play Store", "Hangouts".

Setting items are as below (besides the items below, register "First" name and "Last" name).

User name	Register your Google account (user ID) and a character string for mail address. You can register a desired name, but a name already registered by another user cannot be set.
Password	Register password for the Google account.

**1** Welcome  
Select "English".  
\* You can change the display language even after the initial settings.

**2** Select Wi-Fi network  
Set up the Wi-Fi network to connect as required.  
\* If you do not set up, tap "SKIP".

**3** Tap & Go  
[SKIP]  
For using Tap & Go, follow the onscreen instructions.

**4** Add your account  
[Or create a new account]  
\* If you have a Google account, enter a mail address → [NEXT].

**5** Create a Google Account  
Enter "First name" and "Last name" → [NEXT]

**6** How you'll sign in  
Enter a user name → [NEXT]  
Checking registration of user name starts.

**7** Create password  
Enter a password and reenter the password for confirmation → [NEXT]

**8** Add phone number  
Check/change the country name and phone number → [NEXT]<sup>1</sup> → [VERIFY]  
\* If you do not set up, tap "SKIP".

**9** Privacy & Terms  
Check the contents, then [I AGREE]

**10** Your Google Account  
Check the contents, then [NEXT]

**11** Set up payment info  
Make purchase settings of Google Play as required → [NEXT]

**12** Protect your phone  
[SET SCREEN LOCK NOW] → Follow onscreen instructions to set security and notification  
\* If you do not set up, tap "SKIP".

**13** Google services  
Confirm the Google service settings, then [NEXT]

<sup>1</sup> Text message for Google verification code will be sent to the set phone number.

#### Changing display language via Settings menu

Home screen → [基本機能 (Basic function)] → [設定 (Settings)] → [言語と入力 (Language & input)] → [言語 (Language)] → Select "English" → [OK]

### au Easy Setting

By setting an au ID, you can use various services provided by au such as "au Kantan Kessai" which allows you to purchase applications from the auスマートパス (au Smart Pass) or Google Play. Main setting items are as follows.

au ID*	Register your au phone number or a character string for au ID (user ID).
au ID password	Register password for using au ID.

\* "au ID" which is already used by another user cannot be set.

If you skip the operation of "au Easy Setting" at that time, you can set au ID later. In that case, operate from Home screen → [基本機能 (Basic function)] → [Settings] → [au Settings Menu] → [au Easy Setting], or from Home screen → [au フォルダー (au folder)] → [au ID Setting]

**1** Welcome to au  
Welcome to au screen → [Next]

**2** au ID Registration  
[Register "au ID"] → [Next]

**3** au ID Setting  
[au ID の設定・保存 (Set and save au ID)]

**4** au ID Setting  
Enter the security code → [OK]  
\* Default value is a four-digit number written at subscription.

**5** au ID Setting  
Enter a security password → [設定 (Settings)] → [終了 (Exit)]

**6** Update  
[Update] → [Next]

**7** Terms of Use of au Services  
Check the terms and conditions (reading requires), [Agree] → [Next]

**8** Terms of Use  
[Agree]<sup>1</sup>

**9** Automatic Backup Setting  
[Turn Auto Backup on/ Turn Auto Backup off] → [Next]  
\* To back up photos and contacts to au Smart Pass automatically using "Data Storage App", tap "Turn Auto Backup on".

**10** おすすめアプリ  
Select apps to install → [次へ (Next)]  
\* If there are apps to be restored, the restoration of apps screen appears. Follow the onscreen instructions.

**11** Texting While Walking Alert  
[Activate]/ [Skip activation] → [Next]

**12** データを戻す  
Select data to restore → [次へ (Next)]  
\* When the screen for checking Wi-Fi® connection is displayed, follow the onscreen instructions.

**13** Initial Setting Completed  
[Finish]  
When the screen for use confirmation or explanation of au Basic Home for Qua app is displayed, follow the onscreen instructions.

<sup>1</sup> Configurations for LISMO and Lookout for au are complete when you tap "Agree".

### E-mail

To use E-mail (@ezweb.ne.jp), subscription to LTE NET is required.

If you did not subscribe it when you purchased the product, contact an au shop or Customer Service Center.

Your E-mail address is determined automatically after initial setting. You can change the E-mail address later.

#### Initial settings

**1** Home screen → [メールアプリ (Mail app)]

**2** Check the contents, then [接続する (Connect)]

**3** Check your E-mail address → [閉じる (Close)]

**4** Check the contents, then [Agree]/ [Disagree] → [Done]

**5** When Outline of customer information for "About use of customer information" appears, tap "Accept". Subsequently the explanation screen for E-mail function appears. Confirm the contents and then tap "Close".

#### Changing your e-mail address

**1** Home screen → [メールアプリ (Mail app)]

**2** [メニュー] → [Change Address/Setting Filter]

**3** Check the contents, then [接続する (Connect)]

**4** [Eメールアドレスの変更 (To Change E-mail address)]

**5** Enter the security code → [送信 (Send)]

**6** Check the contents, then [承諾する (I accept)]

**7** Enter E-mail address → [送信 (Send)]

**8** [OK]

**9** [閉じる (Close)]

#### Checking your E-mail address

Home screen → [メールアプリ (Mail app)] → [MENU] → [E-mail information]

#### Backing up E-mail

You can back up E-mail.  
Backed up data is saved on a microSD memory card (/SD card/private/au/email/BU/) when a microSD memory card is attached. If a microSD memory card is not attached, data is saved on the internal storage (/internal storage/private/au/email/BU/).

**1** Home screen → [メールアプリ (Mail app)]

**2** [メニュー] → [E-mail settings]

**3** [Backup/Restore]

**4** [Mail Backup] → Confirm the notes and [OK]

**5** Select a character code to make backup data → [OK]

**6** Select a folder to back up → [OK]

#### Setting other than E-mail

You can set mail addresses except for E-mail (@ezweb.ne.jp).


You need to use up an account to use it. For the first time use, make settings as follows.

Home screen → [Google] → [Gmail] → Follow the onscreen instructions.

## Making a call


### ■ Adding new contact and making a call

1



Home screen → [Others Apps] → [Contacts] → Tap "CONTACTS" tab


2



[ADD] → Enter necessary items → [SAVE]

\* When "ADD" is not displayed, [CREATE A NEW CONTACT] → [Phone]/[ADD NEW ACCOUNT], then follow the onscreen instructions to register a contact/account.

3



[Call icon]


### ■ Making a call from the call history

1



Home screen → [Call icon] → Tap "RECENT CALLS" tab

2



[Call icon] of a party to call

### Checking your own phone number (Profile)

Home screen → [基本機能 (Basic function)] → [Settings] → [Profile]

Profile screen appears. If you have done the initial settings for "E-mail" app, your e-mail address is displayed.

## Receiving a call

You can receive a call in the following steps.

- \* The incoming screen differs from the one in sleep mode or while the start screen is displayed.
- \* "Receive an incoming call over the operation screen" is set to "ON" in "Sync Call settings" by default. When you set it "OFF", follow the onscreen instructions.

### ■ Calling

Example: When a call is received while Home screen is displayed

1



Receiving screen → [Accept]

2



Calling starts


3



To end the call [End]

Example: When a call is received in sleep mode or while the start screen is displayed

1



Receiving screen → Tap "Answer" and slide right when "Ⓢ" appears.

2



Calling starts

3




To end the call, [END CALL]

### ■ Answering with Auto answering


Answer by the answering memo message and record a message of the party when you cannot answer calls.

1




The incoming screen → [MENU]

2




Drag the operation panel down

3




[MENU] → [Reply Auto answering]

4



The caller hears the guidance.

5



To answer a call, tap "Answer" and slide right when "Ⓢ" appears.

## Setting Wi-Fi®

Use your home Wireless LAN (Wi-Fi®) or public wireless LAN to connect to the Internet.

Main settings are as follows.

Wi-Fi Easy Settings	Answer to the questions on the screen or follow the instructions to register an access point easily.
WPS system	Use for registration of access point compatible with Wi-Fi Protected Setup™ with WPS mark.

- \* If you turn on wireless LAN (Wi-Fi®) function, battery consumption increases. You are recommended to turn wireless LAN (Wi-Fi®) function to OFF when not using wireless LAN (Wi-Fi®) function.

1



Home screen → [基本機能 (Basic function)] → [Settings]

2



[Wi-Fi]

3



Turn "ON" and [Wi-Fi icon]

4



[Wi-Fi Easy Settings]

5



Answer the questions on the screen and follow the instructions to register an access point.

Available Wi-Fi® networks are listed. Select a Wi-Fi® network to connect → Enter a password as required → [CONNECT] to connect the Wi-Fi® network  
If a Wi-Fi® network you want to connect cannot be detected, operate from [Wi-Fi icon] → [Add network] and connect the Wi-Fi® network manually.


### ■ Using Wi-Fi Easy Settings

4



[Wi-Fi Easy Settings]


5



Answer the questions on the screen and follow the instructions to register an access point.


### ■ Using WPS system access point

4



[Advanced] → [WPS Push Button]/[WPS Pin Entry]

5




For using WPS button, tap "WPS Push Button" and then keep pressing WPS button of access point to set to WPS mode. An access point is automatically detected and registration starts.  
For entering WPS PIN, tap "WPS Pin Entry" and enter displayed PIN code for access point, then registration starts.

## Viewing/playing data

By transferring data from the previously used au phone to a microSD memory card, you can view/play\* still image or movie data using "File Commander" in the product. When you activate for the first time, the Terms and Conditions appears. Follow the onscreen instructions.


- \* Copyrighted data on the previously used au phone cannot be transferred to the product. However, some Chaku Uta Full, Video Clip, Chaku Uta Full Plus may be able to be transferred and played on the product with the same phone number by backing up with LISMO Port Ver 4.2 or later.

1



Home screen → [基本機能 (Basic function)] → [File Commander]

2




Tap a category to be displayed → Tap data  
Data is played.

## Saving battery power


Use "Eco Mode" to set sleep time of backlight, screen brightness, etc. so that you can save the battery power. When the battery power is low, set "Data communication" to "OFF" and limit communications only for calling to extend standby time.

1



Home screen → [Others Apps] → [Eco Mode]

2



[ON]/[OFF]


\* Tap "⚙" to check or change the battery saving items.

## Transferring data from au Settings Menu

Restore/back up data from/to your previously used au phone to/from this product using microSD card or the au Smart Pass server.


- Setting au ID is required for restoring/backing up data using au Smart Pass server
- For restoring data using microSD memory card, save the data to the microSD memory card using your previously used au phone in advance.

1




Home screen → [基本機能 (Basic function)] → [Settings]

2




[au Settings Menu]

3



[Data Transfer]


4



[データを保存する (Back up data)]/[データを戻す (Restore data)]

### ■ Restoring data from au Settings Menu


5



Select a method for restoring data

\* Setting au ID is required for restoring data from "au スマートパスから戻す (Restore from au Smart Pass)".


6



When "SD カードから戻す (Restore from SD card)" is selected, select a type of your previously used au cell phone

\* Not appeared when "au スマートパスから戻す (Restore from au Smart Pass)" is selected in step 5.

7



Select data to restore → [戻す (Restore)] → [完了 (Done)]


\* It is the screen for selecting "スマートフォンのデータを戻す (Restore data from smartphone)".

When "SD カードから戻す (Restore from SD card)" is selected

When "au スマートパスから戻す (Restore from au Smart Pass)" is selected

### ■ Saving data from au Settings Menu


5



Select a saving location


\* Setting au ID is required for saving data from "au スマートパスに預ける (Back up to au Smart Pass)".

6



Select data to save → [保存する (Save)] → [完了 (Done)]

7



Select data to back up → [預ける (Back up)] → [OK] → [完了 (Done)]

### Using "Data Storage" App

To use "Data Storage" app to back up photos and contacts to au Smart Pass server automatically, set as follows.

Home screen → [基本機能 (Basic function)] → [Settings] → [au Settings Menu] → [Backup Setting] → Tap to turn on "定期的に自動で預ける (Back up periodically)"