

Thank you for buying the "Qua tab 02" (simply called the "product" from here on). In this guide, settings and precautions for using the product are described. For explanations of basic functions, refer to "Basic Manual".

<p>Basic Operation Describes the basic operations.</p> <p>Initial settings Make initial settings when you turn the power on for the first time.</p> <p>au Easy Setting Set au ID.</p> <p>E-mail Make initial settings for E-mail (@ezweb.ne.jp) etc.</p>	<p>Wi-Fi® Setting Describes how to connect Wi-Fi® network.</p> <p>Transferring data from au Settings Menu Return or store data from your previously used au phone to this product using a microSD card or the au Smart Pass server.</p>	<p>Saving battery power Describes how to save battery consumption by switching ON/OFF of functions in the shortcut items list.</p>
--	---	---

Company names and product names referred to in this manual are trademarks or registered trademarks of respective companies. The TM, © marks may be omitted in this manual. Screen illustrations shown in this manual may look different from the actual screens. In some cases, minor details or a part of a screen may be omitted. In this manual, screenshots for body color "Powder White" are provided as examples.

December 2015, 1st Edition
Sold by: KDDI CORPORATION
OKINAWA CELLULAR TELEPHONE COMPANY
Imported by: HUAWEI TECHNOLOGIES JAPAN K.K.
Manufactured by: HUAWEI TECHNOLOGIES CO., LTD.

Basic Operation

For detailed operations, refer to "Basic Manual".

Power button
Power ON
Touch and hold for 2 seconds or longer.
Sleep mode
While screen backlight is turned on, press the Power button to turn off the screen and put the product into sleep mode. In sleep mode, press the Power button to cancel sleep mode.
Displaying the Home screen from the lock screen
The lock screen is displayed when turning the power on or sleep mode is canceled. The Home screen is displayed when sliding on the lock screen.

Navigation bar

- Return to the previous screen.
- Indicate the current position of home screens.
- Display a list of recently-used applications or functions.

Display (Touch panel)
Touch directly with your finger to operate.

Character entry
Use the software keyboard for entering characters. Tap the entry field in the character entry screen when registering a contact, creating mail, etc. to display the software keyboard.

Software keyboard
With "Wnn IME" for Japanese input, you can change keyboard from "QWERTY keyboard", "10-key keyboard", and "50-key keyboard". Tap to change input mode (Katakana/alphabet/numeric).



Flick input
Touch and hold a key to display input candidates for flick input as shown below. Flick to the direction of the character to enter.

Flick input screen

Initial Settings

When you turn on the product for the first time after purchasing the product, follow the onscreen instructions to set language, functions, services, etc.

Setting up Google account
Set up Google account to use Google applications such as "Gmail", "Play Store", "Hangouts". Main setting items are as follows. You need to register "Last name" and "First name" to create an account.

User name	Register your Google account (user ID) and a character string for mail address. You can register a desired name, but a name already registered by another user cannot be set.
Password	Register password for the Google account.

1 Select language, [NEXT]
 2 Set up the Wi-Fi® network to connect as required¹
 3 Check detailed information, [同意する (Agree)] → [次へ (NEXT)]
 4 [Or create a new account]²
 5 Enter "Last" name and "First" name → [NEXT]
 6 Enter a username → [NEXT]

7 Enter a password, and reenter the password for confirmation → [NEXT]
 8 Confirm/check country name, enter phone number → [NEXT]¹ → [VERIFY]
 A text message with a Google verification code is sent to the specified phone number.
 9 Enter the Google verification code → [NEXT]
 When you set the phone number of this product in step 8, the Google verification code you set is set automatically. Go to step 10.
 10 Check the contents, then [I AGREE]
 11 Check the contents, then [NEXT]
 12 Select whether to set payment information → [NEXT]
 Here, select "Remind me later" and go to next step.
 13 [Set screen lock style]¹ → Follow the onscreen instructions
 14 Check the contents, then [NEXT]
 15 [Begin]

¹ If you do not set up, tap "Skip".
² If you have a Google account, enter the mail address.

au Easy Setting

By setting au ID, you can use various services provided by au such as "au Kantan Kessai" which allows you to purchase applications from the au スマートパス (au Smart Pass) or Google Play. Main setting items are as follows.

au ID*	Register your au phone number or a character string for au ID (user ID).
au ID password	Register password for using au ID.

* "au ID" which is already used by another user cannot be set.
 • If you skip the operation of "au Easy Setting" when you purchased the product, you can set au ID later. In that case, operate from the Home screen → [Settings] → [au menu] → [au Easy Setting], or from the Home screen → [au フォルダー] → [au ID Setting].

1 Welcome to au screen → [Next]
 2 [Register "au ID"] → [Next]
 3 [au IDの設定・保存 (Set and save au ID)]
 4 Enter the security code¹ → [OK]
 5 Enter a security password → [設定 (Settings)]
 6 [終了 (End)]
 7 [Update] → [Next]
 8 Check the terms and conditions (reading requires), [Agree] → [Next] → [Agree]²
 9 Check the contents, [Turn Auto Backup on]/ [Turn Auto Backup off]³ → [Next]
 10 Select apps to install → [次へ (Next)]⁴
 11 Select type of data to return⁵ → [次へ (Next)]
 12 [Finish]⁶

¹ Default value is a four-digit number written at subscription.
² Configurations for Lookout for au is completed when you tap "Agree".
³ To back up photos and contacts to au Smart Pass automatically using "Data Storage App", tap "Turn Auto Backup on".
⁴ If there are apps to be restored, the restoration of apps screen appears. Follow the onscreen instructions.
⁵ If there is no application on au Smart Pass, a restore screen is not displayed.
⁶ When the confirmation screen appears, confirm the content and tap "OK".

E-mail

To use E-mail (@ezweb.ne.jp), subscription to LTE NET is required.
If you did not subscribe it when you purchased the product, contact an au shop or Customer Service Center.
Your E-mail address is determined automatically after initial setting. You can change the E-mail address later.

Initial settings

- 1 Home screen → [E-mail] → Check the contents, then [接続する (Connect)]
- 2 Check your Email address → [閉じる (Close)] → Check the contents, then [同意する (Agree)]/[不同意する (Disagree)] → [完了 (Done)]
- 3 When the overview of send information of "About use of customer information" appears, tap [Accept]. When the description screen for E-mail function appears, confirm the content and tap [Close].

Changing your e-mail address

- 1 Home screen → [E-mail settings]
- 2 [Other settings] → Check the contents, then [接続する (Connect)]
- 3 [Eメールアドレスの変更へ (To Change E-mail address)]
- 4 Enter the security code → [送信 (Send)] → Check the contents, then [承諾する (I accept)]
- 5 Enter E-mail address → [送信 (Send)] → [閉じる (Close)]

Backing up E-mail

You can back up E-mail data on the internal storage (/storage/emulated/0/private/au/email/BU/).
• Home screen → [Settings] → [Storage] → When [Default location] is set to [SD card], data is backed up on the microSD memory card (/storage/sdcard1/private/au/email/BU/).
* When you connect the product to a PC and check the back up data location, the folder name may be displayed differently.

- 1 Home screen → [E-mail settings]
- 2 [Backup/Restore]
- 3 [Mail Backup] → Confirm the notes and [OK]
- 4 Select a character code to make backup data → [OK] → Select a folder to back up → [OK]

Mail Settings Other Than E-mail

You can use mail addresses other than E-mail (@ezweb.ne.jp).
Use of other mail addresses requires accounts to be set. When using another mail address for the first time, set the address as follows.

Example: When you use Gmail

Home screen → [Google] → [Gmail] → Follow the onscreen instructions and enter mail information.

Wi-Fi® Setting

Use your home Wireless LAN (Wi-Fi®) or public wireless LAN to connect to the Internet.
Main settings are as follows.

Select Wi-Fi® network to connect	Search for and connect to an available Wi-Fi® network.
WPS system	Use for registration of access point compatible with Wi-Fi® Protected Setup™ with WPS mark.

* If you turn on wireless LAN (Wi-Fi®) function, battery consumption increases. It is recommended that you turn wireless LAN (Wi-Fi®) function to OFF when not using wireless LAN (Wi-Fi®) function.

- 1 Home screen → [Settings] → [Wi-Fi]
 - 2 Tap [ON] to turn ON
- Available Wi-Fi® networks are listed. Select a Wi-Fi® network to connect → Enter a password as required → [Connect] to connect the Wi-Fi® network.
If an access point you want to connect cannot be detected, tap [Add network...] and connect the Wi-Fi® network manually.

Using WPS system access point

- 3 [Advanced settings] → [WPS connection]/[WPS PIN connection]
- 4 For using WPS button, tap [WPS connection] and then press and hold the WPS button of the access point to set to WPS mode. The access point is automatically detected and registration starts.
For entering WPS PIN, tap [WPS PIN connection] and enter displayed PIN code on the access point, then registration starts.

Transferring Data from au Settings Menu

Return or store data from your previously used au phone to this product using a microSD card or the au Smart Pass server.

- Setting an ID is required for returning/storing data using the au Smart Pass server.
- For returning data using a microSD memory card, save the data to the microSD memory card using your previously used au phone in advance.

Returning data from au Settings Menu

- 1 Home screen → [Settings] → [au menu] → [Data Transfer]
 - 2 In the data transfer screen, [データを戻す (Return data)]
 - 3 Select a method for returning data
* To return data from "auスマートパスから戻す (Return from au Smart Pass)" (data stored on the au Smart Pass server), you must set an au ID.
 - 4 When you select "SDカードから戻す (Return from SD card)", select the type of your previously used au cell phone
* This menu does not appear when "auスマートパスから戻す (Return from au Smart Pass)" is selected in step 3.
 - 5 Select data to return → [戻す (Return)] → [完了 (Done)]
* This screen appears when "スマートフォンのデータを戻す (Return smartphone data)" is selected.
- When "SDカードから戻す (Return from SD card)" is selected
- When "auスマートパスから戻す (Return from au Smart Pass)" is selected

Saving data from au Settings Menu

- 1 Home screen → [Settings] → [au menu] → [Data Transfer]
 - 2 In the data transfer screen, [データを保存する (Save data)]
 - 3 Select a saving location
* To save data from "auスマートパスに預ける (Store to au Smart Pass)" (Store data to the au Smart Pass server), you must set an au ID.
 - 4 Select data to save → [保存する (Save)] → [完了 (Done)]
 - 5 Select data to store → [預ける (Store)] → [完了 (Done)]
- When "SDカードに保存する (Saving to SD card)" is selected
- When "auスマートパスに預ける (Store to au Smart Pass)" is selected

Using "Data Storage" app

To use "Data Storage" app to back up photos and contacts to the au Smart Pass server automatically, set as follows.

Home screen → [Settings] → [au menu] → [Backup Setting] → Turn on "定期的に自動で預ける (Back up periodically)"

Saving Battery Power

From the shortcut items list, you can configure the setting such as Wi-Fi® function, Bluetooth® function, and screen brightness adjustment.
You can save battery consumption by switching the communication function to OFF or adjusting brightness of the display.

Opening the shortcut items list

- 1 Slide down the status bar
- 2 "Shortcuts" tab
- 3 Set each item
* To show hidden items, slide up or down.

Shortcut items list

Wi-Fi	ON/OFF of the Wi-Fi® function
Bluetooth	ON/OFF of the Bluetooth® function
Auto-rotate	ON/OFF of the auto-rotate screen
Settings	Open the settings menu
Screenshot	Capture the screen
Sound/Silent	ON/OFF of Manner mode
Mobile data	ON/OFF of the mobile data communication
Flashlight	ON/OFF of flash/photo light
GPS	ON/OFF of the location information function
Eyes protection	ON/OFF of the eyesight protection
Wi-Fi hotspot	ON/OFF of the Wi-Fi® tethering function
Airplane mode	ON/OFF of the airplane mode
Auto-sync	ON/OFF of the account auto synchronize function
(Adjusting screen brightness)	Adjust the screen brightness * When you tap "Auto" to ON, the screen brightness is automatically adjusted according to your condition.