

Qua tab PZ

Setting Guide

Thank you for purchasing the "Qua tab PZ" (simply called the "product" from here on).

This "Setting Guide" describes the basic operations and initial settings for using the product.

For descriptions on various functions, refer to "Basic Manual" or "User Guide 取扱説明書 詳細版 (Full Instruction Manual)" (Japanese) on the au website.

Before using the product, be sure to read the "Notes on Usage" to ensure correct and safe use.

All other company names and product names are registered trademarks or trademarks of respective companies referred to in this manual.

The ® marks and TM marks may be omitted in this manual.

Sold by: KDDI CORPORATION, OKINAWA CELLULAR TELEPHONE COMPANY
Imported by: LG Electronics Japan, Inc.
Manufactured by: LG Electronics Inc.
October 2016, 1st Edition

MBM65756003(1.0)

- Learning the Basic Operations**
Describes the names of parts and operation.
- Initial Settings**
Described in the steps for the following:
 - Language settings, Accessibility
 - Wireless LAN (Wi-Fi®) settings
 - Google account settings
 - Other settings
- au Easy Setting**
Sets au ID and services.
- E-mail Settings**
Sets up to use e-mail (@ezweb.ne.jp).
- "Basic Manual application"**
Installs and starts up the Basic Manual.
- Transferring Contacts**
You can transfer your contacts data from your previous au device.
- How to Transfer Data from the au Settings Menu**
You can restore/backup data from your previous au device to this product using a microSD memory card or au servers.
- Reducing Battery Consumption**
You can reduce the battery consumption by setting up Battery saver.

Learning the Basic Operations

Basic operations of the keys

- Power key (side)**
 - Power ON
Press and hold the power key.
 - Power OFF
Press and hold the power key → Select [Power off] → [POWER OFF].
 - Sleep mode
Press the power key in operation to switch to sleep mode.
 - Cancel sleep mode
Press the power key in sleep mode to display the lock screen.
- Display (Touch panel)**
Directly touch an item or button displayed on the screen to operate.
- Home button**
Use it to display the Home screen.
- Dual window button**
Divides the screen and uses two applications at one time.
- Task button**
Check running applications.
- Back button**
Returns to the previous screen.

Unlocking the screen

Swipe on the lock screen.

* The way to release the lock screen differs depending on the screen lock being set.

Basic operations of the touch panel

The display of the product is a touch panel and you can touch directly with your finger to operate.



Tap/Double Tap

Lightly touch the display and then immediately release your finger. Tapping the same place twice is called a double tap.






Touch and hold

Keep touching the screen.


Basic operations to input characters

This product uses the software keyboard displayed at the bottom of the screen to enter characters.


Tap the keys on the screen to enter characters.



Flick input



Flick guide



Slide

While your finger is lightly touching the screen, move it in the desired direction.



Flick (Swipe)

Quickly move (flicking) your finger up, down, right, or left.

How to read the notification panel

When a notification icon appears on the left side of the status bar, slide the status bar down to open the notification panel to check the notification or launch the application.



Slide down the status bar



The notification panel appears.

Setting Application Authority

When activating the applications/functions to access the functions or information of the product for the first time, the confirmation screen appears to request the permission for the access authority.

When the confirmation screen appears, confirm the content and tap "DENY" or "ALLOW".

- The explanation screen may be displayed depending on the application/function. Also, the confirmation screen may be displayed several times or the display may be different. Carefully check the displayed content, follow the onscreen instructions.
- If the application authority is not allowed, applications/functions may not be activated or using functions may be restricted.
- In this manual, description of the confirmation screens may be omitted.



Pinch

Touch the screen with two fingers and widen (pinch-out) or narrow (pinch-in) the fingers' distance.



Drag

Keep touching items or icons and trace to the desired position.

Initial Settings: STEP1

Setting the language, accessibility

This section describes the initial settings screen that appears when you turn on the power for the first time.


Changing the language



[日本語 (日本)] → select language → []

* Once you select your desired language, the language for the initial settings screen also changes. From here on, follow the onscreen instructions.

Setting up accessibility



After switching to the English display, [Accessibility] → review the precautions, [YES] → set Accessibility → [] → []

* The operations herein differ depending on the configured Accessibility settings.

* If the language was not switched via the initial settings, switch the language via the following procedures.
On the Home screen, [基本機能 (Basic functions)] → [設定 (Settings)] → [言語と入力 (Language & keyboard)] → [言語 (Language)] → [English].

The folder names will not be changed from the language of the initial settings. Convert the folder names contained in "Setting Guide" (this manual), "Basic Manual", "Notes on Usage" into Japanese as per the following and operate.

English	Japanese
au Supports	au サポート
Others Apps	その他アプリ

Initial Settings: STEP2


Setting wireless LAN (Wi-Fi®)

By using the wireless LAN (Wi-Fi®) function, you can access to the Internet using a wireless LAN environment built in your home or a public wireless LAN environment away from home.

When setting the wireless LAN (Wi-Fi®) as described in this guide, you need to be in an environment where the radio waves can be received from the wireless LAN device or public wireless LAN that you want to access to. Check the following information before setting the wireless LAN (Wi-Fi®) function.


SSID	The name set for the wireless LAN device or public wireless LAN service that you are connecting to
Password	The password for connecting to the wireless LAN device or public wireless LAN service

- * Connection to all public wireless LAN services is not guaranteed.
- * You may need a separate contract with a service provider to use some public wireless LAN services.
- * Enabling the wireless LAN (Wi-Fi®) function uses a lot of battery power. We recommend turning off the wireless LAN (Wi-Fi®) function when not using it.



[] of "Wi-Fi" → tap the network that you are connecting to

* If you do not set up, tap [NEXT].



Enter Password → [CONNECT] → confirm the connection → [NEXT]

* This step is not required if you select a wireless LAN (Wi-Fi®) network without security settings.

Initial Settings: STEP3

Setting up Google account

You can use online services provided by Google, such as Gmail and Google Play, by setting up a Google account.

This section describes how to set up an account on the initial settings screen that appears when you turn on the power for the first time.

User name	Register your Google account (user ID) and the characters that you want to use as your mail address. You can register a desired name, but a name already registered by another user cannot be set.
Password	Register password for the Google account.

- [No thanks] → [NEXT]
- * To copy the settings of an Android device to the product, tap [Copy your Google Accounts, apps, and data from your other device].
- [Or create a new account]
- * If you have a Google account, enter the mail address.
- Enter your first and last names → [NEXT] → enter your birthday and gender → [NEXT] → enter your user name → [NEXT] → enter your password → [NEXT]
- * User names already being used by another user cannot be used.
- Confirm your phone number → [NEXT] → [VERIFY]
- * When a code input screen appears, follow the onscreen instructions.
- Confirm the contents → [I AGREE]

- [NEXT]
- Check the details of Google services → [NEXT]
- [No thanks] → [CONTINUE]
- * If you are purchasing applications from Google Play, enter payment information.
- Set whether to protect the tablet
- * To set the screen lock, place a check mark on "Protect this device and require a PIN, pattern, or password to unlock the screen" → [NEXT] → set the unlock method of the lock screen, etc. → tap [OK].
- * If you do not set up, clear the check mark on "Protect this device and require a PIN, pattern, or password to unlock the screen" → tap [SKIP] → [SKIP ANYWAY].

Initial Settings: STEP4

Other settings

- Check legal documents → place check marks on "I agree" and "I agree (Optional)" → [DONE]

au Easy Setting

Setting au ID

You can setup convenient au functions and services.

This section describes how to set up an au ID on the initial settings screen that appears when you turn on the power for the first time.

The settings can be changed with the "au ID Setting" application.

au ID*	Register your au phone number or any other character string as an au ID.
au ID password	Register password for using au ID.

- * The same "au ID" as another user's cannot be registered.
- You can also setup au services on the Home screen by tapping [基本機能 (Basic functions)] → [Settings] → [au Settings Menu] → [au Easy Setting].





- [Next]
- [Register "au ID" → [Next]
- [au IDの設定・保存 (Set and save au ID)]
- Enter the security code → [OK]
- Enter a security password → [設定 (Settings)] → [終了 (End)]
- [Update] → [Next]
- Confirm the terms of use → [Agree] → [Next] → [Agree]
- * If you selected [Disagree], the au Easy Setting Completed screen will appear.
- To use Lookout for au, [Activate] → [Next]
- * If you do not use it, tap [Skip activation] → [Next].
- * Allowing each authority of Lookout for au completes the pre-configuration.
- Place checkmarks on the data you want to restore → [次へ (Next)]
- * If there is no data to be restored, this screen will not be displayed.
- Place checkmarks on the application to be installed → [次へ (Next)]
- * When a different screen from the above appears, follow the displayed screen.

E-mail Settings

E-mail (@ezweb.ne.jp) is a service that enables you to exchange e-mails with other cell phones, which support e-mail, and with PCs. Your e-mail address is decided automatically after the initial settings. The e-mail address in the initial settings can be changed. Also, the setting to send/receive e-mails of au cell phones/smartphones by a tablet can be performed.

Initial Settings

* If the confirmation screen for e-mail application appears, check the content and follow the onscreen instructions.








- 
On the Home screen, [基本機能 (Basic functions)]
- 
Confirm e-mail address → [閉じる (Close)]
- 
Confirm the contents → [設定する (Set)]/[設定しない (Not set)]
 - * Select [設定しない (Not set)] here and finish the initial setting.
 - * When [設定する (Set)] is selected, au ID log in screen appears. Follow the onscreen instructions, and the "When select [設定する (Set)]" screen appears.
 - * The operations herein differ when [設定する (Set)] is selected.
- 
When select [設定する (Set)]
Confirm that it is the desired mail address → [完了 (Done)]
 - * If the mail address is not the desired one, change it from [変更 (Change)].
 - * For details of notes for adding an account, refer to au homepage.

Confirming your e-mail address

- 
On the E-mail screen, [Eメール情報 (E-mail information)]
- 
Your e-mail address appears in the e-mail address field.



* The initial setting of the e-mail cannot be performed via Wi-Fi® communications.

Changing your e-mail address




- 
On the E-mail screen, [Eメール設定/フィルタ (E-mail setting/filter)] → [変更アドレス/設定フィルタ (Change address/setting filter)]
- 
[Eメールアドレスの変更へ (To change e-mail address)]
- 
Enter the security code → [送信 (Send)]
- 
Confirm the contents → [承諾する (I accept)]
- 
Enter e-mail address → [送信 (Send)]
- 
[OK]
- 
[閉じる (Close)]

"Basic Manual application"

Downloading "Basic Manual application"

- 
On the Home screen, [au Supports] → [Basic Manual]
- 
[UPDATE] → [CONTINUE]
 - * If confirmation screens are displayed, follow the onscreen instructions to operate.







Using "Basic Manual application"

- 
On the Home screen, [au Supports] → [Basic Manual]
- 
Confirm contents displayed → [OK]
- 
The Basic Manual cover is displayed.

* Packet communications fees are charged for downloading the "Basic Manual application" (no charges for Wi-Fi® connections).

Transferring Contacts

You can transfer data from your au device to the product using a microSD memory card.








- 
Save the contacts (address book) from your au device to a microSD memory card, and insert the card into the product
Refer to the instruction manual of your au device, etc. on how to save the contacts.
- 
On the Home screen [基本機能 (Basic functions)] → [Contacts]
- 
[管理] → [Manage contacts] → [Import]
 - * When a contact is not registered, tap [管理] → [Import] → the import source to proceed to step 5. If a saving location screen appears, select the desired account or location.
- 
[SD card] → [NEXT]
 - * If a saving location screen appears, select the desired account or location.
- 
Place checkmarks on the item to be imported → [IMPORT]
- 
[IMPORT]
 - * When the import is complete, "Contacts imported" appears.

How to Transfer Data from the au Settings Menu







Return or store data from your previously used au device to this product using a microSD card or the au Smart Pass server.

- * You need to setup an au ID to restore or save data using au Smart Pass servers.
- * If you use a microSD memory card to restore data, save the data from your previous au device to a microSD memory card.

How to restore data from the au Settings Menu

- 
On the Home screen, [基本機能 (Basic functions)] → [Settings]
- 
[au Settings Menu]
- 
[Data Transfer]
 - * If the terms of use appears, check the content and follow the onscreen instructions.
- 
Select a method for returning data
 - * You need to setup an au ID to restore data using [auスマートパスのサーバから戻す (Restore data from au Smart Pass server)] (data backed up on au Smart Pass servers).
- 
If you selected [SDカードから復元する (Restore data from SD card)], select your previous au device
 - * This screen is not displayed if you selected [auスマートパスのサーバから戻す (Restore data from au Smart Pass server)] on the restore data method screen.
- 
When [SDカードから復元する (Restore data from SD card)] is selected
Place checkmarks on the data you want to restore → [戻す (Restore)] → [完了 (Done)]
 - * This screen is displayed if you selected [スマートフォンのデータを戻す (Restore smartphone data)].
 - * When a confirmation screen appears, follow the onscreen instructions.
- 
When [auスマートパスのサーバから戻す (Restore data from au Smart Pass server)] is selected
Place checkmarks on the data you want to restore → [戻す (Restore)] → [完了 (Done)]
 - * When a confirmation screen appears, follow the onscreen instructions.

Saving data from au Settings Menu






- 
On the Home screen, [基本機能 (Basic functions)] → [Settings]
- 
[au Settings Menu]
- 
[Data Transfer]
 - * If the terms of use appears, check the content and follow the onscreen instructions.
- 
Select a saving location
 - * You need to setup an au ID to save data from [auスマートパスのサーバに預ける (Save data to au Smart Pass server)] (saving data to au Smart Pass servers).
- 
When [SDカードに保存する (Saving to SD card)] is selected
Place checkmarks on the data to be saved, [保存する (Save)] → [完了 (Done)]
- 
When [auスマートパスのサーバに預ける (Save data to au Smart Pass server)] is selected
Place checkmarks on the data to be saved, [預ける (Save)] → confirm the details, follow the instructions on the screen → [完了 (Done)]
 - * When a confirmation screen appears, follow the onscreen instructions.
- If you want to use the "Data Storage App" application to automatically save your photos and contacts to the au Smart Pass server, you can set it up by following the procedure below.

On the Home screen → [基本機能 (Basic functions)] → [Settings] → [au Settings Menu] → [Backup Setting] → place checkmarks on the data to be saved

Reducing Battery Consumption

Using Battery Saver

Set up to switch to Battery Saver Mode automatically when the battery is running low.

- 
On the Home screen, [基本機能 (Basic functions)] → [Settings]
- 
[Battery & power saving]
- 
[Battery saver]
 - * Confirm the status such battery etc. on "BATTERY INFORMATION".
- 
[Turn Battery saver on]
- 
Tap timing

Setting Battery saver on timing