

Setting Guide


Thank you for buying the Galaxy S7 edge (simply called the "product"). In this guide, settings and precautions for using the product are described. For basic operations, refer to "Basic Manual". All company names and product names referred to in this manual are trademarks or registered trademarks of respective companies.

- **Basic operation**
Describes the basic operations and names of parts.
- **Initial settings**
Describes how to configure settings when turning on the power for the first time.
- **Mail settings**
Make initial settings to use E-mail (@ezweb.ne.jp).
- **Making a call**
Describes how to make a call.
- **Receiving a call**
Describes how to receive a call.
- **Importing/Exporting contacts**
Describes how to import and export contacts to this product using the au Nano IC Card O4 or the microSD memory card.
- **Viewing/playing data**
Describes how to view/play images or video data.
- **How to transfer data from the au Settings menu**
Describes how to restore and store data into this product from the previously used au phone.

Sold by: KDDI CORPORATION, OKINAWA CELLULAR TELEPHONE COMPANY
Imported by: SAMSUNG ELECTRONICS JAPAN Co., Ltd.
Manufactured by: Samsung Electronics Co., Ltd.
April 2016, 1st Edition

Basic operation

For details, refer to the "Basic Manual" application installed on the product or "取扱説明書 (詳細版) (Full Instruction Manual)" (Japanese) available on the au homepage.



Opening notification panel

When a notification icon is displayed, slide down the status bar to open the notification panel and then check the notification overview.




Edge screen

Edge screen provides panels that you can register contacts, apps or shortcuts to, or panels that display various information.



You can check whether you have received a call or notifications when the product is face down by the lights on the edge screen. By registering important contacts, you can also identify that you have received a notification from that contact by color.



Touch panel operations

- Tap**
Lightly touch the screen and then immediately release your finger.
- Slide**
If the displayed item does not fit within the screen, lightly touch and trace to the desired direction.
- Pinch**
Touch the screen with two fingers and widen (pinch-out) or narrow (pinch-in) the fingers' distance.
- Touch and hold**
Quickly move (flick) your finger up, down, right, or left.
- Flick (Swipe)**
Quickly move (flick) your finger up, down, right, or left.
- Drag**
Keep touching an item or icon, trace it to the desired direction.

Selecting item



Displaying menu

There are a few methods to display a menu screen; by tapping "MORE" / doing touch and hold [] or by doing touch and hold an entry field or item.

Switch setting

When checkbox, radio button or ON/OFF switch appears at side of setting item, tap check box, radio button or ON/OFF switch to switch the ON/OFF of the setting.

Icon	Description
☒	Setting is On.
☐	Setting is Off.

Configuring the app's permissions

When you access a function or information on the terminal for the first time, a confirmation screen will appear requesting you to permit the access. If a confirmation screen appears, read through the displayed information and tap either "DENY" or "ALLOW".

- A screen explaining the permission may be displayed for some apps/functions. Or, a confirmation screen may appear multiple times and or be displayed differently. Check the displayed information carefully and follow the on-screen instructions.
- If you do not select "ALLOW", you may be unable to activate the app/function or the function may be restricted.
- Descriptions on the contents displayed on the confirmation screen(s) may have been omitted in this manual.

Character entry

To enter characters, tap character entry field to display keyboard and then tap each key.

Software keyboard


Use "QWERTY Keyboard" or "3x4 Keyboard".



Tap [], and in the displayed menu, tap "3x4 Keyboard ⇌ QWERTY Keyboard" to toggle between "3x4 Keyboard" and "QWERTY Keyboard". If the [] is not displayed, press and hold the keys that are located here in the screenshots and select [].

Flick input

In "3x4", entering candidates for flick input appears as shown when you touch a key. Flick to the direction of character to enter.



STEP 1: Wireless LAN (Wi-Fi®) function setting

Use your home wireless LAN (Wi-Fi®) or public wireless LAN to connect to the Internet. * Password (security key) is set on access point. Check in advance.

1. Tap Wi-Fi® network to connect. * Tap [NEXT] to set later.
 2. Enter a password (security key) → [CONNECT] → [NEXT].
- If an access point device supports WPS Push button system, in Step 1, [MORE] → [WPS push button], and press WPS button on the access point device within 2 minutes to connect Wi-Fi® network.
 - If an access point device supports WPS PIN code system, in Step 1, [MORE] → [WPS PIN entry], and enter PIN code on the access point device to connect Wi-Fi® network.

STEP 2: Basic setting

1. [Learn more] → confirm the content, then [] → after confirming all the contents tap [NEXT] → [AGREE].
2. Set whether to copy your Google account from other Android device. * Select [No thanks] here and tap [NEXT] to proceed to the next step.

STEP 3: Google setting

Set up Google account to use Google applications such as "Gmail", "Google Play", and "Google+", Gmail address "(User name)@gmail.com" is automatically created by user name set in Google account.

1. Add your account. [Or create a new account]. * If you already have a Google account, tap the [Enter your email] field.
2. Enter your "First name" and "Last name" → [NEXT]. * If you tap [SKIP] in step 1, you can skip Google account setup (in that case, follow the instructions displayed on the screen). Proceeding the settings will display the screen on step 12.
3. Enter your user name → [NEXT]. * If an entered user name is unavailable, an entry screen for prompting another user name appears.
4. Enter a password → reenter the password → [NEXT].
5. Enter a phone number in case you forget your password → [NEXT]. * Append the country code to the beginning of the phone number. Japan is "+81". After the country code, enter your phone number omitting the first digit. For example, if your Japan phone number is "090...", enter "+81.90...". * Tap [Skip] if you do not want to set.
6. If the precautions screen related to confirming your phone number appears, confirm the content → [VERIFY].
7. Confirm the content → [I AGREE].
8. [NEXT].
9. Confirm the content → [NEXT]. * Uncheck services you don't use.
10. Select whether to set payment information. * Select [No thanks] here and tap [CONTINUE].
11. Set whether to add another email address. * Select "Personal (IMAP/POP)" to add. * Select "Not now" and tap [NEXT] to add later.
12. Set whether to protect your phone. * To set, select "Set up fingerprint" or "Set up PIN, pattern or password". * To not set, select "No, thanks" → [SKIP ANYWAY].

STEP 4: Set up is complete

If it is ready to use this product, set up completion screen appears.

1. Set Galaxy account as required. * Tap [] → [SKIP] here.
 2. Set whether to display weather forecast on home screen → [NEXT]. * Uncheck services you don't use and [NEXT].
 3. Switch to Easy mode if necessary → [FINISH].
- When "Easy mode" is enabled, frequently used applications such as Contact or Settings, etc., can be displayed with large icons on the home screen.

STEP 5: au Easy Setting

When you have registered an au ID, you can use various au services including "au Simple Payment Service" which offers you a simple way to purchase applications from "au Smart Pass" and "Google Play". Create new au ID with this product or use your au ID.

- au ID which is already used by another user cannot be set.
- You can still setup au services after completing initial settings by tapping [基本フォルダ (Basic folder)] → [Settings] → [au Settings menu] → [au Easy Setting] on the home screen.

1. [Next].
2. [Register "au ID" → [Next].
3. [au IDの設定・保存 (Set/save au ID)].
4. Enter a security password → [OK]. * Default value is 4-digit security code written at subscription.
5. Enter a password → [設定 (Set)].
6. [終了 (Done)].
7. To update this product, select "Update" → [Next]. * If you do not want to update this product, select "Skip update" and tap [Next] to proceed.
8. Check the terms of service of the initial settings → select "Agree" → [Next] → [Agree].
9. Confirm the content, select "Turn Auto Backup on"/"Turn Auto Backup off" → [Next]. * Select [Turn Auto Backup on] if you want to use the "データお預け(Data Storage)" application to automatically backup your pictures and address book to the au server.
10. Confirm the content, select "Activate"/"Skip activation" → [Next]. * If there are apps which are to be restored, the App restoration screen will appear. If the screen is displayed, follow the onscreen instructions to operate.
11. To use Texting While Walking Alert App, select "Activate" → [Next]. * To set later, select "Skip activation" then tap [Next].
12. To use Lookout for au App, select "Activate" → [Next]. * To set later, select "Skip activation" then tap [Next]. * Presetting is done by selecting "ALLOW" for each permission.
13. If the "データを戻す (Restore data)" screen appears, select the check box of the type of data you want to restore → [次へ (Next)].
14. Check the apps to install → [次へ (Next)]. * When "おすすめアプリ (Recommended Apps)" screen is displayed, follow the onscreen instructions.
15. [Finish]. * Follow the onscreen instructions.

Mail settings

Initial Setup of E-mail

To use E-mail (@ezweb.ne.jp), subscription to LTE NET is required. If you did not subscribe it when you purchased the product, contact an au shop or Customer Service Center.

- For model change from au phone, you can continue to use the E-mail address that is used on the former model by making initial settings.



On the home screen, [E-mail]



Confirm the contents → [接続する (Connect)]



Initial settings are complete, E-mail address appears → [閉じる (Close)]

- If welcome screen appears, confirm the content and tap [Close].
- If confirmation matter screen appears, confirm the content and tap [同意する (Agree)] → [完了 (Finish)].

Changing your E-mail address


Although E-mail address is automatically decided by performing Initial settings, the E-mail address can be changed.




On the home screen, [E-mail]



[設定] → [E-mail settings]



[Other settings]



Confirm the contents → [接続する (Connect)]




[Eメールアドレスの変更へ (To Change E-mail address)]




Enter the security code → [送信 (Send)]

* The security code is the four-digit number which you wrote down when you contracted your au cell phone. Verify it in the "Application form copy".



Confirm the contents → [承諾する (Accept)]



Enter E-mail address → [送信 (Send)]



[OK]



[閉じる (Close)]

Checking E-mail address



On the E-mail settings screen, [E-mail information]




E-mail address appears

Backing up E-mail

E-mails can be backed up to phone memory. And backup data can be restored to E-mail application.




On the E-mail settings screen, [Backup/Restore]



[Mail Backup] → [OK]
* To backup all E-mails including E-mail settings, [Whole Backup].



Select character code → [OK]



Mark mail types to back up → [OK]


- If a microSD memory card is inserted into this product, then data will be backed up onto the microSD memory card.

Making a call

Calling by direct input



On the home screen, [Phone]




Enter a phone number → [緑電話機]

- To dial using call log, in Step 2, tap "LOG" to select a log, then tap [緑電話機].
- To return to the keypad screen from the "LOG" tab, tap [緑電話機].


Calling overseas (au International Call Service)
You can make international calls without any special procedure from the product.
To call overseas, in the phone number entry screen, enter an access code, country code, area code*, and the phone number of the other party, then tap [緑電話機].

* If the area code starts with "0", dial it without including the "0". (There are some exceptions such as fixed-line phones in some countries or regions including Italy and Moscow).


Calling from the contacts



On the home screen, [基本フォルダ (Basic folder)] → [Contacts]




Tap a contact to call




Tap a phone number

Receiving a call


Calling



Drag/slide [緑電話機] out of the circle



Your call will begin



To end the call, [赤電話機]


- To reject a call, in Step 1, drag/slide [赤電話機] out of circle. When a call rejected, the caller hears the guidance.

Using Sync Call


You can talk on the phone without changing screens. If you receive a phone call while using an app, a pop-up screen appears.



To answer the call, [緑電話機]




Your call will begin




To end the call, [赤電話機]

- To talk on speaker phone while looking at the display, in step 1 tap [スピーカー].

Setting up Sync Call



During a call, [設定]



Configure the various settings


* You can still the settings screen by tapping [基本フォルダ (Basic folder)] → [Settings] → [au Settings menu] → [Sync Call] on the home screen.

Importing/Exporting contacts


You can transfer contacts data in the previously used au Nano IC Card O4 or microSD memory card.




On the home screen, [基本フォルダ (Basic folder)] → [Contacts]




[MORE] → [Settings] → [Import/Export contacts]



[IMPORT] → [Device storage]/[SD card]/[SIM card]



[Device]/Synchronized account



Select contacts data to import → [DONE]

- To export contacts, in Step 3, tap [EXPORT] → [Device storage]/[SD card]/[SIM card].
- You can export up to 50 contacts to the au Nano IC Card O4.

* Contacts data is imported. If there are multiple contacts data saved, go to Step 5.


* To import from au Nano IC Card O4, select contacts data to import and then tap [DONE].

Viewing/playing data


View/play images or videos saved in the phone memory or the microSD memory card.



On the home screen, [基本フォルダ (Basic folder)] → [Gallery]



Select an album




Select data to view

* When a screen other than album list is displayed, go to Step 3.

* To play video, tap [再生].

How to transfer data from the au Settings menu


How to restore data from the au Settings menu



On the home screen, [基本フォルダ (Basic folder)] → [Settings]




[au Settings menu]




[Data Transfer]

How to save data from the au Settings menu



On the home screen, [基本フォルダ (Basic folder)] → [Settings]



[au Settings menu]



[Data Transfer]

If you want to use the "データお預かり(Data Storage)" application to automatically save your pictures and address book (contacts) to the au Smart Pass server, you can set it up by following the procedure below.

- On the home screen, select [基本フォルダ (Basic folder)] → [Settings] → [au Settings menu] → [Backup Setting]

You can restore/backup data from your previous au phone to this product using a microSD memory card or au Smart Pass servers.

- You need to setup an au ID to restore or save data using au Smart Pass servers.
- If you use a microSD memory card to restore data, save the data from your previous au phone to a microSD memory card.

- If you selected [SDカードから復元する (Restore data from an SD card)], select your previous au phone model
- If you selected [auスマートパスのサーバから復元する (Restore data from au Smart Pass server)], select [auスマートパスのサーバから復元する (Restore data from au Smart Pass server)] on step 4.
- If you selected [SDカードから復元する (Restore data from an SD card)], select your previous au phone model
- If you selected [auスマートパスのサーバから復元する (Restore data from au Smart Pass server)], select [auスマートパスのサーバから復元する (Restore data from au Smart Pass server)] on step 4.

- You need to setup an au ID to restore data using [auスマートパスのサーバから復元する (Restore data from au Smart Pass server)].
- This screen is not displayed if you selected [auスマートパスのサーバから復元する (Restore data from au Smart Pass server)] on step 4.
- This screen is displayed if you selected [スマートフォンのデータを復元する (Restore smartphone data)].

- If you selected [SDカードから復元する (Restore data from an SD card)], select your previous au phone model
- If you selected [auスマートパスのサーバから復元する (Restore data from au Smart Pass server)], select [auスマートパスのサーバから復元する (Restore data from au Smart Pass server)] on step 4.

- You need to setup an au ID to restore data using [auスマートパスのサーバから復元する (Restore data from au Smart Pass server)].
- This screen is not displayed if you selected [auスマートパスのサーバから復元する (Restore data from au Smart Pass server)] on step 4.
- This screen is displayed if you selected [スマートフォンのデータを復元する (Restore smartphone data)].

- If you selected [SDカードから復元する (Restore data from an SD card)], select your previous au phone model
- If you selected [auスマートパスのサーバから復元する (Restore data from au Smart Pass server)], select [auスマートパスのサーバから復元する (Restore data from au Smart Pass server)] on step 4.

- You need to setup an au ID to restore data using [auスマートパスのサーバから復元する (Restore data from au Smart Pass server)].
- This screen is not displayed if you selected [auスマートパスのサーバから復元する (Restore data from au Smart Pass server)] on step 4.
- This screen is displayed if you selected [スマートフォンのデータを復元する (Restore smartphone data)].

- If you selected [SDカードから復元する (Restore data from an SD card)], select your previous au phone model
- If you selected [auスマートパスのサーバから復元する (Restore data from au Smart Pass server)], select [auスマートパスのサーバから復元する (Restore data from au Smart Pass server)] on step 4.

- You need to setup an au ID to restore data using [auスマートパスのサーバから復元する (Restore data from au Smart Pass server)].
- This screen is not displayed if you selected [auスマートパスのサーバから復元する (Restore data from au Smart Pass server)] on step 4.
- This screen is displayed if you selected [スマートフォンのデータを復元する (Restore smartphone data)].

- If you selected [SDカードから復元する (Restore data from an SD card)], select your previous au phone model
- If you selected [auスマートパスのサーバから復元する (Restore data from au Smart Pass server)], select [auスマートパスのサーバから復元する (Restore data from au Smart Pass server)] on step 4.

- You need to setup an au ID to restore data using [auスマートパスのサーバから復元する (Restore data from au Smart Pass server)].
- This screen is not displayed if you selected [auスマートパスのサーバから復元する (Restore data from au Smart Pass server)] on step 4.
- This screen is displayed if you selected [スマートフォンのデータを復元する (Restore smartphone data)].

- If you selected [SDカードから復元する (Restore data from an SD card)], select your previous au phone model
- If you selected [auスマートパスのサーバから復元する (Restore data from au Smart Pass server)], select [auスマートパスのサーバから復元する (Restore data from au Smart Pass server)] on step 4.

- You need to setup an au ID to restore data using [auスマートパスのサーバから復元する (Restore data from au Smart Pass server)].
- This screen is not displayed if you selected [auスマートパスのサーバから復元する (Restore data from au Smart Pass server)] on step 4.
- This screen is displayed if you selected [スマートフォンのデータを復元する (Restore smartphone data)].

- If you selected [SDカードから復元する (Restore data from an SD card)], select your previous au phone model
- If you selected [auスマートパスのサーバから復元する (Restore data from au Smart Pass server)], select [auスマートパスのサーバから復元する (Restore data from au Smart Pass server)] on step 4.

- You need to setup an au ID to restore data using [auスマートパスのサーバから復元する (Restore data from au Smart Pass server)].
- This screen is not displayed if you selected [auスマートパスのサーバから復元する (Restore data from au Smart Pass server)] on step 4.
- This screen is displayed if you selected [スマートフォンのデータを復元する (Restore smartphone data)].

How to back up data to a PC using Galaxy Smart Switch

There are two versions of Smart Switch: Smart Switch for PC/Mac and Smart Switch for mobile. By using the Smart Switch for PC, you can back up data to and restore data from a PC.

For details, refer to the Smart Switch homepage below.
<http://www.samsung.com/smartswitch/>

You can only forward content that you own or have the rights to. Samsung Electronics Co., Ltd. takes no responsibility for any infringements on the Copyright Law.