

AQUOS SERIE

SHV32

Setting Guide

Thank you for buying the “AQUOS SERIE SHV32” (simply called the “product” from here on). This manual describes the settings and precautions for using the product. For detailed descriptions of various functions, refer to the “Instruction Manual application” (Japanese version) that can be used on the product.

* For illustrations and descriptions in this manual, refer to “Basic Manual” available on the au homepage and on the product.

* The company names and product names appearing in this manual are trademarks or registered trademarks of their respective holders.

* Phone illustrations and screen shots are for descriptive purposes only, and may differ from the actual product.

Basic Operations
Describes names of parts and basic operations.

Initial Settings

- **STEP1: Language Setting**
Set the language to use on the product.
- **STEP2: Wi-Fi® Connection Settings/Tap & Go**
You can connect to an Internet service via a household wireless LAN (Wi-Fi®) environment or a public wireless LAN environment when out and about. Continue your Google™ accounts, etc. from another Tap & Go-compatible device.
- **STEP3: Google Account Settings**
Set up a Google account for using services such as Google Play™ and Gmail™.
- **STEP4: auかんたん設定 (au Easy Setting)**
Set an au ID etc. to use various services provided by au.

E-mail Settings and Changing E-mail Address
Set for using E-mail (@ezweb.ne.jp). An E-mail address is set automatically in the initial settings. You can change the e-mail address set in the initial settings.

Making/Receiving Calls
You can make/receive a call.

How to Transfer Data with the au Settings Menu
Return or store data with the au Settings Menu.

Infrared Communication
You can send/receive data with devices which support the infrared communication function.

Reducing Battery Consumption
You can switch the setting of functions using “function buttons” to reduce the battery consumption.

May 2015, 1st Edition

Sold by: KDDI CORPORATION, OKINAWA CELLULAR TELEPHONE COMPANY
Manufactured by: SHARP CORPORATION


When using the product

- The battery is built into the product, and cannot be removed by the customer.
- To force the power off, hold  down for 8 or more seconds (Release your finger after the product vibrates to turn the power off).

Basic Operations

For detailed operations, refer to the “Instruction Manual application” (Japanese version) that can be used on the product.

- On the home screen, “Apps Sheet” → [Basic Manual].
- When the display language is Japanese, on the home screen, “Apps Sheet” → **[取扱説明書]** (Instruction Manual). You can switch the display language for function names and other items to English.
- On the home screen, “Apps Sheet” → **[設定]** (Settings) → **[言語と文字入力]** (Language & input) → **[言語(Language)を選択]** (Select language) → [English].



① Display
Touch it directly with your fingers to operate.

Tap/Double tap
Tap: Gently touch the screen and then immediately release your finger.
Double tap: Tap the same position twice.

Slide/Swipe/Drag
While your finger is gently touching the screen, an item, etc., trace it to the desired direction or position.

Pinch
Touch the screen with two fingers and widen (pinch-out) or narrow (pinch-in) the fingers' distance.


② (Back key): Tap it to return to the previous screen.
③ (Home key): Tap it to display the home screen.
④ (Recent Apps key): Tap it to display Quick Launcher. Long touch it to display the notification/status panel.
⑤ (Power key): Hold it down to turn the power on. Hold it down while the power is turned on → [Power off] → [OK] to turn it off.

Unlocking the screen
Unlock the screen by sliding “” up.

- If a password, etc. is set for the screen lock, it is displayed as “”.

Long touch
Keep touching an item etc. with your finger.

Flick
Touch the screen and then quickly move (flick) your finger up, down, right or left.





でめませんか?
こまめなタップ



〈Character entry screen (12 Key)〉

Character Input Method

You can enter characters by flick input or tapping keys repeatedly. Tap “” to switch the input modes.

Flick input

By touching a key, the candidates that can be entered by flick input are displayed as shown on the right. By flicking the key in the direction of a desired character being displayed, the character is entered in the character entry area.


Initial Settings

The Google initial settings screen is displayed automatically when you turn the power on for the first time. Follow the on-screen instructions to set each function.

STEP1: Language Setting

- Alternatively, on the home screen, “Apps Sheet” → [Settings] → [Language & input] → [Select language].

1




Select the language → .

STEP2: Wi-Fi® Connection Settings/Tap & Go

You may skip the steps here for making Wi-Fi® connection and Tap & Go settings. By using Tap & Go, you can copy your Google accounts, data, etc. from an Android™ device compatible with this function to the product. For detailed Wi-Fi® settings, refer to the “Instruction Manual application” (Japanese version) that can be used on the product.


- Alternatively, on the home screen, “Apps Sheet” → [Settings] → Tap “OFF” to set “ON” to set Wi-Fi® connection.

1




[SKIP].

2



[SKIP ANYWAY].

3



[SKIP].*

* To use Tap & Go functions, follow the on-screen instructions.


STEP3: Google Account Settings

You can use applications provided by Google Inc. such as “Gmail”, “Play Store” and “Hangouts” by setting up a Google account. You can use the product without a Google account set, but in such case some applications are not available. The main setting items are as follows.

Username	Register your Google account (user ID) and any characters which you want to use as a mail address. You can register any user name but you cannot set the same user name as another user's.
Password	Register the password for using your Google account.


- The Google account setup screen is also displayed when you activate an application for which a Google account is required for the first time.
- Depending on how you operate, screens other than those below may be displayed.

1




[Or create a new account].*1

2




Enter your “First name” and “Last name” → [NEXT].

3




Enter your “Username” → [NEXT].

4




Enter the password → [NEXT].

5




Confirm rescue information → [NEXT].

6




Confirm phone number → [VERIFY].

7




[AGREE].

8




[NEXT].

9




Select “Remind me later”*2 → [NEXT].

10



Confirm the contents of Google services → [NEXT].

11



Select “Skip”*3 → [NEXT].

- *1 If you already have a Google account, enter the e-mail address.
- *2 To specify payment information for use with Google Play, follow the on-screen instructions.
- *3 To use Google Now™, select “Yes, I'm in”.


STEP4: auかんたん設定 (au Easy Setting)

You can use various services provided by au such as au Smart Pass and “au Simple Payment Service” in which you can purchase applications displayed on Google Play by setting an au ID.

au ID	Register your au phone number or any other characters as an au ID. The same “au ID” as another user's cannot be registered.
au ID password	Register the password for using your au ID.


- Alternatively, on the home screen, “Apps Sheet” → [Settings] → [au Settings Menu] → [au Easy Setting].

1



[Next].

2



[Register “au ID”] → [Next].

3




[au IDの設定・保存 (Set/Save “au ID”)].

4



Enter the security code → [OK].*1

5




Enter the password → [設定] (Settings).

6




[終了] (Finish).*2

7




Confirm the contents and follow the on-screen instructions → [Next].

8




Confirm the contents and follow the on-screen instructions → [Agree] → [Next].

9



Confirm the contents → [Agree].*3*4

10




Confirm the contents and follow the on-screen instructions → [Next].*5

11




Select the applications to install → [次へ] (Next).

12



Confirm the contents and follow the on-screen instructions → [Next].

13




Confirm the contents and follow the on-screen instructions → [Next].

14



Select data you want to return from au Smart Pass*6 → [次へ] (Next).*7

15



[Finish].

- *1 The default value is the four-digit security code you wrote on the application form.
- *2 au ID registration is complete.
- *3 When the confirmation screen is displayed, follow the on-screen instructions.
- *4 Preliminary settings for Lookout for au are finished.
- *5 To use the “Data Storage” application and automatically store photos and address book entries to the au server, select “Turn Auto Backup on”.
- *6 If no data is stored to au Smart Pass, this screen is not displayed. Proceed to the next step.
- *7 If a confirmation screen is displayed for Wi-Fi® connection, follow the on-screen instructions.

E-mail Settings and Changing E-mail Address

E-mail (@ezweb.ne.jp) is a service which enables you to exchange e-mails with other cell phones which support e-mail and with PCs. An e-mail address is set automatically in the initial settings. You can change the e-mail address set in the initial settings.


Initial Settings

1




Home screen → .

2



Confirm the contents → [接続する] (Connect).

3



Confirm the contents → [閉じる] (Close).*

* When an Information for improvement screen or the information on E-mail update is displayed, confirm the contents and follow the on-screen instructions.


Changing E-mail Address

1




Home screen → .

2




[E] → [E-mail settings].

3




[Other settings].

4




Confirm the contents → [接続する] (Connect) → [Eメールアドレスの変更へ] (To change e-mail address).

1




Enter the security code →
[送信] (Send).

2




Confirm the contents →
[承諾する] (Accept).

3



Enter an e-mail address →
[送信] (Send).

4



[OK] → [閉じる] (Close).

Backing Up E-mail

- If a microSD™ memory card is inserted into the product, e-mails are saved on the card. If not, they are saved on the internal memory.

1




Home screen → [].

2




[] → [E-mail settings].

3



[Backup/Restore] →
[Mail Backup] → [OK].

4



Select the character code →
[OK] → Select the type of mail
to back up → [OK].

PC-mail settings

You can use a mail address other than the one used for E-mail (@ezweb.ne.jp). For using PC-mail, PC-mail settings need to be finished by the following operations in advance. For details, refer to the "Instruction Manual application" (Japanese version) that can be used on the product.

- On the home screen, "Apps Sheet" → [PC-mail] → Follow the on-screen instructions.

Making/Receiving Calls

- Screens displayed when you receive a call or during a call may differ depending on "Sync Call settings". For details, refer to the "Instruction Manual application" (Japanese version) that can be used on the product.


Entering a Phone Number and Making a Call

1



Home screen → [].

2



Enter a phone number →
[CALL].


Making a Call Using Incoming History/Outgoing History

1




Home screen → [].

2



[Incoming]/[Outgoing].

3



Tap " " of the other party you
want to make a call to.


Making a Call Using Address Book

1




Home screen → [].

2




[].

3



Select the other party you want
to make a call to.


4



[].


Answering a Call

1




Slide "Answer" down while an
incoming call is arriving.

2




The call starts.

3




Tap "End call" to end the call.

1



Slide "Answer" down while an
incoming call is arriving.

2



The call starts.

3




Tap "End call" to end the call.

Putting a Current Call on Hold


While the call is on hold, guidance is played for the other party.

1




Tap "Answer Holding" during a
call.

2



The call is put on hold and the
guidance is played for the
other party.

3




Tap "Unhold" to return to
the call.

How to Transfer Data with the au Settings Menu

- You can return or store data from an old au phone to this product using a microSD™ memory card or au Smart Pass server.
- To return/store data using an au Smart Pass server, you must set an au ID.
- To return data using a microSD™ memory card, save the data from the old au phone to the microSD™ memory card beforehand.


Returning Data with the au Settings Menu

1




On the home screen,
"Apps Sheet" → [Settings].

2




[au Settings Menu].

3



[Data Transfer].¹

4



[データを戻す] (Return data).

5



Select method for returning
data.²

6



If you selected "SDカードから
戻す(Return from SD card)",
select your old au phone
type.³

7



Checkmark the data to return,
[戻す](Return) → [完了]
(Done).⁴

8



Checkmark the data to return,
[戻す](Return) → [完了](Done).


- ¹ If a confirmation screen is displayed for terms of use/privacy policy, follow the on-screen instructions.
- ² To return data from "auスマートパスから戻す(Return from au Smart Pass)" (data stored on an au Smart Pass server), you must set an au ID.
- ³ Not displayed if you selected "auスマートパスから戻す(Return from au Smart Pass)" at step 5.
- ⁴ This screen is displayed when "スマートフォンのデータを戻す(Return smartphone data)" is selected.

How to Save Data from au Settings Menu

To protect important data, be sure to save (back up) data periodically to a microSD™ memory card or au Smart Pass server.


When the product is kept at an au shop or another shop for repairs, the memory will be deleted. Back up data in advance.

1




On the home screen,
"Apps Sheet" → [Settings].

2




[au Settings Menu].

3




[Data Transfer].¹

4



[データを保存する]
(Save data).

5



Select where to save to.²

6



Checkmark the data to save,
[保存する](Save) →
[完了](Done).

7



Checkmark the data to store,
[預ける](Store) →
Confirm displayed contents,
and follow on-screen
instructions →[完了](Done).

- ¹ If a confirmation screen is displayed for terms of use/privacy policy, follow the on-screen instructions.
- ² If "auスマートパスに預ける(Store to au Smart Pass)" is selected, you must set an au ID as you will be using an au Smart Pass server.

Automatically Storing Photos and Address Book

Use the following steps to set automatic backup of photos and address book entries to the au server using the "Data Storage" application. Photos can only be automatically stored with a Wi-Fi® connection.

- On the home screen, "Apps Sheet" → [Settings] → [au Settings Menu] → [Backup Setting] and tap " " for "定期的に自動で預ける(Auto-store periodically)".

Viewing/Playing data


- You can view/play data on the product by the following operations.
- On the home screen, "Apps Sheet" → [Contents Manager] → Tap the data to display.

Infrared Communication

Sending Data


- The information and number of screens displayed when data is sent differ depending on the data.

1




On the home screen,
"Apps Sheet" →
[Send/receive by infrared].

2




[SINGLE].

3



Select data to send.*

4




Follow the on-screen
instructions → [OK].

* When sending a profile, you can set items to send in "Send Setting".

Receiving Data


- Set the other party's device ready for sending data via infrared communication in advance. For details, refer to the instruction manual of the other party's device which will send data.
- The information and number of screens displayed when data is received differ depending on the data.

1




On the home screen,
"Apps Sheet" →
[Send/receive by infrared].

2




[MULTIPLE].

3




Enter the authentication code
→ [OK].¹

4




Follow the on-screen
instructions → [OK].

5




Unlock.²

6



[Add registration]/
[Delete and register].³

7



When the confirmation screen,
the account selection screen,
etc., is displayed, follow the
on-screen instructions.

- ¹ Authentication code is four-digit number prepared along with the other party before sending/receiving data.
- ² The security key is set to "1234" by default.
- ³ If you perform "Delete and register", the original data will be deleted.

Reducing Battery Consumption

You can access "function buttons" from the notification/status panel to enable/disable functions and modify their settings. You can reduce the battery consumption by switching their setting frequently, such as when not using the functions. Enabled functions are displayed in white.


- You can also reduce the battery consumption using "Energy saving settings". For details, refer to the "Instruction Manual application" (Japanese version) that can be used on the product.

1



Slide the status bar down.

2



Tap the functions whose setting
you want to switch by using
"function buttons".