Be sure to read this manual before use

XPERIAZL2 SOT21

Cautions on using Xperia™ Z2 Tablet

- Company names and product names referred to in this manual are generally ademarks or registered trademarks of respective companies. The TM, ® narks may be omitted in this manual.
- In this manual, "Setting Guide", "Basic Manual", "取扱説明書(詳細版)(Full Instruction Manual)" (Japanese), "Cautions on using Xperia™ Z2 Tablet" are
- collectively referred to as "Instruction Manual". In this manual "microSD™ memory card" "microSDHC™ memory card" and "microSDXC™ memory card" are abbreviated as "microSD memory card" or
- In this manual. "Xperia™ Z2 Tablet" is usually referred to as "the product".

Do not leave on unstable places such as rocky stands or tilting surfaces especially while the vibration mode set. Dronning the product many

charging the product. Doing so might cause fire, fault or injury

external source. Doing so might cause low-temperature burns.

The product may become hot by prolonged use especially in high-

temperature environment. Be careful when using the product touching

Do not use power outlets or wiring apparatus beyond its rating. Also

exceeding rating, for example, by connecting multiple devices to a

your skin for a long time, as it might cause low-temperature burns.

Do not touch the main unit or the specified AC adapter (solo

Do not touch the main unit or the specified AC adapter (sold separately) for a long time white power is being supplied from an

single power strip might cause overheating and fire.

Do not place near corrosive chemicals or in places where corrosive gas is generated. Doing so might cause a fault or loss of internal data

Do not use if there is smoke, abnormal odor or noise, excessive

disconnect the specified charging equipment (sold separately) from

the power outlet, make sure that the product is not overheating before turning the power off, and contact an au shop or Keitai Guarantee Service Center. Also, if you have dropped or damaged the product,

do not continue to use it in that state, and contact an au shop or Keitai

When inserting an earphone, etc. into the product, adjust the volume to the proper level. Setting too loud a volume or using the earphone continuously for a long period of time might adversely affect your

ears. Also, raising the volume too high might prevent you from hearing

sounds around you, which might in turn lead to a traffic accident at a

When adjusting the volume with an earphone, etc. inserted into the

nuch from the outset, sudden loud noise from the earphone, etc.

product, raise the volume a little at a time. If you raise the volume too

Remove the power plug of the specified AC adapter (sold separately)

Charging equipment is not waterproof. Do not use in places subject to

from the outlet when not using the adapter for an extended period.

verheating, or other abnormalities. If an abnormality occurs

cause injury or damage. Also, pay sufficient attention to impact, etc.

Do not cover or wrap the product with bedding, etc. while using or

June 2014, 1st Edition 1285-4440.1

Since this product uses radio waves, the possibility of communication intercent

• Hold the product at least 1.0 cm away from your body and also do not contain

Communication is not possible even inside the service area in places where

Communication is sometimes interrupted if you move into a poor reception

metal parts between the product and your body while in communication

ne signal does not reach (e.g. tunnels and basements). Also

communication is sometimes not possible in poor reception areas

- by third parties cannot be eliminated (Though LTE/MIMAX 2+/CDMA/GSM/UMTS system has highly secure confidential communication features). This product is compatible with the international roaming service. Each
- network service described in the manual varies depending on the area and service content. For details, refer to the "Instruction Manual" (Japanese) application installed on the product or "取扱説明書 (詳細版) (Full Instruction Manual)* (Japanese) available on the au homepage.

 • Since this product is a radio station under the Radio Law, you may be asked
- to temporarily submit the product for inspection in accordance with the Radio
- The IMEI information of the product is automatically sent to KDDI CORPORA

When using the product

- TION for maintenance and monitoring operational status of the product.
- Take care not to inconvenience people around you when you use the product
- in a public place.
- Before you start using the product overseas, check the relevant laws and egulations of the country/region you visit.
- When the product is used by a child, parents or guardians should thoroughly read the "Basic Manual" and "Cautions on using XperiaTM Z2 Tablet" and ach the child how to use it.
- Use of the product is not allowed in the following places!
- Do not use the product while driving a car or riding a motorbike or bicycle Failure to do so might cause a traffic accident. Use of the product while ratine to do so might cause a trainic accident. Use of the product while riding a bicycle may be punishable by some regulations.
- Do not use this product while you are aboard an airplane. Use of electric devices transmitting radio waves in an airplane is prohibited by law. Some airline companies, however, allow their passengers to use the product. For details, contact the airline company you use.


connector straight to/from the terminal. Make sure the orientation of the

When using an AC adapter or external device, insert/remove the

onnector is correct. Failure to do so might cause damage or a fault.

Danger Be sure to read the following hazards before use.

Do not puncture the product with a nail, hit with a hammer or step on the product. Doing so might cause fire or damage.




Be careful not to have the product bitten by your pet. It might cause eakage of the internal battery, overheating, rupture, ignition, fire or

/!\ Warning

Be sure to read the following warnings before

Do not use the product while driving a car or riding a motorbike or bicycle. It might cause a traffic accident. Use of the product while driving a car or motorbike is prohibited by law. Use of the product while riding a bicycle may be punishable by some regulations.



electric devices transmitting radio waves in airplane is prohibited by law. Some airline companies, however, allow their passengers to use them. For details, contact the airline company you use When a cable is connected to the microUSB terminal of the product to charge the battery etc., the power is turned on, even though operation is not available. Therefore, cable connection for charging etc. should not be made in areas where use is prohibited, such as in airplanes and hospitals.

waves might affect these units and devices. So, please observe the Do not disassemble, modify or directly solder the product. Doing so might cause spilling of the battery liquid received. . Those with an implanted pacemaker or implanted cardioverter defibrillator should carry or use the product at least 15 cm away might cause spilling of the battery liquid resulting in an accident such from the implanted pacemaker or implanted cardiove

 Set the product to "Airplane Mode" or turn it off beforehand, if you may not keep distance 15 cm or more such as when you canno

move easily etc., since there may be people with an implanted cardiac pacemaker or implanted cardioverter-defibrillator nearby.

3. Pay attention to the following points when using the product inside

Do not bring the product into operating theaters, intensive-care

- units (ICU) and coronary care units (CCU).
- Turn the product off in hospital wards.
- Even if you are in a lobby, etc., be sure to turn the product off when there are electronic medical devices nearby.

 When a medical institution has laid down designated areas where use of the product is prohibited or is not allowed to be brought in,
- abide by the instructions of that medical institution When using electronic medical devices other than an implanted pacemaker and implanted cardioverter-defibrillator outside a medical institution (e.g. home medical treatment), check individually with the manufacturer of the electronic medical device regarding the influence of radio waves.

Stay alert to your surroundings when messaging, browsing the nternet, shooting photos, playing games, watching TV or listening to nusic. Failure to do so might cause a fall or traffic accident.

Pay attention to items becoming stuck to the Desktop Holder. The magnetic connector uses magnets, and so thumbtacks and pins, craft knife blades, staples, and other metal objects sometimes become product, be sure to check that there are no foreign objects on the

Do not bring magnetized objects such as cash cards, floppy disks, credit cards, and prepaid cards close to the magnet connector of the desktop holder because magnets are used. Doing so might result in loss of recorded information.

If you feel any abnormality with your skin, immediately consult a dermatologist. Itching, rashes, eczema, etc. sometimes occurs lepending on your physical constitution and condition. The materials of parts used on the Desktop Holder are as follows.

magnetic connector or other parts.

Part	Material	Surface treatment
Upper case	ABS resin	-
Lower case	ABS resin	-
Attachment	PC resin	-
Housing	PC resin	-
Magnet connector	Samarium cobalt	Nickel plating
Contact terminal	Brass	Gold plating
Label	PS resin	-
Rubber foot	Polyurethane resin	_

au Micro IC Card (LTE)



Do not put the au Micro IC Card (LTE) in a cooking apparatus such as a microwave oven or a pressure vessel. Doing so might occur

Pay attention to the place of use!

Consider people around you!

instructions of that medical institution.

Exemptions

e Company.

related to the Company.

a hotel lobby etc

• To prevent ringtone from bothering other people, power off or use Silent mode at a movie theater, theater, museum, library, etc.

It is extremely dangerous to walk while looking at the screen of the product.

Move to a place where you do not disturb others while you are in shinkansen

There may be a person with a cardiac pacemaker nearby at a place filled

When a medical institution has laid down designated areas where use of the

with people such as in a crowded train. Set "Airplane mode" or turn of

product is prohibited or is not allowed to be brought in, abide by the

The Company is not liable for any damages arising from earthquakes.

The Company is not liable for any incidental damages (change)

lightning, storms, floods or other natural disasters, as well as fires, actions by third parties, other accidents, intentional or mistaken misoperation by the

customer, or use under other unusual conditions outside the responsibility of

disappearance of described content, loss of business income, disruption of business, etc.) arising from use of or inability to use the product.

The Company is not liable for any damages arising from failure to observe the described content of the "Instruction Manual".

O Captured image data or downloaded data may sometimes be altered or lost

due to faults, repair or other handling of the product. The Company is not

liable for any damage or lost income resulting from recovery of these data.

The product sometimes affects high-precision electronic devices. So

onic medical devices, fire alarms, and

turn it off near such devices (Examples of electronic devices that

night be affected by the product include cardiac pacemakers

natic doors. If you are using an electronic medical de-

When using the product near an implanted pacemaker, implanted cardioverter-defibrillator or other electronic medical device, radio

possible affect of radio waves).

contact the device manufacturer or retailer for information about the

The Company is not liable for any damages arising, for example, from

In a city area, use in a place where you do not bother people walking

onot operate the product while walking or by stopping suddenly.

Ask permission if you take photos with camera of the product

Be sure to read the following cautions before use.

careful not to injure your hand or finger when attaching/removing the au Micro IC Card (LTE).



cause loss of data or a fault. For the specified devices, contact an au shop or Customer Service Center.

Do not use or leave the au Micro IC Card (LTE) in hot places such as

ning, loss of data or a fault.

Do not throw the au Micro IC Card (LTE) into a fire or heat it. Doing so

o not fold, bend or place a heavy object on the au Micro IC Card (LTE). Doing so may cause a fault.

Do not scratch the IC (metal) part of the au Micro IC Card (LTE). Doing so might cause a fault.

Do not store the au Micro IC Card (LTE) in dusty places. Doing so might cause a fault.

Do not store the au Micro IC Card (LTE) in places exposed to direct

O It is recommended you keep a copy of important data on your PC's hard disk

etc. Whatever the cause of the defect or malfunction may be, the Company assumes no responsibility for alteration or loss of saved data. "The Company" as appears in this manual refers to the following companie

Manufactured by: Sony Mobile Communications Inc.

Sold by: KDDI CORPORATION OKINAWA CELLUI AR TELEPHONE COMPANY

he content of "Instruction Manual" is subject to change without notice

Should you notice any unclear points, omissions, etc., feel free to

Before using this product, thoroughly read these safety precautions

prevent damage to property or injury to the customer or others using the

. Every effort has been made in the preparation of "Inst

Wrong page order or missing pages will be replaced.

Safety Precautions (Observe Strictly)

These instructions are divided into the following categories.

iury *1 to a person

person or physical damage

Explanation of indications used in this manual

♠ Danger

♠ Caution

de panel

ton key (power key)

orative ring (power key)

orative ring (camera)

sparent plate (display

roduction of the content of "Instruction Manual" in part or in whole is

use. After reading, store the precautions in a safe place

This symbol indicates the potential and imminent

anger of death or serious injury *1 to a person

This symbol indicates the possibility of death or seriou

This symbol indicates the possibility of minor injury *2

residual aftereffects from poisoning, etc., and injuries

Sometimes, very rarely some people demonstrate symptoms such as

atedly flickering screens. Those with a past history of this should

temporary muscle spasms, loss of consciousness, etc. by watching

Caution Be sure to read the following cautions before use.

Use of the main unit in an automobile might sometimes affect onvehicle electronic devices, though this report.

depending on your physical constitution and condition

The materials of parts used on the product are as follows

If you feel any abnormality with your skin, immediately consult a

dermatologist. Itching. rashes, eczema, etc. sometimes occurs

ass 55%)

oft feeling coating (bla

Soft feeling coating (bla

/ coating

Jrethane coating (white

1

requiring hospital admission for treatment or long-term hospital attendance as an outpatient This refers to injuries, burns (high- and low-temperature), electric shock, etc. that do not require hospital admission for

treatment or long-term hospital attendance as an outpatient *3 Physical damage: This refers to extended damage to buildings, furniture, livestock, or pets.

Explanation of graphic symbols used in this manual


Indicates that use in a place

O _{Don't}	Indicates an action that is not allowed.	No liquids	get wet or allowing the product to get wet is not allowed.		
No wet hands	Indicates that handling with wet hands is not allowed.	0	Indicates an action that must be done.		
No. of Control of Cont	Indicates that disassembly is not allowed.	Unplug	Indicates that the power plug must be disconnected from the power outlet.		
■ Precautions common to the main unit, internal battery, charging					

equipment, au Micro IC Card (LTE), peripheral devices

Danger Be sure to read the following hazards before use.

Be sure to use only the specified peripheral devices. Use of other




Before entering an area where flammable gas is generated such as a gas station, be sure to turn off the product. Do not charge the battery. Failure to do so might cause the gas to catch fire.

Doing so might cause ignition, rupture, fault, fire or injury.

Part Material Surface treatment

Do not bring the product close to magnetized objects such as cash cards, floppy disks, credit cards, and prepaid cards. Doing so might result in loss of recorded information. Do not allow liquids, metal objects, burnable items, and other foreign



Use the product with the covers of the microUSB connection terminal nicroSD memory card slot or au Micro IC Card (LTE) slot cover etc

closed. If the covers are open, dirt or water may get inside causing a Stow the TV antenna when not watching TV. Use with the TV antenna

If you have a weak heart, be careful when setting the incoming ation and ringtone volume to prevent adverse effects on your

Pay attention to items becoming stuck to the main unit. The microphone of ray attention to treat becaming status to the main unit. The microphone or speaker uses magnets, and so thumbtacks and pins, craft knife blades, staples, and other metal objects sometimes become stuck to the main unit, and cause unexpected injury. Before using the product, be sure to

check that there are no foreign objects on the microphone or speaker or other parts.

Do not put the product directly on the sand at a beach, etc. Sand or other small particles might get inside the microphone, speaker, etc. causing the volume to drop. If sand gets inside the the product's main unit, it might cause overheating or a fault.

These precautions are provided to ensure that performance can be fully

equipment, au Micro IC Card (LTE), peripheral devices

by the warranty, even if there is no external damage. To ensure waterproof property (equivalent to IPX5 and IPX8) of this product, use the product with the microUSB connection terminal cover, microSD memory card slot cover/au Micro IC Card (LTE) slot cover tightly closed. Note that the waterproof property is not guaranteed in every usage

sulting in a malfunction. Such damage and malfunction are not covered

Malfunctions determined to be caused by water are not covered by the

 Do not use the product in extremely hot, cold or humid places. (Use within an ambient temperature range of 5°C to 35°C and humidity range of 35% to 85%)

When using the product for data communication, be careful not to When using the product for data communication, be careful not to keep the product in direct contact with your skin for a prolonged eriod or not to cover the product with paper cloth, hedding, et The main unit might get hot, causing fire, injury or a fault.

Do not put the product in a cooking apparatus such as microwav

Do not short-circuit the desktop holder contact terminals, microUSB

confluctive foreign objects (metal fragments, pencil leads, etc.) to come into contact with or get inside the desktop holder contact

terminals, microUSB connection terminals or headset connection

When using a metal accessory, etc., take sure not to allow the metal par come in contact with the microUSB connection terminals or power

outlet. Doing so might cause electric shock, ignition, injury or a fault

Do not expose the camera lens to direct sunlight for an extended period. Doing so might cause ignition, rupture or fire by the light-collecting mechanism of the lens.

The customer is not allowed to disassemble, modify or repair the

Warning

Be sure to read the following warnings before use.

Do not drop or subject to strong impact, such as throwing. Doing so might cause rupture, overheating, fire, leakage or a fault.

Do not use outside when you can hear thunder. Doing so might risk lightning strikes and electric shock.

product. Doing so might cause a fault, ignition, electric shock, or injury. The Company is not liable even in the event of any nonconformities

arising on the product or peripheral devices as a result of modification, etc. Modification of the product is in violation of the Wireless Telegraphy

terminals. Doing so might cause fire, burns, a fault due to heat

onnection terminals or headset connection terminals. Do not allow

Do not put the product in a cooking apparatus such as microwave oven or a pressure vessel. Doing so might cause ignition, rupture,

Do not throw the product into a fire or heat it. Doing so might cause ignition, rupture or fire.

fault, fire or injury.


Internal battery

4

(The internal battery of this product is a lithium-ion rnal battery is not fully charged at the time of

purchase. Charge the battery before using the product Li-ion 00

Danger Be sure to read the following hazards before use. f the leaked liquid gets on your skin or clothes, immediately rinse it off



The internal battery is a consumable item. If the performance of a battery does not recover (e.g. the usable time after each charge has become extremely short), the battery is at the end of service life, so stop use. Failure to do so might cause overheating, fire, rupture or leakage. Battery is built into the product. For repair, the product must be collected to au shop etc. and charges will be incurred. And you may not use the product during certain period of time. Please be forewarned. Note that the length of service life varies depending on

■ Charging equipment

Warning Be sure to read the following warnings before use.

Do not let your hands, fingers and other parts of the body touch the

desktop holder contact terminal, microUSB connection terminal or

display is cracked or internal parts are exposed, do not touch the

cracked display or exposed parts with your hands. Doing so might

cause electric shock or injury from damaged parts. Contact an au shop or Keitai Guarantee Service Center.

If the wet product is charged, electric shock, short circuit, or corrosion

slot. Continued use of the product in this state might cause

If charging is not completed after the specified charging time, stop charging. Failure to do so might cause leakage of liquid, overheating, rupture or fire.

Do not leave in places within the reach of small children, Small

Caution Be sure to read the following cautions before use.

Do not store the product in places subject to direct sunlight (e.g. in automobiles), places that get hot, places that get extremely cold, and

in humid or dusty places. Doing so might cause overheating, ignition, deformation or a fault.

children might swallow small parts, etc. by mistake and choke on

them, or might drop them by mistake and cause accidents or injury.

Do not operate the product while driving an automobile or motorized

bicycle, riding a bicycle or walking. Doing so may compromise traffic

overheating, fire or a fault.

safety and cause an accident.

headset connection terminal. Doing so might cause electric shock

If the product is damaged because it is dropped or something, and its

Do not use at other voltages than the specified power supply voltage.


Doing so might cause ignition, fire, overheating, electric shock or AC adapter (sold separately): 100 VAC to 240 VAC (Connect to the


AC outlet for internal household use)
When charging the product overseas, use AC Adapter for global use (sold separately).

Firmly insert the plug of the specified charging equipment (sold separately) into the power outlet down to the base of its pins. Incomplete insertion of the power plug might result in fire or injury caused by electric shock, overheating or ignition. Do not use

Do not damage, modify, twist, pull or place a heavy object on the cable of the specified charging equipment (sold separately). Do not use a damaged cable. Doing so might cause an electric shock, short

circuit, fire or injury.





safety equipment such as airbags. Failure to do so might cause a traffic accident. Install in-car devices following the instructions of their

cause malfunction. Operation with gloved hands

Operation with protective sheet or seal on the screen
 Operates when the display is wet or fogged

regulations for the specified radio station based on the Radio Law, and the

Checking procedure. From the Horne screen, [] [] Settings [Adout tablet] — [Legal information] — [Certificates] If the screws of the product are removed and modifications are made to the internal components, the certification of conformity with technical regulations will

become invalid. Never use the product without the valid certification. Doing so violates the Radio Law.

annot be easily disassembled. Modifying the product is prohibited by the Radio Law.

Contents saved in the product, such as contacts and Album data might be altered or lost in an accident, fault, repair or mishandling. Be sure to keep a

Note that contents data (both charged or free content) saved with the product cannot be returned to the customer when the product is replaced

for repair of a fault, for example.

irect splashing with water, pet urine or other liquids. Doing so migh result in faults or injury resulting from overheating, fire, electric shock, or short-circuiting of electronic circuits. In the event that the product is hed with liquid, immediately disconnect the power plug of the

used in the room and stable place.

Failure to do so might cause fire or a fault

might adversely affect your ears.

Guarantee Service Center.

Be sure to read the following cautions before Caution Be suse

Do not use in humid places such as bath areas, or connect/

disconnect the specified charging equipment (sold separately) wet hands. Doing so might cause electric shock, a fault or injury. Charge the battery in a stable place especially while the vibration node set. If placed on an inclined surface or wobbly stand, the

with a cloth or bedding. Doing so might cause fire, a fault or injury.

When unplugging the plug of the specified charging equipment (so separately) from the outlet, hold and pull the power plug. If you pull the cable, the cable might be damaged. Do not use the desktop holder in a car. Doing so might disturb driving and cause an accident. It is presumed that the desktop holder will be

Warning Be sure to read the following warnings before use.

? Caution

e only the devices specified by the Company to insert the au Micro C Card (LTE) in. Using a device not specified by the Company migh

Do not disassemble or modify the au Micro IC Card (LTE). Doing so might cause loss of data or a fault

by the fire or a heater. Doing so might cause melting, overheating,

Do not throw the au Micro IC Card (LTE) into a fire or heat it. Doin might cause melting, overheating, fuming, loss of data or a fault. Do not touch the IC (metal) part of the au Micro IC Card (LTE) or short-

circuit it. Doing so might cause loss of data or a fault. Do not drop the au Micro IC Card (LTE) or subject it to strong impact. Doing so may cause a fault.

Do not wet the au Micro IC Card (LTE). Doing so may cause a fault.

Do not store the au Micro IC Card (LTE) in places exposed to a sunlight or hot and humid places. Doing so may cause a fault.

Store the au Micro IC Card (LTE) out of reach of small children. Failure to do so might cause injury or asphyxiation, etc. if they accidentally swallow and choke on it. Sony Mobile TV antenna input microUSB conversion cable 01

Be sure to read the following warnings before

Warning Be su use. Sony Mobile TV antenna input microUSB conversion cable 01 is not waterproof. Do not use in places subject to direct splashing with water, pet urine or other liquids. Doing so might result in a fault/injury resulting from overheating, fire, electric shock, or short-circuiting of

Caution Be sure to read the following cautions before use.

When the product is used by a child, parents or guardians should

teach the child how to use it. Do not allow them to use the equipment

Part Material Surface treatment

f you feel any abnormality with your skin, immediately consult a matologist. Itching, rashes, eczema, etc. sometimes occurs depending on your physical constitution and conditio The materials of parts used on Sony Mobile TV antenna input microUSB conversion cable 01 are as follows

without adult supervision. Failure to do so might cause injury.

ode section, connector section			
type connector (metal section) type connector (periphery of pPS — PPS — connector section (metal section, tich) connector section (terminal) connector section (terminal) connector section (periphery of pPA — PPA — PAA — PA	ode section, connector section	Elastomer resin	-
type connector (periphery of priminal) onnector section (metal section, ltch) onnector section (terminal) onnector section (periphery of periphery of peripher	type connector case	ABS	-
rminal) onnector section (metal section, tch) substituting the properties of the pro	type connector (metal section)	Brass	Nickel plating
tch) onnector section (terminal) onnector section (periphery of PPA —		PPS	-
onnector section (periphery of PPA –		SUS304	-
	onnector section (terminal)	Au plating	-
			-

Handling precautions

demonstrated. Thoroughly read these precautions to ensure correct use Precautions common to the main unit, internal battery, charging

 Do not apply excessive force to the product during use. Be sure not to put the product into a tightly packed bag or place a heavy object on the product in a bag. Doing so may cause a damage or fault of the display, Keeping an external device connected to the microUSB connection terminal or headset connection terminal might damage the connector

condition. Do not allow water to get inside the product or splash water or charging equipment or optional accessories. Do not attach/remove the microSD memory card or au Micro IC Card (LTE), or open/close the microUSB connection terminal cover in the rain or with waterdrops on the surface of the product. Doing so might cause water intrusion resulting in internal corrosion

warranty.

Peripheral devices

cause a fault. headset connection terminal with dry cotton swabs, etc. every now and then Soiled terminals might cause poor connection. Do not exert a strong force to

> ■ Clean the product with a soft dry cloth (such as the type used for eyeglasses). Forceful rubbing with a dry cloth may scratch the display. The display may be stained if splash or smear is left attached to the surface Wiping the product using alcohol, thinner, benzine, detergent, etc. might erase the printing on the outer casing or cause discoloration.

Xperia™ 72 Tablet main unit

• Use as far away as possible from household electrical appliances (TV, peaker, etc.). Use nearby might affect them. This product may become warm while watching TV, charging or during other

neadset connection terminal to prevent deformation.

operations, depending on the situation, but this is not abnormal. ■ When the product is used by a child, parents or guardians should thoroughly read "Instruction Manual" and teach the child how to use it.

Do not use the product in extremely hot, cold or humid places.

of 36°C to 40°C and humidity range of 86% to 90% is allowed)

au Micro IC Card (LTE) (attached to Xperia™ Z2 Tablet main unit)

Do not use in places subject to lots of dust or vibration. Doing so might

clean the desktop holder contact terminal, microUSB connection terminal or

(Use within an ambient temperature range of 5°C to 35°C and humidity range of 35% to 85%. Temporary use within an ambient temperature range of 35% to 85%.

If the product becomes high temperature, the display may become dim


 Do not forcefully press, tap or intentionally subject the display to strong impact. Doing so might cause scratching or damage

6

damaged adapters or loose power outlets.

Do not let your hands, fingers and other parts of the body touch the desktop holder contact terminals or microUSB connection terminals. Doing so might cause electric shock, injury or a fault.

If you hear thunder, do not touch the power plug. Doing so might cause an electric shock etc. as a result of a lightning strike.



Wipe off dust on the power plug. Failure to do so might cause fire, burns or electric shock.

Install and position in-car devices where they do not hinder driving or

● Do not forcefully press your fingernails or hard objects against keys o display surface. Doing so might cause scratching or damage

strong pressure with your fingers or sharp-pointed objects (such as fingernails, ballpoint pens and pins) on the touch panel. ching the panel may not work in the following cases. Note that it may

Operation with fingernails . Operation with foreign object on the screen

Operation with wet or sweaty fingers

 Operation under water Never use modified au device. Use of a modified device violates the Radio Law This product has acquired the certification of conformity with technical

echnical Conformity Mark 😂" is checkable on au device as a certificate. Checking procedure: From the Home screen, [] \rightarrow [Settings] \rightarrow [About

To prevent unlawful modification, the product has been designed so that it

copy of important contents. Note that the Company assume no responsibility for any damages or lost profits resulting from altered or lost contents.

● This product uses liquid crystal for its display. The display response speed may become slow when the ambient temperature is low, which is due to the

property of liquid crystal and not a malfunction. The display response speed will return to normal at room temperature. Although the display used on the product is made using high-precision echnology, some pixels (dots) might be lit or out at all times. This is not a

 Take care not to inconvenience people around you when you use the product in a public place.

● You are recommended to store copies of individual data such as photo you took, videos and music on your PC by sending each file as mail attachment, etc. Note, however, that you may not be able to make copies of any copyrighted data even by the above-mentioned means.

 Take care not to place magnetized items such as magnetic cards, speakers and TV sets pear the product, as it might cause malfunction Putting a strong magnetism close to the product might cause false

 When you put the product in your bag, take care so that the display does which you but the product in your bag, take care so that the display do not come in contact with metal objects or other hard objects, as it might cause scratching or damage.

● When suddenly brought into a warm place from a cold place, or when in a when saddeling brodgittling a warm page from a color place; or when it is humid location, or when used where temperature suddenly changes (e.g. near the air discharge port of an air conditioner), water droplets (i.e. condensation) sometimes are formed inside the product. Note that when under conditions such as this, the humidity might cause corrosion or a

 When wiping the display, wipe with a soft, dry cloth. Use of a glass cleaner or other similar liquid might cause a fault.

 When connecting the external device to the microUSB connection terminal or headset connection terminal, insert/remove the external device connector and plug straight to/from the microUSB connection terminal or headset onnection terminal. Failure to do so might cause damage or a fault.

 Note that applying excessive force with the external device connected to the microUSB connection terminal or headset connection terminal might cause damage.

After entering the PUK code, you need to set a new PIN code in "Change SIM

If the PUK code is incorrectly entered ten times consecutively, contact an au shop PiPit or Customer Service Center

Notes on waterproof and dustproof properties

This product has a waterproof property equivalent to IPX5*1 and IPX8*2, as well as a dustproof property equivalent to IP5X*3 on the condition that the microUSB connection terminal cover, microSD memory card/au Micro IC Card (LTE) slot cover are securely attached (based on in-house testing). Specifically, you can operate holding the product with wet hands in the rain (less than 20 mm per hour) without an umbrella, as well as use the product in a place with water such as a bathroom or kitchen. Before using the product, thoroughly read "Important items to remember before use" and "Tips for comfortable use" to ensure correct use. Failure to follow the contents described in these sections may cause the intrusion of water, sand or other foreign material, resulting in overheating, ignition, electric shock, injury or a fault, 1 IPX5 equivalent means that the product will maintain its operability as a

communication device even if it is sprayed with water from a 6.3 mm diameter nozzle at a distance of about 3 meters for more than 3 minutes at a rate of about 12.5 liters per minute from any direction *2 IPX8 equivalent means that the product will maintain its operability as a


communication device with no water getting inside the main unit even if it is gently submerged in a tank of still tap water at room temperature to a depth of 1.5 meter for about 30 minutes.

3 IP5X equivalent means that the product will securely maintain its operability as a communication device even after it has been placed in an apparatus with grit and dust of diameters of 75 μ m or less and shaken for 8 hours ce operation of the product on each usage scene was confirmed based the above assumption, proper operation of the product in every possible condition during actual use is not guaranteed. Malfunctions determined to be caused by mishandling by the customer are not covered by the warranty.

Important items to remember before use

1) Make sure that the microUSB connection terminal cover, microSD memory card/au Micro IC Card (LTE) slot cover are firmly closed.

(3) If water flows out from inside of the product, wipe it off with a dry cloth etc. Water left on microphone or speaker is not easily wiped off. Face the product downward and push it on a cloth to wipe off the water.



4 Place a dry towel or cloth under the product and leave them for a couple of hours at room-temperature to dry.

If the product is not dried enough, you cannot hear the sound easily. eave the product enough time to dry before use

■ Precautions on charging

The supplied and optional accessories are the following before and after charging. sories are not waterproof/dustproof. Check Never charge the battery if the main unit is wet. Doing so might cause electric

shock or short circuit resulting in a fire, a fault or burns.

Check that the main unit is not wet. If you are charging the battery just after

the product gets wet, drain water well and wipe the remaining water off with a clean dry cloth before placing it in the desktop holder or opening the microUSB connection terminal cover.

If you charge the battery with the microUSB connection terminal cover open, be sure to tightly close the cover when charging is finished. We recommend using the desktop holder to charge the battery to prevent water leak or dust penetration from entering from the microUSB connection terminal. Do not discard the product together with regular trash. Please cooperate in Do not put stickers or sheets (e.g. commercially available protective films, the collection of the product when it is no longer needed to protect the rironment and effectively use resources. Old products are collected at au shops and other places.

Do not exert excessive force when attaching/removing a microSD memory

card. Doing so might injure your hands or fingers. While reading/writing data, do not subject the product to vibration or impact, pull out microSD memory card, force-quit, or turn off the power.

 Do not cover the light sensor with your finger or put a sticker on it. Doing so night hinder the light sensor from detecting the ambient brightness and functioning correctly.

Doing so might cause loss of data or a fault.

 Do not apply excessive force to the product during use. Note that applying ssive force to the product such as swinging or carving the product body cause malfunction or damage.

 Do not forcefully pull microUSB connection terminal cover, microSD emory card/au Micro IC Card (LTE) slot cover. It might cause damage.

While watching TV, the product becomes hot. Be careful when touching the product with your hands or face. Note that when the shooting screen is displayed continuously for a long

time for still image shooting, video shooting, or TV watching, parts of the main unit may get warm, and that contact by your skin with these parts for a long time might cause low-temperature burns

 Do not use the product while driving a car, etc. It might cause a traffic accident and is prohibited by law

Display (Touch Panel)

21

Use your finger to operate the touch panel. Do not use ballpoint pens pencils or other sharp-pointed objects. Using such objects does not only hinder correct operation of the touch panel, but also might cause



Waterproofness/dustproofness is only effective when the covers are

 Just a small particle (a hair, etc.) between contact surfaces can cause water leak or dust penetration.

 Do not open/close the microl ISB connection terminal cover microSD. memory card/au Micro IC Card (LTE) slot cover if the main unit or your hands are wet. Do not connect Sony Mobile TV antenna input microUSB conversion cable.

01 or earphones to the product when it is wet by water. Doing so may cause a fault. When closing each cover, after stowing the cover hinge, press the entire

cover with the flat part of your finger. Then, trace the cover to ensure that the cover is not partially open.

② Do not immerse the product in water with

soap, detergent or bath salts in it. 3 Do not immerse the product in seawater, a

swimming pool or hot spring. Do not immerse the product in any liquid

(alcohol, juices, etc.) other than fresh water and tap water of room-temperature (5-35 $^{\circ}{\rm C}$). (5) Do not place the product directly on the sand

at a beach, etc. Grains of sand or other small particles might get into microphone or speaker causing the volume to drop. And if sand gets inside the product's main unit, it might cause overheating or a fault. 6 Do not use the product underwater.



Soap/detergent/ Seawater

Do not leave the product in a humid place such as a bathroom or kitchen for an extended period of time.

Tips for comfortable use

 Once the product gets wet, water may remain in gaps on the main unit. Shake the product well to drain water. Especially make sure to drain water remaining. n headset connection terminal, power key and volume key parts.

 Even after the water is drained, the inner parts might still be wet. Although you can use the product, do not place it near things that must not get wet. Take care not to wet your clothes, bag or contents of the bag.

29

 Do not touch the specified charging equipment or desktop holder with wet. hands. Doing so might cause electric shock.

Do not splash water over the specified charging equipment and desktop

holder when using them. Do not use them near water such as in a bathroom, shower room, kitchen or washroom. Doing so might cause fire, electric shock, a fault or injury. Do not bring them into a bathroom, etc. even when you are not charging with them. Doing so might cause fire or electric shock, a fault or

Notes on using Bluetooth®/wireless LAN (Wi-Fi®) functions

 The Bluetooth® and wireless LAN (Wi-Fi®) functions of this product conform to domestic, FCC standards and EC Directive, and has been certified

 The 2.4 GHz band used by wireless LAN (Wi-Fi®) and Bluetooth® devices is shared by various other devices. For this reason, the communication speed and connectable range may be decreased, or disconnection may occur, due to interference from other devices.

· Do not use this product in places where electromagnetic waves are generated or near electric products, AV and OA equipment, or other anetized devices

 Subjecting this product to magnetic or electrical noise might increase noise and prevent it from performing communications. (This product is particularly susceptible to noise when it used near a microwave oven.)

· Using this product near a TV, radio or similar appliance might cause reception

interference and disrupt TV images.

The searching might not be successful if there are multiple wireless LAN (Wi-

Fi^(a) access points near to the product or the same channel is being used. The wireless LAN (Wi-Fi^(a)) function cannot be used in airplane. Be sure to turn off the power even in a wireless LAN (Wi-Fi®) compliant airplane. Some airline ompanies, however, allow their passengers to use. For details, contact the

airline company you use. The communication speed and connectable range vary depending on the distance between communication devices, obstacles and the Bluetooth® wireless LAN (Wi-Fi®) devices used.

If the display surface is dirty or wet with sweat or water, it may not function correctly. In such case, wipe the display surface with a dry, soft cloth.

Note that pressing the touch panel forcefully may cause malfunction or damage.

When carrying the product in your bag, take care not to put the touch panel

close to metals or other conductive materials, as it might cause false

automobile with the windows closed in summer, will cause the battery

The internal battery gradually discharges after charging even if the product is not used. The internal battery may discharge completely after long time

Do not store the product under the following conditions. They might cause

degradation of performance or service life of the internal battery.

Charge the battery before using the product for the first time after

hase, or if you have not used the product for a long time

may not use the product during certain period of time. Please be

The internal battery is a consumable item. If the performance of a battery

does not recover after charge, the battery is at the end of service life, so

stop using it. The battery is built into the product. For repair, the product

forewarned. Note that the length of service life varies depending on the

Drain water if it becomes temporarily hard to hear the sound due to water

In the rain: You can make calls holding the product with wet hands in the rain

. The rain in this case means a moderately-heavy rain (less than 20 mm per

Water drops on the display might cause errors in the touch panel operation

Never open/close the microUSB connection terminal cover, microSD memory card/au Micro IC Card (LTE) slot cover if the product is exposed to rain, or

In the shower: You can make calls holding the product with wet hands while

designed to withstand high water pressure.

Washing: You can wash the product under a mild flow (less than 6 liters per

minute) of tap water at room temperature (5°C to 35°C) at a distance of about

On not spray the product with high-pressure water or submerge it in water for extended periods of time, as the product is not designed to withstand high

Make sure to hold the microUSB connection terminal cover, microSD memory

card/au Micro IC Card (LTE) slot cover so that they do not open, wash the

· Do not splash the product with or immerse it in soap water, detergent water

In the bath: You can use the product in a bathroom. Although you can make calls

vith wet hands, do not immerse the product into a bathtub. The product is not

Do not use the product in a bathroom for an extended period of time. The

Do not immerse the product in hot spring water, soap water, detergent water

e frequencies used by the Bluetooth® and/or wireless LAN (Wi-Fi®) function

of this product are in the 2.4 GHz band. In this frequency band, other similar

wireless stations, in-plant wireless stations for mobile unit identification that

wireless stations that do not require licenses, amateur wireless stations

(collectively called "other wireless stations" from here on) are operated in

In the event that instances of radio wave interference have occurred

between this product and "other wireless stations", immediately either

3. If you are unclear on any points or are troubled by anything, contact an au-

The connections between this product and all other Bluetooth[®] and wireless

LAN (Wi-Fi[®]) devices have not been confirmed. Therefore, connections with all Bluetooth® and wireless LAN (Wi-Fi[®]) devices are not guaranteed.

This product supports security features for wireless communications that are

specifications, but the security may not be sufficient depending on the usage

environment and configuration. Be careful when making data communication using Bluetooth® or wireless LAN (Wi-Fi®) function.

anywhere within the radio wave range, as it uses radio waves for exchanging information. At the same time, there is a risk that a malicious third party may

obtain unauthorized access if security settings have not been configured. Yo

are recommended to configure security settings before using wireless LAN

The Company assumes no responsibility for leakage of data or information that may occur during Bluetooth®/wireless LAN (Wi-Fi®) communication.

Since Bluetooth® and wireless LAN (Wi-Fi®) functions use the same frequency

interference resulting in decreased communication speed or disconnection

band, using the both functions at the same may cause radio wave

Wireless LAN (Wi-Fi®) has the advantage that it can be freely connected

ompliant with the Bluetooth® and wireless LAN (Wi-Fi®) standard

elocate this product or stop operation of the device (stop the emission of

require a license to use, such as factory production lines, specific small power

addition to home electrical appliances such as microwave ovens, devices for

. Before using this product, make sure that "other wireless stations" are not in

water with bath salts in it. Also, do not use the product under

2.4 GHz frequency band precautions

ndustrial, scientific and medical devices.

shop or Customer Service Center.

(Wi-Fi®) at your decision and responsibility.

adio waves).

product with your hands. Do not use a brush or sponge.

Do not wash the product in a washing machine or ultrasound bath.

Avoid spraying the product with high-pressure water, as the product is not

must be collected to au shop etc. and charges will be incurred. And you

Fully charged (soon after completion of charging)

Empty (the product does not turn on)

In high-temperature and humidity

aining in microphone or speake

■ Notes on various usage scenes

10 cm from the faucet or showerhead.

usage condition, etc.

vour hands are wet.

water pressure.

etc. other than tap water.

sistant to high temperatures.

so may cause a fault.

taking a shower.

canacity to drop and shorten the available battery usage time. This will also

shorten the internal battery's service life. Try to use the product as far as

• Use in very hot or cold environments, for example, when left in an

operation of the touch panel.

possible at room temperature.

no use. Charge before using.

■ Internal battery

 Internal batteries sometimes swell up as they approach the end of their service life. This is due to the properties of lithium-ion batteries, and is not a problem in terms of safety.

Charging equipment

 When not using the specified charging equipment (sold separately), remove the plug from the power outlet

 Do not wrap the cord of the specified charging equipment (sold separa around the adapter itself. Failure to do so might cause electric shock, overheating fire fault or injury

 Do not forcibly bend the charging equipment's plug or the connection between the connector and cable. Doing so might cause electric shock, overheating, fire, fault or injury. au Micro IC Card (LTF)

● The au Micro IC Card (LTE) is lent to you by au. In case of loss or damage, the card will be replaced at your expense. When a malfunction is suspected, or in case of theft or loss, contact an au shop or PiPit.

Do not forcibly remove or insert the au Micro IC Card (LTE). Be careful not to exert excessive force when inserting the card into your au device. You are responsible for any damage caused by inserting your au Micro IC Card (LTE) into some other IC card reader/writer, etc.

Keep the IC (metal) part of your au Micro IC Card (LTE) clean. Clean the

product with a soft dry cloth (such as the type used for eyeglasses) Do not put stickers, etc. on the au Micro IC Card (LTE)

Do not insert a card other than au Micro IC Card (LTE) into the product. You

cannot use the product with a card other than au Micro IC Card (LTE). Do not insert an au Nano IC Card (LTE) with a conversion adapter. Doing so

may cause a fault.

 Extreme changes in temperature cause condensation. Wait until the main unit eaches room temperature before you bring the product from a cold place

temperature for a while until the condensation is cleared. Do not splash the product with hot water. The product is not resistant to high

If condensation occurs inside the display leave the product at room.

 Do not bring the desktop holder into a bathroom Use within an ambient temperature range of 5 °C to 40 °C (temporary use at 36 °C to 40 °C in bathroom etc. allowed) and humidity range of 35% to 90%

orary use at 86% to 90% in bathroom etc. allow In the kitchen: You can use the product in the kitchen and other places where

water is used. Do not splash the product with or immerse it in soap water, detergent water, seasonings, juices, etc. other than tap water.

 Do not immerse the product in or splash it with boiling water. The product is ot resistant to high temperatures

 Do not place the product where it gets extremely hot or cold such as near a stove or in a refrigerator.

On the poolside Do not immerse the product in or splash it with pool water

· Do not use the product underwater. Doing so may cause a fault. When the product gets pool water, wash the product under a mild flow (less

than 6 liters per minute) of tap water at room temperature (5 $^{\circ}$ C to 35 $^{\circ}$ C). When washing the product, make sure to hold the microUSB connection

terminal cover, microSD memory card/au Micro IC Card (LTE) slot cover so that they do not open. Wash the product with your hands. Do not use a brush

■ Common precautions

vireless I AN (Wi-Fi®) functions

■ Bluetooth[®] function: 2.4FH1/XX8

Wireless LAN (Wi-Fi®) function: 2.4DS/OF4

of mobile unit identification devices can be avoided

vailable channels differ depending on the country.

in the 2.4 GHz band.

microUSB connection terminal covers, microSD memory card/au Micro IC Card (LTE) slot cover

Make sure that the microUSB connection terminal cover, microSD memory card/au Micro IC Card (LTE) slot cover are firmly closed. Just a small particle (a hair, etc.) on the seals can cause water leak or dust penetration. Do not open/close the microUSB connection terminal cover microSD memory card/au Micro IC Card (LTE) slot cover with gloved hands. Just a small particle (a hair, etc.) on the seals can cause water leak or dust penetration.

from the network. If connection fails, stop using either of the Bluetooth® and

Bluetooth® and wireless LAN (Wi-Fi®) functions of this product use frequencies

2.4FH1/XX8/DS4/0F4

This product uses the 2.4 GHz band. FH1 uses FH-SS as the modulation

scheme. The interference distance is about 10 m or less. XX8 uses another

This product uses the 2.4 GHz band. DS-SS and OFDM are used as the modulation schemes. The interference distance is about 40 m or less.

This means that all bandwidths of 2.4 GHz band can be used, and that band

ce distance is about 80 m or less.

If any liquid other than plain water gets on the product

24)

and lost profits.

audible sound is recorded.

might be discolored or burnt

Music, videos, TV and Radio

pedestrian crossings.

many people around you.

If any liquid other than plain water (e.g. seawater, detergent, alcohol, juices) gets on the product, immediately rinse it with plain water. You can wash the product under a mild flow (less than 6 liters per minute) of tap water at room temperature (5°C to 35°C) at a distance of about 10 cm from the faucet or showerhead. If the product gets dirty, wash it with your hands holding the microUSB connection terminal cover, microSD memory card/au Micro IC Card (LTE) slot cover so that they do not open. Do not use a brush or sponge. After the product gets wet

Wipe off any minuscule droplets of water or dirt with a clean dry cloth before

If the microUSB connection terminal cover, microSD memory card/au Micro

IC Card (LTF) slot cover is deteriorated or damaged, the waterproof/dustproof

perty becomes ineffective. In such case, contact an au shop near you

covery of altered or lost data, damages resulting from altered or lost data,

When photographing important occasions (such as a wedding), take a trial shot and check the shot image to make sure it is correctly shot and the

Do not leave the camera lens exposed to direct sunlight. Imaging elements

bothol lister to mission of water videos, ry, etc. white univing a car of motorbike, or riding a bicycle. Use of the product while driving a car or motorbike is prohibited by law. (Use of the product while riding a bicycle

may also be punishable by law.) In addition, stay alert to the traffic around

you even when walking. Surrounding sounds may not be heard clearly, and gazing at the screen might distract your attention causing a traffic

accident. Be especially careful at railroad crossings, station platform and

● Take care not to listen at ear-splitting volume for a long time, as it might

Be careful of sound leakage from earphones in trains or other places with

■ Do not use the camera for recording commercially available books or

● Do not listen to music or watch videos,TV, etc. while driving a car or

nation of which photographing is not allowed.

After the product gets wet.

After the product gets wet, drain water, and wipe the main unit with a clean dry cloth. In cold climates, water on the main unit may turn to frost. Using the product with frost may cause a fault. Do not leave the product without wiping off the water (No special measures against condensation have beer implemented in this product).

Do not leave the product without wiping off water. Water may get in the headset connection terminal, power key or volume key parts. If that happens, remove the water by shaking the product (Check your surroundings and be careful not to drop the product). Wipe off the remaining water quickly with a clean dry cloth. Note that your clothes or bag may get wet by water that is not removed or collects in the groove.

Rubber seals

The rubber seals on the inner edges of the microUSB connection terminal cover, microSD memory card/au Micro IC Card (LTF) slot cover are important to maintain waterproof/dustproof property. Do not damage or remove the rubber seals.

When closing the microUSB connection terminal cover, microSD memory card/au Micro IC Card (LTE) slot cover, take care not to get the rubber seals caught. Forcibly closing the cover with the rubber seals caught may damage them resulting in loss of waterproof/dustproof property. Just a small particle (a hair, etc.) on the seals can cause water leak or dust pe If any liquid other than plain water (e.g. alcohol) gets on the rubber seals, it may cause deterioration in durability.

© To browse homepages, download applications, communicate using applications, send/receive e-mails and configure various settings, connection to the Internet is required, to which packet communication

charge applies. * Packet communication charge does not apply to wireless LAN (Wi-Fi®).

Notes on applications

O Be sure to check the security of the application, then install it at your own risk Some applications might cause virus infection, damage various data, and ation, usage history or personal information stored in the product via the Internet. The Company assumes no responsibility for any failures that might be

caused by applications you have installed. Repair costs in this case may be charged even during the warranty period. The Company assumes no responsibility for any disadvantage brought to you or any third party by the applications you have installed.

O Insertion of a microSD memory card is necessary to use some applications

 Some applications prohibit the product from entering sleep mode while they are active, or rapidly drain the battery while running in the background.

O Operational procedures and screen appearances of the applications preinstalled in this product and those installed by you are subject to change without notice as a result of version upgrade. In addition, operating procedures described in "Instruction Manual" may differ from the actual

regulations and international guidelines regarding exposure to radio waves. This data communication device has been designed in observance of the sposure to radio waves recommended by equivalent international guidelines

Security code

Example of To do various inquiries, applications, and modifications on the au • You are not allowed to copy, distribute, publish, modify or edit the data you shot, recorded or downloaded using this product without consent of the copyright holder, except for personal use, under the copyright law. In nitial value. A four digit number chosen by the customer and noted on the addition, do not use or modify portraits or names of other individuals without the consent, as it might infringe on rights of portrait. Note that

Setting screen lock

Example of To set and release the screen lock Be careful about the copyright and portrait right when posting photos you Initial value Swipe

PIN code

Example of To prevent unauthorized use of the au Micro IC Card (LTE) by third parties

PIN code

■ PIN code

■ PUK code

26

rized use of the au Micro IC Card (LTE) by a third party, you can set the product to require PIN code entry each time the power is turned or If the PIN code is incorrectly entered three times consecutively, the PIN code will be locked. You can unlock the PIN code using PUK code. Entering PIN code is not required by default state. In "Set up SIM card lock"


however, you can change the setting requiring to enter PIN code. Note that setting up SIM card lock requires entry of PIN code.

ode is set to "1234" by default state. In "Change SIM PIN", however, you can change the PIN code to any four- to eight-digit number as necessary.

PIN code is not reset by initializing the product.

In case the PIN code is locked, you can unlock it by entering the PUK code. PUK code is an eight-digit number given at the time of purchase, and is printed on the back side of the plastic card on which your au Micro IC Card (LTF) is attached.

1) Wipe off water on the product with dry cloth, etc.



(2) Hold the product firmly and shake it approximately 20 times as shown When shaking the product, check the safety around you and hold it firmly enough not to drop it



As some parts of this product are not watertight. If you use the product after it gets wet, water remaining in those parts might wet your clothes or bag, or the sound might become hard to hear. Follow the steps below to drain water

The Japanese technical regulations and international guidelines define the limits

using a unit of measurement known as the Specific Absorption Rate (SAR), which

nts the average amount of radio frequency energy absorbed by the

human. The SAR limit for data communication devices is 2.0 W/kg. The highest

anual is 1.61 W/kg. There may be slight differences in SAR levels among

The actual SAR of this data communication device while in communication, etc can be well below that indicated above. This is due to automatic changes in the

general, the closer you are to a base station, the lower the power output of the data

You can hold the product at least 1.0 cm away from your body and also do not

contain metal parts between the product and your body while in communication

By doing this, this data communication device complies with Japanese technical

regulations and international guidelines regarding exposure to radio waves. The World Health Organization has stated that present scientific information does

not indicate that use of mobile devices has any harmful effects on the human body.

They recommend that if you are still worried about your exposure then you can limit your talk time or use a handsfree kit to keep the data communication device away

please refer to the WHO website. (http://www.who.int/docstore/peh-emf/publications/facts_press/fact_english.htm)

from your head and body. If you would like to know more detailed information.

Ministry of Internal Affairs and Communications website:

http://www.tele.soumu.go.jp/e/ele/index.htm

Association of Radio Industries and Businesses website:

http://www.arib-emf.org/index02.html (in Japanese only)

power level of the data communication device to ensure it only outputs the

ninimum power required to communicate with a base station. Therefore in

SAR value for this data communication device in normal use described in the

Copyrights and rights of portrait

shot etc on Internet homen

http://www.mpegla.com

■ Backup content on the product

Available Security Codes

causing water leak or dust penetration

The product does not float on water.

Charging

Shock

Waterproof property

25

32

electricity or a fault, repair, mishandling, etc.

e product has various security codes that you can use

shooting and recording may be restricted at some live performances shows and exhibitions even for personal use.

● This product is licensed based on MPEG-4 and AVC patent portfolio

(hereinafter referred to as MPEG-4 and AVC Video)

license with MPEG LA. LLC. The use is allowed for personal and nonprofit

Playing MPEG-4 and AVC Videos recorded personally by consumers not engaged in profit activities

Playing MPEG-4 and AVC Video supplied from the provider licensed from

MPEG-LA, LLC. For further utilizing, please contact MPEG LA, LLC in

Please back up important content recorded or downloaded for the product

How to make backups: Store important data such as contacts data.

there are some data that cannot be copied by using these means.

metimes disappears or is altered by unexpected factors, such as static

music, shot photos and videos on microSD memory cards. You can also send files as mail attachment or transfer to your PC. Note, however, that

e available security codes are as follows. Do not forget the various security

codes that are set as they are necessary for various operations and contracts

Do not insert sharp objects into grooves around the microLISB connection

Do not linear stalp objects into growes around internitorous confections terminal cover, microSD memory card/au Micro IC Card (LTE) slot cover. Doing so might damage or deform the product or damage the rubber seals,

It is recommended to replace the parts for maintaining waterproof/dustproof

present. For information on part replacement, contact an au shop near you.

property once every two years regardless of whether any abnormality is

Never charge the battery if the product is wet. The supplied and optional

Do not use the product in places where it may be sprayed with high-pressure

water (e.g. near a faucet or showerhead) or submerge it in water for extended periods of time, as the product is not designed to withstand high water

pressure. Also, do not expose the product to a water flow stronger than the specified flow rate (i.e. 6 liters per minute from a faucet or showerhead, at

which you might even feel pain in the skin). Doing so might cause a fault, even

though the product has a waterproof property equivalent to IPX5. Do not wash the product in a washing machine or ultrasound bath.

Do not use the product in places where boiling water may splash on it, in

saunas or near hot air (e.g. hairdryer). The product is not resistant to high

deform the main unit causing water leak or dust penetration

■ Draining water after wetting the product

individual products, but they all satisfy the limit.

communication device.

information regarding SAR.

to an outside source. Content recorded to memory on the product

use only in the cases below.
• Recording videos that conform to MPEG-4 and AVC Visual Standard

safety margin designed to assure the safety of all persons, regardless of age and Technical regulations are defined by the Ministerial Ordinance Related to Radio Law (Article 14-2 of Radio Equipment Regulations).

> product or "取扱説明書 (詳細版) (Full Instruction Manual)" (Japanese) product of ஆத்திற்து (சின்றி) (பாரியாள் (புவரியாரி) (Japane: available on the au homepage for the followings. • Radio Wave Exposure and Specific Absorption Rate (SAR) Information

Badio Frequency (BF) exposure and Specific Absorption Bate (SAR)

 Guidelines for Safe and Efficient Use • FCC Statement for the USA

Declaration of Conformity for SOT21

Exchange and Foreign Trade Act and other related laws and regulations in

may be applicable. In cases of exporting or reexporting the products and accessories, customers

are requested to follow the necessary procedures at their own responsibility

Department of Commerce of the United States for details about procedures.

The products and accessories may be subject to the application of the Foreign

Please refer to the websites listed below if you would like to know more detailed





This product is not resistant to shock. Do not drop the product or subject it to shock. Also, do not jab the microphone, speaker or headset connection terminal etc. with a cotton swah or any sharp object. Doing so might damage

Refer to the "Instruction Manual" (Japanese) application installed on the

http://www.au.kddi.com/support/mobile/quide/manual/

Foreign Exchange and Foreign Trade Act

In addition, the Export Administration Regulations (EAR) of the United States

Please contact the Ministry of Economy, Trade and Industry of Japan or the

pration of the touch panel Insert only a microSD memory card into the microSD memory card slot on

• Do not operate the touch panel with fingernails. Doing so might result in

split nails or jammed fingers.

peep prevention sheets) on the display. Doing so might hinder correct vironment and effectively use resources, au shops and other reta collect used batteries.

 Do not discard batteries with regular trash. Please cooperate in the collection of hatteries nacks when it is no longer needed to protect the When using the camera, follow common rules of etiquette regarding camera use. Image data might be altered or lost due to malfunction, repair or mishandling of the product. The Company takes no responsibility for

. For use in an airplane, check with the airline company in advance. 5 GHz frequency band precautions

J52 W52 W53 W56

Non-Ionizing Radiation Protection (ICNIRP), which is in collaboration with the

Japanese technical regulations regarding exposure to radio waves* and limits to

World Health Organization (WHO), and the permissible limits include a substantia

33

may be performed automatically by some applications,

resulting in high packet communication charges. Therefore, subscription to a packet communication charge discount service or flat late plan is 39

Wireless LAN (Wi-Fi®) function of this product uses 5 GHz band. Using the 5.2 GHz band and 5.3 GHz band outdoors is prohibited by the Radio Law. The channels used on the product are as follows. procedures. W52 (5.2 GHz band/36, 40, 44, 48 ch) IEEE802.11b/g/n W53 (5.3 GHz band/52, 56, 60, 64 ch) W56 (5.6 GHz band/100, 104, 108, 112, 116, 120, Specific Absorption Rate (SAR) 124, 128, 132, 136, 140 ch) This model SOT21 data communication device complies with Japanese technical

Notes on packet communication charge

O Since a constant Internet connection is possible with this product, packet

http://www.au.kddi.com/ ○ Sony Mobile Communications Inc. website: http://www.sonymobile.co.jp/support/ (in Japanese only)

40

Intellectual property rights













- Bluetooth® is a registered trademark owned by the Bluetooth SIG, Inc., and Sony Mobile Communications is licensed to use this trademark.
- "Wi-Fi[®]" is a registered trademark of Wi-Fi Alliance[®].
- Wi-Fi Protected Setup™, Wi-Fi Protected Setup logo, WPA, Wi-Fi Direct™ and
- Wi-Fi CERTIFIED Miracast™ are trademarks of Wi-Fi Alliance®.

- When CENTIFED Miladast: "are traderliars of with Alliantes".

 Xperia, TrackID, Socialife and Xperia Lounge are trademarks or registered trademarks of Sony Mobile Communications AB.

 Sony, Sweep Panorama, Smile shutter, Premium Omakase Auto, Face Detection, WALKMAN, X-Reality, PlayMemories, TRILUMINOS, STAMINA, Reader, Sony Entertainment Network, TV SideView and Video Unlimited are
- trademarks or registered trademarks of Sony Corporation. POBox and POBox logo are registered trademarks of Sony Computer Science Laboratories, Inc.
- POBox is a co-developed technology of Sony Computer Science
 Laboratories, Inc. and Sony Mobile Communications Inc.

 PlayStation, and "DUALSHOCK" are trademarks or registered trademarks
- The microSD logo, microSDHC logo and microSDXC logo are trademarks of SD-3C, LLC.
- "Twitter" is a trademark or registered trademark of Twitter. Inc.
- Twitter is a trademark or registered trademark of lwitter, inc.
 Google and Google logo, Android, Google Play, Google+, Gmail, Google Maps, Hangouts, Google Calendar, YouTube and Google Chrome are trademarks or registered trademarks of Google, Inc.
 Facebook and Facebook logo are trademarks or registered trademarks of Facebook, Inc.
- "DLNA" and "DLNA" logo are trademarks or registered trademarks of Digital Living Network Alliance.

- MHL, Mobile High-Definition Link and MHL Logo are trademarks or registered The software installed on this product or part of it may not be altered, trademarks of MHLLLC. HDMI, HDMI logo and High-Definition Multimedia Interface are trademarks or
- registered trademarks of HDMI Licensing LLC. MirrorLink and MirrorLink logo are trademarks or registered trademarks of Car Connectivity Consortium LLC. "Microsoft Excel", "Windows Vista", "Microsoft Excel", "Windows Media", and "Microsoft Exchange ActiveSync" are trademarks or registered

trademarks of Microsoft Corporation in the United States and/or other

This product contains technology subject to certain intellectual property rights of Microsoft. Use or distribution of this technology outside of this

OR code is a registered trademark of Denso Wave Inc.

Ni is a registered trademark of Denso Wave Inc.

Ni is a registered trademark of trademark of NFC Forum, Inc. in the United

video") or the AVC standard ("AVC video") and/or (ii) decoding MPEG-4 or AVC video that was encoded by a consumer engaged in a personal and non-commercial activity and/or was obtained from a video provider licensed by

product is prohibited without the appropriate license(s) from Microsoft.

Linux is a registered trademark of Linus Torvalds, individual.

Rovi, G-GUIDE, G-GUIDE MOBILE and G-Guide related logos are trademarks or registered trademarks of Rovi Corporation and/or its

TRENDMICRO, VirusBuster are trademarks of Trend Micro Inc.

 Copyright © 2010 - Three Laws of Mobility. All Rights Reserved. The product includes pictograms that are licensed by NTT DOCOMO, INC. This product is licensed under the MPEG-4 visual and AVC patent portfolio license for the personal and non-commercial use of a consumer for (i) encoding video in compliance with the MPEG-4 visual standard ("MPEG-4")

"Microsoft Word" is a trade name of Microsoft Corporation

States and/or other countries.

• "jibe" is a trademark of Jibe Mobile K.K.

subsidiaries in Japan.

42

 All other company names and product names are trademarks or registered. An other company familes and product names are trademarks or registered trademarks of respective companies referred to in this manual. In context, TM and @ mark may be omitted.

translated/adapted, reverse-engineered, decompiled or reverse-assembled and any such actions are prohibited.

44

- Any rights not expressly granted herein are reserved. All other trademarks are property of their respective owners.

MPEG LA to provide MPEG-4 and/or AVC video. No license is granted or shall be implied for any other use. Additional information including that relating to promotional, internal and commercial uses and licensing may be obtained MPEG LA, LLC. ("See http://www.mpegla.com"). MPEG Layer-3 audio decoding technology licensed from Fraunhofer IIS and Thomson.

43

For inquiries, call: Customer Service Center

For general information, charges and operation information (toll free) Business hours 9:00-20:00 (7 days a week)

From fixed-line phones: From au cell phones

0077-7-111 | 157 without area code

PRESSING ZERO WILL CONNECT YOU TO AN OPERATOR AFTER CALLING 157 ON YOUR au CELL PHONE

For loss or theft (toll free)

From fixed-line phones: From au cell phones:

0077-7-113 | 113 without area code

In case above numbers are not available (toll free). 0120-977-033 (except Okinawa)

6 0120-977-699 (Okinawa)

Keitai Guarantee Service Center

For loss, theft, damage.

Business hours 9:00-21:00 (7 days a week

0120-925-919 (toll-free)

Sold by: KDDI CORPORATION, OKINAWA CELLULAR TELEPHONE COMPANY Manufactured by: Sony Mobile Commu