

**When using the product**

- Before you start using the product, make sure to read the "Safety Precautions" to ensure correct use.
- Before you assume that the product is malfunctioning, check for possible remedies in the following au Customer Support site of au homepage: <http://www.au.kddi.com/support/mobile/trouble/repair>
- Communication is not possible even inside the service area in places where the signal does not reach (e.g. tunnels and basements). Also, communication is sometimes not possible in poor reception areas. Communication is sometimes interrupted if you move into a poor reception areas during communications.
- Since this product uses radio waves, the possibility of communication intercepts by third parties cannot be eliminated (Though LTE/M/MAX 2+/GSM/UMTS system has highly secure confidential communication features).
- For connecting to an emergency office, au VoLTE (LTE network) is used. 3G (Line exchange network) connection is not available.
- This product is compatible with the international roaming service. Each network service described in the manual varies depending on the area and service content. For details, refer to the "Instruction Manual" (Japanese) app installed on the product or "取扱説明書 (詳細版) (Full Instruction Manual)" (Japanese) available on the au homepage.
- Since this product is a radio station under the Radio Law, you may be asked to temporarily submit the product for inspection in accordance with the Radio Law.
- The IMEI information of your cell phone is automatically sent to KDDI CORPORATION for maintenance and monitoring operational status of your cell phone.
- Before you start using the product overseas, check the relevant laws and regulations of the country/region you visit.
- The Company is not liable for any damages arising from earthquakes, lightning, storms, floods or other natural disasters, as well as fires, actions by third parties, other accidents, intentional or mistaken misoperation by the customer, or use under other unusual conditions outside the responsibility of the Company.
- The Company is not liable for any incidental damages (change/disappearance of described content, loss of business income, disruption of business, etc.) arising from use of or inability to use the product.

- Company names and product names referred to in this manual are generally trademarks or registered trademarks of respective companies. The TM, ® marks may be omitted in this manual.

- In this manual, "Setting Guide", "Basic Manual", "取扱説明書 (詳細版) (Full Instruction Manual)" (Japanese), "Cautions on using Xperia™ Z5" are collectively referred to as "Instruction Manual".
- In this manual, "microSD™ memory card", "microSDHC™ memory card" and "microSDXC™ memory card" are abbreviated as "microSD memory card" or "microSD".
- In this manual, "Xperia™ Z5" is usually referred to as "the product".

October 2015, 1st Edition 1299-0027.1

	Never connect the microUSB plug to the product or charging equipment when it is wet. Although this product model has the waterproof property, inserting microUSB plug to the product when it is wet might cause electric shock or short circuit due to the moisture or foreign substance on the product or microUSB plug, or might cause abnormal overheating, fire damage, fire, burns, or a fault if corrosion occurs.	<b>1</b>
	Although this product model has waterproof property, stop use if liquid such as water gets inside the main unit from the headset connection terminal, microUSB connection terminal, microSD memory card/au Nano IC Card 04 slot. Continued use of the product in this state might cause overheating, ignition or a fault.	
	Do not use the product while driving an automobile or motorized bicycle, riding a bicycle or walking. Failure to do so might cause a traffic accident, or falling down/overturn. Use of a cell phone while driving a car or motorbike is prohibited by law. Use of a cell phone while riding a bicycle may be punishable by some regulations.	
	If charging is not completed after the specified charging time, stop charging. Failure to do so might cause leakage of liquid, overheating, rupture or fire.	
	Do not leave in places within the reach of small children. Small children might swallow small parts, etc. by mistake and choke on them, or might drop them by mistake and cause accidents or injury.	
	Do not cover or wrap the product with bedding, etc. while using or charging the product. Doing so might cause fire, fault or injury.	
	When using a charging equipment or external device, insert/remove the connector straight toward the terminal. Make sure the orientation of the connector is correct. Unless it's correct, it may cause overheating, ignition, damage or a fault.	
	<b>Caution</b> Be sure to read the following cautions before use.	
	Do not expose the camera lens to direct sunlight for an extended period. Doing so might cause ignition, rupture, fire or damage by the light-collecting mechanism of the lens.	<b>7</b>

-  Wipe off dust on the power plug. Failure to do so might cause fire, burns or electric shock.

-  Remove the power plug of the specified AC adapter (sold separately) from the outlet or cigarette lighter socket when not using the adapter for an extended period. Failure to do so might cause fire or a fault.

-  Charging equipment is not waterproof. Do not use in places subject to direct splashing with water, pet urine or other liquids. Doing so might result in faults or injury resulting from overheating, fire, electric shock, or short-circuiting of electronic circuits. In the event that the product is splashed with liquid, immediately disconnect the power plug of the specified AC adapter (sold separately).

-  When not using the specified charging equipment (sold separately), do not remain the plug connected to the power outlet or cigarette lighter socket. Also, do not wrap the cord of the specified charging equipment (sold separately) around the adapter itself. Failure to do so might cause electric shock, overheating, fire, fault or injury.

-  Do not forcibly bend the charging equipment's plug or the connection between the connector and power cord. Failure to do so might cause electric shock, overheating, fire, fault or injury.

**Caution** Be sure to read the following cautions before use.

-  Do not use in humid places such as bath areas, or connect/disconnect the specified charging equipment (sold separately) with wet hands. Doing so might cause electric shock, a fault or injury.

-  When unplugging the plug of the specified charging equipment (sold separately) from the outlet or cigarette lighter socket, hold and pull the power plug. If you pull the cable, the cable might be damaged.

-  Do not use Common DC Adapter 03 (sold separately) when the vehicle engine is turned off. Doing so might cause drain the vehicle's battery.

	Do not store the product in places subject to direct sunlight (e.g. in automobiles), places that get hot, places that get extremely cold, and in humid or dusty places. Doing so might cause overheating, deformation or a fault.	<b>2</b>
	Do not leave on unstable places such as rocky stands or tilting surfaces especially while the vibration mode set. Dropping the product may cause injury or damage. Also, pay sufficient attention to impact, etc. Doing so might cause a fault or injury.	
	The product might become hot by prolonged use or connection to external power source. Do not touch the product or the specified charging equipment (sold separately) for a long time. Doing so might cause low-temperature burns. In addition, do not cover or wrap the product with a sheet of paper, cloth or bedding. Doing so might cause fire, injury or a fault.	
	Do not use power outlets or wiring apparatus beyond its rating for charging the product. Also, exceeding rating, for example, by connecting multiple devices to a single power strip might cause overheating and fire.	
	Do not place near corrosive chemicals or in places where corrosive gas is generated. Doing so might cause a fault or loss of internal data.	
	Do not use if there is smoke, abnormal odor or noise, excessive overheating, or other abnormalities. If an abnormality occurs, disconnect the specified charging equipment (sold separately) from the power outlet, make sure that the product is not overheating before turning the power off, and contact an au shop or Keitai Guarantee Service Center. Also, if you have dropped or damaged the product, do not continue to use it in that state, and contact an au shop or Keitai Guarantee Service Center.	
	When inserting an earphone, etc. into the product, adjust the volume by raising a little at a time to the proper level. Sudden loud noise by raising the volume too much from the outset, too much volume sound, or using the earphone continuously for a long period of time might adversely affect your ears. Also, raising the volume too high might prevent you from hearing sounds around you, which might in turn lead to a traffic accident at a railroad crossing or pedestrian crossing.	
<b>8</b>		

**au Nano IC Card 04****Caution** Be sure to read the following cautions before use.

-  Be careful not to injure your hand or finger when attaching/removing the au Nano IC Card 04.

-  Do not damage the card by using the product in a hot place, dropping into fire, contacting to the metal parts with foreign object, giving an impact, bending, applying load, etc. Doing so might cause loss of data or a fault.

-  Do not store the au Nano IC Card 04 in places exposed to direct sun light, or hot or dusty places. Doing so may cause a fault.

-  Store the au Nano IC Card 04 out of reach of small children. Failure to do so might cause injury or asphyxiation, etc. if they accidentally swallow and choke on it.

**Caution** Be sure to read the following cautions before use.

-  When using the product near an implanted pacemaker, implanted cardioverter-defibrillator or other electronic medical device, radio waves might affect these units and devices. So, please observe the following.
  - Those with an implanted pacemaker or implanted cardioverter-defibrillator should carry or use the product at least 15 cm away from the implanted pacemaker or implanted cardioverter-defibrillator.
  - Set the product to "Airplane mode" or turn it off beforehand, if you may not keep distance 15 cm or more such as when you cannot move easily etc., since there may be people with an implanted cardiac pacemaker or implanted cardioverter-defibrillator nearby.
  - When a medical institution has laid down designated areas where use of the product is prohibited or is not allowed to be brought in, abide by the instructions of that medical institution.
  - When using electronic medical devices other than an implanted pacemaker and implanted cardioverter-defibrillator outside a medical institution (e.g. home medical treatment), check individually with the manufacturer of the electronic medical device regarding the influence of radio waves.

**Sony Mobile TV antenna cable 02****Warning** Be sure to read the following warnings before use.

-  Sony Mobile TV antenna cable 02 is not waterproof. Do not use in places subject to direct splashing with water, pet urine or other liquids. Doing so might result in faults resulting from overheating, fire, electric shock, or short-circuiting of electronic circuits.

**Caution** Be sure to read the following cautions before use.

-  When the product is used by a child, parents or guardians should teach the child how to use it. Do not allow them to use the equipment without adult supervision. Failure to do so might cause injury.

	When using handsfree call, take care to keep the speaker at a safe distance from your ears, as the speaker volume may be too loud.	<b>3</b>
<b>Main unit</b>		
	<b>Danger</b> Be sure to read the following hazards before use.	
	Do not puncture the product with a nail, hit with a hammer or step on the product. Doing so might cause fire or damage.	
	Do not disassemble, modify or directly solder the product. Doing so might cause spilling of the battery liquid resulting in an accident such as loss of eyesight if it gets into eyes, or cause overheating, ignition, rupture or injury.	
	Be careful not to have the product bitten by your pet. It might cause leakage of the internal battery, overheating, rupture, ignition, fire or injury.	
	<b>Warning</b> Be sure to read the following warnings before use.	
	Turn off the product or put it in Airplane mode before boarding an airplane. Use of cell phones on board is restricted. Follow the instructions of each airline. Failure to do so may adversely affect on-board electronic equipment. Prohibited acts related to cell phone usage on an airplane may be punished by law.	
	Follow the instructions of each medical facility for the use of cell phones on their premises. Power off the product in a place where the use is prohibited. Failure to do so may affect electronic equipment and electronic medical equipment.	
	When using a flash/photo light, do not lighten in front of a person, person who drives an automobile, motorized bicycle, bicycle, etc. Also, while a flash/photo light is turning on, do not look at lighting part directly. Doing so might cause disabilities such as decreased vision, etc. Especially, do not shoot small children at close range.	<b>9</b>

**Using near medical equipment or in healthcare facilities****Warning** Be sure to read the following warnings before use.

-  When using the product near an implanted pacemaker, implanted cardioverter-defibrillator or other electronic medical device, radio waves might affect these units and devices. So, please observe the following.
  - Those with an implanted pacemaker or implanted cardioverter-defibrillator should carry or use the product at least 15 cm away from the implanted pacemaker or implanted cardioverter-defibrillator.
  - Set the product to "Airplane mode" or turn it off beforehand, if you may not keep distance 15 cm or more such as when you cannot move easily etc., since there may be people with an implanted cardiac pacemaker or implanted cardioverter-defibrillator nearby.
  - When a medical institution has laid down designated areas where use of the product is prohibited or is not allowed to be brought in, abide by the instructions of that medical institution.
  - When using electronic medical devices other than an implanted pacemaker and implanted cardioverter-defibrillator outside a medical institution (e.g. home medical treatment), check individually with the manufacturer of the electronic medical device regarding the influence of radio waves.

**Sony Mobile TV antenna cable 02****Warning** Be sure to read the following warnings before use.

-  Sony Mobile TV antenna cable 02 is not waterproof. Do not use in places subject to direct splashing with water, pet urine or other liquids. Doing so might result in faults resulting from overheating, fire, electric shock, or short-circuiting of electronic circuits.

**Caution** Be sure to read the following cautions before use.

-  When the product is used by a child, parents or guardians should teach the child how to use it. Do not allow them to use the equipment without adult supervision. Failure to do so might cause injury.

- Notice**
  - Reproduction of the content of "Instruction Manual" in part or in whole is prohibited.
  - The content of "Instruction Manual" is subject to change without notice.
  - Every effort has been made in the preparation of "Instruction Manual". Should you notice any unclear points, omissions, etc., feel free to contact us.

**Cell Phone Etiquette**

- Use of the product is not allowed in the following places!
  - Do not listen to music or watch videos, TV, etc. while driving a car or motorbike, or riding a bicycle. Use of cell phones while driving a car or motorbike is prohibited by law. (Use of cell phones while riding a bicycle may also be punishable by law.) In addition, stay alert to the traffic around you even when walking. Surrounding sounds may not be heard clearly, and gazing at the screen might distract your attention causing a traffic accident.
- These instructions are divided into the following categories.
  - Explanation of indications used in this manual**
-  **Danger** This symbol indicates the potential and imminent danger of death or serious injury<sup>1</sup> to a person from improper use.
-  **Warning** This symbol indicates the possibility of death or serious injury<sup>2</sup> to a person from improper use.
-  **Caution** This symbol indicates the possibility of minor injury<sup>2</sup> to a person or physical damage<sup>3</sup> from improper use.

<sup>1</sup> Serious injury: This refers to loss of sight, injury, burns (high- and low-temperature), electric shock, broken bones, injuries with residual aftereffects from poisoning, etc., and injuries requiring hospital admission for treatment or long-term hospital attendance as an outpatient.

<sup>2</sup> Minor injury: This refers to injuries, burns (high- and low-temperature), electric shock, etc. that do not require hospital admission for treatment or long-term hospital attendance as an outpatient.

<sup>3</sup> Physical damage: This refers to extended damage to buildings, furniture, livestock, or pets.

-  Sometimes, very rarely some people demonstrate symptoms such as temporary muscle spasms, loss of consciousness, etc. by watching repeatedly flickering screens. Those with a past history of this should consult with a physician beforehand.

**Caution** Be sure to read the following cautions before use.

-  Use of the main unit in an automobile might sometimes affect on-vehicle electronic devices, though this rarely happens. If this happens, stop use since this may impair safe travel.

-  If you feel any abnormality with your skin, immediately consult a dermatologist. Itching, rashes, eczema, etc. sometimes occurs depending on your physical constitution and condition. The materials of parts used on the product are as follows.

Part	Material	Surface treatment
Exterior case (top, bottom and side panels, microSD memory card/au Nano IC Card 04 slot cover), Volume key, Camera key	Aluminum alloy	Anodic oxide coating
Exterior case (4 corners)	Polycarbonate resin	Coating
Exterior case (frame)	Nylon resin (with glass)	— (Graphite Black, Gold, Green) Coating (White)
Exterior case (strap hole, headset connection terminal, microUSB connection terminal)	Nylon resin (with glass)	—
Transparent plate (display)	Hardened glass	AFP coating
Transparent plate (rear panel)	Hardened glass	AR coating + AFP coating
Transparent plate (Flash/Photo light)	Acrylic resin	—
Power key	Epoxy resin	Coating

 If you feel any abnormality with your skin, immediately consult a dermatologist. Itching, rashes, eczema, etc. sometimes occurs depending on your physical constitution and condition. The materials of parts used on Sony Mobile TV antenna cable 02 are as follows.											
<table> <thead> <tr> <th>Part</th> <th>Material</th> <th>Surface treatment</th> </tr> </thead> <tbody> <tr> <td>Connecting plug (body), cable, headset connection terminal (body)</td> <td>Elastomer resin</td> <td>—</td> </tr> <tr> <td>Connecting plug (metal parts)</td> <td>Brass</td> <td>Gold plating</td> </tr> </tbody> </table>	Part	Material	Surface treatment	Connecting plug (body), cable, headset connection terminal (body)	Elastomer resin	—	Connecting plug (metal parts)	Brass	Gold plating		
Part	Material	Surface treatment									
Connecting plug (body), cable, headset connection terminal (body)	Elastomer resin	—									
Connecting plug (metal parts)	Brass	Gold plating									

**Handling precautions**

These precautions are provided to prevent the product from damage and ensure that performance can be fully demonstrated. Thoroughly read these precautions to ensure correct use.

- Precautions common to the main unit, internal battery, charging equipment, au Nano IC Card 04, peripheral devices**

- Do not apply excessive force to the product during use. Be sure not to put the product into a tightly packed bag or place a heavy object on the product in a bag. Sitting on the product in your pocket might damage the display or internal circuit board resulting in a malfunction. Keeping an external device connected to the headset connection terminal or microUSB connection terminal might damage the connector resulting in a malfunction. Such damage and malfunction are not covered by the warranty, even if there is no external damage.

- To ensure waterproof property (equivalent to IPX5 and IPX8) of this product, use the product with the microSD memory card/au Nano IC Card 04 slot cover tightly closed. Note that the waterproof property is not guaranteed in every usage condition. Do not allow water to get inside the product or splash water on charging equipment or optional accessories. Do not attach/remove the microSD memory card or au Nano IC Card 04 in the rain or with waterdrops on the surface of the product. Doing so might cause water intrusion resulting in internal corrosion. Malfunctions determined to be caused by water are not covered by the warranty.

- There may be a person with a cardiac pacemaker nearby at a place filled with people such as in a crowded train. Set "Airplane mode" or turn off beforehand.
- When a medical institution has laid down designated areas where use of the product is prohibited or is not allowed to be brought in, abide by the instructions of that medical institution.

**Safety Precautions (Observe Strictly)**

- Before using this product, thoroughly read these safety precautions for proper use. After reading, store the precautions in a safe place.
- These "Safety Precautions" describe instructions that should be observed to prevent damage to property or injury to the customer or others using the product.
- When the product is used by a child, parents or guardians should thoroughly read the "Basic Manual" and "Cautions on using Xperia™ Z5" (this manual) and teach the child how to use it.
- These instructions are divided into the following categories.

**Explanation of indications used in this manual**

	<b>Danger</b> This symbol indicates the potential and imminent danger of death or serious injury <sup>1</sup> to a person from improper use.
	<b>Warning</b> This symbol indicates the possibility of death or serious injury <sup>2</sup> to a person from improper use.
	<b>Caution</b> This symbol indicates the possibility of minor injury <sup>2</sup> to a person or physical damage <sup>3</sup> from improper use.

<sup>1</sup> Serious injury: This refers to loss of sight, injury, burns (high- and low-temperature), electric shock, broken bones, injuries with residual aftereffects from poisoning, etc., and injuries requiring hospital admission for treatment or long-term hospital attendance as an outpatient.

<sup>2</sup> Minor injury: This refers to injuries, burns (high- and low-temperature), electric shock, etc. that do not require hospital admission for treatment or long-term hospital attendance as an outpatient.

<sup>3</sup> Physical damage: This refers to extended damage to buildings, furniture, livestock, or pets.

	Do not bring the product close to magnetized objects such as cash cards, floppy disks, credit cards, and prepaid cards. Doing so might result in loss of recorded information.	<b>4</b>
	The product may get warm. Do not touch the warm part for a long time. Doing so might cause low-temperature burns.	
	Do not allow liquids, metal objects, burnable items, and other foreign matter to get inside the headset connection terminal, microUSB connection terminal, or microSD memory card/au Nano IC Card 04 slot. Doing so might cause fire, electric shock, a fault or injury.	
	Do not swing the product around by holding Sony mobile TV antenna cable 02, the hand strap, etc. Doing so might cause an accident or damage.	
	Use the product with the covers of the microSD memory card slot or au Nano IC Card 04 slot cover etc. closed. If the covers are open, dirt or water may get inside causing a fault.	
	If you have a weak heart, be careful when setting the incoming vibration and ringtone volume to prevent adverse effects on your heart.	
	Pay attention to items becoming stuck to the main unit. The earpiece/speaker and microphone use magnets, and so thumbtacks and pins, craft knife blades, staples, and other metal objects sometimes become stuck to the main unit, and cause unexpected injury. Before using the product, be sure to check that there are no foreign objects on the earpiece/speaker, microphone/speaker or other parts.	
	Do not put the product directly on the sand at a beach, etc. Sand or other small particles might get inside the earpiece/speaker, microphone/speaker, second microphone, etc. causing the volume to drop. If sand gets inside the product's main unit, it might cause overheating or a fault.	
	When the still image shooting screen is displayed continuously for a long time, video shooting screen or TV is operated for a long time, or video call function is used continuously, part of the main unit may get warm. Do not touch the part for a long time. Doing might cause low-temperature burns.	<b>11</b>

- Do not use the product in extremely hot, cold or humid places. (Use within an ambient temperature range of 5°C to 35°C and humidity range of 35% to 85%.)
  - Charging equipment
  - Peripheral devices

- Do not use the product in extremely hot, cold or humid places. (Use within an ambient temperature range of 5°C to 35°C and humidity range of 35% to 85%. Temporary use within an ambient temperature range of 36°C to 40°C and humidity range of 86% to 90% is allowed)
  - Xperia™ Z5 main unit
  - au Nano IC Card 04 (attached to Xperia™ Z5 main unit)
- Do not use in places subject to lots of dust or vibration. Doing so might cause a fault.

- Clean the headset connection terminal and microUSB connection terminal with dry cotton swabs, etc. every now and then. Solid terminals might cause poor connection. Do not exert a strong force to clean the headset connection terminal or microUSB connection terminal to prevent deformation.

- Clean the product with a soft dry cloth (such as the type used for eyeglasses). Forceful rubbing with a dry cloth may scratch the display. The display may be stained if splash or smear is left attached to the surface. Wiping the product using alcohol, thinner, benzine, detergent, etc. might erase the printing on the outer casing or cause discoloration.

- Use as far away as possible from land-line phones, TVs and radios. Use nearby might affect them.

- This product may become warm while talking, watching TV, charging or during other operations, depending on the situation, but this is not abnormal.

**Main unit**

- If the product becomes high temperature, the display may become dim. This is normal.
- Do not forcefully press, tap or intentionally subject the display to strong impact. Doing so might cause scratching or damage.

**Explanation of graphic symbols used in this manual**

	Indicates an action that is not allowed.		Indicates that use in a place where the product is likely to get wet or allowing the product to get wet is not allowed.
	Indicates that handling with wet hands is not allowed.		Indicates an action that must be done.
	Indicates that disassembly is not allowed.		Indicates that the power plug must be disconnected from the power outlet.

**Precautions common to the main unit, internal battery, charging equipment, au Nano IC Card 04, peripheral devices****Danger** Be sure to read the following hazards before use.

-  Be sure to use only the specified peripheral devices. Use of other peripheral devices might cause overheating, ignition, rupture, fault, or leakage of liquid.

-  Do not use, store or leave the product in hot places (e.g. by the fire, near a heater, under a kotatsu, in direct sunlight, in car in the hot sun). Doing so might cause ignition, rupture, fault, fire or injury.

-  Do not put the product in a cooking apparatus such as microwave oven or a pressure vessel. Doing so might cause ignition, rupture, fault, fire or injury.

-  Do not throw the product into a fire or heat it. Doing so might cause ignition, rupture or fire.

-  The customer is not allowed to disassemble, modify or repair the product. Doing so might cause a fault, ignition, electric shock, or injury. The Company is not liable even in the event of any nonconformities arising on the product or

