

E-mail setting

This is a service with which you can send/receive mails using E-mail (@ezweb.ne.jp).
To use E-mail (@ezweb.ne.jp), subscription to LTE NET is required. If you did not subscribe it when you purchased the product, contact an au shop or Customer Service Center.
Your E-mail address is determined automatically after initial setting. You can change the E-mail address later.

* For model change from an au mobile phone, E-mail address used on the previous model can be used continuously after initial settings.

Initial settings

- From the Home screen, [E-mail]
- Check the contents → [接続する (Connect)] → Confirm your E-mail address → [閉じる (Close)]
- Confirm the content → [同意する (Agree)]/[同意しない (Disagree)] → [完了 (Done)]
* When an explanation screen for Email function appears, follow the onscreen instructions.

Checking E-mail address

- From the Home screen, [E-mail information]
- Check your E-mail address

Changing E-mail address

- From the Home screen, [E-mail]
- [Change Address/Setting Filter] → Confirm the content → [接続する (Connect)]
- [Eメールアドレスの変更へ (To change E-mail address)]
- Enter the security code → [送信 (Send)] → Confirm the content → [承諾する (I agree)]
- Enter E-mail address → [送信 (Send)] → [OK]

PC-mail

You can use mail addresses except for E-mail (@ezweb.ne.jp).
To use PC-mail, set up PC-mail account. For the first time use, set up as follows.
From the Home screen, [E-mail] → [GET STARTED] → Enter Email address → [NEXT] → Enter a password → [NEXT] → Select the sync option → [NEXT] → Select the notification option → [NEXT] → Enter account name and name as sender → [FINISH SETUP]

Backing up Email

- From the Home screen, [Mail Backup]
- [Mail Backup] → [OK]
- Select character code for backup data → [OK]
* For character code, tap "Help" to check.
- Mark to back up folder → [OK]

- Mail data is saved in the internal storage (/storage/emulated/0/private/au/email/BU).
If a microSD memory card is attached, data is saved in the microSD card (/storage/XXXXXX/private/au/email/BU).
("XXXXXX" varies by microSD memory card)
- To back up mail data or E-mail settings (notification settings, filtering settings etc.) all at once, back up selecting "Whole Backup" in the step 4.

Making a call

Direct input calling

- From the Home screen, [Contacts]
- Tap a party to call
- Enter a phone number → [Call]

Calling from call log

- From the Home screen, [Recent calls]
- Tap a party to call
- Tap a phone number or [Call]

Calling overseas from au mobile phones (au International Call Service)

You can make international calls without any special procedure from the product.
On the phone number input screen → Enter an access number, country code, area code*, and the phone number of the other party → [Call]
* If the area code starts with "0", Enter it without including the "0". (There are some exceptions such as fixed-line phones in Italy or Moscow).

Receiving a call

Answering a call

- Drag [Answer]
- Start a call
- To end the call, [End]

* To reject an incoming call, drag [Decline] left on the receiving screen

Answering a call (pop-up display)

- [Accept]/[Speaker]
- Start a call
* Show/hide pop-ups with [Show/Hide]
- To end the call, [END]

Transferring data from au Settings Menu

Import or export data between the product and your previous au mobile phone using microSD memory card or au Smart Pass
● To import or export data using au Smart Pass server, set au ID.
● To import data using microSD memory card, save data to microSD memory card using your previous au mobile phone in advance.

Importing data from au Settings Menu

- From the Home screen, [Settings] → [au Settings Menu]
- [Data Transfer]
- Mark data to import, then [戻す (Import)] → [完了 (Done)]
* It is a screen for selecting "スマートフォンのデータを戻す (Import smartphone data)".
* When a confirmation screen appears, follow the onscreen instructions.
- When "SDカードから復元する (Restore from SD card)" is selected, select your previous au phone type
* Does not appear if you select "auスマートパスのサーバから戻す (Import from au Smart Pass server)" in the step 4.

When "SDカードから復元する (Restore from SD card)" is selected

- Mark data to import, then [戻す (Import)] → [完了 (Done)]
- When "auスマートパスのサーバから戻す (Import from au Smart Pass server)" is selected
Check the content → Follow the onscreen instructions → [完了 (Done)]

Saving data from au Settings Menu

- From the Home screen, [Settings] → [au Settings Menu]
- [Data Transfer]
- Mark data to save → [保存する (Save)] → [完了 (Done)]
- Mark data to export and [預ける (Export)] → Check the content → Follow the onscreen instructions → [完了 (Done)].

- Select a saving location from [データを保存する (Save data)]
* When saving from "auスマートパスのサーバに預ける (Export to au Smart Pass server)", set au ID.

When "SDカードに保存する (Save to SD card)" is selected

- When "auスマートパスのサーバに預ける (Export to au Smart Pass server)" is selected
Mark data to export and [預ける (Export)] → Check the content → Follow the onscreen instructions → [完了 (Done)].
- In "データ移行 (Data transfer)" screen, select "データをコピーする (Copy data)" in "2台の端末でデータをコピーする (Copy data to two units of devices)" to copy data to the product and the other device.
- To back up photos and contacts to au Smart Pass server automatically using "Data Storage" application, from the Home screen, [Settings] → [au Settings Menu] → [Backup Setting] → Mark items to be restored automatically

Sending contacts

You can send contacts to another phone.

- From the Home screen, [Contacts]
- Tap a contact to send
- [Share]
- Select how to send a contact → Follow the onscreen instructions
* Operation differs depending on the app you selected.

Sending several contacts

- Contact list screen → [Mark several] → Mark contacts to send
- [Share] → Select an app → Follow the onscreen instructions
* Operation differs depending on the app you selected.

Saving battery power

Use the quick setting panel or the quick setting tools to set Wi-Fi® function, Bluetooth® function, NFC function, Auto-rotate etc. Switching the settings frequently can reduce the battery power consumption.

Opening the quick setting panel

- Slide down the status bar with two fingers
- Set each item

Quick settings tools

- Brightness: Adjust screen brightness
- Wi-Fi: Wi-Fi® On/Off
- Bluetooth: Bluetooth® On/Off
- NFC: NFC On/Off
- Hotspot: Wi-Fi® hotspot On/Off
- Location: Location On/Off
- Auto-rotate: Auto rotate On/Off
- Airplane mode: Airplane mode On/Off
- Sound: Set Sound/Silent mode (Vibrate)/Silent mode (mute)
- Glove mode: Glove mode On/Off
- Flashlight: Flash/Photo light On/Off
- Cast: Display screens of the product on Google Cast device