

Setting Guide (Version for Android 6.0)

Thank you for buying the "TORQUE G02" (simply called the "product" from here on). In this guide, settings and precautions for using the product are described. For explanations of basic functions, refer to "Basic Manual" (Version for Android 6.0).

Company names and product names referred to in this manual are trademarks or registered trademarks of respective companies. The TM, ® marks may be omitted in this manual. Screen illustrations shown in this manual may look different from the actual screens. In some cases, minor details or a part of a screen may be omitted.

June 2016, 1st Edition

- Basic Operation**  
Describes the basic operations.
- Initial Settings**  
Make initial settings when you turn the power on for the first time.
- au Easy Setting**  
Sets au ID.
- E-mail**  
Make initial settings for @ezweb.ne.jp etc.
- Making a Call**  
Adds a contact as a new and makes a call.
- Receiving a Call**  
Describes how to receive a call.
- Importing/Exporting Contacts**  
Import/export contacts using a microSD or other memory card.
- Saving Battery Power**  
Describes the setting to save battery consumption using "Eco Mode".
- Setting Wi-Fi®**  
Describes how to connect Wi-Fi® network.
- Viewing/Playing Data**  
Describes how to view and play still image and video data.
- How to Transfer Data with the au Settings Menu**  
You can return or store data from a previously used au phone to the product using a microSD memory card or auスマートパス (au Smart Pass) server.

Sold by: KDDI CORPORATION,  
OKINAWA CELLULAR TELEPHONE COMPANY  
Manufactured by: KYOCERA Corporation

Basic Operation

For detailed operations, refer to the "Basic Manual" application that can be used on the product.

Power button  
Power On (Long-touch at least 2 seconds)  
Displaying the Home Screen from the Start Screen  
Tap "START" and slide/swipe (flick) toward "START" to display the Home screen. Swiping (flicking) toward "CAMERA"/"PHONE" activates camera/phone.  
Widget  
Notification display  
Indicator  
Start icon  
Start screen  
Widgets are displayed in the Start screen. Slide/swipe (flick) left/right or press (Direct button) to switch between widgets.  
Apps list  
Display the Apps list.  
Recents button  
Display the recently-used apps.  
Home button  
Display the Home screen or use for canceling sleep mode.  
Back button  
Tap to return to the previous screen.  
Direct button  
Long-touch to use the function set from the Apps list → [Settings] → [Direct button].

Display (Touch panel)  
Operate directly touching with your finger.  
Tap  
Lightly touch a screen and then immediately release your finger.  
Long-touch  
Keep touching a screen.  
Swipe (flick)  
Touch the screen and flick up/down/left/right.  
Slide  
Slide your finger across the screen in a desired direction to view hidden content.

Character Entry

Enter character by flick input or tapping key repeatedly.

Flick input  
Long-touch a key to display input candidates for flick input as right screen. Flick to the direction of character to enter.  
Character entry mode switch key  
Tap to switch character type.  
(Character entry screen (10-key))

Silent Mode Setting

- Long-touch [Volume DOWN button] on left side of the product to set Silent mode on/off.
- To change the Silent mode type, access the Apps list → [Settings] → [Sound & notification] → [Silent mode type] → [Vibrate]/[Mute]/[Drive].

Setting Application Privileges

When activating applications/functions for the first time that access functions and information on the product, a confirmation screen appears asking what access privileges to permit. If a confirmation screen appears, confirm the content and tap "DENY"/"ALLOW". Depending on the application/function, a description of the permission may appear. A confirmation screen may also appear several times, or display may also differ. Carefully confirm the displayed content, and follow the onscreen instructions. If privileges are not permitted, applications/functions may not activate, or the use of functions may be restricted. This manual may not describe content displayed on confirmation screens.

Initial Settings

When you turn on the product for the first time, follow the onscreen instructions to set the language, functions, services, etc.

Setting Up a Google Account

Set up Google account to use Google apps such as "Gmail", "Play Store", "Hangouts". Setting items are as below (besides the items below, register "First" name, "Last" name).

User name	Register your Google account (user ID) and any character string for mail address. You can register a desired name, but a registered name by another user cannot be set.
Password	Register password for the Google account.

1 Welcome  
Select language, [OK] → Set up the Wi-Fi network to connect as required<sup>1</sup>

2 Get another device?  
Back up apps and data as required  
Here, tap "No thanks" and go to the next step.

3 Create a Google Account  
[Or create a new account]<sup>2</sup> → Enter your [First name] and [Last name] → [NEXT]

4 How you'll sign in  
Enter a user name → [NEXT]  
Checking registration of username starts.

5 Create password  
Enter a password, and reenter the password for confirmation → [NEXT]

6 Add another email  
Confirm/change name of country and phone number → [NEXT]<sup>11</sup> → [VERIFY]

7 Your Google Account  
Check the contents, then [I AGREE] → Check the contents, then [NEXT]

8 Set up payment info  
Check the terms of Google service, then [NEXT]<sup>11</sup> → Select whether to set payment information → [CONTINUE]  
Here, tap "No thanks" and go to the next step.

9 Add another email  
Select whether to add another e-mail address → [NEXT]  
Here, tap "Not now" and go to the next step.

10 Protect your phone  
Checkmark the option, then [NEXT] → Follow the onscreen instructions  
If not setting this option, remove the checkmark.

<sup>1</sup> If you do not set up, tap "SKIP".  
<sup>2</sup> If you already have a Google account, enter the e-mail address.  
<sup>3</sup> By agreeing to use location service, note that the product will now transmit your location without prompting you for your confirmation.

au Easy Setting

By setting au ID, you can use various services provided by au such as "au Simple Payment Service" which allows you to purchase applications from the au スマートパス (au Smart Pass) or Google Play. Main setting items as follows.

au ID <sup>*</sup>	Register your au phone number or any character string for au ID (user ID).
au ID password	Register password for using au ID.

<sup>\*</sup> "au ID" which is already used by another user cannot be set.

- If you skipped completing "au Easy Setting" after purchasing the product, you can set an au ID later. To set, either tap the Apps list → "Settings" → "au Settings Menu" → "au Easy Setting", or tap the Apps list → "au ID Setting".

1 Welcome to au screen → [Next]

2 [Register "au ID"] → [Next]

3 [au IDの設定・保存 (Set/save au ID)]

4 Enter the security code<sup>1</sup> → [OK]

5 Enter a security password → [設定 (Settings)]

6 [終了 (Done)]  
au ID is set.

7 [Update] → [Next]

8 Check the terms and conditions (reading required), [Agree] → [Next] → [Agree]

9 Check the contents, then [Turn Auto Backup on]/[Turn Auto Backup off]<sup>2</sup> → [Next]  
To use the [Data Storage App] application and automatically store photos and address book entries to the auスマートパス (au Smart Pass) server, select [Turn Auto Backup on].

10 Check the contents, then [Activate]/[Skip activation]<sup>3</sup> → [Next]  
To use au Basic Home, select [Activate].

11 Check the contents, then [Activate]/[Skip activation]<sup>3</sup> → [Next]  
To use the smartphoning while walking application, select [Activate].

12 Check the contents, then [Activate]/[Skip activation]<sup>3</sup> → [Next]  
To use the "Lookout for au" application, select [Activate].

13 Select type of data to return<sup>4</sup> → [次へ (Next)]

14 Select the application to install → [次へ (Next)]

15 [Finish]

<sup>1</sup> Default value is a four-digit number written at subscription.  
<sup>2</sup> When a screen different from that shown here appears, follow the onscreen instructions.  
<sup>3</sup> "Lookout for au" is set beforehand by permitting all privileges.  
<sup>4</sup> If no data is stored to auスマートパス (au Smart Pass), this screen is not displayed.

E-mail

To use E-mail (@ezweb.ne.jp), subscription to LTE NET is required.

If you did not subscribe it when you purchased the product, contact an au shop or Customer Service Center. Your E-mail address is determined automatically after initial setting. You can change the E-mail address later.

Initial Settings

1 Home screen → [E-mail]

2 Check the contents, then [接続する (Connect)]

3 Confirm e-mail address → [閉じる (Close)]

4 Check the contents, then [Close] → Check the contents, then [同意する (Agree)] → [完了 (Done)]

5 Check the contents, then [OK]

Changing Your E-mail Address

1 Home screen → [E-mail]

2 [Eメール]

3 [Change Address/Settings Filter] → [接続する (Connect)]

4 [Eメールアドレスの変更へ (To change E-mail address)]

5 Enter the security code → [送信 (Send)]

6 Eメールアドレスの変更  
Check the contents, then [承諾する (I accept)]

7 Eメールアドレスの変更  
Enter E-mail address → [送信 (Send)]

8 Eメールアドレスの変更  
[OK]

9 Eメールアドレスの変更  
[閉じる (Close)]

Backing Up E-mail

You can back up E-mail. E-mail data is saved to the internal storage (/storage/emulated/0/private/au/email/BU). If a microSD memory card is attached, it is saved to the card (/storage/XXXX/private/au/email/BU) ("XXXX" depends on the microSD memory card).

1 Home screen → [E-mail]

2 [Eメール] → [E-mail settings]

3 [Backup/Restore]

4 [Mail Backup] → Confirm the contents and [OK]

5 Select a character code to make backup data → [OK]

6 Select a folder to back up → [OK]


Mail Settings Other Than E-mail

You can use mail addresses other than E-mail (@ezweb.ne.jp). Use of other mail addresses requires accounts to be set. When using another mail address for the first time, set the address as follows.  
Apps list → [Gmail] → Follow onscreen instructions



Making a Call

■ Adding a New Contact and Making a Call



\*1 If you tapped "ADD NEW ACCOUNT", follow onscreen instructions to set an account.  
If the contacts list is displayed, tap \*1,2.  
\*2 If you tap "IMPORT CONTACTS", see the section "Importing/Exporting Contacts".


Checking your own phone number (Profile)  
Operate as follow to check your own phone number.  
Apps list → [Settings] → [Profile] → The profile screen is displayed.

Receiving a Call


When a call arrives, answer the call as follows.  
\* By default, the Sync Call "Receive an incoming call over the operation screen" setting is "ON".

■ Calling

If the Sync Call "Receive an incoming call over the operation screen" setting is on.




If in Silent mode, the Start screen is displayed, etc.



■ Answering with Answering Memo


Answer by the answering memo message and record a message of the party when you cannot answer calls.



Importing/Exporting Contacts


You can import/export contacts from/to an au server/internal storage/microSD memory card.  
• Depending on the contact, data may not be completely imported/exported.

■ Importing (First Import after Purchase)



\*1 If only one file to import (vCard file) is saved, importing starts.  
\*2 Can only be selected when an account is registered.  
\*3 If you tapped "Import all vCard files", importing starts.


■ Importing/Exporting (Contacts Already Registered)



\*1 If you tapped "Import from Phone"/"Import from SD card" and only one file to import (vCard file) is saved, importing starts.  
If you tapped "Export to Phone"/"Export to SD card", go to step 5.  
\*2 If you tapped "Import from Phone"/"Import from SD card", can only be selected when an account is registered.  
\*3 If you tapped "Import all vCard files", importing starts.

Saving Battery Power

Use "Eco Mode" to adjust the sleep time of the backlight and the screen brightness or to enable/disable auto rotation of the screen so that you can save battery power.




Setting Wi-Fi®

Use your home Wireless LAN (Wi-Fi®) or public wireless LAN to connect internet.  
Main settings are as follows.


Select Wi-Fi® network for connection	Search for and connect to an available Wi-Fi® network.
WPS system	Use for registration of access point compatible with Wi-Fi Protected Setup™ with WPS mark.

\* If you turn on wireless LAN (Wi-Fi®) function, battery consumption increases. You are recommended to turn wireless LAN (Wi-Fi®) function to OFF when not using wireless LAN (Wi-Fi®) function.



\*1 If the Wi-Fi® network you want to connect to cannot be detected, tap [📞] → "Add network" and add the network manually.  
\*2 To connect to a protected Wi-Fi® network, enter the password (security key) and tap "CONNECT". The password (security key) is set with the Wi-Fi® network. For details, contact with the network administrator.


■ Using a WPS System Access Point



Viewing/Playing Data

By transferring data from a previously used au phone to a microSD memory card, you can view or play\* still images, videos, and other data with "File Commander" on the product. The first time you start up the product, terms and conditions appear. Follow onscreen instructions.  
\* Copyrighted data on the previously used au phone cannot be transferred to the product. However, some 着うたフル®, ビデオクリップ®, 着うたフルプラス® may be able to be transferred and played on the product with the same phone number by backing up with LISMO Port Ver 4.2 or later.

■ Viewing/Playing Data



How to Transfer Data with the au Settings Menu

You can return or store data from a previously used au terminal to the product using a microSD memory card or au スマートパス (au Smart Pass) server.  
• To return/store data using an au スマートパス (au Smart Pass) server, you must set an au ID.  
• To return data using a microSD memory card, save the data from the previously used au phone to the microSD memory card beforehand.

■ Returning Data with the au Settings Menu



■ Saving Data with the au Settings Menu



Storing data automatically to au スマートパス (au Smart Pass)  
To use the "Data Storage App" application and automatically store still images and address book entries to an au スマートパス (au Smart Pass) server, set as follows.  
Apps list → [Settings] → [au Settings Menu] → [Backup Setting] → Checkmark the type of data to be stored automatically.