

URBANO v01 Setting Guide

Introduction

Thank you for buying the "URBANO V01" (simply called the "product" from here on). In this guide, settings and precautions for using the product are described. For explanations of basic functions, refer to "Basic Manual".

<p>Basic operation Describes the basic operations.</p> <p>Initial settings Make initial settings when you turn the power on for the first time.</p> <p>au Easy Setting Sets au ID</p> <p>E-mail Make initial settings for @ezweb.ne.jp etc.</p>	<p>Making a call Adds a contact as a new and makes a call.</p> <p>Receiving a call Describes how to receive a call.</p> <p>Saving battery power Describes the setting to save battery consumption using "E-saving settings".</p> <p>Setting Wi-Fi* Describes how to connect Wi-Fi* network.</p>	<p>Viewing/playing data Describes how to view/play still images or video data.</p> <p>Infrared communication Describes how to send/receive data between the product and another device using infrared communication function.</p>
---	---	---

Company names and product names referred to in this manual are trademarks or registered trademarks of respective companies. The TM, © marks may be omitted in this manual. Screen illustrations shown in this manual may look different from the actual screens. In some cases, minor details or a part of a screen may be omitted.

November 2014, 1st Edition
Sold by: KDDI CORPORATION,
OKINAWA CELLULAR TELEPHONE COMPANY
Manufactured by: KYOCERA Corporation

Basic operation

For detailed operation method, refer to "Basic Manual".

◀ Home screen (Standard home) ▶

- 天気 (Weather) widget**
Display the weather information. When you activate for the first time, tap and select an area.
- Change home**
Switch the home app.
- Power key**
- Power ON**
Press and hold [Power] until the incoming light turns on.
- Disabling Security**
Slide "Security" to disable security
- Chrome**
You can browse websites using Google Chrome.
- [(Apps)] Apps list**
Display the Apps list.
- RECENTS key**
Display the recently-used apps.
- HOME HOME key**
Display the Home screen or use for canceling sleep mode.
- BACK key**
Tap to return to the previous screen.
- Display**
Operate directly touching with your finger.

Tap
Lightly touch a screen and then immediately release your finger.

Long-touch
Keep touching an item or key.

Flick
Quickly move (flicking) your finger up, down, right, or left.

Character entry

Enter character by flick input or tapping key repeatedly.

Flick input
Long-touch a key to display input candidates for flick input as right screen. Flick to the direction of character to enter.

Character entry mode switch key
Tap to switch character type.

Enlarging characters

You can display large and sharp characters on menu items etc. For change of character size, make settings as follows.

Apps list → [Settings] → [Accessibility] → [Large text]

Alternatively, press and hold [Magnifier] then tap [Magnify] to magnify and see the desired area with "拡大鏡 (Magnifier)". Tap [Close] at the top of Magnifier to close.

(After change of the character size)

Initial settings

When you turn on the product for the first time, follow the onscreen instructions to set the language, functions, services, etc.

Setting up Google account

Set up Google account to use Google apps such as "Gmail", "Play Store", "Hangouts". Setting items are as below (besides the items below, register "First" name, "Last" name).

User name	Register your Google account (user ID) and any character string for mail address. You can register a desired name, but a registered name by another user cannot be set.
Password	Register password for the Google account.

1. Welcome screen. Select language, [Next].
2. Select Wi-Fi. Set up the Wi-Fi network to connect as required. * If you do not set up, tap "Skip".
3. Got Google? Do you have a Google Account? If you use Gmail or Google Apps, answer Yes. [No] → [Get an account] If you have Google account, tap "Yes".
4. Your name. Enter "First" name and "Last" name → [Next].
5. Choose username. Enter a user name → [Next]. Checking registration of username starts.
6. Create password. Enter a password, and reenter the password for confirmation → [Next].
7. Google password recovery. [Set up recovery options] → Enter spare mail address* in case you forgot the password → [Next]. * If you have no another mail address, leave the area blank.
8. Google services. Check the contents, then [Next].
9. Finish account. Check the contents, then [I accept].
10. Authenticating... Enter text displayed on screen → [Next]. * This screen may not be displayed.

11. Upgrade to Google+. Select if you join Google+ Tap "Not now" to go to the next.
12. Set up payment info. Make purchase settings of Google Play as required.

au Easy Setting

By setting au ID, you can use various services provided by au such as "au Simple Payment Service" which allows you to purchase applications from the au スマートパス (au Smart Pass) or Google Play. Main setting items as follows.

The first time the product turns ON, "au へようこそ (Welcome to au)" appears to help you make Initial settings for "au かんたん設定 (au Easy Setting)" etc. Press [Menu] twice and then from the Home screen → [設定 (Settings)] → [言語と入力 (Language & input)] → [言語 (Language)] → "English" to switch language, then set au Easy Setting. From the Home screen → [Apps] → [au Easy Setting].

au ID*	Register your au phone number or any character string for au ID (user ID).
au ID password	Register password for using au ID.

* Username which is already used by another user cannot be set.
• If you skip the operation of "au かんたん設定 (au Easy Setting)" when you purchased the product, you can set au ID later. In that case, Apps list → Tap "au かんたん設定 (au Easy Setting)" or "au ID 設定 (au ID Setting)".

1. Welcome to au screen → [Next].
2. [Register "au ID"] → [Next].
3. [au ID の設定・保存 (Set/save au ID)].
4. Enter the security code → [OK]. * Default value is a four-digit number written at subscription.
5. Enter a security password → [設定 (Settings)] → [終了 (終了)].
6. [Update] → [Next].
7. Check the terms and conditions (reading required), [Agree] → [Next].
8. [Agree]. * Pre-configuration of Lookout for au is complete.
9. Select whether to restore data → [Next]. * If no data to restore, the screen does not appear. * When a screen different from the above appears, follow the onscreen instructions.
10. Select a service to use → [Next].
11. Select apps to restore → [次へ (Next)]. * It is displayed only if you downloaded from au website before.
12. Select apps to install → [次へ (Next)] → [OK]. * When a screen different from the above appears, follow the onscreen instructions.
13. [Yes]/[No] → [Next].
14. [Activate]/[Skip activation] → [Next].
15. [Finish].

E-mail

To use E-mail (@ezweb.ne.jp), subscription to LTE NET is required. If you did not subscribe it when you purchased the product, contact an au shop or Customer Service Center. Your E-mail address is determined automatically after initial settings. You can change the E-mail address later.

Initial settings

1. Home screen → [メール (Mail)] → [E-mail].
2. Check the contents, then [接続する (Connect)].
3. After E-mail initial settings, your E-mail address appears. Check E-mail address and tap "閉じる (Close)".
4. Check the content of "Information for improvement" → [Agree]/[Disagree] → [Done].
5. When the description screen for E-mail function appears, confirm the content and tap [Close].

Changing your e-mail address

1. Home screen → [メール (Mail)] → [E-mail settings].
2. [E-mail settings] → [接続する (Connect)].
3. [E-mail settings] → [E-mail settings] → [接続する (Connect)].
4. [Eメールアドレスの変更 (To Change E-mail address)].
5. Enter the security code → [送信 (Send)].
6. Check the contents, then [承諾する (I accept)].
7. Enter E-mail address → [送信 (Send)].
8. [OK].
9. [閉じる (Close)].

Backing up E-mail

You can back up E-mail.
Backed up data is saved on a microSD™ memory card (/storage/sdcard1/private/au/email/BU/) when a microSD™ memory card is attached. If a microSD™ memory card is not attached, data is saved on the internal storage (/storage/emulated/0/private/au/email/BU/).

- Home screen → [メール (Mail)] → [E-mail]
- [E-mail settings]
- [Backup/Restore]
- [Mail Backup] → Confirm the notes and [OK]
- Select a character code to make backup data → [OK]

PC-mail settings
You can use mail addresses except for E-mail (@ezweb.ne.jp). You need to set up a PC-mail account to use PC-mail. For the first time use, make settings as follows.
Apps list → [PC mail] → Enter E-mail address and password → [Next] → Set account → [Next] → Enter account name etc. → [Next]

- Select a mail type to back up → [OK]

Making a call

Adding new contact and making a call

- Apps list → [Contacts]
- [Create a new contact] → [Keep local]/[Add account] → Enter necessary item → [OK]
If you tap "Add account", follow the onscreen instructions to set an account. When All Contacts screen appears, tap "Create contact".
- [Phone]

- Home screen → Tap [Outgoing call]/[Incoming call] tab
- [Phone] → Tap [Outgoing call]/[Incoming call] tab

Checking your own phone number (Profile)
Operate as follow to check your own phone number.
Apps list → [Settings] → [Profile] → Profile screen appears.

Checking your E-mail address
Your E mail address can also be checked on profile screen.
If you make initial settings for [E-mail] app as follows, the E-mail address of E-mail (@ezweb.ne.jp) can be automatically registered to profile screen.
Home screen → [メール (Mail)] → [E-mail] → [Connect] → [閉じる (Close)] → Registered to profile screen.

Receiving a call

You can receive a call in the following steps.
*Display the popup on an incoming call" is set to ON in Sync Call settings by default. When it is set to OFF, while sleep mode is activated or while the start screen is displayed, follow the onscreen instructions.

Calling

- Receiving screen → [Accept]
- Start calling
- To end the call, [End]

Answering with answering memo

Answer by the answering memo message and record a message of the party when you cannot answer calls.

- Receiving screen → [Phone Screen]
- Drag the operation panel downwards
- [Menu] → [Reply Auto answering]
- The caller hears the guidance
- To answer the call, slide to the right from "☎" to "☎"

Saving battery power

Use "E-saving settings" to set sleep time of backlight and screen brightness to the minimum value or to enable/disable auto rotation of screen, Wi-Fi®, Auto data control, Bluetooth®, GPS satellites, Reader/Writer, P2P, Voice Wake Up, Pedometer, CPU clock restriction, Data communication, etc. so that you can save the battery power. When the battery power is low, set "Auto data control" to OFF and limit communications only for calling to extend standby time.

- Apps list → [E-saving settings]
- [Custom]/[Long life]

Tap "⚙" by "Custom"/"Long life" to check and change items to save power.

Setting Wi-Fi®

Use your home Wireless LAN (Wi-Fi®) or public wireless LAN to connect internet. Main settings are as follows.

Easy setting by camera	Use for registration of access point compatible with "Easy setting by camera".
WPS system	Use for registration of access point compatible with Wi-Fi Protected Setup™ with WPS mark.

* If you turn on wireless LAN (Wi-Fi®) function, battery consumption increases. You are recommended to turn wireless LAN (Wi-Fi®) function to OFF when not using wireless LAN (Wi-Fi®) function.

- Apps list → [Settings]
- [Wi-Fi]
- [Wi-Fi EASY SETTINGS]

When access point is not detected, tap "+" to add access point manually.

Available Wi-Fi networks are detected automatically and their SSIDs appear in the Wi-Fi networks.

Using Wi-Fi connection tool by the camera

- [Easy setting by camera]
- Select the set place
- Follow the onscreen instructions to register an access point.

Using WPS system access point

- [WPS button]
- Keep pressing WPS button of access point to set to WPS mode. An access point is automatically detected and registration starts.
- [WPS Pin Entry]
- Enter displayed PIN code for access point, then registration starts.

Viewing/playing data

By transferring data from the previously used au phone to a microSD™ memory card, you can view/play* still images, movie data, etc. using "Photo library" in the product.
* Copyrighted data on the previously used au phone cannot be transferred to the product. However, some 着うたフル®, ビデオクリップ®, 着うたフルプラス® may be able to be transferred and played on the product with the same phone number by backing up with LISMO Port Ver 4.2 or later.

- Apps list → [Photo library]
- When you activate for the first time, an explanation screen appears. Follow the onscreen explanations, [Next] → [Next] → [Exit] to complete.

Backing up by au Backup App
You can back up/restore various data saved on your smartphone to microSD™ memory card by downloading au Backup App. Backup data of your old terminal can be completely migrated. Also, the contacts on a feature phone can be migrated easily. For details about downloading etc., refer to au homepage.
<http://www.au.kddi.com/mobile/service/smartphone/safety/backup/>

Infrared communication

You can send/receive profiles or various data between the product and another device using infrared communication.

Receiving data

- Apps list → [Infrared com.]
- [Receive]
- Point the infrared data port of the product to the infrared data port of the other device. When the authentication code entry screen appears, enter authentication code (four-digit number) → [OK].

Sending data

- Apps list → [Infrared com.]
- [Send profile]/[Send contacts]/[Send file]
- Select a data item to send → [OK]
- When authentication code entry screen appears, enter authentication code (four-digit number) → [OK].
* In the case of data transmission with File Commander, tapping [OK] is not required.