

# URBANO vo3 Setting Guide

Introduction

Thank you for buying the "URBANO VO3" (simply called the "product" from here on). In this guide, settings and precautions for using the For explanations of basic functions, refer to "Basic Manual"

Basic Operation

Describes the basic operations

## Initial settings

Make initial settings when you turn the power on for the first time

au Easy Setting Set au ID

E-mail Make initial settings for E-mail (@

ezweb.ne.jp) etc ■ 取扱説明書アプリケーション

(Basic Manual app) load/use 取扱説明 Describes how to download/use 取扱説明書アプリケーション (Basic Manual app)

## Making a call

Describes how to make a call

Receiving a call Describes how to receive a call

Settings Describes basic operations when you use "settings" of the apps menu.

Setting Wi-Fi® Describes how to connect Wi-Fi® network

■ Viewing/Playing data ew/play still images or video data.

#### Infrared communication

Describes how to send/receive data between the product and another device using infrared communication function.

Transferring data from au Settings Menu

Describes how to restore/back up data from/to your previously used phone to/ from this product using the au Smart

Company names and product names referred to in this manual are trademarks or registered trademarks of respective companies.


The TM, ® marks may be omitted in this manual Screen illustrations shown in this manual may look different from

In some cases, minor details or a part of a screen may be omitted

October 2016, 1st Edition Sold by: KDDI CORPORATION OKINAWA CELLULAR TELEPHONE COMPANY Manufactured by: KYOCERA Corporation

#### **Basic Operation**

For explanations of basic functions, refer to "Basic Manual"



Touch directly with your finger to operate.

In the Keitai input screen, [  $\cong$  ]  $\rightarrow$  [Standard Input], and in the Smartphone input screen, [ % ] / [ % ]  $\rightarrow$  [Keitai Input] to switch

Flick input is available with the Smartphone input (10-key keyboard)

screen. Touch a key to display characters can be input. Flick to the

Lightly touch a elease your finger.


screen and then immediately Character entry For character entry, there are "Keitai Input" and "Smartphone

Keep touching a screen









mode switch key

Tap or long-touch

to switch character

screen

**Smartphone** input screen \* 10-key keyboard

#### direction of the character to enter. Setting Silent mode

• Press and hold (Volume down button) for at least one second to set the Silent mode to ON/OFF.

When you first activate app/function that access the functions or information of the product, a confirmation screen for requesting access

permission appears. When the screen for confirmation is displayed, confirm the content and tap "DENY"/"ALLOW" • If you do not permit, app/function may not be activated or use of function may be restricted.

• For some apps/functions, an explanation screen for the permission appears. A confirmation screen may appear in several times and its content may vary. Confirm the content and follow the on-screen instructions

• In this manual, description of such confirmation screen may be omitted.

# Initial settings

When you turn on the product for the first time after purchasing the product, follow the on-screen instructions to set language, functions and services.

# Setting up Google account

Set up Google account to use Google applications such as "Gmail", "Play Store", "Hangouts" Setting items are as below (besides the items below, register "First" name and "Last" name).

Register password for the Google account

Register your Google account (user ID) and a character string for mail address. You can register a desired name, User name but a name already registered by another user cannot be set



Password

Tap "日本語" to select "ENGLISH", and then tap [→] Tap "ENGLISH" to


language you want

to use.



network to connect as required

\* If you do not set up,
tap [SKIP] → [SKIP
ANYWAY].



as required \* If you do not copy, [No thanks] → [NEXT]



[Or create a new accountl \* If you have a Google account, enter a mail address → [NEXT].



Enter "First name" and "Last name"→[NEXT]→Enter the date of birth and gender → [NEXT].



→ [NEXT] reenter the password for Checking registration of user name starts. confirmation → [NEXT]



and phone number → [NEXT]\*




G Google in Setti

Yahoo

Exchang

0 2



Check the contents

then [NEXT]

Mark the check

box, then [NEXT]

Make settings of adding a mail address as required. \* Tap (Later) here.

Mark the check box, then [NEXT] → Follow onscreen instructions to set security and notification

Check the contents

then [I AGREE]

If you do not set up. remove the check mark, tap [SKIP] -[SKIP ANYWAY].

\*1 Text message for Google verification code will be sent to the set phone number

CONTINUE >

Make purchase

settings of Google

Play as required →

[CONTINUE]

#### au Easy Setting

NEXT >

Confirm the Google

service settings, then

[NEXT]

By setting au ID, you can use various services provided by au such as "au Kantan Kessai" which allows you to purchase applications from ートパス (au Smart Pass) or Google Play, Main

ı	au ID*	Perietary your people in all many south gracetary atrian for an ID (year ID)
ŀ	au iD	Register your au phone number or a character string for au ID (user ID).
	au ID password	Register password for using au ID.

\* "au ID" which is already used by another user cannot be set.

• If you skip the operation of "au Easy Setting" at that time, you can set au ID later. In that case, operate from Apps menu → [Tools] → [au ID Setting].



O Agree Disagree

[Update] → [Next] → [Next]



Check the terms and conditions (reading requires), [Agree] -



[Agree]



at subscription

Check the contents, then [Activate] / [Skip activation] → [Next] →





しければ [設定] をタップしておすすみく し、なお、[設定] を押した場合、本項 ゆ 二確認のうる問題 | たものとみなしま

Enter a security

password → [設定

(Settings)] → [終了

(Exit)]

/ [Turn Auto Backup off] → [Next]

\* In "Basic Manual" of the product, the operations on Home screen of "Entry Home" is provided as Tap (Skip activation) here



\*1 To complete the initial setting of Lookout for au, permit the access permission on each request screen.

# E-mail

To use E-mail (@ezweb.ne.jp), subscription to LTE NET is required.

If you did not subscribe it when you purchased the product, contact an au shop or Customer Service Center Your E-mail address is determined automatically after initial setting. You can change the E-mail address later.

■ Initial settings \* You cannot make initial settings in Wi-Fi® communication



Changing your e-mail address




Setting Filter]

(Close)] → Check

the contents, then [閉じる (Close)]



Home screen → [Mail]





[E-mail]

Enter E-mail [ 送信 (Send)]



You can use SMS (short message service via phone numbers as recipients).

2

Enter the security code

→ [送信 (Send)]

When [SMS] is

selected in step

# [ 閉じる (Close)]

更へ (To Change E-mail

address)]

でも変更することがで -ル設定->改善情報送

細については、Eメールアプリプ イバシーポリシーをご参照くださ ールアプリプライバシーポリ ご確認の上、以下を選択し、完了ポ アンを押してください。

Check the contents,

[同意する (Agree)] →

[Done]

## 取扱説明書アプリケーション (Basic Manual app)

■ Downloading"取扱説明書アプリケーション (Basic Manual app)



Home screen → [Apps] → [Support] → [取扱説明書 (Basic Manual app)]

■ Using "取扱説明書アプリケーション (Basic Manual app)'



Home screen →
[Apps] → [Support] → [取扱説明書 (Basic Manual app)]

The front cover of 取扱説明書 (Instruction manual) is displayed.

\* When the instruction screen (how to turn pages) is displayed, tap 「閉じる (Close)]

# Making a call

Adding new contact and making a call



Home screen → [Phone] → [Contacts] → Tap "CONTACTS" tab



CONTACT] → Enter necessary items →

[SAVE] When "CREATE A NEW CONTACT" is not displayed, tap [ADD NEW CONTACT) the follow the on-screen instructions to register a contact.

Making a call from the call history

"OUTGOING" tab



Tap [ 🛇 ] of a party → Tap "INCOMING" /

# Adding a pair and making a call



#### Checking your own phone number (Profile) Operate as follow to check your own phone number.

Apps menu → [Profile] → Profile screen appears

#### Checking your E-mail address

on the right side of the main unit for at least one second → tap "PAIR" tab

to display.

Your E-mail address can also be checked on profile screen.

If you make initial settings for [E-mail] app as follows, the E-mail address (@ezweb.ne.jp) can be automatically registered to profile

Home screen → [Mail] → [B-mail] → [閉じる (Close)] → [閉じる (Close)] → [Agree] → [Done] → The e-mail address is registered to the profile screen.

#### Receiving a call

You can receive a call in the following steps.

\* "Receive an incoming call over the operation screen" is set to "ON" in "Sync Call settings" by default. When you set it "OFF", in sleep mode, or when the start screen is displayed, follow the on-screen instructions.

#### Calling




[Accept] \* Alternatively, press and hold (Phone button) on the right side of the main unit for at least one second



To end the call, [End]

Receiving Screen in sleep mode or while the start screen is

displayed



Follow the on-screen instructions.

To answer the call, slide ( S ) right.
Alternatively, press and hold 🗹 (Phone button) on the right side of the main unit for at least one second to call.

#### Answering with Auto answering

Answer by the answering memo message and record a message of the party when you cannot answer calls







Answering with SMS Reject an incoming call and answer with SMS.

Operate as follow to answer with SMS.

Receiving screen  $\rightarrow$  [  $\blacksquare$  ]  $\rightarrow$  Drag the operation panel down  $\rightarrow$  [MENU]  $\rightarrow$  [SMS answering] → Select a message → SMS message is sent.


# Forwarding an incoming call without answering

Forward an incoming call to the forwarding phone number or remote operation of voice mail service. Forward the incoming call in the following steps.

Receiving screen  $\rightarrow$  [  $\P$  ]  $\rightarrow$  Drag the operation panel down  $\rightarrow$  [MENU]  $\rightarrow$  [Forward] → The incoming call is forwarded.

## Settings

You can perform the basic operations in the "Settings" of the apps menu.



[Settings]

<b>+</b> :	Settings
•	Wallpapers Set your favorite wallpaper and star screen background
•	Sound & notification Set ringtone, silent mode, vibration and LED
٨	Home screen Change clock display, notification display and shortcut etc.
Э	Start screen Change clock pattern and security type of start screen
Ø	Font Set font size and typeface
	Input method

Wallpapers Set your favorite wallpaper and start screen background. Sound & notification Set ringtone, silent mode, vibration and LED. Change clock display, notification display and Home screen shortcut etc. Start screen Change clock pattern and security type of start Set font size and typeface. Input method Select input method from Keitai input or Smartphone input. Button settings Customize the Phone button, Home button and Recents button. Show you explanation about Entry Home. Entry Home guide More For more advanced settings



Use your home Wireless LAN (Wi-Fi®) or public wireless LAN to connect to the Internet. Main settings are as follows

Answer to the questions on the screen or follow the instructions to register an access point easily.

WPS system Use for registration of access point compatible with Wi-Fi Protected Setup ™ with WPS mark.

If you turn on wireless LAN (Wi-Fi®) function, battery consumption increases. You are recommended to turn wireless LAN (Wi-Fi®) function to OFF when not using wireless LAN (Wi-Fi®) function.



Answer the questions on the screen and follow the instructions

to register an access point.

Available Wi-Fi® networks are listed. Select a Wi-Fi® network to connect → Enter a password as required → [CONNECT] to connect the Wi-Fi® network

If a Wi-Fi® network you want to connect cannot be detected, operate from [MENU] → [Add network] and connect the Wi-Fi® network manually.

# Using Wi-Fi Easy Settings



[Wi-Fi Easy Settings]

Using WPS system access point



For using WPS button, tap "WPS Push Button" and then keep pressing WPS button of access point to set to WPS mode. An access point is automatically detected and registration starts. For entering WPS PIN, tap "WPS PIN Entry" and enter displayed PIN code for access point, then registration starts.

[Advanced] → [WPS Push Button] / [WPS PIN Entry]

### Viewing/Playing data

By transferring data from the previously used au phone to au a microSD TM memory card, you can insert the microSD memory card into this product and view/play still image or movie data using "File Commander" in the product. When you activate for the first time, the Terms and Conditions appears. Follow the on-screen instructions.



→ [File Commander]

Infrared communication

displayed → Tap a file

→ Tap data Data is played

\* Copyrighted data on the previously used au phone cannot be transferred to the product. However, some Chaku Uta Full<sup>®</sup>, Video Clip, Chaku Uta Full Plus<sup>®</sup> may be able to be transferred and played on the product with the same phone number by backing up with LISMO Port Ver 4.2 or later.

Use infrared communication to send/receive profile or various data between the product and other devices.



Apps menu → [Tools] Select an item to operate → [Infrared]

To receive data, select "Infrared" and point the infrared data port of the product to the infrared data port of the other device.

To send, select "Send profile" Send contacts "Send file", select data to send

for sending contacts/file  $\rightarrow$  [OK], and then point the infrared data port of the

- product to the infrared data port of the other device.

  \* For sending data from File Commander, tapping "OK" operation is not
- When authentication code entry screen appears, enter authentication code (four-digit number) → [OK].

# Transferring data from au Settings Menu

Restore/back up data from/to your previously used au phone to/from this product using microSD card or the au Smart Pass server.



- Setting au ID is required for restoring/backing up data using au Smart Pass server
- For restoring data using microSD memory card, save the data to the microSD memory card using your previously used au phone in advance.

Restoring data from au Settings Menu

When "auスマートパスのサー When "SDカードか ら復元する (Restore バから戻す (Restore from au from SD card)" is Smart Pass)" is selected



restoring data

\* Setting au ID is required for restoring data from "au スマートパス のサーバから戻す (Restore from au Smart Pass server)".



元する (Restore from SD card)" is selected, select a type of your previously used au cell phone

Not appeared when "au スマートパスのサーバから戻す (Restore from au Smart Pass server)" is selected in



selected

Select data to restore → [ 戻す (Restore)] → [OK] → [ 完了 (Done)] It is the screen for selecting "スマートフォンのデータを戻す

smartphone)".

(Restore data from

以下のデータをauスマートパスのサ ら戻します。

Select data to restore -[ 戻す (Restore)] → [ はい (OK)] → [完了(Done)]

Saving data from au Settings Menu

When "SD カードに 保存する (Saving to SD card)" is selected

Select data to save → [保存する (Save)] →

[ 完了 (Done)]



Select a saving location Setting au ID is required for saving data from "au スマートパスのサーバに預ける (Back up to au Smart Pass server)".

When "au スマートパスに預け る (Back up to au Smart Pass server)" is selected



Select data to back up → [預ける (Back up)] → [はい (OK)] → [完了 (Done)]

#### Using "Data Storage App'

To use "Data Storage App" to back up photos and contacts to au Smart Pass. server automatically, set as follows

Apps menu → [Settings] → [More] → [au Settings Menu] → [Backup Setting] → Tap to select a data type to back up automatically