

SAMSUNG Galaxy S26 Ultra Galaxy S26+ Galaxy S26

Quick Start Guide

"オンラインマニュアル (Online Manual)" (Japanese)

For detailed descriptions on various functions, scan the QR code on the right.



• Please keep the software up-to-date. For details on how to update the software, please refer to the "取扱説明書 詳細版 (Full Instruction Manual)" (Japanese) on the website of the contracted carrier.

• For the latest information, please refer to the "取扱説明書 詳細版 (Full Instruction Manual)" (Japanese) on the website of the contracted carrier.

• For the latest information on the product, refer to the following website: <https://www.samsung.com/jp/> (Japanese)

• The software of the product may differ from the information in this guide depending on version upgrades, service changes, or termination. The contents of this manual are subject to change without notice in the future.

• In this manual, "Galaxy S26 Ultra" / "Galaxy S26+" / "Galaxy S26" are usually referred to as "the product".

• Company names and product names referred to in this manual are trademarks or registered trademarks of respective companies. The TM and © marks may be omitted in this manual.

April 2026, 1st Edition
Imported by: SAMSUNG ELECTRONICS JAPAN Co., Ltd.
Manufactured by: Samsung Electronics Co., Ltd.

List of Packaged Items


- Main unit
- S Pen (used only with the Galaxy S26 Ultra)
- SIM ejector tool (sample)
- USB cable (CtoC) (sample)
- クイックスタートガイド (Quick Start Guide) (Japanese)
- データ移行ガイド (Data Transfer Guide) (Japanese)

memo

- The battery is built into the product.
- The illustrations of the bundled products and the product used in this manual are just images for explanations. They may be different from the actual ones.
- The USB cable (CtoC) (sample) attached to the product corresponds to charge up to 3 A.
- When using a protective film, make sure that it is a product compatible with the fingerprint recognition sensor. If you attach a commercially available protective film on the display, fingerprint recognition may fail.

Names of Parts

Galaxy S26 Ultra



1

2

3


- 1 Mouthpiece/Microphone (upper)¹
- 2 Vent hole¹
- 3 Pen button
- 4 S Pen
- 5 Front camera
- 6 Proximity/Light sensor²
- 7 Display (touch panel)
- 8 Receiver/Speaker^{1,3}
- 9 Volume button
- 10 || (Side button)
- Used to turn the product on and off. When the power is off, press and hold to turn it on.
- 11 Fingerprint recognition sensor²
- 12 Mouthpiece/Microphone (lower)¹
- 13 S Pen slot
- 14 Speaker¹
- 15 USB Type-C™ connection terminal (external connection terminal)
- 16 nanoSIM card tray
- 17 Tray eject hole
- 18 Microphone (rear)¹
- 19 Rear camera
- 20 Wireless charging position
- 21 Range AF sensor
- 22 Flash/Light
- 23 NFC/FeliCa® location⁴

- ¹ Be careful not to block this area with your fingers or other objects. Related functions may not work properly. Do not accidentally insert the SIM ejector tool (sample), etc., as this may cause damage.
² Do not cover this with stickers or other materials. Functions may not work correctly.
³ The product uses this for both a receiver and a speaker.
⁴ No FeliCa® mark () is printed on this product. Hold the enclosed portion up to a reader/writer to use.

memo

- The antenna is built into the main unit. For the antenna position, please refer to the "取扱説明書 詳細版 (Full Instruction Manual)" (Japanese) on the website of the contracted carrier.

Galaxy S26+ / Galaxy S26



4

5

- 1 Mouthpiece/Microphone (upper)¹
- 2 Vent hole¹
- 3 Front camera
- 4 Proximity/Light sensor²
- 5 Display (touch panel)
- 6 Receiver/Speaker^{1,3}
- 7 Volume button
- 8 || (Side button)
- Used to turn the product on and off. When the power is off, press and hold to turn it on.
- 9 Fingerprint recognition sensor²
- 10 Mouthpiece/Microphone (lower)¹
- 11 Tray eject hole
- 12 nanoSIM card tray
- 13 USB Type-C connection terminal (external connection terminal)
- 14 Speaker¹
- 15 Microphone (rear)¹
- 16 Rear camera
- 17 Wireless charging position
- 18 Flash/Light
- 19 NFC/FeliCa® location⁴ (Galaxy S26)
- 20 NFC/FeliCa® location⁴ (Galaxy S26+)


- ¹ Be careful not to block this area with your fingers or other objects. Related functions may not work properly. Do not accidentally insert the SIM ejector tool (sample), etc., as this may cause damage.
² Do not cover this with stickers or other materials. Functions may not work correctly.
³ The product uses this for both a receiver and a speaker.
⁴ No FeliCa® mark () is printed on this product. Hold the enclosed portion up to a reader/writer to use.

memo


- The antenna is built into the main unit. For the antenna position, please refer to the "取扱説明書 詳細版 (Full Instruction Manual)" (Japanese) on the website of the contracted carrier.

Attaching the nanoSIM card


Galaxy S26 Ultra



Galaxy S26+



Galaxy S26



For Using the Product

Before you start using the product, be sure to read the "Safety Precautions" to ensure correct use.

Before assuming a malfunction, please refer to the "故障とお考えになる前に (Troubleshooting)" from "取扱説明書 詳細版 (Full Instruction Manual)" (Japanese).

- Communication is not possible even inside the service area in places where the signal does not reach (for example, tunnels and basements). Also, communication may not be possible in places with poor reception. Please note that communication may be interrupted if the product is moved to a location with poor reception during communication.

- Since the product uses radio waves, the possibility of communication intercepts by third parties cannot be eliminated. (Though 5G/LTE/WiMAX 2+/GSM/UMTS system has highly secure confidential communication features.)
- Only VoLTE (LTE network) is available when connecting to Japanese emergency services.
- While the product supports the au World Service, each network service described in this manual varies depending on the area and service content.
- Since the product is a radio station under the Radio Law, you may be asked to temporarily submit the product for inspection in accordance with the Radio Law.
- The IMEI information of your phone is automatically sent to carrier for maintenance and monitoring operational status of the product.
- To use the product overseas, check the condition such as regulations of the country/region in advance.
- The Company is not liable for any damages or lost profits caused by natural disasters such as earthquakes, lightning, storms, floods, as well as fires, actions by third parties, other accidents, intentional or mistaken operation by the customer, or use under other unusual conditions outside the responsibility of the Company.
- The Company is not liable for any incidental damages (change/disappearance of saved content, loss of business income, disruption of business, etc.) arising from use of or inability to use the product.
- The Company is not liable for any damages or lost profits resulting from failure to observe the described content of "取扱説明書 詳細版 (Full Instruction Manual)" (Japanese), "Quick Start Guide" (this manual).

- Information such as positioning obtained from the product's measurement sensor and GPS is for reference only and is not intended for purposes that require a high degree of reliability. Note that the Company assumes no responsibility for any damages or lost profits resulting from positioning errors.
- The Company is not liable for any damages or lost profits resulting, for example, from malfunctions caused by combination with connected devices or software not related to the Company.
- Malfunction, repair, or other handling of the product may result in changes or loss of captured or downloaded image data. The Company is not liable for any damage or lost income resulting from recovery of these data.
- It is recommended you save the important data on your PC's hard disk, etc. Whatever the cause of the defect or malfunction may be, the Company assumes no responsibility for alteration or loss of saved data.
- Data saved in the product, such as contacts, and images/videos, might be altered or lost in accident, fault, repair or mishandling. Be sure to keep a copy of important contents. Note that the Company assumes no responsibility for any damages or lost profits resulting from altered or lost contents.
- Note that content data (whether paid or free) and other data stored in the product cannot be transferred when the product is replaced due to malfunction or repair.

8

- If the same image is displayed for a long time on the Organic EL display, if the display lighting is set to a brighter brightness than necessary, or if the display is used for an extremely long time, afterimages may appear, the brightness may decrease in parts, or the color may change. It is not abnormal because that is the characteristic of Organic EL display. To prevent afterimages and to save power consumption, we recommend setting the lighting time to a short time.
- Organic EL displays are made with highly advanced technology, but there may be some dots that do not light up or dots that are always lit. Also, depending on the viewing angle, you may see streaky color unevenness, uneven brightness, or color changes. These are due to the structure of the organic EL display and are not a malfunction. Please be aware of this in advance.
- Leaving the Organic EL display exposed to the direct sunlight might cause a fault. Take care when you place the product by the window or outside.
- It is recommended that you keep a copy of the photo/video data and music data stored in the product on your computer or cloud service, etc. Note, however, that some data, such as data with copyright protection, cannot be copied even by the above means.
- Do not dispose of this product together with regular household waste. Doing so may cause fires in garbage collection trucks or waste processing facilities and is extremely dangerous. This product (including optional accessories) can be collected at au Style / au shops and other authorized locations.

9

* "The Company" as appears in this manual refers to the telecommunications operator with whom you have a contract, as well as the following companies:
Imported by: SAMSUNG ELECTRONICS JAPAN Co., Ltd.
Manufactured by: Samsung Electronics Co., Ltd.

memo

- Reproduction of the content of this manual in part or in whole is prohibited.
- The content of this manual is subject to change without notice.
- Some functions of the product may become unavailable as a result of changes in OS specifications, changes or termination of services, etc.
- Every effort has been made in the preparation of this manual. In the unlikely event that you notice anything suspicious or omissions, please contact us.

10

Safety Precautions (Observe Strictly)




- Before using the product, read the precautions below to ensure safe use and handling.
- These precautions are intended to protect you and others around you. Read and follow them carefully to avoid injury, damage to the product or damage to property.
- The signs below differentiate between the levels of danger that can occur if the product is not used within the specified guidelines.

Danger	This sign denotes that "death or serious injury" ⁽¹⁾ may directly result from improper use".
Warning	This sign denotes that "death or serious injury" ⁽¹⁾ may result from improper use".
Caution	This sign denotes that "minor injury" ⁽²⁾ or property damage ⁽³⁾ to property may result from improper use".

- ¹ Serious injury: Loss of sight, injuries, burns (high/low temperature), electric shocks, bone fracture, poisoning, etc. with subsequent complications or those that require hospitalization or prolonged hospital visits.
² Minor injury: Injuries, burns (high/low temperature), electric shocks, etc. that do not require hospitalization or prolonged hospital visits.
³ Property damage: Severe damage to property or live stock/pets, etc.


11


■ Explanation of Prohibition and Mandatory graphical symbols used in this manual

	Indicates an action that is not allowed.
	Indicates that disassembly is not allowed.
	Indicates an action that must be obeyed at all times.


■ Precautions common to the product main unit, internal battery, charging equipment, nanoSIM card, S Pen (used only with the Galaxy S26 Ultra), accessory devices


Danger

 **Do not use, store, or leave the product in a place subject to high temperature or in places where heat builds up (such as close to fires or heating devices, inside kotatsu or bedding, under direct sunlight, or in a car on an extremely hot day).** May cause fire, burns, injuries or electric shocks, etc.


 **Do not place the product in or near microwave ovens, induction cookers or other heaters, pressure cookers or other high-pressure vessels.** May cause fire, burns, injuries or electric shocks, etc.


12


 **When using in some facilities such as gas station, follow the instructions from each facility.**
Do not charge in gas station, etc. When using the product in a gas station, etc., be careful not to drop it, and especially not while refueling. Ignition to flammable gas, etc. may cause explosion or fire, etc.

 **If abnormalities such as unusual odor, noise, smoke, heat, discoloration, or deformation are observed while using, charging, or storing the product, take safety precautions and perform the following operations.**
• Remove the power plug from the outlet.
• Turn the product OFF.
If the above operations are not performed, this may cause fire, burns, injuries or electric shocks, etc.


Caution


 **Do not use the product in a damaged condition.** May cause fire, burns, injuries, etc.


 **Do not place the product on an unstable surface, such as on a wobbly stand or on a tilted surface. Be especially careful when the product is in vibration mode.** May fall and cause injuries, etc.


 **Do not use or store the product in damp, dusty or hot areas.** May cause fire, burns, or electric shocks, etc. For waterproofness/dustproofness, please refer to the "取扱説明書 詳細版 (Full Instruction Manual)" (Japanese).


16

 **If you have weak heart, be careful when setting the vibrate ringtone (vibration) or ringtone volume setting.**
Surprised by sudden vibrate ringtone (vibration) or ringtone, it may cause harmful effect on heart.


 **When you use electronic medical equipment, check with the equipment manufacturer or distributor to determine how the equipment is affected by radio waves before using.**
Radio waves from the product may cause adverse effects on medical electrical equipment, etc.


 **When the display or camera lens is accidentally broken, be careful of broken parts or exposed internal parts of the product.**
Touching broken or exposed part may cause burns, injuries, electric shocks, etc.


 **Should the internal battery leak or emit a strange odor, stop using the product immediately and move it away from fire.** The leaked fluid may catch fire and may cause ignition or explosion, etc.


 **Take care to prevent pets and other animals from biting the product.** The internal battery may ignite, explode, generate heat or leak and may result in fire, burns, injuries, etc.


20


 **Do not put liquids (drinking water, sweat, seawater, pet urine, etc.) into the charging jack or the external connection terminal. Also, do not charge the product in places exposed to water such as in a bathroom or near a humidifier.** May cause fire, burns, injuries, electric shocks, etc. For waterproofness, please refer to the "取扱説明書 詳細版 (Full Instruction Manual)" (Japanese).

 **Do not apply strong pressure to the product or break it. Do not bump or pinch the product against objects, especially when carrying it in a clothing pocket.** Damage to the internal battery may cause fire, burns, or injury.
* Examples to avoid
- Sitting or squatting with the product put in the pocket of trousers or skirt
- Clipping the product to a door or car door with the product in a jacket pocket
- Stepping on the product on a soft object such as a sofa, bed, or bedding, or on the floor
- Inserting the product into the seat of a train, bus, or other seat


 **Do not attempt to disassemble or modify the product.** May cause fire, burns, injuries or electric shocks, etc.


 **Do not remove the internal battery in the product.** May cause fire, burns or injuries, etc.


 **Do not attempt to disassemble or modify the product.** May cause fire, burns, injuries or electric shocks, etc.

 **Do not remove the internal battery in the product.** May cause fire, burns or injuries, etc.

13


 **Children using the product should be instructed in proper operation by an adult. Make sure they use the product correctly.** May be accidentally swallowed, or cause injuries, electric shocks, etc.

 **Do not place the product within reach of infants or where pets can touch it. Please pay particular attention to the storage places for small parts such as nanoSIM card tray and SIM ejector tool (sample), etc.** May be accidentally swallowed, or cause injuries, electric shocks, etc.

 **Note that the temperature may become high when the product is used continuously or when the product is being charged. Also, be careful not to continuously touch the product by placing it in a pocket of your clothing or falling asleep.** The temperature of the product or charging equipment may become high during continuous use or charging, such as when using applications, making calls, communicating data, or watching videos. Continuous direct contact with high-temperature areas may cause skin redness, itching, rash, or low-temperature burns depending on your constitution or physical condition.


■ Main unit


Danger


 **Do not put the product in a fire or attempt to heat it.** May cause fire, burns or injuries, etc.


17

Caution


 **For using a motion sensor, check the safety around, hold the product and do not swing it more than necessary.** May cause injuries, etc.


 **If the display is damaged and internal substance leaks out, do not make the substance contact with your skin of face or hands, clothes, etc.** May cause eyes or skin problems, etc. If the substance gets into your eyes or mouth, etc. or comes into contact with your skin or clothes, rinse with clean water immediately. And if it gets into your eyes or mouth, etc., rinse with clean water and seek medical care immediately.

 **Do not dispose of the product with regular trash.** May cause fire, burns, injuries, etc. Environmental damage may also be caused. If the product becomes no longer needed, follow the instructions given by the collecting municipalities.


 **If material inside the internal battery leaks, do not get it on your face, hands, or other skin or clothing.** May cause eyes or skin problems, etc. If material inside the internal battery gets into your eyes or mouth, or on your skin or clothing, rinse immediately with clean water. And if it gets into your eyes or mouth, etc., rinse with clean water and seek medical care immediately.


21


 **The rear cover of the product cannot be removed. Do not attempt to remove it. Also, do not attempt to remove the rear cover or force it into the product if the product is swollen caused by a swollen internal battery or other reason. Doing so may cause fire, burns, or injury.**

 **Use the optional equipment specified by the Company for the product.** If you use something other than the specified equipment, or if the manufacturer, distributor, or specifications are unclear, then doing so may cause fire, burns, injuries or electric shocks, etc.


Warning


 **Do not subject the product to strong forces, impacts or vibration such as dropping, stepping on, or throwing it, etc.** May cause fire, burns, injuries or electric shocks, etc.

 **Do not allow conductive foreign objects (metal pieces, pencil lead, etc.) to come into contact with the charging jack or external connection terminals, and do not allow dust or sand to get inside the product.** May cause fire, burns, injuries or electric shocks, etc.


 **Do not stick metal objects (such as stickers, straps and clips that contain metal) on the wireless charger (sold separately) or the product also do not place them between the wireless charger (sold separately) and the product.** May cause fire, burns or injuries, etc.


14


 **Do not puncture with a sharp object (nail, etc.), strike with a hard object (hammer, etc.), stomp on, or apply excessive force on the product.** May cause fire, burns or injuries, etc.

 **If the substance inside the product gets into your eyes or mouth, etc., rinse with clean water and receive medical care from a doctor immediately.** The substance inside the product may cause loss of sight or poor health, etc.


Warning


 **Do not turn on or emit light with the light emitting part of the flash/light close to a person's eyes. In particular, keep a sufficient distance away from infants.** This can cause vision problems. It may also cause dizzy or startled eyes, which may result in injury.


 **Do not look at a flashing screen for a long time.** May cause seizure or loss of consciousness, etc.


 **Do not put liquids (drinking water, sweat, seawater, pet urine, etc.) or foreign objects such as metal fragments (such as cutter blades or stapler needle) and flammable materials into nanoSIM card slot and S Pen slot (used only with the Galaxy S26 Ultra). Please do not insert the nanoSIM card in the wrong place or in the wrong direction.** May cause fire, burns, injuries or electric shocks, etc.


18

 **When removing a nanoSIM card, be careful of the tip of the SIM ejector tool (sample) to avoid damaging fingers or other body parts.** Touching the tip of the SIM ejector tool (sample) may cause injuries, etc.


 **To use the product in a car, check with the automobile manufacturer or dealer to determine how the product is affected by radio waves before using.** In some vehicle models, radio waves from the product may cause adverse effects on in-vehicle electronic equipment, in which case, stop using the product immediately.


 **If you develop skin problems, stop using the product immediately, and see a doctor.** Itching, rashes, eczema, etc. sometimes occurs depending on your physical constitution and condition. For information on the materials of the product and the packaged items, please refer to the "取扱説明書 詳細版 (Full Instruction Manual)" (Japanese).

 **Be sure to check that there are no metal fragments (such as cutter blades or stapler needle) adhered to the magnetic parts used in the speaker, front camera, rear camera and vibrator, etc. of the product.** Adhesion of such fragments may cause injuries, etc.


 **When watching the display, take a certain distance from the display in a fully bright place.** Watching the display in the dark or watching too close may cause diminished eyesight, etc.


22

 **When charging with the wireless charger (sold separately), remove the cover, etc. with which the product is equipped.** The cover material, thickness, or foreign matter such as dust caught between the product and the cover may prevent proper charging, resulting in fire, burns, or injury.


 **Turn the product OFF near high-precision electronic control equipment or electronic equipment using low-power signals.** Failure to do so may cause the equipment to fail or malfunction.


* Examples of electronic equipment to avoid
Hearing aids, implanted pacemakers or defibrillators, other electronic medical and other automatic control equipment, etc. Users wearing implanted pacemakers or defibrillators or other electronic medical equipment should check with the manufacturer or sales outlet about the effect of radio wave on the equipment.


 **If charging is not completed after the specified charging time, stop charging.** Overcharging, etc. may cause fire, burns or injuries, etc.


 **Turn the product OFF and stop charging before entering a place where there is a possibility of flammable gases being generated or where there is a possibility of dust being generated.** Ignition to flammable gas, etc. may cause explosion or fire, etc.

15

 **Do not expose the camera lens to direct sunlight, etc. for a long time.** The light-gathering capabilities of the lens may cause fire, burns, injuries, etc.

 **When boarding an airplane, turn the product OFF or turn airplane mode ON.** Follow the instructions of the respective airlines as there are restrictions on the use of these items on board the aircraft. Radio waves from the product may cause adverse effects on aircraft electronics. Prohibited acts in the use of the product on board an aircraft may be punishable by law.

 **When using the product in a medical facility, follow the instructions of the facility.** Turn the product OFF in areas where use is prohibited. Radio waves from the product may cause adverse effects on electronic and medical electrical equipment.


 **Always move the product away from your ear when making a call with the handsfree setting, when a loud ringtone is sounding, or when waiting for a call.** In addition, when plugging in the earphones/microphone, etc. into the product, and playing games, videos or music, etc., set the volume to a moderate volume. When set to handsfree and talking, the product emits a loud sound. Even in the standby mode, ringtone and vibrator may work suddenly. Using continuously for a long time with too loud volume may cause a hearing loss, etc. And, accidents can also occur when the volume is too loud, making it difficult to hear surrounding sounds.

19

■ **Charging equipment**
For more information on safety precautions for charging equipment, please refer to the "取扱説明書 詳細版 (Full Instruction Manual)" (Japanese).


■ nanoSIM card

Caution

 **Be careful of the cut surface so as not to injure fingers or other body parts when handling nanoSIM card.** The cut surface may be sharp, which may cause injuries, etc.

■ Use of the product near medical equipment and inside a medical facility

Warning

 **Wearers of the electronic medical equipment such as implanted pacemakers or defibrillators must carry and use the product at least 15 cm away from the implanted device.** Radio waves from the product may cause adverse effects on the operation of medical electrical equipment. If there is a risk that you may be unable to move freely, or that you may be within 15 cm of people around you, please switch the product to a state that does not emit radio waves (e.g., Airplane mode or power off) before you use it.

23

Do When electronic medical equipment other than implanted pacemakers or defibrillators are in use outside of medical facilities such as in home care settings, check with the device manufacturer to determine how the device is affected by electrical signals. Radio waves from the product may cause adverse effects on the operation of medical electrical equipment.

Do When using the product in a medical facility, be sure to observe the regulations of the facility. Radio waves from the product may cause adverse effects on the operation of medical electrical equipment.

S Pen (used only with the Galaxy S26 Ultra)

Warning

Don't Do not point S Pen toward others. May cause injuries or loss of sight, etc.

Caution

Don't Do not swing the product around by holding the S Pen when the S Pen is not fully inserted into the S Pen slot (when S Pen is protruding from the S Pen slot). May cause accident such as injuries, etc.

24

Internal battery

Li-ion00 (The internal battery of the product is a lithium-ion battery) The internal battery is not fully charged at the time of purchase. Charge the battery before using the product.

Other Notes

For more information on "Notes on using Bluetooth®/Wireless LAN (Wi-Fi) Functions", "Notes on Data Communication Charge", "Notes on Call Charge", and "Take Your Manners with You as Well", please refer to the "取扱説明書 詳細版 (Full Instruction Manual)" (Japanese).

After-Sales Service

When asking for repair

For repair, please contact the Repair and Delivery Support Center.

During the warranty period	Repairs will be done after determining whether it is free or paid, based on the terms of services of the free-of-charge repair warranty described.
Outside the warranty period	We shall repair the product for a charge as requested by the customer if repair renders it usable.

* The warranty is valid for one year from the day that you first buy the product.

28

Intellectual Property Rights

Trademarks

The company names and product names appearing in this manual are trademarks or registered trademarks of their respective holders.

- iWnn of OMRON SOFTWARE Co., Ltd. is used for conversion methods. iWnn® OMRON SOFTWARE Co., Ltd. 2008-2026 All Rights Reserved.
- All other company names and product names are trademarks or registered trademarks of respective companies referred to in this manual.

When getting a malfunction...

Repair and Delivery Support (7 days a week / Toll free)

Troubleshooting reception (Business hours 9:00 - 20:00)

0120-925-919

やめましょう、歩きスマホ。 **あぶない！** 電池への衝撃

キケン！ 水ぬれ充電

Collect and recycle unused telephones, batteries and battery chargers at stores bearing the ♻️ logo regardless of brand and manufacturer to protect the environment and reuse valuable resources.

32

Do If you develop skin problems, stop using S Pen immediately, and see a doctor. Itching, rashes, eczema, etc. sometimes occurs depending on your physical constitution and condition. For information on the materials of the product and the packaged items, please refer to the "取扱説明書 詳細版 (Full Instruction Manual)" (Japanese).

SIM ejector tool (sample)

Warning

Don't The tip of the SIM ejector tool (sample) is sharp. Do not use the SIM ejector tool (sample) against yourself or others. Doing so might hit yourself or other people resulting in injuries or loss of sight.

Caution

Do If you experience any skin problems as a result of using the SIM ejector tool (sample), stop using it immediately and seek medical attention. Itching, rashes, eczema, etc. sometimes occurs depending on your physical constitution and condition. For information on the materials of the product and the packaged items, please refer to the "取扱説明書 詳細版 (Full Instruction Manual)" (Japanese).

25

- Before handing in the product for repair, make a backup of the contents of storage since they may disappear during repair. Note that the Company shall not be liable for any damages and loss of income should the contents of storage be altered or lost.
- Recycled parts that meet the Company's quality standards are sometimes used for repair.
- Mechanical parts replaced by the after-sales service are collected and recycled by our company. Therefore, they cannot be returned to customers.
- The product which is processed, remodeled, analyzed (including by modifying or analyzing the software (including by rooting etc.), reverse engineering, decompiling), or repaired by an unauthorized repair office is not covered by the warranty and repair may be refused.
- The battery in the product is the consumable items and are not covered by the warranty.
- Accessories (for Galaxy S26 Ultra, except for the S Pen) and samples other than the product main unit are not covered by the free-of-charge repairs warranty.

Performance parts for repair

The Company retains performance parts for repair of the product main unit and S Pen (used only with the Galaxy S26 Ultra) for four years after discontinuation of production. "Performance parts for repair" refers to parts required for maintaining the functions of the product.

Free-of-charge repair warranty

- When you contact the repairs help desk, have the serial number (IMEI number) ready. You can find the serial number (IMEI number) on the product or on a sticker attached the box the product is sold in.

29

<For customers with au contracts> au Support

App/Website

- My au app**
This app allows you to easily check your monthly bill, data usage (giga), contract information, points, etc. All procedures and inquiries can be handled smoothly.
My au app icon, QR code, URL: <https://kddi-jp/mFH> (Japanese)
- au Support (web)**
There are various support information that will be useful when you are in trouble.
URL: <https://kddi-jp/3y0> (Japanese)
- Chat**
Consultation is easy anytime, anywhere via chat! AI will respond quickly 24 hours a day, and communicator will respond in detail.
URL: <https://kddi-jp/Q3e> (Japanese)

26

Do Store the SIM ejector tool (sample) in a place where babies and infants or pets cannot reach. If it is accidentally swallowed, it might result in suffocation or injuries, etc.

USB cable (CtoC) (sample)

Caution

Do If you experience any skin problems as a result of using the USB cable (CtoC) (sample), stop using it immediately and seek medical attention. Itching, rashes, eczema, etc. sometimes occurs depending on your physical constitution and condition. For information on the materials of the product and the packaged items, please refer to the "取扱説明書 詳細版 (Full Instruction Manual)" (Japanese).

- If the product malfunctions during the warranty period and during normal use that follows the precautions listed in the instruction manual, the Company will repair the product for free.
- Repairs will not be free of charge in the following cases, even during the warranty period. (Or repair may not be possible.)
 - If you did not follow the instruction manual and use the product correctly.
 - If the product broke or was damaged by unauthorized repairs or modifications.
 - If you had the product repaired at a facility that is not an authorized repair facility as designated by the Company.
 - If the product breaks or is damaged because of an accident or your own negligence when you are using or handling the product. Alternatively, there are indications that the product was dropped, got wet, damp, or the like.
 - If the product breaks or is damaged because of natural disasters, such as earthquakes, wind and flood damage, fire, damage from salt, or abnormal voltage.
- Depending on how damaged the product is, repair may not be possible.
- The Company assumes no responsibility for any damages or lost profits incurred as a result of the failure of the product's equipment.
- The Company assumes no responsibility if an accident occurs in the event that you connect a device that is not designed to be used with the product.
- The company does not offer on-site repairs.
- This warranty is valid only in Japan.

* This warranty guarantees free repair based on the period and conditions listed above. Therefore, customers' legal rights against the issuer of this warranty and other business are not restricted by this warranty.

30

<For customers with UQ mobile contracts> UQ mobile Support

App/Website

- My UQ mobile app**
This app allows you to easily check your monthly bill, data usage (giga), contract information, points, etc. All procedures and inquiries can be handled smoothly.
My UQ mobile app icon, QR code, URL: <https://kddi-jp/F3Z> (Japanese)
- UQ mobile Support (web)**
There are various support information that will be useful when you are in trouble.
URL: <https://kddi-jp/DHC> (Japanese)
- Chat**
Consultation is easy anytime, anywhere via chat! AI will respond quickly 24 hours a day, and communicator will respond in detail.
URL: <https://kddi-jp/NZJ> (Japanese)

Handling Precautions

The following precautions are the main items that provided to prevent the product from getting a malfunction and to ensure that performance can be fully demonstrated. Thoroughly read these precautions to ensure correct use. For details, please refer to the "取扱説明書 詳細版 (Full Instruction Manual)" (Japanese).

Main unit

- The battery for the product is built-in and cannot be replaced by yourself. Please contact the "Inquiries" in the end of this manual to replace the battery.
- Never use modified product. Use of a modified device violates the Radio Law and the Telecommunications Business Act. The product is compliant with the regulations regarding the technical standard conformance of specified wireless equipment based on the Radio Law and the regulations regarding the technology regulatory compliance of terminal device based on the Telecommunications Business Act. As proof of this, the "Technical Conformity Mark" is indicated in the product.

How to confirm: On the home screen, flick up → [Settings] → [About phone] → [Regulatory information]

If the modifications are made to the internal components, the certification of technical standard conformance and the certification of technology regulatory compliance will become not valid. Never use the product without the valid certification. Doing so violates the Radio Law and the Telecommunications Business Act.

27

Repair and Delivery Support Wide with Cloud

To ensure long-term reliable use of au/UQ mobile devices, we offer a monthly membership after-sales service program called "Repair and Delivery Support Wide with Cloud". This is a service that extends coverage for all kinds of problems, including breakdown, theft, and loss. For details of monthly usage fee and services, refer to the au/UQ mobile website.

- For customers with au contracts <https://www.au.com/mobile/service/kosho-funshitsu-wide-cloud/> (Japanese)
- For customers with UQ mobile contracts <https://www.uqwimax.jp/mobile/plan/option/repair-wide-cloud/> (Japanese)
- * Service contents are subject to change without notice.

nanoSIM card

The nanoSIM card is lent to you by contracted carrier. In case of loss or damage, the card will be replaced at your expense. When malfunction is suspected, or in case of theft or loss, contact the "Inquiries" in the end of this manual.

FCC RF Exposure Information

The product has been certified of Federal Communications Consortium (FCC). For details, please refer to the "取扱説明書 詳細版(Full Instruction Manual)" (Japanese).

Export Administration Regulations

The product and its accessories may be subject to the Japan Export Administration Regulations ("Foreign Exchange and Foreign Trade Law" and its related laws). For details, please refer to the "取扱説明書 詳細版 (Full Instruction Manual)" (Japanese).

31