

OPPO Reno7 A

OPG04

Quick Start Guide



Using Online Manual (Japanese)

For detailed description on various functions, scan the QR code on the right side or use the "オンラインマニュアル (Online Manual)" (Japanese) on the product with the following operations.



From the Home screen, [Tools]→

[取扱説明書][Online Manual] (Japanese)

やめましょう、
歩きスマホ。

あぶない！
電池への衝撃



Cell phone and PHS operators collect and recycle unused telephones, batteries and battery chargers at stores bearing the ♻️ logo regardless of brand and manufacturer to protect the environment and reuse valuable resources.

キケン！
水ぬれ充電

Imported by: OGA Japan K.K.

Manufactured by: Guangdong OPPO Mobile Telecommunications Corp., Ltd.

July 2022, 1st Edition


List of packaged items

- Main unit (Protective film (sample) attached)
- SIM ejector pin (sample)
- Protective case (sample)
- クイックスタートガイド (Quick Start Guide) (Japanese)
- ご利用にあたっての注意事項 (Notes on Usage) (Japanese)

memo

- Purchase the specified charging equipment (sold separately).
- The battery is built into the product.
- Illustrations of bundled accessories and the product used in this manual are just images for explanations. They may be different from actual ones.

Attaching SIM card



Turning the power on

- 1 Press and hold the Power button/Screen-lock button for at least 2 seconds





— Power button/Screen-lock button

memo

- If the power cannot be turned off in a regular way or the screen freezes, press and hold the Power button/Screen-lock button and the volume button (up) for at least 10 seconds at the same time to forcibly restart.

Names of parts



- ① Receiver¹
- ② Proximity sensor/Light sensor²
- ③ In-camera
- ④ Display (touch panel)
- ⑤ On-screen fingerprint sensor
- ⑥ Flashlight
- ⑦ 5G antenna³
- ⑧ 4G/5G antenna³
- ⑨ GPS/Wi-Fi[®]/Bluetooth[®] antenna³
- ⑩ Out-camera
- ⑪ NFC detector area
- ⑫ Rear cover⁴
- ⑬ SIM card/microSD memory card tray
- ⑭ Hole for tray removal
- ⑮ Volume button (up/down)
- ⑯ Power button/Screen-lock button
- ⑰ Sub-microphone¹
- ⑱ Earphone jack¹
- ⑲ Mouthpiece/Main microphone¹

⑳ USB Type-C connection jack (external connection jack)

㉑ Speaker¹

- ¹ Be careful not to cover with your finger etc. while using the corresponding function. Do not insert the SIM ejector pin (sample) in a wrong way because it may cause damage.
- ² Do not cover with a sticker etc. Functions may not work properly.
- ³ The antenna is built into the main unit. Covering the antenna area with your hand may affect quality of call/communication.
- ⁴ The rear cover cannot be removed. Attempting to remove it forcibly may cause a damage or malfunction. Also, the battery is built into the main unit and you cannot take out it by yourself.

- Refer to "Notes on Usage" for disclaimers.
- For the latest contents of this manual, refer to the "取扱説明書 詳細版 (Instruction Manual)" (Japanese) on the homepage of your mobile carrier.
- The descriptions may be different from those in this manual due to software version upgrade of the product, change/termination of services. Also, the content of this manual is subject to change without notice.