


Galaxy A23 5G


SCG18


Quick Start Guide

 やめましょう、
歩きスマホ。

 あぶない！
電池への衝撃

 キケン！
水ぬれ充電


E141414 リサイクルネットワーク
環境と資源の持続可能な利用のために。

Cell phone and PHS operators collect and recycle unused telephones, batteries and battery chargers at stores bearing the  logo regardless of brand and manufacturer to protect the environment and reuse valuable resources.

November 2022, 1st Edition
Imported by: SAMSUNG ELECTRONICS JAPAN Co., Ltd.
Manufactured by: Samsung Electronics Co., Ltd.

List of Packaged Items


- Main unit
- SIM card removal tool (sample)
- クイックスタートガイド (Quick Start Guide) (Japanese)
- ご利用にあたっての注意事項 (Notes on Usage) (Japanese)




memo


- Please use specified charging equipment (sold separately).
- The battery is built into the product.
- Illustrations used in this manual are just images for explanations. They may be different from the actual ones.

Attaching the SIM card




Turning the Power On


- 1 Press and hold  (Side key)/Fingerprint recognition sensor for over 2 seconds




- 2 Swipe the screen up and down, left and right to unlock the screen



memo

- When the product is turned on for the first time, the initial setting screen appears.
- If you have set a screen unlock method, unlock the screen using the method you have set.
- Press and hold  (Side key)/Fingerprint recognition sensor and lower side of Volume key simultaneously for over 7 seconds, when the power cannot be turned off in the usual way or the screen freezes.

Names of Parts



- ① Mouthpiece/Microphone (upper)^{*1}
- ② Headset connection terminal
- ③ SIM card/microSD memory card tray
- ④ Tray eject hole
- ⑤ Front camera
- ⑥ Display (touch panel)
- ⑦ Receiver^{*1}
- ⑧ Proximity sensor^{*2}
- ⑨ Volume key
- ⑩ || (Side key)/Fingerprint recognition sensor^{*2}
- ⑪ Mouthpiece/Microphone (lower)^{*1}
- ⑫ USB Type-C[®] connection terminal (external connection terminal)
- ⑬ Speaker^{*1}
- ⑭ Rear camera
- ⑮ Flash/Light
- ⑯ ↻ mark

^{*1} Be careful to not cover over with your fingers, etc. Related functions may not work properly. In addition, do not insert the SIM card removal tool (sample) into the product since this might cause damage.

^{*2} Do not cover the product with stickers or other materials. Functions may not work correctly.

memo

- ◎ The antenna is built into the main unit. For the antenna position, please refer to the "取扱説明書 詳細版 (Full Instruction Manual)" (Japanese), available on the website of the contracted carrier.

- For the latest information, please refer to the "取扱説明書 詳細版 (Full Instruction Manual)" (Japanese), available on the website of the contracted carrier.
- For the latest information on the product, refer to the following website.
<https://www.galaxymobile.jp/> (Japanese)
- The contents described in this manual may be different due to the version upgrade of the software of this product or the change / end of service. And the contents of this manual are subject to change without notice.
- Reproduction of the content of this manual in part or in whole is prohibited.
- Every effort has been made in the preparation of this manual. Should you notice any unclear points, omissions, etc., feel free to contact us.