


Galaxy Tab S9 FE+ 5G

SCT22

Basic Manual

"オンラインマニュアル (Online Manual)" (Japanese)



For detailed descriptions on various functions, scan the QR code on the right or use the "オンラインマニュアル (Online Manual)" (Japanese) on your product with the following operations.

On the home screen, flick up → [Samsung] → [取扱説明書 (Online Manual)]

• Please keep the software up-to-date. For details on how to update the software, please refer to the "取扱説明書 詳細版 (Full Instruction Manual)" (Japanese) on the website of the contracted carrier.

• For the latest information, please refer to the "取扱説明書 詳細版 (Full Instruction Manual)" (Japanese) on the website of the contracted carrier.

• For the latest information on the product, refer to the following website: <https://www.samsung.com/jp/> (Japanese)

• The software of the product may differ from the information in this guide depending on version upgrades, service changes, or termination. The contents of this manual are subject to change without notice in the future.

• In this manual, "Galaxy Tab S9 FE+ 5G" is usually referred to as "the product".

• Company names and product names referred to in this manual are trademarks or registered trademarks of respective companies. The TM and ® marks may be omitted in this manual.

• The Company is not liable for any damages or lost profits caused by natural disasters such as earthquakes, lightning, storms, floods, as well as fires, actions by third parties, other accidents, intentional or mistaken operation by the customer, or use under other unusual conditions outside the responsibility of the Company.

• The Company is not liable for any incidental damages (change/disappearance of saved content, loss of business income, disruption of business, etc.) arising from use of or inability to use the product.

• The Company is not liable for any damages or lost profits resulting from failure to observe the described content of "取扱説明書 詳細版 (Full Instruction Manual)" (Japanese), "Basic Manual" (this manual), or information such as positioning data obtained by the measurement sensor and GPS of the product is only a guide and cannot be used for purposes that require a high degree of reliability. Note that the Company assumes no responsibility for any damages or lost profits resulting from positioning errors.

• The Company is not liable for any damages or lost profits resulting, for example, from malfunctions caused by combination with connected devices or software not related to the Company.

• Malfunction, repair, or other handling of the product may result in changes or loss of captured or downloaded image data. The Company is not liable for any damage or lost income resulting from recovery of these data.

• It is recommended you save the important data on your PC's hard disk, etc. Whatever the cause of the defect or malfunction may be, the Company assumes no responsibility for alteration or loss of saved data.

• Data saved in the product, such as contacts, and images/videos, might be altered or lost in accident, fault, repair or mishandling. Be sure to keep a copy of important contents. Note that the Company assumes no responsibility for any damages or lost profits resulting from altered or lost contents.

• Note that product replacement for failure repair or other reasons will not retain any content data (whether paid or free) or other data stored in the product.

• The product uses an LCD for the display. The display response speed may slow down at low temperatures, but this is due to the nature of the liquid crystal and is not a malfunction. It will return to normal when the temperature returns to normal.

• Although the display used by the product is made using high precision technology, some pixels (dots) might not light or are lit at all times. Please note that this is not a fault.

• It is recommended that you keep a copy of the photo/video data and music data stored in the product on your computer or cloud service, etc. Note, however, that some data, such as data with copyright protection, cannot be copied even by the above means.

• Do not discard the product together with regular trash. Please cooperate in the collection of the product (including optional accessories) when it is no longer needed to protect the environment and effectively use resources.

• "The Company" as appears in this manual refers to the following companies:
Sold by: Contracted Carrier
Imported by: SAMSUNG ELECTRONICS JAPAN Co., Ltd.
Manufactured by: Samsung Electronics Co., Ltd.

• The rear cover of the product cannot be removed. Do not attempt to remove it. Also, do not attempt to remove the rear cover or force it into the product if the product is swollen caused by a swollen internal battery or other reason. Doing so may cause fire, burns, or injury.

• Do not let the product get wet with liquids (drinking water, sweat, seawater, pet urine, etc.). May cause fire, burns, injuries or electric shocks, etc. For waterproofness, refer to the following: ▶P.42 "Precautions for Waterproofness/Dustproofness"

• Do not put liquids (drinking water, sweat, seawater, pet urine, etc.) into the charging jack, the external connection terminal or pogo pin. May cause fire, burns, injuries or electric shocks, etc. For waterproofness/dustproofness, refer to the following: ▶P.42 "Precautions for Waterproofness/Dustproofness"

• Use the optional equipment specified by the Company for the product. If you use something other than the specified equipment, or if the manufacturer, distributor, or specifications are unclear, then doing so may cause fire, burns, injuries or electric shocks, etc.

• When notification sound is sounding loudly or during standby, keep the product away from your ear. And, when connecting the headphones/microphone, etc. to the product and play a game, video or music, etc. adjust the volume moderately. Sudden notification or alarm tones may sound even when the product is in standby mode. Using continuously for a long time with too loud volume may cause a hearing loss, etc. And, accidents can also occur when the volume is too loud, making it difficult to hear surrounding sounds.

• If you have weak heart, be careful when setting the vibrate notification sound (vibration) or notification sound volume setting. Surprised by sudden vibrate notification sound (vibration) or notification sound, it may cause harmful effect on heart.

• Turn the product OFF near high-precision electronic control equipment or electronic equipment using low-power signals. Failure to do so may cause the equipment to fail or malfunction. * Examples of electronic equipment to avoid: Hearing aids, implanted pacemakers or defibrillators, other electronic medical and other automatic control equipment, etc. Users wearing implanted pacemakers or defibrillators or other electronic medical equipment should check with the manufacturer or sales outlet about the effect of radio wave on the equipment.

• When you use electronic medical equipment, check with the equipment manufacturer or distributor to determine how the equipment is affected by radio waves before using. The product's signals may affect the performance of electronic medical equipment.

• When the display or camera lens is accidentally broken, be careful of broken parts or exposed internal parts of the product. Touching broken or exposed part may cause burns, injuries, electric shocks, etc.

• If the internal battery leaks or smells strange, stop using it immediately and keep it away from fire. The leaked fluid may catch fire and may cause ignition or explosion, etc.

• Be careful to prevent pets and other animals from biting the product. The internal battery may ignite, explode, generate heat or leak and may result in fire, burns, injuries, etc.

• For using a motion sensor, check the safety around, hold the product and do not swing it more than necessary. May cause injuries, etc.

• If the display is damaged and internal substance leaks out, do not make the substance contact with your skin of face or hands, clothes, etc. May cause eyes or skin problems, etc. If the substance gets into your eyes or mouth, etc. or comes into contact with your skin or clothes, rinse with clean water immediately. And if it gets into your eyes or mouth, etc., rinse with clean water and seek medical care immediately.

• Do not dispose of the product with general waste. May cause fire, burns, injuries, etc. Environmental damage may also be caused. If the product becomes no longer needed, follow the instructions given by the collecting municipalities.

• Be sure to check that there are no metal fragments (such as cutter blades or staples) adhered to the magnetic parts used in the speaker, front camera, rear camera, vibrator and magnet part, etc. of the product. Adhesion of such fragments may cause injuries, etc.

• When watching the display, take a certain distance from the display in a fully bright place. Watching the display in the dark or watching too close may cause diminished eyesight, etc.

• Do not pull or place a heavy object on the power cord of the specified charging equipment (sold separately). May cause fire, burns or electric shocks, etc.

• Do not connect the voltage converter (travel converter for overseas travel, etc.) to the specified charging equipment (sold separately). May cause ignite, heat or electric shocks, etc.

• Do not use the specified charging equipment (sold separately) code if it gets damaged. May cause fire, burns or electric shocks, etc.

• If you hear thunder, do not touch the specified charging equipment (sold separately). May cause electric shocks, etc.

• Do not short the charging jack while it is connected to the outlet. Do not touch the charging jack with a part of your body such as your hand or finger. May cause fire, burns or electric shocks, etc.

• Do not pull or place a heavy object on the power cord of the specified charging equipment (sold separately). May cause fire, burns or electric shocks, etc.

• When plugging or unplugging the specified charging device (sold separately) into the outlet, do not allow metal objects to come into contact with it. May cause fire, burns or electric shocks, etc.

• Do not connect the voltage converter (travel converter for overseas travel, etc.) to the specified charging equipment (sold separately). May cause ignite, heat or electric shocks, etc.

• Do not use the specified charging equipment (sold separately) code if it gets damaged. May cause fire, burns or electric shocks, etc.

• If you hear thunder, do not touch the specified charging equipment (sold separately). May cause electric shocks, etc.

• Do not short the charging jack while it is connected to the outlet. Do not touch the charging jack with a part of your body such as your hand or finger. May cause fire, burns or electric shocks, etc.

• Do not pull or place a heavy object on the power cord of the specified charging equipment (sold separately). May cause fire, burns or electric shocks, etc.

• When plugging or unplugging the specified charging device (sold separately) into the outlet, do not allow metal objects to come into contact with it. May cause fire, burns or electric shocks, etc.

• Do not connect the voltage converter (travel converter for overseas travel, etc.) to the specified charging equipment (sold separately). May cause ignite, heat or electric shocks, etc.

• Do not use the specified charging equipment (sold separately) code if it gets damaged. May cause fire, burns or electric shocks, etc.

• If you hear thunder, do not touch the specified charging equipment (sold separately). May cause electric shocks, etc.

• Do not short the charging jack while it is connected to the outlet. Do not touch the charging jack with a part of your body such as your hand or finger. May cause fire, burns or electric shocks, etc.

• Do not pull or place a heavy object on the power cord of the specified charging equipment (sold separately). May cause fire, burns or electric shocks, etc.

• When plugging or unplugging the specified charging device (sold separately) into the outlet, do not allow metal objects to come into contact with it. May cause fire, burns or electric shocks, etc.

• Do not connect the voltage converter (travel converter for overseas travel, etc.) to the specified charging equipment (sold separately). May cause ignite, heat or electric shocks, etc.

• Do not use the specified charging equipment (sold separately) code if it gets damaged. May cause fire, burns or electric shocks, etc.

• If you hear thunder, do not touch the specified charging equipment (sold separately). May cause electric shocks, etc.

• Do not short the charging jack while it is connected to the outlet. Do not touch the charging jack with a part of your body such as your hand or finger. May cause fire, burns or electric shocks, etc.

• Do not pull or place a heavy object on the power cord of the specified charging equipment (sold separately). May cause fire, burns or electric shocks, etc.

• When plugging or unplugging the specified charging device (sold separately) into the outlet, do not allow metal objects to come into contact with it. May cause fire, burns or electric shocks, etc.

• Do not connect the voltage converter (travel converter for overseas travel, etc.) to the specified charging equipment (sold separately). May cause ignite, heat or electric shocks, etc.

• Do not use the specified charging equipment (sold separately) code if it gets damaged. May cause fire, burns or electric shocks, etc.

• If you hear thunder, do not touch the specified charging equipment (sold separately). May cause electric shocks, etc.

• Do not short the charging jack while it is connected to the outlet. Do not touch the charging jack with a part of your body such as your hand or finger. May cause fire, burns or electric shocks, etc.

• Do not pull or place a heavy object on the power cord of the specified charging equipment (sold separately). May cause fire, burns or electric shocks, etc.

• When plugging or unplugging the specified charging device (sold separately) into the outlet, do not allow metal objects to come into contact with it. May cause fire, burns or electric shocks, etc.

• Do not connect the voltage converter (travel converter for overseas travel, etc.) to the specified charging equipment (sold separately). May cause ignite, heat or electric shocks, etc.

• Do not use the specified charging equipment (sold separately) code if it gets damaged. May cause fire, burns or electric shocks, etc.

• If you hear thunder, do not touch the specified charging equipment (sold separately). May cause electric shocks, etc.

• Do not short the charging jack while it is connected to the outlet. Do not touch the charging jack with a part of your body such as your hand or finger. May cause fire, burns or electric shocks, etc.

• Do not pull or place a heavy object on the power cord of the specified charging equipment (sold separately). May cause fire, burns or electric shocks, etc.

• When plugging or unplugging the specified charging device (sold separately) into the outlet, do not allow metal objects to come into contact with it. May cause fire, burns or electric shocks, etc.

• Do not connect the voltage converter (travel converter for overseas travel, etc.) to the specified charging equipment (sold separately). May cause ignite, heat or electric shocks, etc.

• Do not use the specified charging equipment (sold separately) code if it gets damaged. May cause fire, burns or electric shocks, etc.

• If you hear thunder, do not touch the specified charging equipment (sold separately). May cause electric shocks, etc.

• Do not short the charging jack while it is connected to the outlet. Do not touch the charging jack with a part of your body such as your hand or finger. May cause fire, burns or electric shocks, etc.

• Do not pull or place a heavy object on the power cord of the specified charging equipment (sold separately). May cause fire, burns or electric shocks, etc.

• When plugging or unplugging the specified charging device (sold separately) into the outlet, do not allow metal objects to come into contact with it. May cause fire, burns or electric shocks, etc.

• Do not connect the voltage converter (travel converter for overseas travel, etc.) to the specified charging equipment (sold separately). May cause ignite, heat or electric shocks, etc.

• Do not use the specified charging equipment (sold separately) code if it gets damaged. May cause fire, burns or electric shocks, etc.

• If you hear thunder, do not touch the specified charging equipment (sold separately). May cause electric shocks, etc.

• Do not short the charging jack while it is connected to the outlet. Do not touch the charging jack with a part of your body such as your hand or finger. May cause fire, burns or electric shocks, etc.

• Do not pull or place a heavy object on the power cord of the specified charging equipment (sold separately). May cause fire, burns or electric shocks, etc.

• When plugging or unplugging the specified charging device (sold separately) into the outlet, do not allow metal objects to come into contact with it. May cause fire, burns or electric shocks, etc.

• Do not connect the voltage converter (travel converter for overseas travel, etc.) to the specified charging equipment (sold separately). May cause ignite, heat or electric shocks, etc.

• Do not use the specified charging equipment (sold separately) code if it gets damaged. May cause fire, burns or electric shocks, etc.

• If you hear thunder, do not touch the specified charging equipment (sold separately). May cause electric shocks, etc.

• Do not short the charging jack while it is connected to the outlet. Do not touch the charging jack with a part of your body such as your hand or finger. May cause fire, burns or electric shocks, etc.

• Do not pull or place a heavy object on the power cord of the specified charging equipment (sold separately). May cause fire, burns or electric shocks, etc.

• When plugging or unplugging the specified charging device (sold separately) into the outlet, do not allow metal objects to come into contact with it. May cause fire, burns or electric shocks, etc.

• Do not connect the voltage converter (travel converter for overseas travel, etc.) to the specified charging equipment (sold separately). May cause ignite, heat or electric shocks, etc.

• Do not use the specified charging equipment (sold separately) code if it gets damaged. May cause fire, burns or electric shocks, etc.

• If you hear thunder, do not touch the specified charging equipment (sold separately). May cause electric shocks, etc.

• Do not short the charging jack while it is connected to the outlet. Do not touch the charging jack with a part of your body such as your hand or finger. May cause fire, burns or electric shocks, etc.

• Do not pull or place a heavy object on the power cord of the specified charging equipment (sold separately). May cause fire, burns or electric shocks, etc.

• When plugging or unplugging the specified charging device (sold separately) into the outlet, do not allow metal objects to come into contact with it. May cause fire, burns or electric shocks, etc.

• Do not connect the voltage converter (travel converter for overseas travel, etc.) to the specified charging equipment (sold separately). May cause ignite, heat or electric shocks, etc.

• Do not use the specified charging equipment (sold separately) code if it gets damaged. May cause fire, burns or electric shocks, etc.

• If you hear thunder, do not touch the specified charging equipment (sold separately). May cause electric shocks, etc.

• Do not short the charging jack while it is connected to the outlet. Do not touch the charging jack with a part of your body such as your hand or finger. May cause fire, burns or electric shocks, etc.

• Do not pull or place a heavy object on the power cord of the specified charging equipment (sold separately). May cause fire, burns or electric shocks, etc.

• When plugging or unplugging the specified charging device (sold separately) into the outlet, do not allow metal objects to come into contact with it. May cause fire, burns or electric shocks, etc.

• Do not connect the voltage converter (travel converter for overseas travel, etc.) to the specified charging equipment (sold separately). May cause ignite, heat or electric shocks, etc.

• Do not use the specified charging equipment (sold separately) code if it gets damaged. May cause fire, burns or electric shocks, etc.

• If you hear thunder, do not touch the specified charging equipment (sold separately). May cause electric shocks, etc.

• Do not short the charging jack while it is connected to the outlet. Do not touch the charging jack with a part of your body such as your hand or finger. May cause fire, burns or electric shocks, etc.

• Do not pull or place a heavy object on the power cord of the specified charging equipment (sold separately). May cause fire, burns or electric shocks, etc.

• When plugging or unplugging the specified charging device (sold separately) into the outlet, do not allow metal objects to come into contact with it. May cause fire, burns or electric shocks, etc.

• Do not connect the voltage converter (travel converter for overseas travel, etc.) to the specified charging equipment (sold separately). May cause ignite, heat or electric shocks, etc.

• Do not use the specified charging equipment (sold separately) code if it gets damaged. May cause fire, burns or electric shocks, etc.

• If you hear thunder, do not touch the specified charging equipment (sold separately). May cause electric shocks, etc.

• Do not short the charging jack while it is connected to the outlet. Do not touch the charging jack with a part of your body such as your hand or finger. May cause fire, burns or electric shocks, etc.

• Do not pull or place a heavy object on the power cord of the specified charging equipment (sold separately). May cause fire, burns or electric shocks, etc.

• When plugging or unplugging the specified charging device (sold separately) into the outlet, do not allow metal objects to come into contact with it. May cause fire, burns or electric shocks, etc.

• Do not connect the voltage converter (travel converter for overseas travel, etc.) to the specified charging equipment (sold separately). May cause ignite, heat or electric shocks, etc.

• Do not use the specified charging equipment (sold separately) code if it gets damaged. May cause fire, burns or electric shocks, etc.

• If you hear thunder, do not touch the specified charging equipment (sold separately). May cause electric shocks, etc.

• Do not short the charging jack while it is connected to the outlet. Do not touch the charging jack with a part of your body such as your hand or finger. May cause fire, burns or electric shocks, etc.

• Do not pull or place a heavy object on the power cord of the specified charging equipment (sold separately). May cause fire, burns or electric shocks, etc.

• When plugging or unplugging the specified charging device (sold separately) into the outlet, do not allow metal objects to come into contact with it. May cause fire, burns or electric shocks, etc.

• Do not connect the voltage converter (travel converter for overseas travel, etc.) to the specified charging equipment (sold separately). May cause ignite, heat or electric shocks, etc.

• Do not use the specified charging equipment (sold separately) code if it gets damaged. May cause fire, burns or electric shocks, etc.

• If you hear thunder, do not touch the specified charging equipment (sold separately). May cause electric shocks, etc.

• Do not short the charging jack while it is connected to the outlet. Do not touch the charging jack with a part of your body such as your hand or finger. May cause fire, burns or electric shocks, etc.

• Do not pull or place a heavy object on the power cord of the specified charging equipment (sold separately). May cause fire, burns or electric shocks, etc.

• When plugging or unplugging the specified charging device (sold separately) into the outlet, do not allow metal objects to come into contact with it. May cause fire, burns or electric shocks, etc.

• Do not connect the voltage converter (travel converter for overseas travel, etc.) to the specified charging equipment (sold separately). May cause ignite, heat or electric shocks, etc.

• Do not use the specified charging equipment (sold separately) code if it gets damaged. May cause fire, burns or electric shocks, etc.

• If you hear thunder, do not touch the specified charging equipment (sold separately). May cause electric shocks, etc.

• Do not short the charging jack while it is connected to the outlet. Do not touch the charging jack with a part of your body such as your hand or finger. May cause fire, burns or electric shocks, etc.

• Do not pull or place a heavy object on the power cord of the specified charging equipment (sold separately). May cause fire, burns or electric shocks, etc.

• When plugging or unplugging the specified charging device (sold separately) into the outlet, do not allow metal objects to come into contact with it. May cause fire, burns or electric shocks, etc.

• Do not connect the voltage converter (travel converter for overseas travel, etc.) to the specified charging equipment (sold separately). May cause ignite, heat or electric shocks, etc.

• Do not use the specified charging equipment (sold separately) code if it gets damaged. May cause fire, burns or electric shocks, etc.

• If you hear thunder, do not touch the specified charging equipment (sold separately). May cause electric shocks, etc.

• Do not short the charging jack while it is connected to the outlet. Do not touch the charging jack with a part of your body such as your hand or finger. May cause fire, burns or electric shocks, etc.

• Do not pull or place a heavy object on the power cord of the specified charging equipment (sold separately). May cause fire, burns or electric shocks, etc.

• When plugging or unplugging the specified charging device (sold separately) into the outlet, do not allow metal objects to come into contact with it. May cause fire, burns or electric shocks, etc.

• Do not connect the voltage converter (travel converter for overseas travel, etc.) to the specified charging equipment (sold separately). May cause ignite, heat or electric shocks, etc.

• Do not use the specified charging equipment (sold separately) code if it gets damaged. May cause fire, burns or electric shocks, etc.

• If you hear thunder, do not touch the specified charging equipment (sold separately). May cause electric shocks, etc.

• Do not short the charging jack while it is connected to the outlet. Do not touch the charging jack with a part of your body such as your hand or finger. May cause fire, burns or electric shocks, etc.

• Do not pull or place a heavy object on the power cord of the specified charging equipment (sold separately). May cause fire, burns or electric shocks, etc.

• When plugging or unplugging the specified charging device (sold separately) into the outlet, do not allow metal objects to come into contact with it. May cause fire, burns or electric shocks, etc.

• Do not connect the voltage converter (travel converter for overseas travel, etc.) to the specified charging equipment (sold separately). May cause ignite, heat or electric shocks, etc.

• Do not use the specified charging equipment (sold separately) code if it gets damaged. May cause fire, burns or electric shocks, etc.

• If you hear thunder, do not touch the specified charging equipment (sold separately). May cause electric shocks, etc.

• Do not short the charging jack while it is connected to the outlet. Do not touch the charging jack with a part of your body such as your hand or finger. May cause fire, burns or electric shocks, etc.

• Do not pull or place a heavy object on the power cord of the specified charging equipment (sold separately). May cause fire, burns or electric shocks, etc.

• When plugging or unplugging the specified charging device (sold separately) into the outlet, do not allow metal objects to come into contact with it. May cause fire, burns or electric shocks, etc.

• Do not connect the voltage converter (travel converter for overseas travel, etc.) to the specified charging equipment (sold separately). May cause ignite, heat or electric shocks, etc.

• Do not use the specified charging equipment (sold separately) code if it gets damaged. May cause fire, burns or electric shocks, etc.

• If you hear thunder, do not touch the specified charging equipment (sold separately). May cause electric shocks, etc.

• Do not short the charging jack while it is connected to the outlet. Do not touch the charging jack with a part of your body such as your hand or finger. May cause fire, burns or electric shocks, etc.

• Do not pull or place a heavy object on the power cord of the specified charging equipment (sold separately). May cause fire, burns or electric shocks, etc.

• When plugging or unplugging the specified charging device (sold separately) into the outlet, do not allow metal objects to come into contact with it. May cause fire, burns or electric shocks, etc.

• Do not connect the voltage converter (travel converter for overseas travel, etc.) to the specified charging equipment (sold separately). May cause ignite, heat or electric shocks, etc.

• Do not use the specified charging equipment (sold separately) code if it gets damaged. May cause fire, burns or electric shocks, etc.

• If you hear thunder, do not touch the specified charging equipment (sold separately). May cause electric shocks, etc.

• Do not short the charging jack while it is connected to the outlet. Do not touch the charging jack with a part of your body such as your hand or finger. May cause fire, burns or electric shocks, etc.

• Do not pull or place a heavy object on the power cord of the specified charging equipment (sold separately). May cause fire, burns or electric shocks, etc.

</

Do not apply excessive force to the product connected to the specified charging equipment (sold separately). May cause fire, burns, injuries or electric shocks, etc.

Do not touch the code of the specified charging equipment (sold separately), USB cable, charging jack, power plug or wireless charger (sold separately) with wet hands. May cause fire, burns or electric shocks, etc.

Only use with the specified power source and voltage. When charging the product overseas, use the specified charging equipment (sold separately) that can be used overseas. If incorrect power source and voltage is used, this may cause fire, burns or electric shocks, etc.

AC adapter (sold separately): 100 VAC (Connect to the AC outlet for internal household use)
AC adapter for global use (sold separately): Between 100 VAC and 240 VAC (Connect to an AC outlet for internal household use)

Wipe off any dust that accumulates on the power plug. If the product is used with dust adhering to it, this may result in fire, burns, or electric shocks, etc.

24

When you connect the specified charging equipment (sold separately) to the outlet, do not fail to properly connect to the outlet. If not firmly inserted, this may result in fire, burns, or electric shocks, etc.

When you disconnect the power plug from the outlet, do not put excessive force such as pulling the cord of the adapter with excessive force. Instead, hold the specified charging equipment (sold separately) to disconnect. If the specified charging equipment (sold separately) cord is pulled on, this may result in scratches the cord, fire, burns, or electric shocks, etc.

When unplugging and plugging in the specified charging equipment (sold separately) from and into the product, do not forcibly pull on the cord, etc., and straightly unplug and plug into the connecting terminals. If not properly unplugged or plugged in, this may cause fire, burns, injuries, electric shocks, etc.

Immediately discontinue use if the charging jack is bent or deformed. Do not try to straighten and re-use a deformed charging jack. The short of the charging jack may result in fire, burns, injuries, electric shocks, etc.

Leave the power plug unplugged from the outlet when not using the specified charging equipment (sold separately). If the power plug is left plugged in, this may cause fire, burns, injuries, electric shocks, etc.

25

Immediately unplug the specified charging equipment (sold separately) from the outlet if water or other liquids (drinking water, sweat, seawater, pet urine, etc.) get into the specified charging equipment. Adhesion of such fragments may cause fire, burns or electric shocks, etc.

Always unplug the power plug from the outlet when cleaning the product. Cleaning while still plugged in may cause fire, burns or electric shocks.

Caution

Do not touch a specified charging equipment (sold separately) continuously that has been connected to the outlet. May cause burns, etc.

SIM card

Caution

Be careful not to injure yourself (finger, etc.) with the cut section when handling SIM card. The cut surface may be sharp, and it may cause injuries, etc.

26

Use of the product near medical equipment and inside a medical facility

Warning

Wearers of the electronic medical equipment such as implanted pacemakers or defibrillators must carry and use the product at least 15 cm away from the implanted device. The product's signals may affect the operation of the electronic medical equipment.

When electronic medical equipment other than implanted pacemakers or defibrillators are in use outside of medical facilities such as in home care settings, check with the device manufacturer to determine how the device is affected by electrical signals. The product's signals may affect the operation of the electronic medical equipment.

If there is a risk that you may be unable to move freely or otherwise get closer than 15 cm to the people around you, please switch the product to a state where no radio waves are emitted beforehand. There may be wearers of medical equipment such as implanted pacemakers or defibrillators around you. The product's signals may affect the operation of electronic medical equipment.

27

Caution

If you experience any skin problems as a result of using the USB cable (CtoC) (sample), stop using it immediately and seek medical attention. Itching, rashes, eczema, etc. sometimes occurs depending on your physical constitution and condition. For parts materials ▶P31 "Material List"

30

Material List

Main unit

Part	Material	Surface treatment
Display (touch panel)	Glass	AF coating
Display surrounding area	Glass	Printing, AF coating
Exterior case (side, top, bottom)	Aluminum	Anodizing
Side button/Fingerprint recognition sensor	Aluminium, Epoxy	Anodizing, Paint coating
Volume button	Aluminum	Anodizing
SIM card/microSD memory card tray	PC	-
SIM card/microSD memory card tray (side)	Aluminum	Anodizing
SIM card/microSD memory card tray (rubber gaskets)	Si Rubber	-
Rear cover	Aluminum	Anodizing
Rear camera window	Glass	Painting, AF coating

31

Part	Material	Surface treatment
Rear camera surrounding area	Aluminum	Anodizing
USB Type-C connection terminal	Corson alloy	Pd-Ni+Ni+Au
USB Type-C connection terminal surrounding area	Aluminum	-
Speaker (upper, lower)	Aluminum	Anodizing
Pogo pin	Brass	Ni+Pd

S Pen (sample)

Part	Material	Surface treatment
Main unit	PC/ABS	SF Painting
Pen button	PC	SF Painting
Pen tip	Elastomer/POM	-

SIM card removal tool (sample)

Part	Material	Surface treatment
Main unit	SUS304	Barrel polishing

32

USB cable (CtoC) (sample)

Part	Material	Surface treatment
Cable	TPE	-
Plug (metal part)	SUS304	Nickel plating
Plug (outer covering)	PC	-

33

When using the product in a medical facility, be sure to observe the regulations of the facility. The product's signals cause adverse effects on the operation of the electronic medical equipment.

S Pen (sample)

Warning

Do not point the S Pen (sample) toward others. May cause injuries or loss of sight, etc.

Caution

If you develop skin problems, stop using the S Pen (sample) immediately, and see a doctor. Itching, rashes, eczema, etc. sometimes occurs depending on your physical constitution and condition. For parts materials ▶P31 "Material List"

SIM card removal tool (sample)

Warning

The tip of the SIM extraction pin (sample) is sharp. Do not use the pin against yourself or others. Doing so might hit yourself or other people resulting in injuries or loss of sight.

28

Caution

If you experience any skin problems as a result of using the SIM card removal tool (sample), stop using it immediately and seek medical attention. Itching, rashes, eczema, etc. sometimes occurs depending on your physical constitution and condition. For parts materials ▶P31 "Material List"

Store the SIM card removal tool (sample) in a place where babies and infants or pets cannot reach If it is accidentally swallowed, it might result in suffocation or injuries, etc.

USB cable (CtoC) (sample)

Warning

Do not use in places subject to direct splashing with water, pet urine or other liquids. May cause overheating, fire, electric shocks, injuries or short circuiting of electronic circuits.

29

Handling Precautions

The following precautions are the main items that provided to prevent the product from getting a malfunction and to ensure that performance can be fully demonstrated. Thoroughly read these precautions to ensure correct use. For details, please refer to the "取扱説明書 詳細版 (Full Instruction Manual)" (Japanese).

Precautions common to the main unit, internal battery, charging equipment, SIM card, S Pen (sample), accessory devices

- In the following cases, do not use them in places that have extremely hot or low temperatures, or high humidity. (Use within an ambient temperature range of 5 °C to 35 °C and a humidity range of 35% to 85%. However it can be provisionally used if it is 36 °C to 40 °C.)
 - The product main unit
 - SIM card (when attached to the product main unit)
- In the following cases, do not use the product in extremely hot, cold or humid places. (Use within an ambient temperature range of 5 °C to 35 °C and humidity range of 35% to 85%.)
 - Charging equipment
 - Accessory devices
- Clean the charging jack, the external connection terminal or pogo pin with dry cotton swabs, etc. every now and then. Soiled terminals might cause poor connection. Do not exert a strong force to clean the charging jack or the external connection terminal to prevent deformation.

34

Main unit

- The battery for the product is built-in and cannot be replaced by yourself. Please contact the "Inquiries" in the end of this manual to replace the battery.
- Never use modified product. Use of a modified device violates the Radio Law and the Telecommunications Business Act. The product is compliant with rules on the technical standard conformance of specified wireless equipment based on the Radio Law and rules on the technology regulatory compliance of terminal device based on the Telecommunications Business Act. As proof of this, the "Technical Conformity Mark" is indicated in the product.

How to confirm: On the home screen, flick up → [Settings] → [About tablet] → [Regulatory information]

- If the modifications are made to the internal components, the certification of conformity with technical regulations will become not valid. Never use the product without the valid certification. Doing so violates the Radio Law and the Telecommunications Business Act.
- Take care not to place magnetized items such as magnetic cards, speakers and TV sets near the product, as it might cause malfunction. Putting a strong magnetism close to the product might cause false operation.
- Do not bring the product close to magnetized objects such as cash cards, credit cards, and prepaid cards. Doing so might result in loss of recorded information.
- The product has a built-in magnet. Keep the product away from objects that may be affected by magnetism (credit cards and medical devices). Users of medical devices should consult a physician before using the product.

36

- When suddenly brought into a warm place from a cold place, or when in a humid location, or when used where temperature suddenly changes (for example, near the air discharge port of an air conditioner), water droplets (that is condensation) sometimes are formed inside the product. Note that when used under conditions such as this, the humidity might cause corrosion or a fault.
- Do not subject the microSD memory card to vibration or shock, or turn off the power while writing or reading data from the microSD memory card. Doing so may cause data loss or malfunction.
- Do not cover the light sensor with your finger or put a sticker on it. If you do so, the light sensor may not be able to respond to ambient light and may not work properly.

Touch Panel

- The touch panel is designed to be touched lightly with fingers. Do not press hard on the touch panel with your fingers or press pointed objects (such as fingernails, ballpoint pens and pins) against the touch panel.
- Do not apply stickers or sheets (such as commercially available protective films or anti-peep sheets) to the display. If you do so, the touch panel may not operate properly.
- When carrying the product in a bag, etc., take care not to put the touch panel close to metals or other conductive materials, as it might cause false operation of the touch panel.

Internal battery

(The internal battery of the product is a lithium-ion battery.) The internal battery is not fully charged at the time of purchase. Charge the battery before using the product.



37

- Extreme high or low temperatures, such as leaving the product in a closed car during the summer, will reduce the capacity of the internal battery and shorten the time it can be used. This will also shorten the life of the internal battery. Use the product at room temperature as much as possible.
- The internal battery gradually discharges after charging, even if the product is not used. Overdischarging may make it impossible to recharge the battery after a long period of inactivity, so regular recharging is recommended.
- Depending on the use condition, the internal battery may be inflated as it comes close to the end of its service life. This is because of or caused by the properties of lithium-ion battery and does not pose any safety risks.
- The internal battery is a consumable item. If the performance of the internal battery does not recover (for example, the usable time after each charge has become extremely short, the internal battery is swollen, etc.), stop using the battery as it is at the end of its service life. As the battery is built, please check the "取扱説明書 詳細版 (Full Instruction Manual)" (Japanese) or our website, and contact your carrier to replace the battery. Battery life varies depending on usage conditions and other factors.

SIM card

- Do not forcibly remove or insert the SIM card.
- You are responsible for any damage caused by inserting your SIM card into some other IC card reader/writer, etc.
- Do not put stickers, etc. on the SIM card.
- Do not insert a SIM card to which a conversion adapter is attached. Doing so may cause a fault.

38

- Do not performs actions that may damage the SIM card (for example, using in high temperature areas, tossing into fire, allowing foreign matter to come into contact with metal part, subjecting to shock, bending, applying heavy load, getting wet, etc.). It may cause data loss or other malfunctions.

S Pen (sample)

- Do not intentionally subject the S Pen (sample) to strong shocks such as strong pushing or tapping. Doing so may cause scratches or damage to the S Pen (sample).
- Do not subject the S Pen (sample) to strong impacts by dropping, throwing, or stepping on it. Doing so may cause it to malfunction.
- Do not use the S Pen (sample) if the tip is chipped or chiseled. Doing so may damage the display or cause the display to misoperate.
- Do not use a touch pen or the S Pen (sample) that is not specified. Doing so may damage the display or cause the display to misoperate.
- Do not use the S Pen (sample) with other devices as this may cause malfunctions or damage to the S Pen (sample) or device.
- Use the S Pen (sample) without excessive force; placing the S Pen (sample) in a luggage filled with many things may cause the S Pen (sample) to damage or malfunction.
- Please note that bringing magnetic cards, speakers, TVs, accessories with magnets, or other magnetic devices close to the S Pen (sample) may cause malfunctions. Strong magnetism may cause malfunctions. Strong magnetism may cause the S Pen (sample) to malfunction.

39

Notes on using Bluetooth®/Wireless LAN (Wi-Fi) Functions

- The connections between the product and all other Bluetooth® and wireless LAN (Wi-Fi®) devices have not been confirmed. Therefore, connections with all Bluetooth® and wireless LAN (Wi-Fi®) devices are not guaranteed.
- The product supports security features for wireless communications that are compliant with the Bluetooth® and wireless LAN (Wi-Fi®) standard specifications, but the security may not be sufficient depending on the usage environment and configuration. Be careful when making data communication using Bluetooth® or wireless LAN (Wi-Fi®) function.
- Wireless LAN (Wi-Fi®) has the advantage that it can be freely connected anywhere within the radio wave range, as it uses radio waves for exchanging information. At the same time, there is a risk that a malicious third party may obtain unauthorized access if security settings have not been configured. You are recommended to configure security settings before using wireless LAN (Wi-Fi®) at your decision and responsibility.
- The Company assumes no responsibility for leakage of data or information that may occur during Bluetooth®/wireless LAN (Wi-Fi®) communication.
- Since Bluetooth® and wireless LAN (Wi-Fi®) functions use the same frequency band, using the both functions at the same may cause radio wave interference resulting in decreased communication speed or disconnection from the network. If connection fails, stop using either of the Bluetooth® and wireless LAN (Wi-Fi®) functions.

45

Notes on Data Communication Charge

- Since a constant Internet connection is possible with the product, data communication may be performed automatically by some applications, resulting in high data communication charges. Therefore, subscription to a data communication charge discount service or flat late plan is recommended.
- Communications that occur when browsing websites, downloading applications, etc., communicating with applications, sending/receiving e-mails, and performing various settings on the product are connected via the Internet, and data communications will be charged.

Take Your Manners with You as Well

The product must not be used in the following places!

- Do not listen to music or watch videos while driving a car or riding a motorized bicycle, bicycle, etc. Use of the phone or tablet while driving a car or motorized bicycle is prohibited by law (use while riding a bicycle may also be punishable by law, etc.). Also, please pay close attention to the traffic around you even when walking. Using a phone makes it difficult to hear the sounds around you and may cause a traffic accident if you are distracted by the display. Please be especially careful at railroad crossings, station platforms and pedestrian crossings.
- As there are usage restrictions in an airplane, follow the instructions from the airline.

46

Appendix

After-Sales Service

When asking for repair

For repair, please contact the Repair and Delivery Support Center.

During the warranty period	Repairs will be done based on the terms of services of the free-of-charge repair warranty described.
Outside the warranty period	We shall repair the product for a charge as requested by the customer if repair renders it usable.

* The warranty is valid for one year from the day that you first buy the product.

- Before handing in the product for repair, make a backup of the contents of storage since they may disappear during repair. Note that the Company shall not be liable for any damages and loss of income should the contents of storage be altered or lost.
- Recycled parts that meet the Company's quality standards are sometimes used for repair.
- Tablet used up to now that are collected by the replacement phone delivery service are reused as replacement tablet after being reconditioned and repaired. In addition, mechanical parts replaced by the after-sales service are collected and recycled by our company. Therefore, they cannot be returned to customers.

47

Important precautions

- To ensure waterproof property of the product, make sure that the SIM card/microSD memory card tray is securely installed.
- Never open or close the SIM card/microSD memory card tray when your hand or the product is wet.

42

43

44

48

- The product which is processed, remodeled, analyzed (including by modifying or analyzing the software (including by rooting etc.), reverse engineering, decompiling), or repaired by an unauthorized repair office is not covered by the warranty and repair may be refused.
- The battery in the product is the consumable items and are not covered by the warranty.
- Accessories and samples other than the product main unit are not covered by the free-of-charge repairs warranty.

■ Performance parts for repair

The Company retains performance parts for repair of the product main unit and its peripherals for four years after discontinuation of production. "Performance parts for repair" refers to parts required for maintaining the functions of the product.

■ Free-of-charge repair warranty

1. When you contact the repairs help desk, have the serial number (IMEI number) ready. You can find the serial number (IMEI number) on the product or on a sticker attached to the box the product is sold in.
2. If the product malfunctions during the warranty period and during normal use that follows the precautions listed in the instruction manual, the Company will repair the product for free.
3. Repairs will not be free of charge in the following cases, even during the warranty period. (Or repair may not be possible.)
 - ① If you did not follow the instruction manual, and use the product correctly.
 - ② If the product broke or was damaged by unauthorized repairs or modifications.

- ③ If you had the product repaired at a facility that is not an authorized repair facility as designated by the Company.
 - ④ If the product breaks or is damaged because of an accident or your own negligence when you are using or handling the product. Alternatively, there are indications that the product was dropped, got wet, damp, or the like.
 - ⑤ If the product breaks or is damaged because of natural disasters, such as earthquakes, wind and flood damage, fire, damage from salt, or abnormal voltage.
4. Depending on how damaged the product is, repair may not be possible.
 5. The Company assumes no responsibility for any damages or lost profits incurred as a result of the failure of the product's equipment.
 6. The Company assumes no responsibility if an accident occurs in the event that you connect a device that is not designed to be used with the product.
 7. The company does not offer on-site repairs.
 8. This warranty is valid only in Japan.

* This warranty guarantees free repair based on the period and conditions listed above. Therefore, customers' legal rights against the issuer of this warranty and other business are not restricted by this warranty.

■ Repair and Delivery Support with Cloud

To ensure long-term reliable use of au/UQ mobile tablet, we offer a monthly membership after-sales service program called "Repair and Delivery Support with Cloud".

- This is a service that extends coverage for all kinds of problems, including breakdown, theft, and loss. For details of monthly usage fee and services, refer to the au/UQ mobile website.
- For customers with au contracts
<https://www.au.com/mobile/service/kosho-funshitsu-cloud/> (Japanese)
 - For customers with UQ mobile contracts
<https://www.uqwimax.jp/mobile/plan/option/repair-cloud/> (Japanese)
- * Service contents are subject to change without notice.

■ SIM card

The SIM card is lent to you by contracted carrier. In case of loss or damage, the card will be replaced at your expense. When malfunction is suspected, or in case of theft or loss, contact the "Inquiries" in the end of this manual.






Export Administration Regulations

The product and its accessories may be subject to the Japan Export Administration Regulations ("Foreign Exchange and Foreign Trade Law" and its related laws). In addition, U.S. Export Administration Regulations may apply to the product and its accessories. To export and re-export the product and its accessories, take the required measures on your responsibility and at your expenses. For details on the procedures, contact the Ministry of Economy, Trade and Industry or the U.S. Department of Commerce.

Intellectual Property Rights

Trademarks

The company names and product names appearing in this manual are trademarks or registered trademarks of their respective holders.

-    microSD logo, microSDHC logo, and microSDXC logo are trademarks of SD-3C, LLC.
-  Bluetooth The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc.
-  Wi-Fi Wi-Fi®, Wi-Fi CERTIFIED®, and the Wi-Fi logo are registered trademarks of the Wi-Fi Alliance.
- iWnn of OMRON SOFTWARE Co., Ltd. is used for conversion methods. iWnn® OMRON SOFTWARE Co., Ltd. 2008-2023 All Rights Reserved.
- QR code is a registered trademark of the DENSO WAVE Incorporated.
- USB Type-C™ is a trademark of the USB Implementers Forum.
- All other company names and product names are trademarks or registered trademarks of respective companies referred to in this manual.

48

49

50

51

52

<For customers with au contracts>

au Support

App/Website

■ **My au app**
 You can check usage charges, points, contract details, etc., and perform various procedures.
* If you are using povo, please check with the povo2.0 app/povo1.0 app.

 Check here to download 

URL <http://kddi-l.jp/mFH> (Japanese)

■ **au Support (web)**
 There are various support information that will be useful when you are in trouble.

URL <http://kddi-l.jp/G19> (Japanese) 

Message
 Consultation is easy anytime, anywhere via chat! AI will respond quickly 24 hours a day, and advisors will respond in detail.



URL <http://kddi-l.jp/Bx6> (Japanese) 

<For customers with UQ mobile contracts>

UQ mobile Support


App/Website

■ **My UQ mobile (app)**
 You can check the remaining amount of data, the billing amount, and the subscription status of various services.


 Check here to download 

URL <http://kddi-l.jp/E17> (Japanese)

■ **UQ mobile Support (web)**
 There are various support information that will be useful when you are in trouble.

URL <http://kddi-l.jp/QX> (Japanese) 

Chat
 Consultation is easy anytime, anywhere via chat! AI will respond quickly 24 hours a day, and advisors will respond in detail.

URL <http://kddi-l.jp/19z> (Japanese) 

Repair and Delivery Support / Repair and Delivery Support with Cloud Service for Members

Repair and Delivery Support (7 days a week / Toll free)	From au cell phones / UQ mobile / general subscriber phones
Troubleshooting/replacement phone delivery service reception (Business hours 9:00 - 20:00)	☎ 0120-925-919



Phone and PVB operators collect and recycle unused telephones, batteries and battery chargers at stores bearing the ♻️ logo regardless of brand and manufacturer to protect the environment and reuse valuable resources.

November 2023, 1st Edition
 Imported by: SAMSUNG ELECTRONICS JAPAN Co., Ltd.
 Manufactured by: Samsung Electronics Co., Ltd.